Form No. 3328–774

36in SFS Side Discharge Mower

Model No. 30135—2300000001 and Up

Parts Catalog

Ordering Replacement Parts

To order replacement parts, please supply: the part number, the quantity, and the description of each part desired.

Understanding Reference Numbers

Each identified part in an illustration has a reference number. The reference number for a part also appears in the parts list, along with other information about the part.

This catalog uses two special reference number formats, one to indicate parts in a service assembly and another to indicate the quantity of a given part in an illustration.

Service Assembly Reference Numbers

Parts in service assemblies have reference numbers in the form **a:b.** The **a** represents the reference number of the entire service assembly and the **b** represents a sequential number unique to each part within the service assembly.

For example, a wheel assembly might be identified by reference number **6**, the tire by **6:1**, the valve by **6:2**, and the wheel by **6:3**. When you order the assembly identified by reference number 6, you receive all parts identified by reference numbers 6:1, 6:2, and 6:3. However, you may also order any part individually.

Reference numbers of this type appear in illustrations and in part lists.

Reference Numbers Indicating Quantity

In an illustration, if a reference number indicates more than one part, the reference number has the form **nX y.** The **n** represents the quantity of the part, the **X** is the multiplication symbol, and the **y** represents the reference number.

For example, in an illustration, the reference number **2X 37** means that two of the parts identified by reference number 37 are indicated.

© The TORO Company — 2002
All Rights Reserved


Contents

Description	Page
Decal and Deck Assembly	3
Carrier Frame and Caster Assembly	4
Spindle and Idler Assembly	5
Spindle Housing Assembly No. 27–0870	6
Spindle Housing Assembly No. 54–7781	7

Part Description Abbreviations

Part descriptions in this catalog may include the following abbreviations.

Abbreviation	Meaning
AR	as required
ASM	assembly
CARR	carriage
DEG	degrees
FH	flat head
GA	gauge
HF	hex flange
HH	hex head
HHF	hex head flange
HLH	hex lag head
HJ	hex jam
HOC	height-of-cut
HS	hex socket
HSBH	hex socket button head
HSFH	hex socket flat head
HSH	hex socket head
HWH	hex washer head
HWHTF	hex washer head thread forming
HYD	hydraulic
INC	incorporated
LH	left hand
NI	nylon insert
PPH	Phillips pan head
PTH	Phillips truss head
PTO	power take off
RH	right hand
SFH	slotted fillister head
SHH	slotted hex head
SQH	square head
SHWH	slotted hex washer head
SPH	slotted pan head
SRH	slotted round head
STD	standard
TAP	self tapping
TTH	Torx truss head
WH	wing head




Sheet No.:2

Decal and Deck Assembly

Ref. No.	Part No.	Qty.	Description
1	82–5460–01	1	Cover
2	52–4780	2	Rod–Belt
3	32128–21	2	Nut–HF
4	3256–24	4	Washer–Flat
5	3231–22	2	Screw–CARR
6	106–0745	1	Deck ASM
6:2	43–8480	1	Decal–Danger
6:3	93–1122	1	Decal–Danger
6:4	68–8340	1	Decal–Torque
6:5	67–5360	1	Decal–Danger
6:6	66–1340	1	Decal–Danger
6:8	32148–10	2	Insert–Threaded
7	104–8554	1	Spring–Torsion
8	105–4622	1	Spacer
9	104–7753	1	Deflector ASM
9:2	54–9220	1	Decal–Danger
15	98–5967	1	Spacer
16	68–2730	2	Wheel–Gage
17	322–50	2	Screw–HH
18	3296–29	2	Nut–Lock, NI
19	32151–72	2	Ring–Retaining
20	62–6520	2	Knob
27	106–0703	1	Decal

Ref. No.	Part No.	Qty.	Description




Sheet No.:3

Carrier Frame and Caster Assembly

Ref. No.	Part No.	Qty.	Description
1	74–0350	4	Cushion–Rubber
4	17–5999–01	1	Frame–Carrier
5	302–5	2	Fitting–Grease
6	1–809020	2	Pin
7	93–1166	2	Spacer–Castor
8	100–6455–01	2	Castor Fork ASM
9	32153–5	2	Nut–Lock
11	100–6453	2	Bushing–Spanner
12	100–6451	2	Castor Wheel ASM
12:1	232–27	1	Stem–Valve
12:2	302–11	1	Fitting–Lube, 45°
12:3	83–4740	1	Bearing
12:4	62–5580	2	Bearing–Outside
12:5	100–6452	1	Tire–Tubeless
13	325–19	2	Screw–HH
14	3–6781	8	Washer–Thrust
15	256–156	2	Bushing–Flange
16	74–0290	2	Spring
17	41–8440	2	Washer
18	3218–5	4	Nut–Jam
19	3290–355	4	Pin–Hair
20	74–0310	2	Shaft–Adjusting
21	3296–45	2	Nut–Lock, NI
22	283–55	4	Pin–Clevis
23	85–7450	1	Decal–HOC, LH
24	85–7460	1	Decal–HOC, RH

Ref. No.	Part No.	Qty.	Description
25	80–3340–01	1	Weight–Front
26	322–12	2	Screw–HH
27	3296–29	2	Nut–Lock, NI
28	94–1291	4	Bushing–Special




Sheet No.:4

Spindle and Idler Assembly

Ref. No.	Part No.	Qty.	Description
1	3231–22	11	Screw–CARR
2	32128–21	12	Nut–HF
3	27–0870	1	Spindle ASM
4	54–7781	1	Spindle Housing ASM
5	55–7660	1	V–Belt
6	51–3530	1	V–Belt–Drive, Deck
7	3296–29	2	Nut–Lock, NI
8	56–4360	1	Rod–Spring
9	3230–22	2	Screw–CARR
10	51–3650	1	Spring–Extension
11	323–12	1	Screw–HH
12	3256–24	2	Washer–Flat
13	51–3641	1	Sleeve–Pivot, Idler
14	56–4341–03	1	Idler Arm ASM
15	51–3660	1	Pulley–Idler
16	3211–5	1	Screw–HH
17	3296–5	1	Nut–Lock, NI

Ref. No.	Part No.	Qty.	Description




T–3920
Sheet No.:A1

Spindle Housing Assembly No. 27–0870

Ref. No.	Part No.	Qty.	Description
1	106–0806	1	Shaft ASM
2	302–2	1	Fitting–Grease
4	46–8530	1	Bearing ASM
5	27–0950	1	Spacer
6	253–139	2	Seal–Oil
7	61–4160	1	Housing
8	27–0970	1	Pulley And Hub ASM
9	32146–20	1	Nut–Jam
10	106–0776	1	Washer– Pinion

Ref. No.	Part No.	Qty.	Description



T–3919
Sheet No.:A2

Spindle Housing Assembly No. 54–7781

Ref. No.	Part No.	Qty.	Description
1	253–139	2	Seal–Oil
2	27–0950	1	Spacer
3	27–0960	1	Bearing ASM
4	27–5970	1	Spacer–Set, Matched
5	302–2	1	Fitting–Grease
6	32146–20	1	Nut–Jam
7	3253–7	1	Washer–Lock
8	44–2200	1	Screw–Blade
10	106–0800	1	Spindle ASM
11	55–7610	1	Pulley And Hub ASM
12	56–2390–03	1	Blade
13	61–4160	1	Housing
14	106–0776	1	Washer– Pinion
15	72–9361	1	Cup–Scalp, Anti

Ref. No.	Part No.	Qty.	Description


TORO®