Form No. 3328–967

Mid–Size Mower

ProLine T–Bar Gear 15hp with 36in Side Discharge Mower

Model No. 30178—230005001 and Up

Parts Catalog

Ordering Replacement Parts

To order replacement parts, please supply: the part number, the quantity, and the description of each part desired.

Understanding Reference Numbers

Each identified part in an illustration has a reference number. The reference number for a part also appears in the parts list, along with other information about the part.

This catalog uses two special reference number formats, one to indicate parts in a service assembly and another to indicate the quantity of a given part in an illustration.

Service Assembly Reference Numbers

Parts in service assemblies have reference numbers in the form **a:b.** The **a** represents the reference number of the entire service assembly and the **b** represents a sequential number unique to each part within the service assembly.

For example, a wheel assembly might be identified by reference number **6**, the tire by **6:1**, the valve by **6:2**, and the wheel by **6:3**. When you order the assembly identified by reference number 6, you receive all parts identified by reference numbers 6:1, 6:2, and 6:3. However, you may also order any part individually.

Reference numbers of this type appear in illustrations and in part lists.

Reference Numbers Indicating Quantity

In an illustration, if a reference number indicates more than one part, the reference number has the form **nX y.** The **n** represents the quantity of the part, the **X** is the multiplication symbol, and the **y** represents the reference number.

For example, in an illustration, the reference number **2X 37** means that two of the parts identified by reference number 37 are indicated.

© The TORO Company — 2003
All Rights Reserved

Contents

Description	Page
Engine and Fuel System Assembly	3
Transmission and Drive Pulley Assembly	4
Wheel Drive Assembly	6
Upper Handle Assembly	7
Deck Assembly	8
Front Caster and Blade Brake Assembly	9
Spindle Assembly	11
Crankcase Assembly Kohler CV15T–41608	12
Oil Pan and Lubrication Assembly Kohler CV15T–41608	13
Cylinder Head, Valve and Breather Assembly Kohler CV15T–41608	14
Ignition and Electrical Assembly Kohler CV15T–41608	15
Blower Housing and Baffle Assembly Kohler CV15T–41608	16
Starter Assembly Kohler CV15T–41608	17
Fuel System Assembly Kohler CV15T–41608	18
Engine Control Assembly Kohler CV15T–41608	19
Air Cleaner Assembly Kohler CV15T–41608	20
Exhaust Assembly Kohler CV15T–41608	21


Accessories

Description	Model / Part No.
Recycler Kit	30142
Soft Bagger	30198
Atomic Blade	104–8595
High Lift Blade	102–2507

Part Description Abbreviations

Part descriptions in this catalog may include the following abbreviations.

Abbreviation	Meaning
AR	as required
ASM	assembly
CARR	carriage
DEG	degrees
FH	flat head
GA	gauge
HF	hex flange
HH	hex head
HHF	hex head flange
HLH	hex lag head
HJ	hex jam
HOC	height-of-cut
HS	hex socket
HSBH	hex socket button head
HSFH	hex socket flat head
HSH	hex socket head
HWH	hex washer head
HWHTF	hex washer head thread forming
HYD	hydraulic
INC	incorporated
LH	left hand
NI	nylon insert
PPH	Phillips pan head
PTH	Phillips truss head
PTO	power take off
RH	right hand
SFH	slotted fillister head
SHH	slotted hex head
SQH	square head
SHWH	slotted hex washer head
SPH	slotted pan head
SRH	slotted round head
STD	standard
TAP	self tapping
TTH	Torx truss head
WH	wing head




Sheet No.: 2

Engine and Fuel System Assembly

Ref. No.	Part No.	Qty.	Description
1	1–633023	2	Stud
2	3256–23	4	Washer–Flat
3	1–633349	2	Spring–Tank, Fuel
4	3296–47	2	Nut–Lock, NI
5	1–303077	6	Clamp
6	1–303197	1	Filter–Fuel
7	47–2983	1	Hose–Fuel
☆9		1	Engine–Kohler, Cv15t–41608
10	106–0699	1	Decal–Warning, Hot Surfaces
11	3290–357	2	Nut–HHF
12	323–13	1	Screw–HH
13	33114–025	4	Screw–HH
14	1–303334	4	Washer–Spring
15	1–303431	1	Fitting–90°
16	1–323326	1	Nipple
17	1–543233	1	Cap–Hex
18	1–603776	1	Hose–Line, Fuel
19	1–603770	1	Valve–Fuel
20	1–603955	1	Hose–Fuel
22	322–3	2	Screw–HH
24	1–805005	2	Washer–Lock
26	106–0730	1	Fuel Tank ASM
26:2	103–2605	1	Fitting–Fuel, Bulkhead

Ref. No.	Part No.	Qty.	Description
27	88–3980	1	Gas Cap ASM
27:3	88–4010	1	Gasket–Cap, Gas

☆ Not serviced separately




Sheet No.: 3

Transmission and Drive Pulley Assembly

Ref. No.	Part No.	Qty.	Description
1	103–2923–01	1	Deck–Rear
2	1–323252	2	Bearing–Shaft
3	1–323254	2	Flange–Output
4	1–803310	3	Screw–Set
5	1–323257–03	2	Sheave–Transmission
6	321–3	4	Screw–HH
7	103–4177	1	Key–Square
8	3242–4	2	Screw–Set, SQH
9	3296–39	1	Nut–Lock, NI
10	3256–24	1	Washer–Flat
11	1–323285	1	Idler–Drive, Transmission
12	3256–5	2	Washer–Flat
13	322–3	4	Screw–HH
14	1–805005	4	Washer–Lock
15	1–633181	1	Plate–Tapped
16	1–513152	1	Switch–Closed, Normally
17	32151–62	2	Ring–Retaining
18	3257–5	3	Key–Woodruff
19	1–323502	2	Shaft–Transmission
20	51–4220	2	Guard–Coupler
21	1–323680	2	Coupler
22	1–323630	1	V–Belt
23	3245–41	2	Screw–HSH
24	1–323278	1	Sheave–Transmission

Ref. No.	Part No.	Qty.	Description
25	302–19	2	Fitting–Grease
26	1–323500	1	Transmission
27	3230–1	2	Bolt–CARR
28	1–323387–03	1	Plate–Shift
29	98–3256	1	Decal–Speed, Ground
30	1–303020	1	Grip–Lever
31	98–3274–03	1	Lever–Shift
32	98–5975	1	Washer–Belleville
33	3296–6	1	Nut–Lock, NI
35	1–323379	1	Washer
36	32128–20	2	Nut–HF
37	9264964	4	Screw
38	1–603403	1	Bolt–Shoulder
39	1–323389–03	2	Bracket–Plate, Shift
40	1–806003	1	Pin–Hair
41	1–303186	1	Bellcrank
42	3290–357	1	Nut–HHF
43	95–2814	1	Decal–Shut Off, Fuel
44	3290–500	2	Screw–PPH
45	1–543296	1	Grommet
46	3231–6	1	Screw–CARR
47	3296–42	4	Nut–Lock, NI
48	98–0776	1	Decal–Caution
49	1–323256	1	Sheave–Transmission
50	1–643292	1	Sheave–Split
53	1–323318–01	2	Hitch–Sulky




Sheet No.: 3

Transmission and Drive Pulley Assembly (Continued)

Ref. No.	Part No.	Qty.	Description
54	323–6	4	Screw–HH
55	3290–357	4	Nut–HHF
56	1–603610	2	Washer–Spring
57	3212–6	1	Screw–HH
58	1–633453	1	Spacer–Clutch
59	1–373034	2	Washer

Ref. No.	Part No.	Qty.	Description




Wheel Drive Assembly

Ref. No.	Part No.	Qty.	Description
1	98–3273	2	Spring–Extension
2	323–10	2	Screw–HH
3	32151–47	2	Ring–Retaining
4	1–806003	4	Pin–Hair
5	3256–23	2	Washer–Flat
6	104–1321–03	1	RH Idler Arm ASM
7	104–1322–03	1	LH Idler Arm ASM
8	74–0521	2	Fitting–Rod
9	283–6	2	Pin–Clevis
10	1–323296	2	Rod–Brake
11	1–322125	2	Swivel–Brake
12	1–513959	2	Wingnut–Nylock
13	3290–357	14	Nut–HHF
14	323–16	4	Screw–HH
16	98–5131–01	2	Shield–Wheel, Drive
17	1–323694	4	Spacer–Shield
18	1–323634	2	Idler–Drive, Wheel
19	302–19	2	Fitting–Grease
21	1–323307	4	Pin–Clevis
22	1–322209–03	2	Arm–Brake
23	32120–47	2	Ring–Retaining, External
24	1–803051	4	Nut–Push
25	1–323595	2	Band–Brake
26	1–322212–03	1	Axle ASM
27	1–543436	8	Washer–Spacer

Ref. No.	Part No.	Qty.	Description
27	1–523157	6	Washer–Spacer
☆30		2	Wheel And Tire ASM
30:1	1–323720	1	Tire–Turfmaster
30:2	1–323328	1	Wheel And Hub ASM
30:2:1	1–323329	2	Bearing–Flanged
☆30:2:2		1	Rim ASM
☆30:2:3		1	Fitting–Grease
☆30:2:4		1	Valve Stem
34	1–808519	2	Ring–Snap
37	1–412358	2	Scraper
38	1–323631	2	V–Belt
39	3296–29	2	Nut–Lock, NI
40	2412–104	2	R–Clamp
41	98–3259	1	Shield–Trailing
42	322–3	2	Screw–HH
43	98–5975	4	Washer–Belleville
44	323–6	4	Screw–HH
☆47		2	Drum And Sheave ASM
47:1	1–323253	2	Sheave–Wheel, Drive
47:2	1–323261	1	Drum–Brake
47:3	1–323260	4	Spacer–Sheave, Wheel
47:4	322–6	4	Screw–HH

☆ Not serviced separately




Sheet No.: 5

Upper Handle Assembly

Ref. No.	Part No.	Qty.	Description
1	98–3282	2	Rod–Control
2	95–5522–03	1	Control Bar ASM
3	3296–2	5	Nut–Lock
4	82–2290	1	Decal–Bar, Control
5	32105–1	1	Screw–SHH
6	98–3289–03	1	Bail ASM
7	82–2280	1	Decal–Handle, Reverse
8	3272–11	2	Pin–Cotter
9	99–8501–03	1	Control–Pivot
10	218–595	1	Connector–Body
11	98–3261–03	1	Lever–Brake, Parking
12	98–3266	1	Decal–Brake, Parking
13	740275	1	Switch–Seat
14	1–806003	3	Pin–Hair
15	237–141	2	Grommet–Rubber
16	98–3267–03	1	Upper Handle ASM
17	283–55	2	Pin–Clevis
18	1–323637	1	Cable–Throttle
19	2412–120	2	R–Clamp
20	95–5537	1	Decal–Engage, Deck
21	1–303335	1	Tie–Plastic
22	1–303160	1	Spring–Compression
23	3256–24	2	Washer–Flat
24	3296–39	5	Nut–Lock, NI
25	98–3258	1	Harness–Wire

Ref. No.	Part No.	Qty.	Description
26	98–3279	1	Linkage–Drive, Blade
27	98–3287–03	1	Lever–Engagement, Blade
28	323–6	4	Screw–HH
29	32104–76	2	Screw
30	1–304259	1	Panel–Control
31	104–7050	1	Housing–Manual
32	32105–14	4	Screw
33	106–0709	1	Decal–Panel, Control
34	99–8509	1	Spacer
35	1–303020	1	Grip–Lever
36	323–10	1	Screw–HH
37	98–4387	1	Decal–Protection, Ear
41	104–7048	1	Cap–Housing




Sheet No.: 6

Deck Assembly

Ref. No.	Part No.	Qty.	Description
1	1–304258	1	Belt Shield ASM
1:5	106–0711	1	Decal–Proline 36
3	1–323385	4	Knob–3 Prong
4	1–323417	4	Washer
5	1–303536	2	Stud–Shield, Belt (Long)
6	1–303537	2	Stud–Shield, Belt (Short)
9	105–4680	1	Deck ASM
9:1	1–302189–01	1	Baffle
9:3	1–403005	1	Decal–Danger
9:5	322–2	8	Screw–HH
9:6	32128–20	8	Nut–HF
9:10	66–1340	1	Decal–Danger
9:11	98–5954	1	Decal–Missing, Cover
9:13	98–3296	1	Decal–Routing, Belt
9:14	98–5130	1	Decal–Torque
15	1–304256	1	Chute–Discharge
15:2	54–9220	1	Decal–Danger
17	98–3281	1	Spacer–Spring
18	98–3280	1	Spring–Deflector
19	3296–29	1	Nut–Lock, NI
20	323–8	6	Screw–HH
21	98–5975	6	Washer–Belleville
22	3290–357	6	Nut–HHF
25	322–50	1	Screw–HH

Ref. No.	Part No.	Qty.	Description



Sheet No.: 7


Front Caster and Blade Brake Assembly

Ref. No.	Part No.	Qty.	Description
2	302–52	2	Fitting–Grease
3	1–513338	2	Washer–Flat
5	1–303314	8	Spacer–Caster
6	1–809020	2	Pin
7	1–322145–01	2	Fork
8	325–20	2	Screw–HH
9	1–513648	2	Wheel And Tire ASM
9:2	1–513808	1	Tire
9:3	1–513809	1	Bearing
9:4	1–513810	2	Bushing
10	1–513547	2	Spacer
11	3217–9	2	Nut–Hex
12	3253–7	2	Washer–Lock
15	323–4	8	Screw–HH
16	3290–357	8	Nut–HHF
17	3296–42	2	Nut–Lock, NI
18	302–19	1	Fitting–Grease
19	32128–20	3	Nut–HF
20	1–323071	1	Spring–Extension
21	322–6	1	Screw–HH
22	103–3600	1	Idler Arm ASM
22:2	1–323729	2	Sleeve–Bearing
24	1–303348	1	Eyebolt–Thread, LH
25	1–303434	1	Bushing–Engagement
26	1–603843	1	Pulley–Idler
27	98–5975	1	Washer–Belleville

Ref. No.	Part No.	Qty.	Description
28	702809	1	Screw–Cap
29	1–808280	1	Pin–Clevis
30	1–303105	1	Yoke–Adjustable
31	1–806003	3	Pin–Hair
32	1–323303	1	Linkage–Arm
33	1–322235	1	Arm–Assist
34	1–303238	1	Eyebolt–Thread, RH
35	1–303236	1	Body–Turnbuckle
36	32151–103	1	Ring–Snap
37	3296–29	1	Nut–Lock, NI
38	3256–3	1	Washer–Flat
39	1–403179	1	Tube–Pivot
40	3256–23	1	Washer–Flat
41	32120–35	1	E–Ring
42	1–323715	1	Rod–Brake
43	321–4	2	Screw–HH
44	1–323747	1	Spring–Compression
45	1–323746	1	Spacer–Flanged
46	1–324372	1	Pad/Spring ASM
47	1–303334	1	Washer–Spring
48	322–10	1	Screw–HH
49	1–303352	1	Washer–Spindle
50	1–323748	1	Ring–Push On
51	1–302203	2	Support ASM
☆51:1		1	Support–Caster
51:1:1	302–52	1	Fitting–Grease

☆ Not serviced separately

3328–967




Sheet No.: 7

Front Caster and Blade Brake Assembly

Ref. No.	Part No.	Qty.	Description
51:2	1–303514	2	Bearing–Flanged
52	3296–56	1	Nut–Lock, NI

Ref. No.	Part No.	Qty.	Description




Sheet No.: 8

Spindle Assembly

Ref. No.	Part No.	Qty.	Description
1	1–800861	2	Screw–Cap, HH
2	1–513208	2	Washer–Spring
3	103–2528	2	Blade–Notched
3	103–2508	2	Blade–Low Lift
4	1–323539	8	Spacer–Drive, Blade
5	1–323529	2	Tube–Spindle, Short
6	1–807267	2	Key
7	103–2535	2	Spacer–Guard, Bottom
13	103–2533	2	Cutter Housing ASM
13:1	1–323532	1	Housing–Spindle
13:2	103–2477	2	Bearing–Ball
13:3	103–2534	1	Spacer–Bearing
13:4	32120–8	1	Ring–Snap
14	32128–20	8	Nut–HF
15	1–303334	8	Washer–Spring
16	322–6	8	Screw–HH
17	1–403183	2	Sheave
18	1–803310	2	Screw–Set
19	1–323339	2	Washer–Retainer, Sheave
20	3219–6	2	Nut–Hex
21	1–323737	1	Belt–Blade, Drive
22	103–1330	2	Guard–Bearing, Top

Ref. No.	Part No.	Qty.	Description




Crankcase Assembly
Kohler CV15T–41608

Ref. No.	Part No.	Qty.	Description
1	12 032 03–S	1	Seal–Crankshaft
2	12 522 18–S	1	Shortblock
3	12 445 02–S	1	Strap–Lifting
4	M–839025–S	1	Screw–HF M8x1.25x25
5	24 380 13–S	4	Dowel–Locating
6	12 755 49–S	1	Kit–Camshaft (Incl.7–8)
7	12 089 31–S	1	Spring–Actuating
8	12 422 07–S	A/R	Shim–Camshaft, White
8	12 422 08–S	1	Shim–Camshaft, Blue
8	12 422 09–S	A/R	Shim–Camshaft, Red
8	12 422 10–S	A/R	Shim–Camshaft,Yellow
8	12 422 11–S	A/R	Shim–Camshaft, Green
8	12 422 12–S	A/R	Shim–Camshaft, Gray
8	12 422 13–S	A/R	Shim–Camshaft, Black
9	12 144 27–S	1	Shaft–Balance
10	12 874 07–S	1	Piston w/Ring Set STD (Incl. 11,12)
10	12 874 08–S	1	Set–Piston w/Ring .25
10	12 874 09–S	1	Set–Piston w/Ring .50
10	12 874 11–S	1	Set–Piston w/Ring .08
11	12 018 02–S	2	Retainer–Piston Pin
12	12 108 07–S	1	Ring Set STD
12	12 108 08–S	1	Ring Set .25
12	12 108 09–S	1	Ring Set .50

Ref. No.	Part No.	Qty.	Description
13	12 067 05–S	1	Rod–Connecting, STD
13	12 067 06–S	1	Rod–Connecting .25
14	12 380 01–S	1	Pin–Governor Regulating
15	12 043 05–S	1	Gear–Governor
16	M–631005–S	1	Washer–Plain, 6mm
17	12 144 02–S	1	Shaft–Governor Gear
18	52 139 09–S	1	Plug–Cup
19	12 755 64–S	1	Kit–Governor Cross Shaft (Incl. 23)
20	X–25–102–S	1	Washer–Plain, 1/4
21	12 032 01–S	1	Seal–Governor Cross Shaft
22	M–631015–S	1	Washer–Plain, 6mm
23	12 154 05–S	1	Clip–Hitch Pin
24	12 014 30–S	1	Crankshaft ASM (Incl. 25)
25	12 139 01–S	1	Plug–Cup
*	12 755 93–S	1	Set–Gasket

* Not illustrated
Order Parts from Kohler




Oil Pan and Lubrication Assembly
Kohler CV15T–41608

Ref. No.	Part No.	Qty.	Description
1	12 038 01–S	1	Dipstick ASM(Incl. 2–3)
2	25 755 13–S	1	Kit–Oil Fill Cap (Incl. 3)
3	12 153 03–S	1	O Ring–Dipstick
4	12 153 02–S	1	O Ring–Upper Oil Fill Tube
5	12 123 04–S	1	Tube–Oil Fill
6	M–545020–S	1	Screw–HF, M5x0.8x20
7	12 153 01–S	1	O Ring–Lower Oil Fill Tube
8	25 162 07–S	1	Screen–Oil Pickup
9	12 096 03–S	1	Cover–Oil Pickup Screen
10	M–545016–S	1	Screw–HF, M5x0.8x16
11	52 050 02–S	1	Filter–Oil
12	25 139 57–S	1	Plug–Pipe, 3/8 SH
13	12 199 50–S	1	Oil Pan ASM (Incl.14, 16–19)
14	25 462 09–S	1	Valve–Oil Pressure Relief
15	25 139 52–S	1	Plug–Pipe,1/8
16	M–545016–S	3	Screw–HF, M5x0.8x16
17	12 096 34–S	1	Cover–Oil Pump
18	12 153 06–S	1	O Ring–Oil Pump Cover

Ref. No.	Part No.	Qty.	Description
19	12 393 01–S	1	Pump–Oil
20	12 032 03–S	1	Seal–Oil (PTO End)
21	24 086 16–S	11	Screw–HF, M8x1.25x45
22	24 086 17–S	1	Screw–HF, M8x1.25x45

Order Parts From Kohler




Cylinder Head, Valve and Breather Assembly
Kohler CV15T–41608

Ref. No.	Part No.	Qty.	Description
1	12 351 01–S	2	Lifter–Valve
2	12 755 81–S	1	Kit–Cylinder Head (Incl. 3–13, 18–21, 25, Carburator Gasket 12 041 01–S(2), Exaust Manifold Gasket 12 041 03–S, Air Cleaner Gasket 12 041 02–S)
3	12 411 01–S	2	Rod–Push
4	12 041 10–S	1	Gasket–Cylinder Head
5	12 017 01–S	1	Valve–Intake STD
5	12 017 02–S	1	Valve–Intake .25
6	12 016 01–S	1	Valve–Exhaust STD
6	12 016 02–S	1	Valve–Exhaust, .25
7	25 139 60–S	1	Plug–Pipe, HSH 1/8
8	12 318 19–S	1	Head – Cylinder
9	25 186 01–S	2	Arm–Rocker
10	12 599 03–S	2	Pivot–Rocker Arm
11	M–640034–S	2	Screw–HF M6x1.0x34
12	24 032 05–S	1	Seal–Valve Stem
13	12 089 01–S	2	Spring–Valve
14	12 173 01–S	2	Cap–Valve Spring
15	12 755 03–S	2	Kit–Retainer

Ref. No.	Part No.	Qty.	Description
16	12 086 15–S	5	Screw–HF M10x1.5x81
17	12 112 13–S	1	Spacer–Head Bolt Exhaust Port
18	12 468 05–S	1	Washer–Plain 13/32
19	12 326 03–S	1	Hose–Breather
20	25 237 14–S	2	Clamp–Hose
21	M–645020–S	3	Screw–HF M6x1.0x20
22	M–640034–S	2	Screw–HF M6x1.0x34
23	12 096 07–S	1	Cover–Valve w/Nipple
24	M–545010–S	1	Screw–HF M5x0.8x10
25	12 018 01–S	1	Retainer–Breather Reed
26	12 402 02–S	1	Reed–Breather

Order Parts from Kohler




Ignition and Electrical Assembly
Kohler CV15T–41608

Ref. No.	Part No.	Qty.	Description
1	12 086 14–S	1	Screw–HF,M10x1.5x46
2	12 468 03–S	1	Washer–Plain, 3/8
3	M–545010–S	3	Screw–HF,M5x0.8x10
4	12 109 07–S	1	Cup–Drive, Starter
5	12 162 09–S	1	Screen–Grass
6	25 086 47–S	4	Bolt–Shoulder
7	12 157 03–S	4	Fan
8	X–42–15–S	1	Key
9	12 025 31–S	1	Flywheel
8	12 403 01–S	1	Rectifier–Unregulated, 15 amp
9	X–22–11–S	2	Washer – Lock
10	12 132 06–S	1	Spark Plug

Ref. No.	Part No.	Qty.	Description
11	X–728–1–S	2	Clip–Cable
10	M–639016–S	2	Screw–HF, M6x1.0x16
11	41 155 03–S	1	Connector
12	M–545010–S	2	Screw–HF, M5x0.8x10
13	12 584 05–S	1	Module–Ignition
13	M–548025–S	2	Screw–HH M5x0.8x25
14	M–545020–S	2	Screw–HF, M5x0.8x20
*	25 518 05–S	1	Lead–Black, Rectifier/ Regulator,(5”–14Gauge Uninsulated Push On Tab Terminals)
*	12 454 03–S	1	Tie–Wire

* Not illustrated
Order Parts From Kohler




Blower Housing and Baffle Assembly
Kohler CV15T–41608

Ref. No.	Part No.	Qty.	Description
1	12 314 10 S	1	Guard–Grass Screen
2	M–545010–S	9	Screw–HF, M5x0.8x10
3	M–550010–S	6	Screw–HF, M5x0.8x10
4	12 096 29–S	1	Cover–Starter
5	12 027 53–S	1	Housing–Blower
6	12 096 27–S	1	Cover–Rectifier/ Regulator
7	M–6390 16–S	2	Screw–HF, M6x1.0x16
8	12 063 10–S	1	Baffle–Intake, Side
9	12 063 08–S	1	Baffle–Cylinder Head
10	12 313 03–S	1	Grommet–Spark Plug leads
11	12 063 19–S	1	Baffle–Cylinder
12	12 146 07–S	1	Plate–Blower Housing
*	12 113 112–S	1	Decal–Hoursepower

Ref. No.	Part No.	Qty.	Description

* Not illustrated
Order Parts From Kohler




Starter Assembly
Kohler CV15T–41608

Ref. No.	Part No.	Qty.	Description
1	M–550010–S	5	Screw–HF, M5x0.8x10
2	12 165 01–S	1	Starter ASM Retractable (Incl. 3–9)
3	12 081 01–S	1	Housing–Starter
4	12 160 01–S	1	Rope–Starter
5	25 166 01–S	1	Handle–Recoil
6	12 089 06–S	1	Spring & Keeper
7	12 093 01–S	1	Pulley
8	12 757 06–S	1	Kit–Dog Repair (incl. 9)
9	41 086 09–S	1	Screw–Posidrive
*	12 113 07–S	1	Decal–Starting

Ref. No.	Part No.	Qty.	Description

* Not illustrated
Order Parts From Kohler




Fuel System Assembly
Kohler CV15T–41608

Ref. No.	Part No.	Qty.	Description
1	M–641060–S	2	Nut–HF M6x1.0
2	M–629116–S	2	Stud M6x1.0x116
3	12 853 80–S	1	Kit–Carburetor w/Gaskets (Incl. 4–6)
4	12 041 02–S	1	Gasket–Air Cleaner
5	12 053 80	1	Carburetor ASM (For Information Only Not Available Separately) (Service With Kits 12 757 02–S Float Kit 12 757 03–S Carb. Repair Kit and 12 757 08–S Choke Repair Kit)
6	12 041 01–S	2	Gasket–Carburetor
7	12 265 04–S	1	Deflector–Heat
8	47 154 01–S	1	Clip–Cable
*	12 757 02–S	1	Kit–Float
*	12 757 08–S	1	Kit–Choke Repair
*	12 757 03–S	1	Kit–Carburetor Repair
*	12 755 92–S	1	Kit–High Altitude with Gaskets

Ref. No.	Part No.	Qty.	Description

* Not illustrated
Order Parts From Kohler




Engine Control Assembly
Kohler CV15T–41608

Ref. No.	Part No.	Qty.	Description
1	12 079 07–S	1	Linkage–Choke
2	12 237 01–S	1	Clamp–Cable
3	M–664020–S	2	Screw–Lobed Socket M6x1.0x20
4	M–545016–S	1	Screw–HF M5x .08x16
5	12 536 06–S	1	Control–Speed ASM
6	12 089 23–S	1	Spring–Choke Return (Incl. 6–10)
7	12 089 11–S	2	Spring–Speed Control
8	12 086 38–S	1	Screw–Pan Hd with Loctite
9	M–443020–S	1	Screw–SPH, M4x0.7x20
10	25 452 14	1	Terminal–Kill Switch
11	12 089 19–S	1	Spring–Governor
‘12	12 755 83–S	1	Kit – Governor Lever (Incl. 13–15)
13	12 100 07–S	1	Nut–HF
14	52 211 04–S	1	Bolt–Round HD
15	12 090 28–S	1	Lever–Governor
16	12 079 01–S	1	Linkage–Throttle
17	25 158 08–S	1	Bushing–Linkage Retaining

Ref. No.	Part No.	Qty.	Description
18	25 158 11–S	1	Bushing–Throttle Linkage

Order Parts From Kohler




Air Cleaner Assembly
Kohler CV15T–41608

Ref. No.	Part No.	Qty.	Description
1	12 743 02–S	1	Kit–Air Cleaner (Incl. 2–12)
2	25 341 03–S	1	Knob–Air Cleaner Cover
3	12 096 38–S	1	Cover–Air Cleaner
4	12 083 12–S	1	Element–Precleaner
5	12 083 10–S	1	Element–Air Cleaner (Incl. 6–8)
6	12 743 12–S	1	Kit–Seal (Incl. 7–8)
7	12 100 08–S	1	Nut–Wing
8	12 032 11–S	1	Seal
9	12 094 07–S	1	Base–Air Cleaner (Incl. 10,11)
10	12 072 04–S	1	Stud–M6x1.0x66
11	12 086 01–S	2	Screw–#10 Hi–Lo Thread Forming
12	12 041 02–S	1	Gasket–Air Cleaner
*	12 113 04–S	1	Decal–Air Cleaner

Ref. No.	Part No.	Qty.	Description

* Not illustrated
Order Parts From Kohler



Exhaust Assembly
Kohler CV15T–41608

Ref. No.	Part No.	Qty.	Description
1	12 068 44–S	1	Muffler
2	25 072 04–S	2	Stud M8x1.25x33
3	12 041 03–S	1	Gasket–Exhaust Manifold
4	X–25–78–S	1	Washer–Plain,1/4
5	M–545016–S	1	Screw–HF, M5x0.8x16
6	M–841080–S	2	Nut–HF, M8x1.25
7	M–645016–S	2	Screw–HF, M6x1.0x16
8	M–645025–S	2	Screw–HF, M6x1.0x25
9	12 126 71–S	1	Bracket–Muffler
*	12 112 20–S	2	Spacer

Ref. No.	Part No.	Qty.	Description

* Not illustrated
Obtain Parts From Kohler

Maintenance Record

Date								

Maintenance Record

Date								


TORO®