Form Number 3328-980 Rev A

# Groundsmaster® 4500-D

**Model No. 30856 - 230000001 and up.**

## Parts Catalog

**Ordering Replacement Parts**

To order replacement parts, please supply the part number, the quantity, and the description of each part desired.

**Understanding Reference Numbers**

Each Identified part in an illustration has a reference number. The reference number for a part also appears in the parts list, along with other information about the part.

This catalog uses two special reference number formats, one to indicate parts in a service assembly and another to indicate the quantity of a given part in an illustration.

**Service Assembly Reference Numbers**

Parts in service assemblies have reference numbers in the form a:b. The a represents the reference number of the entire service assembly and the b represents a sequential number unique to each part within the service assembly.

For example, a wheel assembly might be identified by reference number 6, the tire by 6:1, the valve by 6:2, and the wheel by 6:3. When you order the assembly identified by reference number 6, you receive all parts identified by reference numbers 6:1, 6:2, and 6:3. However, you may also order any part individually. Reference numbers of this type appear in illustrations and in part lists.

**Reference Numbers Indicating Quantity**

In an illustration, if a reference number indicates more than one part, the reference number has the form nX y. The n represents the quantity of the part, the X is the multiplication symbol, and the y represents the reference number.

For example, in an illustration, the reference number 2X 37 means that two of the parts identified by reference number 37 are indicated.

© The Toro Company - 2006
All Rights Reserved

Register your product at www.Toro.com

# Contents


| Description | Page |
|---|---|
| Hood Screen and Bumper Assembly | 4 |
| Steering Tower Assembly | 6 |
| Steering Valve Assembly No. 104-2213 | 8 |
| Traction and Brake Pedal Assembly | 9 |
| Throttle and Seat Frame Assembly | 10 |
| Control Console Assembly | 11 |
| Hydraulic Filter and Reservoir Assembly | 12 |
| Fuel Tank and Filter Assembly | 13 |
| Front Drive and Brake Assembly | 14 |
| Planetary Assembly No. 105-4500-03 | 15 |
| LH Brake Assembly No. 100-3070 | 16 |
| Piston Motor Assembly No. 105-1218 | 17 |
| RH Brake Assembly No. 100-3069 | 18 |
| Manifold Mounting and Fitting Assembly | 19 |
| Hydraulic Pump Assembly | 20 |
| Triple Pump Assembly No. 105-9845 | 21 |
| Piston Pump Assembly No. 105-9846 | 22 |
| Control Assembly No. 93-6306 | 23 |
| Radiator Assembly | 24 |
| Fan and Solenoid Assembly | 25 |
| Engine Installation Assembly | 26 |
| Air Cleaner Assembly No. 99-5410 | 27 |
| Rear Axle Assembly | 28 |
| Cylinder Assembly No. 105-9861 | 29 |
| Piston Motor Assembly No. 105-1219 | 30 |
| Bevel Pinion Shaft Assembly Rear Axle Assembly No. 100-3784 | 31 |
| Differential Assembly Rear Axle Assembly No. 100-3784 | 32 |
| Axle Support Assembly Rear Axle Assembly No. 100-3784 | 33 |
| Bevel Gear Case Assembly Rear Axle Assembly No. 100-3784 | 34 |
| Bevel Gear Shaft Assembly Rear Axle Assembly No. 100-3784 | 35 |
| Axle Case Assembly Rear Axle Assembly No. 100-3784 | 36 |
| Axle Assembly Rear Axle Assembly No. 100-3784 | 37 |
| Coupler Spacer and Adapter Plate Assembly | 38 |
| Battery Installation Assembly | 39 |
| Water and Fuel Filter Assembly No. 98-9305 | 40 |
| Front Lift Arm Assembly | 41 |
| No. 4 and 5 Lift Cylinder Assembly No. 104-5527 | 43 |
| No. 1 Lift Cylinder Assembly No. 104-5528 | 44 |
| Lift Lever Assembly | 45 |
| No. 2 and 3 Lift Arm Assembly | 46 |
| Hose Installation Assembly | 47 |
| No. 1, 4 and 5 Hose Installation Assembly | 48 |
| Hydraulic Motor Assembly No. 105-9820 | 49 |
| Roll-Over Protection System and Frame Assembly | 50 |
| Front Frame Assembly No. 104-5469 | 51 |
| Roller Support and Access Panel Assembly | 52 |
| Manifold Assembly | 53 |
| Manifold Assembly No. 104-5475 | 54 |
| 4 Wheel Drive Manifold and Filter Assembly | 55 |
| Filter Manifold Assembly No. 100-5558 | 56 |
| 4 Wheel Drive Manifold Assembly No. 105-9875 | 57 |
| Traction Hydraulic Line Assembly | 58 |
| Steering Hydraulic Line Assembly | 59 |
| Mow Block Hydraulic Line Assembly | 60 |
| Lift Hydraulic Line Assembly | 61 |
| Lift Valve and Counter Balance Assembly | 62 |
| Manifold Assembly No. 104-5495 | 63 |
| Single Spool Valve Assembly No. 104-5494 | 64 |
| Crankcase Assembly | 65 |
| Oil Pan Assembly | 66 |
| Cylinder Head Assembly | 67 |
| Gear Case Assembly | 68 |
| Head Cover Assembly | 69 |
| Oil Filter Assembly | 70 |
| Dipstick and Guide Assembly | 71 |
| Oil Pump Assembly | 72 |
| Breather Assembly | 73 |
| Main Bearing Case | 74 |
| Camshaft and Idler Gear Shaft Assembly | 75 |
| Piston and Crankshaft Assembly | 76 |
| Flywheel Assembly | 77 |
| Fuel Camshaft and Governor Shaft Assembly | 78 |
| Engine Stop Lever Assembly | 79 |
| Injection Pump Assembly | 80 |
| Injection Pump Component Parts Assembly | 81 |
| Governor Assembly | 82 |
| Speed Control Plate Assembly | 83 |
| Nozzle Holder and Glow Plug Assembly | 84 |
| Fuel Filter | 85 |
| Alternator and Pulley Assembly | 86 |
| Alternator Component Parts Assembly | 87 |
| Starter Assembly | 88 |
| Starter Component Parts Assembly | 89 |
| Oil Switch / Thermometer and Plug Assembly | 90 |
| Water Flange and Thermostat Assembly | 91 |
| Water Pump Assembly | 92 |
| Water Pipe Assembly | 93 |
| Fan Assembly | 94 |
| Valve and Rocker Arm Assembly | 95 |
| Inlet Manifold Assembly | 96 |
| Exhaust Manifold Assembly | 97 |
| Turbo Charger Assembly | 98 |
| Oil Pipe (Turbo Charger) Assembly | 99 |
| Oil Cooler Assembly | 100 |
| Muffler Gasket and Glow Controller | 101 |
| Operators Manual | 102 |
| Gasket Kit | 103 |

# Part Description Abbreviations


Part descriptions in this catalog may include the following abbreviations.

AR. . . . . as required
ASM. . . . . assembly
BBC. . . . . blade brake clutch
CARR. . . . . carriage
DEG. . . . . degrees
EXT. . . . . external
FH. . . . . flat head
GA. . . . . gauge
HD. . . . . heavy-duty
HF. . . . . hex flange
HH. . . . . hex head
HHF. . . . . hex head flange
HHFTF. . . . . hex head flange thread forming
HJ. . . . . hex jam
HLH. . . . . hex lag head
HOC. . . . . height-of-cut
HSBH. . . . . hex socket button head
HSFH. . . . . hex socket flat head
HSH. . . . . hex socket head
HWH. . . . . hex washer head
HWHTF. . . . . hex washer head thread forming
HYD. . . . . hydraulic
LH. . . . . left hand
NI. . . . . nylon insert
NPTF. . . . . national pipe thread fine
PFH. . . . . phillips flat head
PPH. . . . . phillips pan head
PPHTF. . . . . phillips pan head thread forming
PRH. . . . . phillips round head
PTH. . . . . phillips truss head
PTO. . . . . power-take-off
RH. . . . . right hand
ROPS. . . . . roll-over protection system
SFH. . . . . slotted fillister head
SHH. . . . . slotted hex head
SHWH. . . . . slotted hex washer head
SPH. . . . . slotted pan head
SQH. . . . . square head
SRH. . . . . slotted round head
STD. . . . . standard
TAP. . . . . self tapping
TTH. . . . . torx truss head

# Footnotes

❶ Not illustrated


❷ Not serviced separately




# Hood Screen and Bumper Assembly


| Ref | Part No. | Qty. | Description |
|---|---|---|---|
| 1 | 104-5437-03 | 1 | Tube-Hood Frame, LH |
| 2 | 104-5434-03 | 1 | Tube-Front, Hood |
| 3 | 104-5430 | 1 | Shroud-Front |
| 4 | 104-5446-03 | 1 | Divider-Shroud |
| 5 | 3290-467 | 2 | Pin-Hair |
| 6 | 104-5454-03 | 1 | Screen ASM |
| 7 | 104-5490 | 2 | Decal |
| 8 | 104-5419 | 1 | Hood |
| 9 | 3256-22 | 12 | Washer-Flat |
| 10 | 3296-42 | 12 | Nut-Lock, NI |
| 11 | 3269-17 | 4 | Rivet-Pop |
| 12 | 104-5431 | 1 | Cover-Tube, RH |
| 13 | 3296-29 | 10 | Nut-Lock, NI |
| 14 | 321-10 | 6 | Screw-HH |
| 15 | 322-9 | 8 | Screw-HH |
| 16 | 104-5445-03 | 1 | RH Support ASM |
| 17 | 32128-43 | 6 | Nut-Flange |
| 18 | 321-13 | 6 | Screw-HH |
| 19 | 104-5438-03 | 1 | Tube-Hood Frame, RH |
| 20 | 104-5444-03 | 1 | LH Support ASM |
| 21 | 104-5435-03 | 1 | Tube-Rear, Hood |
| 22 | 3234-11 | 6 | Screw-HHF |
| 23 | 104-5440-03 | 2 | Hood Receiver ASM |
| 24 | 104-5432 | 1 | Cover-Tube, LH |

| Ref | Part No. | Qty. | Description |
|---|---|---|---|
| 25 | 32104-17 | 4 | Screw-HWH |
| 26 | 105-9199-03 | 1 | Weight-Bumper |
| 27 | 105-9221-03 | 1 | Rear Bumper ASM |
| 28 | 240-14 | 2 | Bumper-Rubber |
| 29 | 32128-33 | 5 | Nut-HF |
| 30 | 105-9200-03 | 2 | Clamp-Weight, Bumper |
| 33 | 3296-23 | 4 | Nut-Lock, NI |
| 34 | 322-17 | 2 | Screw-HH |
| 35 | 104-5450 | 2 | Retainer-Receiver, Hood |
| 36 | 3290-221 | 2 | Washer-Spring |
| 37 | 104-5451 | 2 | Spacer-Receiver, Hood |
| 38 | 76-8350 | 2 | Stop-Axle |
| 39 | 3256-26 | 2 | Washer-Flat |
| 40 | 59-9740 | 4 | Flex Draw Latch ASM |
| 40:2 | 249-40 | 1 | Keeper |
| 41 | 3290-55 | 8 | Rivet-Pop |
| 42 | 325-6 | 2 | Screw-HH |
| 43 | 325-33 | 2 | Screw-HH |
| 44 | 105-3912 | 1 | Latch-Draw |
| 45 | 105-9245 | 2 | Pin-Lock |
| 46 | 100-6574 | 2 | Decal-Warning |
| 47 | 104-5459 | 1 | Plate-Latch |
| 48 | 105-9234 | 1 | Seal-Foam |
| 49 | 105-9237 | 2 | Seal-Foam |




# Hood Screen and Bumper Assembly (continued)


| Ref | Part No. | Qty. | Description |
|---|---|---|---|
| 50 | 105-9235 | 2 | Seal-Foam |
| 51 | 93-6028 | 1 | Plate-Logo |
| 52 | 94-2638 | 4 | Nut-Tinnerman |
| 53 | 66-1210 | 2 | Decal |
| 54 | 3269-10 | 8 | Washer-Back |
| 55 | 105-9829 | 1 | Seal-Foam |
| 56 | 3290-55 | 4 | Rivet-Pop |
| 57 | 3269-15 | 4 | Rivet |




# Steering Tower Assembly


| Ref | Part No. | Qty. | Description |
|---|---|---|---|
| 1 | 98-1459 | 1 | Decal |
| 2 | 94-9952 | 1 | Nut-Hex |
| 3 | 98-1471 | 1 | Wheel-Steering |
| 3:1 | 98-1468 | 1 | Cover-Wheel, Steering |
| 4 | 233-17 | 1 | Knob |
| 5 | 21-9260 | 1 | Cover-Dust |
| 6 | 33103-016 | 3 | Screw-HHF |
| 7 | 75-6550 | 1 | Disc-Friction |
| 9 | 3272-2 | 1 | Pin-Cotter |
| 10 | 75-6580 | 1 | Cable-Pedal |
| 11 | 3256-22 | 5 | Washer-Flat |
| 12 | 3296-39 | 1 | Nut-Lock, NI |
| 13 | 3290-461 | 1 | Washer-Spring |
| 14 | 95-7151 | 1 | Tube-Convoluted |
| 15 | 75-6510 | 1 | Bracket-Lever |
| 16 | 94-9951 | 1 | Column-Steering |
| 17 | 104-2213 | 1 | Valve-Steering |
| 18 | 100-8071 | 1 | Lamp-Warning |
| 19 | 100-8070 | 1 | Lamp-Warning |
| 20 | 233-42 | 1 | Knob |
| 21 | 75-6490 | 1 | Lever ASM |
| 23 | 75-2810 | 1 | Bracket-Column, Steering |
| 24 | 3234-7 | 6 | Screw-HHF |
| 25 | 95-1821-03 | 1 | Spring-Compression |

| Ref | Part No. | Qty. | Description |
|---|---|---|---|
| 26 | 33103-020 | 1 | Screw-HHF |
| 27 | 3255-8 | 1 | Washer-Lock |
| 28 | 3256-23 | 6 | Washer-Flat |
| 29 | 3272-5 | 3 | Pin-Cotter |
| 30 | 104-1492 | 1 | Rod ASM |
| 31 | 62-5550 | 1 | Decal |
| 32 | 93-7996-01 | 1 | Cover-Tower |
| 33 | 3272-10 | 1 | Pin-Cotter |
| 34 | 3256-26 | 2 | Washer-Flat |
| 35 | 63-7900-03 | 1 | Rack ASM |
| 36 | 340-2 | 5 | Fitting-Straight, HYD |
| 36:1 | 237-22 | 1 | O-Ring |
| 36:2 | 237-42 | 1 | O-Ring |
| 37 | 100-1270 | 1 | Switch-Proximity |
| 39 | 100-4872 | 1 | Plate-Switch, Neutral |
| 40 | 104-1450 | 1 | Bolt-CARR |
| 41 | 3256-14 | 1 | Washer-Flat |
| 42 | 3296-2 | 1 | Nut-Lock |
| 44 | 87-6620 | 2 | Screw |
| 45 | 3256-1 | 2 | Washer-Flat |
| 46 | 105-9232-03 | 1 | Plate-Instrument |
| 48 | 32121-45 | 1 | Pin-Spring |
| 49 | 88-9830 | 1 | Key Switch ASM |
| 49:1 | 3254-5 | 1 | Washer-Tooth |





# Steering Tower Assembly (continued)

| Ref | Part No. | Qty. | Description |
|---|---|---|---|
| 49:2 | 218-461 | 1 | Nut-HH |
| 50 | 63-8360 | 1 | Key-Ignition |
| 52 | 105-3888 | 1 | Decal-Tower |
| ❶99 | 3290-379 | 1 | Tie-Cable |




# Steering Valve Assembly No. 104-2213


| Ref | Part No. | Qty. | Description |
|---|---|---|---|
| 1 | 94-4099 | 1 | Seal Kit |
| ❷2 | | 1 | Housing |
| 3 | 94-4095 | 1 | Centering Spring Kit |
| ❷4 | | 1 | Spool |
| 5 | 94-4098 | 1 | Ring-Retaining |
| 6 | 94-4094 | 1 | Pin |
| ❷7 | | 1 | Sleeve |
| 8 | 94-4096 | 1 | Bearing Kit |
| 9 | 94-4088 | 7 | Screw-Cap |
| 10 | 94-4089 | 1 | Cap-End |
| 11 | 94-4090 | 1 | Gerotor |
| 12 | 94-4091 | 1 | Spacer |
| 13 | 94-4093 | 1 | Drive |
| 14 | 94-4092 | 1 | Plate-Wear |
| 15 | 99-5511 | 1 | Plug ASM |
| 16 | 99-5500 | 1 | Valve-Relief |




# Traction and Brake Pedal Assembly

| Ref | Part No. | Qty. | Description |
|---|---|---|---|
| 1 | 32144-14 | 6 | Screw-HWH |
| 2 | 74-9110 | 1 | Pad-Pedal, Reverse |
| 3 | 75-2970 | 1 | Pedal-Traction |
| 4 | 32121-45 | 1 | Pin-Spring |
| 5 | 74-9100 | 1 | Pad-Pedal, Forward |
| 6 | 49-6440-03 | 1 | Pedal-Forward |
| 7 | 323-29 | 1 | Screw-HH |
| 8 | 3256-24 | 2 | Washer-Flat |
| 9 | 3220-3 | 4 | Nut-Hex, Jam |
| 10 | 2411-36 | 3 | Bearing-End, Rod |
| 11 | 32121-6 | 1 | Pin-Roll, Slotted |
| 12 | 32128-20 | 12 | Nut-HF |
| 13 | 256-236 | 4 | Bearing-Mount, Flange |
| 14 | 3256-22 | 1 | Washer-Flat |
| 15 | 3272-2 | 1 | Pin-Cotter |
| 16 | 323-9 | 1 | Screw-HH |
| 17 | 104-5632-03 | 1 | Rod-Control, Pump |
| 18 | 75-3270-03 | 1 | Hub-Pivot, Traction |
| 19 | 92-7609 | 1 | Shaft-Spring |
| 20 | 3296-39 | 2 | Nut-Lock, NI |
| 21 | 32121-11 | 1 | Pin-Roll |
| 22 | 92-7608-03 | 1 | Bracket-Spring |
| 23 | 92-7610 | 1 | Retainer-Spring |
| 24 | 84-9100 | 1 | Spring |


| Ref | Part No. | Qty. | Description |
|---|---|---|---|
| 25 | 3256-5 | 1 | Washer-Flat |
| 26 | 75-1470 | 1 | Pin-Pivot, Brake |
| 27 | 3256-69 | 3 | Washer-Flat |
| 28 | 75-1430 | 1 | Pedal-Brake, RH |
| 28:2 | 256-42 | 2 | Bushing |
| 28:3 | 302-5 | 1 | Fitting-Grease |
| 29 | 75-1440-03 | 1 | LH Brake Pedal ASM |
| 30 | 32121-16 | 1 | Pin-Spring |
| 31 | 283-58 | 2 | Pin-Clevis |
| 32 | 92-7530 | 1 | LH Brake Cable ASM |
| ❶33 | 92-7529 | 1 | RH Brake Cable ASM |
| 34 | 63-7880 | 1 | Pin-Latch, Brake |
| 35 | 32121-50 | 1 | Pin-Spring |
| 36 | 3272-10 | 2 | Pin-Cotter |
| 37 | 3290-378 | 1 | Tie-Cable |
| 38 | 93-8742 | 2 | Footpad-Brake |
| 39 | 322-3 | 8 | Screw-HH |
| 42 | 3234-11 | 1 | Screw-HHF |
| 43 | 5-0652 | 1 | Spacer |
| 44 | 3296-59 | 1 | Nut-Lock, NI |
| 46 | 17-9420 | 2 | Screw-Handle |
| 47 | 2412-150 | 1 | J-Clip |
| 48 | 3234-14 | 1 | Screw-HHF |




# Throttle and Seat Frame Assembly

| Ref | Part No. | Qty. | Description |
|---|---|---|---|
| 1 | 322-3 | 8 | Screw-HH |
| 2 | 98-2350-03 | 1 | Seat Plate ASM |
| 3 | 94-8146 | 1 | Strip-Foam |
| 4 | 98-2353 | 2 | Bracket-Latch, Seat |
| 5 | 32128-25 | 4 | Nut-HF |
| 6 | 98-2354-03 | 1 | Latch-Seat |
| 7 | 233-42 | 1 | Knob |
| 8 | 93-7598-03 | 1 | Lever-Throttle |
| 9 | 3296-21 | 1 | Nut-Lock, NI |
| 10 | 3290-307 | 1 | Pin-Hair |
| 11 | 3256-24 | 3 | Washer-Flat |
| 12 | 3256-51 | 1 | Washer-Flat |
| 13 | 75-3680-03 | 1 | Rod-Seat |
| 14 | 66-2920 | 2 | Washer-Friction |
| 15 | 3296-39 | 1 | Nut-Lock, NI |
| 16 | 2411-38 | 1 | Joint-Ball |
| 17 | 3272-10 | 1 | Pin-Cotter |
| 18 | 52-2900 | 2 | Washer-Plastic |
| 19 | 98-2352-03 | 1 | Frame-Seat |
| 20 | 3290-467 | 1 | Pin-Hair |
| 21 | 75-3400 | 1 | Shaft-Pivot, Seat |
| 22 | 104-7547 | 1 | Cable-Throttle |
| 23 | 105-3929-03 | 1 | Bracket-Cable, Throttle |
| 24 | 66-4190-03 | 1 | Spring-Idler, Clutch |


| Ref | Part No. | Qty. | Description |
|---|---|---|---|
| 25 | 105-9824 | 1 | Decal-Quick Reference |
| 26 | 105-9189 | 1 | Harness-Wire, Seat Switch |
| 27 | 2412-133 | 2 | R-Clamp |
| 28 | 100-4928 | 1 | Belt-Seat |
| 29 | 2412-93 | 1 | Clamp-R |
| 30 | 3212-4 | 2 | Screw-HH |
| 31 | 3253-6 | 2 | Washer-Lock |
| 32 | 3256-23 | 4 | Washer-Flat |
| 33 | 3296-29 | 10 | Nut-Lock, NI |
| 34 | 74-0720 | 1 | Tube-Manual |




# Control Console Assembly


| Ref | Part No. | Qty. | Description |
|---|---|---|---|
| 1 | 105-9208 | 2 | Screw-Head, Wing |
| 2 | 104-5599 | 1 | Cover-Console |
| 3 | 3234-13 | 4 | Screw-HHF |
| 4 | 32144-10 | 8 | Screw-HWH |
| 5 | 99-7430 | 3 | Relay |
| 6 | 104-5613-03 | 1 | Panel-Relay |
| 8 | 105-9867 | 1 | Harness-Wire, Console |
| 9 | 3234-14 | 13 | Screw-HHF |
| 10 | 32148-6 | 6 | Insert-Nut |
| 11 | 105-9209 | 2 | Recepticle-Clip On |
| 12 | 104-5612-03 | 1 | Support-Cover |
| 13 | 32128-20 | 4 | Nut-HF |
| 14 | 98-9308 | 1 | Gauge-Temperature |
| 14:1 | 3254-1 | 3 | Washer-Lock, Int |
| 14:2 | 3217-27 | 3 | Nut-Hex |
| 14:3 | 105-9265 | 1 | Bulb And Lamp ASM |
| 15 | 32144-18 | 2 | Screw-HH |
| 16 | 75-6820 | 1 | Hourmeter |
| 17 | 95-8999 | 2 | Switch |
| 18 | 104-5611-03 | 1 | Dash |
| 19 | 105-9223 | 1 | Decal-Console, Ce |
| 19 | 105-3890 | 1 | Decal-Console |
| 20 | 37-2690 | 1 | Capacitor |
| 20:1 | 3252-18 | 2 | Screw |

| Ref | Part No. | Qty. | Description |
|---|---|---|---|
| 20:2 | 3254-1 | 2 | Washer-Lock, Int |
| 21 | 74-2310 | 1 | Clamp-Plastic |
| 22 | 117433 | 2 | Rivet-Pop |
| 23 | 99-7416 | 1 | Cap |
| 24 | 99-7411 | 1 | Point-Power |
| 25 | 3234-4 | 1 | Screw-HHF |
| 26 | 104-5610-03 | 1 | Panel-Dash, Rear |
| 27 | 98-7611 | 1 | Controller-Glow |
| 28 | 32128-33 | 4 | Nut-HF |
| 29 | 3296-2 | 2 | Nut-Lock |
| 30 | 104-5609-03 | 1 | Panel-Dash, Front |
| ❶31 | 105-3986 | 1 | Module-Control, Deck |
| ❶32 | 32105-13 | 4 | Screw-SHH |
| ❶33 | 3296-2 | 2 | Nut-Lock |
| 34 | 321-6 | 2 | Screw-HH |
| 35 | 105-9840 | 1 | Bracket-Latch, RH |
| 36 | 105-9842 | 1 | Plate-Latch, Ce |
| 37 | 105-9841 | 1 | Bracket-Latch, LH |
| 38 | 105-9830 | 1 | Decal-Lever Lock, Ce |
| 40 | 3296-42 | 2 | Nut-Lock, NI |
| 41 | 105-9873-03 | 1 | Bracket-Module, Standard Control |
| 42 | 105-8505 | 1 | Module-Control, Standard |
| 43 | 32144-110 | 3 | Screw-HWH |





# Hydraulic Filter and Reservoir Assembly

| Ref | Part No. | Qty. | Description |
|---|---|---|---|
| 1 | 93-7498 | 1 | Plug-Plastic |
| 2 | 94-8166 | 1 | O-Ring |
| 3 | 75-3710 | 1 | Dipstick |
| 4 | 68-6150 | 1 | Breather |
| 5 | 92-8020 | 1 | Adapter-Breather |
| 6 | 104-5600 | 1 | Tank-HYD |
| 7 | 340-156 | 1 | Fitting-HYD |
| 7:1 | 237-65 | 1 | O-Ring |
| 7:2 | 237-81 | 1 | O-Ring |
| 8 | 104-7546 | 1 | Strainer-Tank |
| 8:1 | 340-136 | 1 | O-Ring |
| 9 | 2412-111 | 2 | Clamp |
| 10 | 340-109 | 1 | Fitting-HYD, Tee |
| 10:1 | 237-79 | 1 | O-Ring |
| 10:2 | 237-30 | 2 | O-Ring |
| 11 | 240-11 | 3 | Bushing-Flange |
| 12 | 63-8410 | 3 | Washer |
| 13 | 3234-11 | 3 | Screw-HHF |
| 14 | 61-2790 | 1 | Filter-Screen |




# Fuel Tank and Filter Assembly


| Ref | Part No. | Qty. | Description |
|---|---|---|---|
| 1 | 104-5604 | 1 | Fitting-Suction |
| 2 | 2412-80 | 2 | Clamp-Line, Fuel |
| 3 | 39-1120 | 1 | Hose-Fuel |
| 4 | 104-5605 | 1 | Fitting-Return |
| 5 | 105-9242 | 1 | Hose-Fuel |
| 6 | 93-3102 | 1 | Cap-Fuel |
| 7 | 46-6560 | 2 | Bushing |
| 10 | 104-5601 | 1 | Fuel Tank ASM |
| 10:1 | 2412-36 | 1 | Clamp-Hose |
| 10:2 | 304-46 | 1 | Draincock |
| 10:4 | 104-5603 | 1 | Gauge-Level, Fuel |
| 10:5 | 95-8972 | 1 | Grommet |
| 11 | 240-11 | 4 | Bushing-Flange |
| 12 | 63-8410 | 4 | Washer |
| 13 | 3234-11 | 4 | Screw-HHF |
| 14 | 98-7612 | 1 | Filter-Fuel |
| 15 | 104-5215 | 1 | Pump-Fuel, Electric |
| 16 | 2412-138 | 1 | R-Clamp |
| 17 | 32144-10 | 4 | Screw-HWH |
| 18 | 2412-148 | 1 | Clamp-R |
| 19 | 105-9196 | 1 | Hose-Fuel |
| 20 | 93-2230 | 1 | Hose-Fuel |
| 21 | 92-2379 | 5 | Clamp-Hose |




# Front Drive and Brake Assembly

| Ref | Part No. | Qty. | Description |
|---|---|---|---|
| 1 | 33106-030 | 12 | Screw-HHF |
| 2 | 100-3046 | 2 | Shaft-Brake, Splined |
| 3 | 105-4500-03 | 2 | Planetary ASM |
| ❷4 | | 2 | Wheel And Tire ASM |
| 4:1 | 95-3465 | 1 | Tire |
| 4:2 | 95-3464 | 1 | Rim |
| 4:3 | 232-24 | 1 | Stem-Valve |
| 5 | 92-7483 | 16 | Nut-Lug |
| 6 | 93-7972 | 4 | Ring-Retaining, Internal |
| 7 | 94-3050 | 2 | Plate-Spring |
| 8 | 94-3088 | 2 | Spring-Compression |
| 9 | 3218-4 | 2 | Nut-Jam |
| 10 | 100-3070 | 1 | Brake ASM |
| 11 | 33106-090 | 8 | Screw-HHF |
| 12 | 353-988 | 1 | Plug-Hex |
| 12:1 | 237-79 | 1 | O-Ring |
| 13 | 105-1218 | 2 | Motor-Piston |
| 14 | 3256-26 | 4 | Washer-Flat |
| 15 | 33116-120 | 4 | Screw-HH |
| 16 | 340-98 | 3 | Fitting-HYD, 90 DEG |
| 16:1 | 237-79 | 1 | O-Ring |
| 16:2 | 237-30 | 1 | O-Ring |
| 17 | 340-142 | 2 | Fitting-HYD, 90 DEG |
| 17:1 | 237-58 | 1 | O-Ring |


| Ref | Part No. | Qty. | Description |
|---|---|---|---|
| 17:2 | 237-81 | 1 | O-Ring |
| 18 | 237-166 | 2 | O-Ring |
| 19 | 100-3069 | 1 | Brake ASM |
| 21 | 104-3797 | 4 | Fitting-HYD, Straight |
| 21:1 | 237-146 | 1 | O-Ring |
| 21:2 | 340-65 | 1 | O-Ring |
| 22 | 100-5530 | 2 | Fitting-HYD, 45 DEG |
| 22:1 | 237-58 | 1 | O-Ring |
| 22:2 | 237-81 | 1 | O-Ring |




# Planetary Assembly No. 105-4500-03


| Ref | Part No. | Qty. | Description |
|---|---|---|---|
| ❷1 | | 1 | Spindle |
| 2 | 105-8122 | 1 | Seal-Boot |
| 4 | 105-8120 | 1 | Bearing-Cone |
| 5 | 105-8119 | 1 | Bearing-Cup |
| 6 | 105-8124 | 8 | Stud-Wheel |
| 7 | 105-8125 | 16 | Bolt-Head, Socket |
| 8 | 3253-18 | 16 | Washer-Lock |
| ❷9 | | 1 | Housing |
| 10 | 105-8121 | 1 | Pin-Dowel |
| 11 | 105-8117 | 1 | Bearing-Cup |
| 12 | 105-8118 | 1 | Bearing-Cone |
| 16 | 105-8113 | 1 | Gear-Ring |
| 17 | 105-8132 | 1 | Ring-Retaining |
| 18 | 353-990 | 2 | Plug |
| 18:1 | 237-78 | 1 | O-Ring |
| 19 | 105-8138 | 1 | Cap-End |
| 21 | 105-8133 | 1 | Plug-Thrust |
| 22 | 105-8123 | 1 | Washer-Thrust |
| 23 | 105-8131 | 1 | Ring-Retaining |
| 24 | 105-8114 | 1 | Gear-Primary |
| 25 | 105-8115 | 1 | Shaft-Drive |
| 26 | 105-8129 | 1 | Primary Carrier ASM |
| 27 | 105-8139 | 1 | Gear-Secondary |
| 28 | 105-8130 | 1 | Secondary Carrier ASM |

| Ref | Part No. | Qty. | Description |
|---|---|---|---|
| 29 | 105-8136 | 1 | Shim Kit |
| ❷29:1 | | 1 | Ring-Snap |
| ❷29:2 | | 1 | Shim-Bearing, 2.9Mm |
| ❷29:3 | | 1 | Shim-Bearing, 2.8Mm |
| ❷29:4 | | 1 | Shim-Bearing, 2.7Mm |
| ❷29:5 | | 1 | Shim-Bearing, 2.6Mm |
| ❷29:6 | | 1 | Shim-Bearing, 2.5Mm |
| ❷29:7 | | 1 | Shim-Bearing, 2.4Mm |
| ❶30 | 105-8137 | 1 | Seal Kit |
| ❷30:1 | | 1 | O-Ring, Flange Cap |
| ❷30:2 | | 1 | Seal-Oil |
| ❷30:3 | | 2 | O-Ring, End Cap |
| ❷30:4 | | 2 | O-Ring, Plug |





# LH Brake Assembly No. 100-3070

| Ref | Part No. | Qty. | Description |
|---|---|---|---|
| 2 | 93-7977 | 1 | Seal |
| 3 | 93-7978 | 1 | Rod-Pull |
| 4 | 93-7983 | 2 | Pin-Clevis |
| 5 | 93-7980 | 2 | Link |
| 6 | 93-7979 | 2 | Pin-Hitch |
| 7 | 93-7986 | 4 | Disc-Stationary |
| 8 | 104-4278 | 3 | Disc-Rotating |
| 9 | 93-7976 | 1 | Ring-Retaining |
| 10 | 93-7984 | 1 | Gasket |
| 11 | 104-4279 | 1 | Actuator-Rotating |
| 12 | 93-7987 | 3 | Spring-Extension |
| 13 | 93-7985 | 3 | Ball |
| 14 | 353-990 | 2 | Plug |
| 14:1 | 237-78 | 1 | O-Ring |





# Piston Motor Assembly No. 105-1218

| Ref | Part No. | Qty. | Description |
|---|---|---|---|
| 1 | 94-3004 | 1 | Shaft-Drive, Splined |
| 2 | 105-2851 | 1 | Backplate ASM |
| ❷2:1 | | 3 | Pin-Dowel |
| ❷2:2 | | 1 | Pin-Dowel |
| ❷2:3 | | 1 | Bearing-Needle |
| ❷3 | | 1 | Housing |
| 4 | 76-6910 | 1 | Rotating Kit |
| 5 | 76-6970 | 1 | Insert-Plate, Cam |
| 6 | 60-6260 | 1 | Ring |
| 7 | 94-3002 | 6 | Capscrew |
| 8 | 94-3007 | 1 | Washer |
| 9 | 105-3331 | 1 | Seal-Shaft |
| 10 | 76-7000 | 2 | Ring-Retaining |
| 11 | 60-6160 | 2 | Race |
| 12 | 76-6980 | 1 | O-Ring |
| 13 | 94-3003 | 1 | Plate-Valve |
| 14 | 60-6170 | 1 | Bearing-Thrust |
| 15 | 353-550 | 1 | Plug-HYD, HH |
| 15:1 | 237-79 | 1 | O-Ring |
| 16 | 63-4390 | 1 | Bearing-Needle |




# RH Brake Assembly No. 100-3069


| Ref | Part No. | Qty. | Description |
|---|---|---|---|
| 2 | 93-7977 | 1 | Seal |
| 3 | 93-7978 | 1 | Rod-Pull |
| 4 | 93-7983 | 2 | Pin-Clevis |
| 5 | 93-7980 | 2 | Link |
| 6 | 93-7979 | 2 | Pin-Hitch |
| 7 | 93-7986 | 4 | Disc-Stationary |
| 8 | 104-4278 | 3 | Disc-Rotating |
| 9 | 93-7976 | 1 | Ring-Retaining |
| 10 | 93-7984 | 1 | Gasket |
| 11 | 104-4280 | 1 | Actuator-Rotating |
| 12 | 93-7987 | 3 | Spring-Extension |
| 13 | 93-7985 | 3 | Ball |
| 14 | 353-990 | 2 | Plug |
| 14:1 | 237-78 | 1 | O-Ring |




# Manifold Mounting and Fitting Assembly

| Ref | Part No. | Qty. | Description |
|---|---|---|---|
| 1 | 33115-016 | 4 | Screw-HH |
| 2 | 104-5492-03 | 1 | Bracket-Mount, Filter |
| 3 | 3234-5 | 4 | Screw-HHF |
| 4 | 3234-17 | 4 | Screw-HHF |
| 5 | 104-5493-03 | 1 | Bracket-Mount, Valve |
| 6 | 32128-20 | 6 | Nut-HF |
| 7 | 340-148 | 2 | Fitting-Tee |
| 7:1 | 237-81 | 1 | O-Ring |
| 7:2 | 237-58 | 2 | O-Ring |
| 8 | 93-2242 | 1 | Oil Filter ASM |
| 8:1 | 75-1310 | 1 | Element-Filter |
| 9 | 104-5471-03 | 1 | Bracket-Valve, Filter |
| 10 | 3234-1 | 4 | Screw-HHF |
| 11 | 3234-14 | 4 | Screw-HHF |
| 12 | 322-48 | 2 | Screw-HH |
| 13 | 104-5467-03 | 1 | Bracket-Mount, Valve |
| 15 | 32128-33 | 2 | Nut-HF |
| 16 | 321-14 | 2 | Screw-HH |
| 17 | 104-5516-01 | 1 | Support-Tube |
| 18 | 3230-23 | 2 | Screw-CARR |
| 19 | 340-2 | 4 | Fitting-Straight, HYD |
| 19:1 | 237-22 | 1 | O-Ring |
| 19:2 | 237-42 | 1 | O-Ring |
| 20 | 353-990 | 1 | Plug |


| Ref | Part No. | Qty. | Description |
|---|---|---|---|
| 20:1 | 237-78 | 1 | O-Ring |
| 22 | 104-5515 | 1 | Manifold-Junction, Lift |
| 24 | 2412-150 | 3 | J-Clip |
| 25 | 105-9868 | 1 | Harness-Wire, Main |
| 26 | 3256-22 | 2 | Washer-Flat |
| 27 | 32144-11 | 1 | Screw-HWHTF |
| 28 | 3234-4 | 1 | Screw-HHF |




# Hydraulic Pump Assembly

| Ref | Part No. | Qty. | Description |
|---|---|---|---|
| 1 | 87-7270 | 2 | Washer-Thrust |
| 2 | 3213-2 | 2 | Screw-HH |
| 3 | 340-16 | 2 | Fitting-HYD, 90 |
| 3:1 | 237-80 | 1 | O-Ring |
| 3:2 | 237-58 | 1 | O-Ring |
| 4 | 340-166 | 1 | Fitting-Tee, HYD |
| 4:1 | 237-22 | 1 | O-Ring |
| 5 | 105-1226 | 1 | Pump ASM |
| 5:1 | 105-9845 | 1 | Triple Pump ASM |
| 5:2 | 105-9846 | 1 | Piston Pump ASM |
| 5:3 | 74-9030 | 1 | Coupler |
| 5:4 | 323-32 | 2 | Screw-HH |
| 5:5 | 60-3540 | 2 | Washer |
| 5:6 | 60-3520 | 2 | O-Ring |
| 5:7 | 99-5510 | 1 | Spacer |
| 6 | 354-77 | 2 | Fitting-Quick |
| 6:1 | 237-78 | 1 | O-Ring |
| 7 | 354-79 | 2 | Cap-Dust |
| 8 | 56-9530 | 1 | Fitting-HYD, 90 DEG |
| 8:1 | 237-117 | 1 | O-Ring |
| 9 | 2412-111 | 2 | Clamp |
| 10 | 92-7526 | 1 | Fitting-HYD, 90 DEG |
| 10:1 | 237-101 | 1 | O-Ring |
| 11 | 104-3797 | 2 | Fitting-HYD, Straight |


| Ref | Part No. | Qty. | Description |
|---|---|---|---|
| 11:1 | 237-146 | 1 | O-Ring |
| 11:2 | 340-65 | 1 | O-Ring |
| 12 | 340-109 | 1 | Fitting-HYD, Tee |
| 12:1 | 237-79 | 1 | O-Ring |
| 12:2 | 237-30 | 2 | O-Ring |
| 13 | 340-98 | 1 | Fitting-HYD, 90 DEG |
| 13:1 | 237-79 | 1 | O-Ring |
| 13:2 | 237-30 | 1 | O-Ring |
| 14 | 104-5482 | 1 | Hose-Suction |
| 15 | 104-5484 | 1 | Hose-Suction |
| 16 | 105-0122 | 1 | Harness-Wire |
| 17 | 105-3874 | 1 | Hose ASM |
| 18 | 105-3875 | 1 | Hose ASM |
| 19 | 92-7595 | 1 | Hose ASM |
| 20 | 105-3869 | 1 | Hose ASM |
| 22 | 340-141 | 1 | Fitting-HYD, Straight |
| 22:1 | 237-22 | 1 | O-Ring |
| 22:2 | 237-80 | 1 | O-Ring |




# Triple Pump Assembly No. 105-9845

| Ref | Part No. | Qty. | Description |
|---|---|---|---|
| ❷1 | | 1 | Front Plate ASM |
| ❷2 | | 1 | Back Plate ASM |
| ❷3 | | 1 | Body |
| ❷4 | | 1 | Body |
| ❷5 | | 1 | Drive Gear ASM |
| ❷6 | | 1 | Gear-Idler |
| ❷7 | | 1 | Gear-Idler |
| ❷8 | | 3 | Gasket-Backup |
| ❷9 | | 3 | Plate-Wear |
| ❷10 | | 3 | Seal-Pressure, Balance |
| 11 | 49-2640 | 1 | Seal-Shaft |
| 12 | 60-5890 | 1 | Washer |
| 13 | 105-9849 | 8 | Capscrew |
| 14 | 105-2866 | 6 | O-Ring |
| ❷15 | | 1 | Plate-Adaptor |
| ❷26 | | 1 | Key |
| ❷28 | | 1 | Body |
| ❷29 | | 1 | Gear-Idler |
| ❷44 | | 1 | Gear |
| ❷45 | | 1 | Key |
| ❷48 | | 1 | Plate-Adaptor |
| ❷49 | | 1 | Gear |
| 50 | 105-9850 | 4 | Washer-Copper |
| 53 | 94-3013 | 1 | Plug |


| Ref | Part No. | Qty. | Description |
|---|---|---|---|
| ❷53:1 | | 1 | Seal-Dust |
| 57 | 94-3011 | 1 | Plug |
| 58 | 105-2870 | 1 | Valve-Proportional |
| ❷65 | | 1 | Plate-Thrust |
| 99 | 105-2868 | 1 | Seal Kit |




# Piston Pump Assembly No. 105-9846


| Ref | Part No. | Qty. | Description |
|---|---|---|---|
| 2 | 3220-2 | 1 | Nut-Jam |
| 3 | 76-7010 | 1 | Ring-Retaining |
| 4 | 76-7000 | 2 | Ring-Retaining |
| 6 | 94-3027 | 1 | Washer-Seal |
| 7 | 3274-81 | 8 | Screw-HSH |
| 8 | 105-9851 | 1 | Rotating Kit |
| 9 | 105-4572 | 1 | Servo Piston ASM |
| 10 | 105-9852 | 1 | Follower-Piston |
| 11 | 105-9853 | 1 | Plate-Cover |
| ❷12 | | 2 | Gasket-Plate, Cover |
| ❷14 | | 1 | Gasket-Housing |
| ❷16 | | 1 | Gasket |
| 17 | 94-3034 | 1 | Plate-Cover |
| 18 | 94-3026 | 1 | Camplate ASM |
| 19 | 76-6950 | 2 | Race-Thrust |
| 20 | 76-6960 | 1 | Bearing-Thrust |
| 21 | 105-2857 | 1 | Valve-Relief |
| ❷21:1 | | 1 | Seal-Dust |
| 22 | 105-2857 | 1 | Valve-Relief |
| ❷22:1 | | 1 | Seal-Dust |
| 23 | 323-45 | 4 | Screw-HH |
| 26 | 3274-59 | 6 | Screw-HSH |
| 27 | 105-9854 | 1 | Plate-Valve |
| 28 | 105-9855 | 1 | Housing ASM |

| Ref | Part No. | Qty. | Description |
|---|---|---|---|
| 29 | 105-9856 | 1 | Backplate ASM |
| 31 | 105-2861 | 1 | Shaft-Drive |
| 34 | 3217-5 | 1 | Nut-Hex |
| 36 | 3253-3 | 1 | Washer-Lock |
| 37 | 94-3007 | 1 | Washer |
| 43 | 105-3331 | 1 | Seal-Shaft |
| 47 | 94-3031 | 1 | Arm-Control |
| 48 | 93-6306 | 1 | Control ASM |
| 51 | 105-2909 | 1 | Orifice-Control |
| 52 | 94-3041 | 1 | Orifice-Control |
| 57 | 105-2864 | 1 | Valve-Bypass |
| ❷57:1 | | 1 | Seal-Dust |
| 60 | 94-3030 | 1 | Washer |
| 61 | 3256-77 | 8 | Washer-Flat |
| 99 | 105-3349 | 1 | Seal Kit |




# Control Assembly No. 93-6306


| Ref | Part No. | Qty. | Description |
|---|---|---|---|
| ❷1 | | 1 | Plug |
| ❷3 | | 1 | Ring-Retaining |
| ❷4 | | 2 | Retainer-Spring |
| ❷5 | | 1 | Spring |
| ❷6 | | 1 | Valve-Spool |
| ❷7 | | 1 | Housing-Control |
| ❷8 | | 1 | Shaft-Input |
| ❷12 | | 1 | Adaptor |
| ❷13 | | 1 | Ball |
| ❷14 | | 1 | Pin |
| 15 | 94-3043 | 1 | Switch-Safety, Neutral |
| ❷17 | | 1 | Screw-Set |
| ❷18 | | 1 | Screw-Set |
| ❷19 | | 1 | Pin |
| ❷20 | | 1 | Ring-Retaining |
| ❷21 | | 1 | Link |
| ❷22 | | 1 | Pin-Dowel |
| ❷23 | | 1 | Crank-Bell |
| ❷24 | | 1 | Screw-Set |
| 25 | 94-3044 | 1 | Seal Kit |
| ❷25:1 | | 1 | Seal-Dust |
| ❷25:2 | | 1 | Seal-Dust |
| ❷25:3 | | 1 | Seal-Wiper |
| ❷25:4 | | 1 | Seal-Dust |
| ❷25:5 | | 1 | Seal-Dust |




# Radiator Assembly


| Ref | Part No. | Qty. | Description |
|---|---|---|---|
| 1 | 104-3796 | 2 | Fitting-HYD, 90 DEG |
| 1:1 | 237-81 | 1 | O-Ring |
| 1:2 | 340-65 | 1 | O-Ring |
| 2 | 99-5495 | 1 | Cooler-Oil |
| 3 | 32128-49 | 4 | Nut-HHF |
| 4 | 105-3994 | 1 | Bracket-Radiator |
| 4:2 | 93-7272 | 1 | Decal-Warning |
| 5 | 104-2223 | 1 | Seal-Bulb |
| 6 | 100-5550 | 1 | Hose-Cleaner, Air |
| 7 | 105-3934-03 | 1 | Bracket-Seal, Hood |
| 8 | 99-5426 | 1 | Radiator |
| 9 | 71-3370 | 2 | Hose |
| 10 | 92-2379 | 3 | Clamp-Hose |
| 11 | 93-5957 | 1 | Cap-Radiator |
| 12 | 99-5428 | 1 | Shroud-Radiator |
| 13 | 2412-111 | 4 | Clamp |
| 14 | 100-5547 | 2 | Hose-Radiator |
| 15 | 104-8300 | 19 | Nut-Flange, NI |
| 16 | 100-5505-03 | 1 | Bracket-Tank |
| 17 | 99-2900 | 4 | Washer-Flat |
| 18 | 3234-7 | 14 | Screw-HHF |
| 19 | 104-2276 | 1 | Reservior-Coolant |
| 19:1 | 87-7050 | 1 | Cap-Reservoir |
| 21 | 3234-11 | 4 | Screw-HHF |

| Ref | Part No. | Qty. | Description |
|---|---|---|---|
| 22 | 32128-43 | 4 | Nut-Flange |
| 24 | 104-5426-03 | 1 | Cover-Bottom |
| 25 | 3234-17 | 6 | Screw-HHF |
| 26 | 94-5780 | 2 | Screw-HWH |
| 27 | 93-6981 | 2 | Spacer |
| 30 | 104-5460-03 | 2 | Plate-Mount, Oil Cooler |
| 31 | 105-3943 | 16 | Clamp-Cooler, Oil |
| 32 | 3256-23 | 14 | Washer-Flat |
| 33 | 322-10 | 8 | Screw-HH |
| 34 | 104-5429 | 2 | Clamp-Form, Wire |
| 35 | 325-17 | 2 | Screw-HH |
| 36 | 41-8440 | 4 | Washer |
| 37 | 104-5428 | 1 | Bracket-Oil Cooler, Top |
| 38 | 93-7275 | 1 | Decal-Fluid, Starting |
| 39 | 105-9233 | 1 | Seal-Foam |
| 40 | 105-9236 | 2 | Seal-Foam |
| 41 | 105-9814 | 1 | Seal-Bulb |
| 42 | 105-9858 | 1 | Seal-Bulb |
| 43 | 105-2841 | 1 | Decal-Radiator |
| 44 | 2412-81 | 2 | Clamp-R |




# Fan and Solenoid Assembly


| Ref | Part No. | Qty. | Description |
|---|---|---|---|
| 1 | 322-2 | 8 | Screw-HH |
| 2 | 3253-4 | 8 | Washer-Lock |
| 3 | 105-0750 | 1 | Fan |
| 4 | 52-6290 | 4 | Screw-HSH |
| 5 | 100-3066 | 1 | Adapter-Fan |
| 6 | 98-9346 | 1 | Sender-Temperature |
| 7 | 104-2212 | 1 | Clutch-Fan |
| 8 | 2411-38 | 1 | Joint-Ball |
| 9 | 3256-51 | 1 | Washer-Flat |
| 10 | 3296-21 | 1 | Nut-Lock, NI |
| 11 | 104-7540-03 | 1 | Support-Cable |
| 12 | 98-3817 | 1 | Solenoid Kit |
| 12:7 | 33113-025 | 3 | Screw-HH |
| 12:8 | 33113-016 | 2 | Screw-HH |
| 12:9 | 48-8020 | 5 | Washer-Spring |
| 12:10 | 33013-00 | 2 | Nut-Hex |
| 12:11 | 33093-00 | 3 | Washer-Flat |
| 12:12 | 3272-2 | 1 | Pin-Cotter |




# Engine Installation Assembly


| Ref | Part No. | Qty. | Description |
|---|---|---|---|
| 1 | 99-5424 | 1 | Muffler-Turbo |
| 2 | 33104-025 | 4 | Screw-HHF |
| 3 | 33104-016 | 4 | Screw-HHF |
| 4 | 18-2130 | 1 | Clamp |
| 5 | 104-5461 | 1 | Pipe-Exhaust |
| 6 | 33004-00 | 4 | Nut-HF |
| 7 | 3296-29 | 4 | Nut-Lock, NI |
| 8 | 3256-3 | 8 | Washer-Flat |
| 9 | 322-8 | 4 | Screw-HH |
| 10 | 95-5622 | 1 | Hanger-Rubber |
| 11 | 93-5023 | 2 | Spacer |
| 12 | 100-3141-03 | 1 | RH Mount ASM |
| 13 | 323-13 | 4 | Screw-HH |
| 14 | 100-3148-03 | 1 | Mount-Engine, RH |
| 15 | 99-5413 | 1 | Engine-Turbo, Kubota |
| 16 | 3234-11 | 8 | Screw-HHF |
| 17 | 53-9682 | 4 | Support-Engine, Rubber |
| 18 | 104-8301 | 12 | Nut-Flange, NI |
| 19 | 63-7400 | 4 | Washer-Rebound |
| 20 | 100-3147-03 | 1 | Mount-Engine, LH |
| 21 | 43-5950 | 4 | Washer-Lock, Spring |
| 22 | 43-3210 | 4 | Screw-HH |
| 23 | 48-8070 | 5 | Washer-Lock |
| 24 | 42-9250 | 5 | Bolt |

| Ref | Part No. | Qty. | Description |
|---|---|---|---|
| 25 | 99-5414 | 1 | Strap-Cleaner, Air |
| 26 | 322-6 | 2 | Screw-HH |
| 27 | 104-3563 | 1 | Indicator |
| ❶27:1 | 94-1416 | 1 | Indicator Adapter ASM |
| 28 | 99-5410 | 1 | Cleaner-Air |
| 29 | 2412-125 | 1 | Clamp-Hose |
| 30 | 2412-110 | 2 | Clamp-Hose |
| 31 | 100-3144-03 | 1 | LH Mount ASM |
| 32 | 99-5421-03 | 1 | Bracket-Mounting |
| 33 | 2412-92 | 1 | Clamp-Hose |
| 34 | 99-5415 | 1 | Hose-Cleaner, Air |
| 35 | 99-3441 | 1 | Harness-Wire, Fusible Link |
| 36 | 105-9869 | 1 | Harness-Wire, Engine |
| 37 | 2412-108 | 2 | Clamp-Worm |
| 38 | 99-7376 | 1 | Hose-Breather |
| 39 | 354-94 | 1 | Fitting-Female, Barbed |
| 40 | 93-5528 | 1 | Fitting-Cock, Drain |
| 41 | 100-9333 | 1 | Gasket-Muffler |
| 42 | 2412-150 | 1 | J-Clip |
| 44 | 32144-11 | 1 | Screw-HWHTF |
| 45 | 43-0090 | 1 | Screw-HH |
| 46 | 48-9590 | 1 | Washer-Lock |




# Air Cleaner Assembly No. 99-5410


| Ref | Part No. | Qty. | Description |
|---|---|---|---|
| 1 | 104-4258 | 1 | Valve-Vacuator |
| ❷2 | | 1 | Plug-Pipe |
| 3 | 104-4259 | 1 | Cover ASM |
| ❷4 | | 1 | Marking |
| ❷5 | | 1 | Body ASM |
| 6 | 104-4260 | 1 | Element ASM |
| 7 | 104-4261 | 1 | Element ASM |




# Rear Axle Assembly

| Ref | Part No. | Qty. | Description |
|---|---|---|---|
| 1 | 105-9861 | 1 | Steering Cylinder ASM |
| 1:1 | 92-5838 | 1 | Joint-Ball |
| 1:2 | 100-3795 | 1 | Joint-Ball |
| 1:3 | 32151-104 | 2 | Ring-Retaining, External |
| 1:4 | 302-5 | 1 | Fitting-Grease |
| 1:5 | 302-60 | 1 | Fitting-Grease, 90 DEG |
| ❷1:6 | | 1 | Hydraulic Cylinder ASM |
| 3 | 340-97 | 2 | Fitting-HYD, 90 DEG |
| 3:1 | 237-22 | 1 | O-Ring |
| 3:2 | 237-78 | 1 | O-Ring |
| 4 | 74-5700 | 1 | Bearing-Needle, Roller |
| 5 | 32120-15 | 2 | Ring-Snap, EXT |
| 6 | 32120-76 | 2 | Ring-Snap, EXT |
| 7 | 340-9 | 1 | Fitting-HYD, Straight |
| 7:1 | 237-58 | 1 | O-Ring |
| 7:2 | 237-81 | 1 | O-Ring |
| 8 | 340-142 | 1 | Fitting-HYD, 90 DEG |
| 8:1 | 237-58 | 1 | O-Ring |
| 8:2 | 237-81 | 1 | O-Ring |
| 9 | 325-7 | 2 | Screw-HH |
| 10 | 3256-26 | 2 | Washer-Flat |
| 11 | 105-1219 | 1 | Motor-Piston |
| 12 | 237-166 | 1 | O-Ring |
| 13 | 104-5663 | 1 | Pinion-28T |


| Ref | Part No. | Qty. | Description |
|---|---|---|---|
| 14 | 104-5664 | 1 | Gear-44T |
| 15 | 340-2 | 1 | Fitting-Straight, HYD |
| 15:1 | 237-22 | 1 | O-Ring |
| 15:2 | 237-42 | 1 | O-Ring |
| 17 | 93-5268 | 10 | Nut-Lug |
| ❷18 | | 2 | Tire And Wheel ASM |
| 18:1 | 232-27 | 1 | Stem-Valve |
| 18:2 | 104-0451 | 1 | Tire |
| 18:3 | 105-9219 | 1 | Wheel |
| 20 | 3272-12 | 2 | Pin-Cotter |
| 21 | 32136-14 | 2 | Nut-SHH |
| 22 | 92-5836 | 1 | Washer |
| 23 | 100-3784 | 1 | Drive Axle ASM |
| 24 | 100-3796 | 1 | Spacer-Joint, Ball |
| 25 | 353-989 | 1 | Plug-Hex, Hollow |
| 25:1 | 237-42 | 1 | O-Ring |
| 26 | 100-3771 | 1 | Pin-Stop |
| 27 | 100-3770 | 1 | Pin-Axle, Pivot |
| 28 | 92-1765 | 1 | Washer-Thrust |
| 29 | 98-3867 | 2 | Washer-Thrust |
| 30 | 3296-68 | 1 | Nut-Lock, NI |
| 31 | 302-33 | 1 | Fitting-Grease |
| 32 | 3253-4 | 6 | Washer-Lock |
| 33 | 33114-025 | 6 | Screw-HH |




**Parts not listed in part list are not serviced separately**


# Cylinder Assembly No. 105-9861

| Ref | Part No. | Qty. | Description |
|---|---|---|---|
| 1 | 92-6593 | 1 | Seal Kit |
| ❷1:1 | | 1 | Seal ASM |
| ❷1:2 | | 1 | Seal-Dust |
| ❷1:3 | | 1 | Seal-Dust |
| ❷1:4 | | 1 | Seal-Dust |
| ❷1:5 | | 1 | U-Cup |
| ❷1:6 | | 1 | Wiper |
| ❷2 | | 1 | Locknut |
| ❷3 | | 1 | Piston |
| ❷4 | | 1 | Gland |
| ❷5 | | 1 | Rod ASM |





# Piston Motor Assembly No. 105-1219

| Ref | Part No. | Qty. | Description |
|---|---|---|---|
| 1 | 105-2853 | 1 | Shaft-Drive |
| 2 | 100-2551 | 1 | Backplate |
| ❷2:1 | | 3 | Pin-Dowel |
| ❷2:2 | | 1 | Pin-Dowel |
| ❷2:3 | | 1 | Bearing-Needle |
| ❷3 | | 1 | Housing |
| 4 | 76-6910 | 1 | Rotating Kit |
| 5 | 76-6970 | 1 | Insert-Plate, Cam |
| 6 | 60-6260 | 1 | Ring |
| 7 | 94-3002 | 6 | Capscrew |
| 8 | 63-4390 | 1 | Bearing-Needle |
| 10 | 76-7020 | 1 | Spacer |
| 11 | 76-7000 | 2 | Ring-Retaining |
| 12 | 94-3003 | 1 | Plate-Valve |
| 13 | 60-6160 | 2 | Race |
| 14 | 76-6980 | 1 | O-Ring |
| 16 | 60-6170 | 1 | Bearing-Thrust |





# Bevel Pinion Shaft Assembly
# Rear Axle Assembly No. 100-3784

| Ref | Part No. | Qty. | Description |
|---|---|---|---|
| 1 | 100-2555 | 1 | Ring And Pinion Matched Set |
| 2 | 99-7570 | 2 | Bearing-Roller, Taper |
| 3 | 95-7534 | 1 | Case-Bearing |
| 4 | 99-7571 | 2 | O-Ring |
| 5 | 99-7572 | 1 | Collar-Seal, Oil |
| 6 | 99-7573 | 1 | O-Ring |
| 7 | 99-7574 | 1 | Seal-Oil |
| 8 | 99-7559 | 1 | Washer-Lock |
| 9 | 99-7560 | 1 | Nut-Lock |
| 10 | 99-7550 | 2 | Shim 0.1 |
| 10 | 99-7551 | 2 | Shim 0.2 |
| 11 | 95-7533 | 1 | Case-Gear |
| 12 | 99-7575 | 2 | Bolt |
| 13 | 100-2556 | 2 | Stud |
| 14 | 99-7527 | 2 | Washer-Spring |
| 15 | 99-7526 | 2 | Nut |
| 16 | 95-7541 | 1 | Plate-Cover |
| 17 | 95-7540 | 1 | Gasket |
| 18 | 104-2353 | 2 | Pin-Dowel |





# Differential Assembly
# Rear Axle Assembly No. 100-3784

| Ref | Part No. | Qty. | Description |
|---|---|---|---|
| 1 | 95-7503 | 1 | Differential ASM |
| 2 | 100-2555 | 1 | Ring And Pinion Matched Set |
| 3 | 95-7502 | 1 | Case-Differential |
| 4 | 99-7576 | 8 | Bolt |
| 5 | 99-7577 | 8 | Washer-Spring |
| 6 | 99-7578 | 1 | Shaft-Differential |
| 7 | 99-7579 | 2 | Pinion-Differential |
| 8 | 99-7580 | 2 | Washer-Differential |
| 9 | 99-7581 | 2 | Gear-Differential |
| 10 | 99-7582 | 2 | Washer-Differential |
| 10 | 99-7583 | 2 | Washer-Differential |
| 10 | 99-7584 | 2 | Washer-Differential |
| 11 | 99-7588 | 1 | Pin-Spring |
| 12 | 99-7562 | 2 | Bearing-Ball |
| 13 | 99-7585 | 2 | Shim 0.1 |
| 13 | 99-7586 | 2 | Shim 0.2 |
| 13 | 99-7587 | 2 | Shim 0.4 |




# Axle Support Assembly
# Rear Axle Assembly No. 100-3784


| Ref | Part No. | Qty. | Description |
|---|---|---|---|
| 1 | 95-7508 | 1 | Support-Axle |
| 2 | 95-7506 | 1 | Support-Axle |
| 3 | 95-7507 | 1 | O-Ring |
| 4 | 95-7537 | 2 | Bushing-Flanged |
| 5 | 99-7590 | 2 | Washer-Seal |
| 6 | 99-7589 | 2 | Plug |
| 7 | 99-7591 | 1 | Oil Plug ASM |
| 8 | 99-7592 | 8 | Bolt |
| 9 | 99-7593 | 2 | O-Ring |
| 10 | 104-2377 | 1 | Extension-Vent |
| 11 | 104-8643 | 1 | Plug |
| 12 | 104-8644 | 1 | O-Ring |




# Bevel Gear Case Assembly
# Rear Axle Assembly No. 100-3784


| Ref | Part No. | Qty. | Description |
|---|---|---|---|
| 1 | 95-7538 | 2 | Case-Gear, Bevel |
| 2 | 100-2557 | 2 | Seal-Oil |
| 3 | 104-2378 | 2 | Bushing |
| 5 | 104-2376 | 2 | Knuckle ASM |
| 5:1 | 104-2373 | 1 | Knuckle |
| 5:2 | 104-2372 | 1 | O-Ring |
| 6 | 104-2374 | 8 | Bolt |
| 7 | 100-3768 | 1 | LH Steering Arm ASM |
| 7:1 | 302-5 | 2 | Fitting-Grease |
| 7:2 | 104-8634 | 1 | Bushing |
| 8 | 100-3766 | 1 | RH Steering Arm ASM |
| 8:2 | 302-5 | 2 | Fitting-Grease |
| 8:3 | 104-8634 | 1 | Bushing |
| 10 | 95-7547 | 2 | Shim 0.1 |
| 10 | 95-7548 | 2 | Shim 0.2 |
| 10 | 95-7549 | 2 | Shim 0.4 |
| 11 | 99-7597 | 4 | Pin-Dowel |
| 12 | 104-2375 | 4 | Bolt |
| 13 | 99-7599 | 8 | Bolt |
| 14 | 99-7525 | 4 | Stud |
| 15 | 99-7526 | 4 | Nut |
| 16 | 99-7527 | 4 | Washer-Spring |
| 18 | 100-3762 | 1 | Tie Rod ASM |
| ❶18:1 | 100-3851 | 1 | LH Tie Rod End ASM |

| Ref | Part No. | Qty. | Description |
|---|---|---|---|
| ❶18:1:1 | 100-3853 | 1 | Cover-Dust |
| ❶18:1:2 | 100-3854 | 1 | Nut-Castle |
| ❶18:1:3 | 302-5 | 1 | Fitting-Grease |
| ❶18:1:4 | 3272-11 | 1 | Pin-Cotter |
| 18:2 | 100-3852 | 1 | RH Tie Rod End ASM |
| 18:2:1 | 100-3853 | 1 | Cover-Dust |
| 18:2:2 | 100-3854 | 1 | Nut-Castle |
| 18:2:3 | 302-5 | 1 | Fitting-Grease |
| 18:2:4 | 3272-11 | 1 | Pin-Cotter |
| 18:3 | 100-3855 | 2 | Bolt |
| 18:4 | 99-7527 | 2 | Washer-Spring |
| 18:5 | 99-7526 | 2 | Nut |





# Bevel Gear Shaft Assembly
# Rear Axle Assembly No. 100-3784

| Ref | Part No. | Qty. | Description |
|---|---|---|---|
| 1 | 95-7509 | 1 | Shaft-Gear, Differential |
| 2 | 95-7512 | 1 | Shaft-Gear, Differential |
| 3 | 95-7517 | 2 | Gear-Bevel, 15 Tooth |
| 4 | 99-7530 | 4 | Bearing-Ball |
| 5 | 99-7552 | 2 | Shim 0.1 |
| 5 | 99-7553 | 2 | Shim 0.2 |
| 5 | 99-7554 | 2 | Shim 0.5 |
| 6 | 99-7531 | 2 | Clip |
| 7 | 95-7529 | 2 | Shaft-Gear, Bevel |
| 8 | 95-7519 | 2 | Gear-Bevel, 17 Tooth |
| 9 | 99-7532 | 2 | Bearing-Roller, Taper |
| 10 | 99-7558 | 2 | Collar |





# Axle Case Assembly
# Rear Axle Assembly No. 100-3784

| Ref | Part No. | Qty. | Description |
|---|---|---|---|
| 1 | 95-7531 | 2 | Case-Axle |
| 2 | 99-7535 | 2 | Plug |
| 3 | 99-7536 | 2 | Washer-Seal |
| 4 | 95-7527 | 2 | Gear-Bevel, 17 Tooth |
| 5 | 99-7532 | 2 | Bearing-Roller, Taper |
| 6 | 100-2560 | 2 | Cover |
| 7 | 100-2561 | 2 | O-Ring |
| 8 | 99-7589 | 2 | Plug |
| 9 | 99-7590 | 2 | Washer-Seal |
| 10 | 100-2562 | 8 | Bolt |





# Axle Assembly
# Rear Axle Assembly No. 100-3784

| Ref | Part No. | Qty. | Description |
|---|---|---|---|
| 1 | 95-7522 | 2 | Axle |
| 2 | 99-7564 | 2 | Seal-Oil |
| 3 | 95-7544 | 4 | Clip |
| 4 | 95-7523 | 2 | Spacer |
| 5 | 99-7555 | 2 | Shim 0.3 |
| 5 | 99-7556 | 2 | Shim 0.2 |
| 5 | 99-7557 | 2 | Shim 0.5 |
| 6 | 95-7524 | 2 | Gear-Bevel, 29 Tooth |
| 7 | 99-7534 | 2 | Bearing-Ball |
| 8 | 95-7521 | 2 | Cover-Axle |
| 9 | 99-7538 | 2 | O-Ring |
| 10 | 99-7561 | 2 | Bearing-Ball |
| 11 | 99-7539 | 2 | Clip |
| 12 | 99-7596 | 12 | Bolt |
| 13 | 99-7563 | 10 | Stud |




# Coupler Spacer and Adapter Plate Assembly


| Ref | Part No. | Qty. | Description |
|---|---|---|---|
| 1 | 42-9250 | 1 | Bolt |
| 2 | 3255-2 | 1 | Washer-Lock / EXT |
| 4 | 42-9850 | 6 | Washer-Lock, Spring |
| 5 | 3255-9 | 1 | Washer-Lock, EXT |
| 6 | 33114-020 | 4 | Screw-HH |
| 7 | 100-5632-03 | 1 | Plate-Adapter |
| 8 | 100-5635 | 2 | Pin-Plate |
| 9 | 58-3590 | 2 | Dowel |
| 10 | 100-5633 | 1 | Spacer-Coupling |
| 11 | 100-5634 | 2 | Bolt-Shoulder |
| 12 | 92-1753 | 1 | Coupling-Spring |
| 13 | 48-9590 | 14 | Washer-Lock |
| 14 | 70-8470 | 6 | Screw-HH |
| 15 | 43-0090 | 8 | Screw-HH |




# Battery Installation Assembly


| Ref | Part No. | Qty. | Description |
|---|---|---|---|
| 1 | 93-7968 | 1 | Pad-Foam |
| 2 | 105-3880 | 1 | Cable-Battery, Negative |
| 3 | 105-0114 | 1 | Cable-Battery, Positive |
| 4 | 93-3220 | 1 | Battery |
| 5 | 93-7595 | 1 | Battery Box ASM |
| 6 | 104-5422-03 | 1 | Bracket-Support, Battery |
| 7 | 66-8800 | 1 | Relay |
| 8 | 321-6 | 4 | Screw-HH |
| 9 | 32128-43 | 6 | Nut-Flange |
| 13 | 3234-29 | 8 | Screw-HHF |
| 14 | 3296-42 | 4 | Nut-Lock, NI |
| 16 | 323-11 | 3 | Screw-HH |
| 17 | 104-5423-03 | 1 | Tray-Battery |
| 18 | 3234-11 | 2 | Screw-HHF |
| 19 | 32128-20 | 14 | Nut-HF |
| 20 | 104-5420-03 | 1 | Battery Support ASM |
| 21 | 104-5417-03 | 1 | Bracket-Conditioner, Air |
| 22 | 98-9305 | 1 | Water / Fuel Filter ASM |
| 23 | 281-13 | 2 | Plug-Pipe |
| 24 | 353-781 | 2 | Fitting-Elbow |
| 33 | 63-7627 | 1 | Hose-Fuel |
| 34 | 92-2379 | 3 | Clamp-Hose |
| 35 | 2412-81 | 2 | Clamp-R |
| 36 | 93-6668 | 1 | Decal-Battery |

| Ref | Part No. | Qty. | Description |
|---|---|---|---|
| 37 | 93-7276 | 1 | Decal-Danger |
| 38 | 94-1445 | 1 | Strap-Battery |
| 39 | 3256-22 | 2 | Washer-Flat |
| 41 | 323-12 | 1 | Screw-HH |




# Water and Fuel Filter Assembly No. 98-9305


| Ref | Part No. | Qty. | Description |
|---|---|---|---|
| 1 | 98-9772 | 1 | Head-Filter |
| 2 | 98-9764 | 1 | Element |
| 3 | 98-9774 | 1 | O-Ring-Base, Filter |
| 4 | 98-9775 | 1 | Base-Filter |
| 5 | 98-9773 | 1 | Plug-Base, Filter |
| 6 | 237-42 | 1 | O-Ring |
| 7 | 237-78 | 1 | O-Ring |
| 8 | 98-9776 | 1 | Plug-Head, Filter |
| 9 | 98-9777 | 1 | Drain Valve ASM |
| 10 | 285-22 | 2 | Plug-Pipe |




# Front Lift Arm Assembly


| Ref | Part No. | Qty. | Description |
|---|---|---|---|
| 1 | 3296-51 | 4 | Nut-Lock, NI |
| 2 | 104-8300 | 6 | Nut-Flange, NI |
| 3 | 105-9201 | 1 | No. 1 Lift Arm ASM |
| 3:2 | 302-60 | 1 | Fitting-Grease, 90 DEG |
| 3:3 | 104-0015 | 2 | Bushing-Flange |
| 4 | 104-5525 | 3 | Cylinder Pin ASM |
| 5 | 3234-5 | 6 | Screw-HHF |
| 6 | 340-77 | 6 | Fitting-HYD, 90 DEG |
| 6:1 | 237-22 | 1 | O-Ring |
| 6:2 | 237-42 | 1 | O-Ring |
| 7 | 328-7 | 4 | Screw-HH |
| 8 | 104-5527 | 2 | Cylinder-Lift, No. 4 And 5 |
| 9 | 104-5528 | 1 | Cylinder-Lift, No. 1 |
| 10 | 76-2980 | 3 | Washer-Thrust |
| 11 | 3296-49 | 3 | Nut-Lock, NI |
| 12 | 95-7158 | 3 | Pin-Pivot |
| 13 | 32121-110 | 3 | Pin-Roll, Slotted |
| 14 | 83-6780 | 3 | Pin-Cylinder |
| 15 | 104-8301 | 6 | Nut-Flange, NI |
| 16 | 32144-14 | 8 | Screw-HWH |
| 17 | 105-3987-03 | 2 | Plate-Skid |
| 18 | 105-9204 | 1 | No. 4 Lift Arm ASM |
| 18 | 105-9205 | 1 | No. 5 Lift Arm ASM |
| 18:2 | 302-5 | 1 | Fitting-Grease |

| Ref | Part No. | Qty. | Description |
|---|---|---|---|
| 18:3 | 104-0015 | 2 | Bushing-Flange |
| 19 | 323-6 | 5 | Screw-HH |
| 20 | 95-8979 | 3 | Shaft |
| 21 | 283-71 | 3 | Pin-Lynch |
| 22 | 3-6781 | 3 | Washer-Thrust |
| 23 | 104-1450 | 2 | Bolt-CARR |
| 24 | 104-5585 | 2 | Bracket-Switch |
| 25 | 100-1270 | 2 | Switch-Proximity |
| 26 | 100-4872 | 2 | Plate-Switch, Neutral |
| 27 | 32149-7 | 2 | Nut-Keps |
| 28 | 104-5689-03 | 1 | Bracket-Support, Bumper |
| 29 | 87-3470 | 2 | Bumper-Axle, Rear |
| 31 | 33025-00 | 2 | Nut-Lock |
| 32 | 105-9831-01 | 2 | Bracket-Bumper, No. 1 |
| 33 | 104-5680-03 | 1 | Front Carrier Frame ASM |
| 35 | 104-5656 | 5 | Carrier Frame ASM |
| 35:2 | 95-8795 | 2 | Bushing |
| 35:3 | 302-5 | 1 | Fitting-Grease |
| 36 | 106-2653-01 | 4 | Foot Guard ASM |
| 37 | 3234-18 | 10 | Screw-HHF |
| 38 | 93-8806 | 10 | Washer-Hardened |
| 39 | 105-9823 | 10 | Bushing-Carrier |
| 40 | 105-9822 | 10 | Spacer |
| 41 | 32128-43 | 10 | Nut-Flange |





# Front Lift Arm Assembly (continued)

| Ref | Part No. | Qty. | Description |
|---|---|---|---|
| ❶99 | 3334-945 | 2 | Tie-Cable |





# No. 4 and 5 Lift Cylinder Assembly No. 104-5527

| Ref | Part No. | Qty. | Description |
|---|---|---|---|
| 1 | 32152-10 | 1 | Locknut |
| 2 | 104-5847 | 1 | Seal Kit |
| ❷2:1 | | 2 | Seal-Dust |
| ❷2:2 | | 1 | Seal-Dust |
| ❷2:3 | | 2 | O-Ring, Backup |
| ❷2:4 | | 1 | T-Seal |
| ❷2:5 | | 2 | Seal-Rod |
| ❷2:6 | | 2 | Seal-Dust |





# No. 1 Lift Cylinder Assembly No. 104-5528

| Ref | Part No. | Qty. | Description |
|---|---|---|---|
| 1 | 32152-10 | 1 | Locknut |
| 2 | 104-5847 | 1 | Seal Kit |
| ❷2:1 | | 2 | Seal-Dust |
| ❷2:2 | | 1 | Seal-Dust |
| ❷2:3 | | 2 | O-Ring, Backup |
| ❷2:4 | | 1 | T-Seal |
| ❷2:5 | | 2 | Seal-Rod |
| ❷2:6 | | 2 | Seal-Dust |




# Lift Lever Assembly


| Ref | Part No. | Qty. | Description |
|---|---|---|---|
| 1 | 104-8300 | 4 | Nut-Flange, NI |
| 2 | 104-5530-03 | 1 | Plate-Switch |
| 3 | 3234-4 | 1 | Screw-HHF |
| 4 | 105-0023 | 1 | Switch-Proximity |
| 5 | 32144-19 | 2 | Screw-SHWH |
| 6 | 3272-1 | 2 | Pin-Cotter |
| 7 | 233-39 | 1 | Knob-Control |
| 9 | 104-5616 | 1 | Center Lever ASM |
| 12 | 69-9140 | 1 | Link-Lever, Valve |
| 13 | 65-9980 | 1 | Spacer |
| 14 | 104-5606-03 | 1 | Valve Support ASM |
| 15 | 323-39 | 1 | Screw-HH |
| 16 | 105-3938 | 1 | Spring-Extension |
| 17 | 61-2780-03 | 2 | Spacer-Tube |
| 19 | 3296-39 | 1 | Nut-Lock, NI |
| 20 | 32148-6 | 1 | Insert-Nut |




# No. 2 and 3 Lift Arm Assembly


| Ref | Part No. | Qty. | Description |
|---|---|---|---|
| 1 | 32128-20 | 2 | Nut-HF |
| 2 | 105-3992-03 | 1 | Bracket-Bulkhead |
| 3 | 340-166 | 2 | Fitting-Tee, HYD |
| 3:1 | 237-22 | 1 | O-Ring |
| 4 | 3234-17 | 2 | Screw-HHF |
| 5 | 33025-00 | 2 | Nut-Lock |
| 6 | 32121-110 | 2 | Pin-Roll, Slotted |
| 7 | 95-7158 | 2 | Pin-Pivot |
| 8 | 87-3470 | 2 | Bumper-Axle, Rear |
| 9 | 3-6781 | 2 | Washer-Thrust |
| 10 | 63-7400 | 2 | Washer-Rebound |
| 11 | 105-9827 | 2 | Shaft |
| 12 | 105-9202 | 1 | No. 2 Lift Arm ASM |
| 12:2 | 302-60 | 1 | Fitting-Grease, 90 DEG |
| 12:3 | 104-0015 | 2 | Bushing-Flange |
| 13 | 105-9203 | 1 | No. 3 Lift Arm ASM |
| 13:2 | 302-60 | 1 | Fitting-Grease, 90 DEG |
| 13:3 | 104-0015 | 2 | Bushing-Flange |
| 14 | 104-8300 | 2 | Nut-Flange, NI |
| 15 | 32151-36 | 4 | Ring-Retaining |
| 16 | 104-5526 | 2 | Cylinder-Lift, No. 2 And 3 |
| 17 | 302-11 | 2 | Fitting-Lube, 45 DEG |
| 18 | 3296-49 | 2 | Nut-Lock, NI |
| 19 | 340-2 | 2 | Fitting-Straight, HYD |

| Ref | Part No. | Qty. | Description |
|---|---|---|---|
| 19:1 | 237-22 | 1 | O-Ring |
| 19:2 | 237-42 | 1 | O-Ring |
| 20 | 92-7548 | 2 | Pin-Cylinder |
| 21 | 76-2980 | 2 | Washer-Thrust |
| 22 | 3234-17 | 2 | Screw-HHF |
| 23 | 104-5525 | 2 | Cylinder Pin ASM |
| 24 | 323-6 | 2 | Screw-HH |
| 25 | 340-77 | 2 | Fitting-HYD, 90 DEG |
| 25:1 | 237-22 | 1 | O-Ring |
| 25:2 | 237-42 | 1 | O-Ring |
| 26 | 323-4 | 2 | Screw-HH |
| 27 | 105-9839 | 2 | Stop-Rotation, No. 2 And 3 |
| 28 | 3245-7 | 4 | Screw-Set |





# Hose Installation Assembly

| Ref | Part No. | Qty. | Description |
|---|---|---|---|
| 3 | 104-5502 | 2 | Hose ASM |
| 5 | 104-5505 | 4 | Hose ASM |





# No. 1, 4 and 5 Hose Installation Assembly

| Ref | Part No. | Qty. | Description |
|---|---|---|---|
| 1 | 104-5500 | 2 | Hose ASM |
| 2 | 104-5501 | 4 | Hose ASM |
| 3 | 104-5502 | 1 | Hose ASM |
| 4 | 104-5504 | 1 | Hose ASM |
| 5 | 104-5505 | 1 | Hose ASM |
| 6 | 104-5511 | 2 | Hose ASM |
| 6:1 | 237-42 | 1 | O-Ring |
| 7 | 104-5512 | 2 | Hose ASM |
| 7:1 | 237-42 | 1 | O-Ring |
| 8 | 104-5513 | 2 | Hose ASM |
| 8:1 | 237-42 | 1 | O-Ring |
| 9 | 105-9820 | 5 | Motor-HYD |
| 10 | 3256-24 | 10 | Washer-Flat |
| 11 | 3274-7 | 10 | Screw-HSH |
| 12 | 340-17 | 10 | Fitting-HYD, 90 DEG |
| 12:1 | 237-65 | 1 | O-Ring |
| 12:2 | 237-80 | 1 | O-Ring |
| 13 | 340-92 | 5 | Fitting-HYD, Straight |
| 13:1 | 237-78 | 1 | O-Ring |
| 13:2 | 237-21 | 1 | O-Ring |





# Hydraulic Motor Assembly No. 105-9820

| Ref | Part No. | Qty. | Description |
|---|---|---|---|
| ❷1 | | 1 | Flange |
| 2 | 105-9191 | 1 | Seal Kit |
| ❷2:1 | | 1 | Ring-Retaining |
| ❷2:2 | | 1 | Seal-Shaft |
| ❷2:3 | | 2 | Seal ASM |
| ❷2:4 | | 2 | Seal-Dust |
| ❷2:5 | | 1 | Seal-Shaft |
| ❷2:6 | | 2 | Seal-Dust |
| 3 | 105-9192 | 2 | Relief Valve Kit |
| ❷3:1 | | 1 | Cap-Valve, Relief |
| ❷3:2 | | 1 | Seal-Dust |
| ❷3:3 | | 1 | Spring |
| ❷3:4 | | 1 | Poppet |
| ❷3:5 | | 1 | Seat-Valve, Relief |
| ❷4 | | 2 | Block-Bushing |
| ❷5 | | 4 | Pin-Dowel |
| ❷6 | | 1 | Housing |
| ❷7 | | 1 | Gear-Drive |
| ❷8 | | 1 | Gear-Idler |
| ❷9 | | 1 | Block-Valve |
| ❷10 | | 4 | Bolt |





# Roll-Over Protection System and Frame Assembly

| Ref | Part No. | Qty. | Description |
|---|---|---|---|
| 1 | 104-5579-03 | 1 | ROPS ASM |
| 2 | 3234-38 | 10 | Screw-HHF |
| 3 | 104-5410-03 | 1 | Frame-Rear |
| 4 | 104-5584-03 | 2 | Plate-Reinforcement, ROPS |
| 5 | 32128-49 | 4 | Nut-HHF |
| 6 | 325-20 | 4 | Screw-HH |
| 7 | 93-6680 | 1 | Decal-Diesel |
| 8 | 93-6686 | 1 | Decal-Oil, HYD |
| 9 | 105-9194 | 4 | Plug |
| 10 | 104-5469 | 1 | Front Frame ASM |
| 11 | 72-3560 | 2 | Decal |
| 12 | 100-6574 | 1 | Decal-Warning |





# Front Frame Assembly No. 104-5469

| Ref | Part No. | Qty. | Description |
|---|---|---|---|
| 2 | 93-7592 | 2 | Tread-Rest, Foot |
| 3 | 75-0620 | 1 | Tread-Foot, LH |
| 4 | 104-5223 | 1 | Tread-Foot, RH |
| 6 | 93-6699 | 1 | Decal-Fast / Slow |
| 7 | 105-7506 | 1 | Decal-Switch, Key |
| 10 | 105-9859 | 6 | Seal-Foam |
| 11 | 105-9860 | 2 | Seal-Foam |




# Roller Support and Access Panel Assembly


| Ref | Part No. | Qty. | Description |
|---|---|---|---|
| 1 | 3234-7 | 7 | Screw-HHF |
| 2 | 75-0630 | 1 | Tread-Foot, Center |
| 3 | 75-1410-01 | 1 | Plate-Access, Floor |
| 4 | 105-9243-01 | 1 | Plate-Access |
| 5 | 3296-23 | 4 | Nut-Lock, NI |
| 6 | 105-3996-01 | 2 | Roller Support ASM |
| 7 | 105-9816 | 2 | Roller-Plastic |
| 8 | 105-3970 | 2 | Spring-Compression |
| 9 | 3256-26 | 2 | Washer-Flat |
| 10 | 3234-38 | 3 | Screw-HHF |
| 11 | 104-5539-01 | 1 | Roller Support ASM |
| 12 | 325-22 | 2 | Screw-HH |
| 14 | 3272-11 | 4 | Pin-Cotter |
| 15 | 104-5545 | 2 | Shaft-Roller |
| 16 | 33025-00 | 1 | Nut-Lock |
| 17 | 87-3470 | 1 | Bumper-Axle, Rear |
| 18 | 105-9222 | 1 | Decal-Warning, Ce |
| 18 | 105-3889 | 1 | Decal-Danger |
| 19 | 325-20 | 2 | Screw-HH |




# Manifold Assembly


| Ref | Part No. | Qty. | Description |
|---|---|---|---|
| 1 | 104-5475 | 2 | Manifold ASM |
| 2 | 340-8 | 4 | Adapter |
| 2:1 | 237-65 | 1 | O-Ring |
| 2:2 | 237-81 | 1 | O-Ring |
| 3 | 340-142 | 1 | Fitting-HYD, 90 DEG |
| 3:1 | 237-58 | 1 | O-Ring |
| 3:2 | 237-81 | 1 | O-Ring |
| 4 | 340-139 | 2 | Fitting-HYD, 90 DEG |
| 4:1 | 237-81 | 1 | O-Ring |
| 4:2 | 237-65 | 1 | O-Ring |
| 5 | 105-3921 | 1 | Fitting-Plug |
| 5:1 | 237-146 | 1 | O-Ring |
| 6 | 340-9 | 1 | Fitting-HYD, Straight |
| 6:1 | 237-58 | 1 | O-Ring |
| 6:2 | 237-81 | 1 | O-Ring |
| 7 | 340-129 | 1 | Fitting-HYD, 90 DEG |
| 7:1 | 237-146 | 1 | O-Ring |
| 7:2 | 340-65 | 1 | O-Ring |
| 8 | 354-77 | 2 | Fitting-Quick |
| 8:1 | 237-78 | 1 | O-Ring |
| 9 | 354-79 | 2 | Cap-Dust |
| 10 | 2412-150 | 1 | J-Clip |
| 11 | 322-22 | 4 | Screw-HH |
| 12 | 32128-44 | 5 | Nut |

| Ref | Part No. | Qty. | Description |
|---|---|---|---|
| 13 | 3234-5 | 1 | Screw-HHF |
| 14 | 104-5487 | 1 | Bracket-L |




# Manifold Assembly No. 104-5475


| Ref | Part No. | Qty. | Description |
|---|---|---|---|
| 2 | 105-9150 | 1 | Relief-Proportional |
| ❶2:1 | 105-9151 | 1 | Seal Kit |
| 3 | 105-9152 | 1 | Coil ASM |
| 4 | 105-9153 | 1 | Element-Logic, Vented |
| ❶4:1 | 105-9154 | 1 | Seal Kit |
| 5 | 105-9155 | 1 | Valve-Relief |
| ❶5:1 | 105-9156 | 1 | Seal Kit |
| 6 | 105-9157 | 1 | Piston-Pilot |




# 4 Wheel Drive Manifold and Filter Assembly


| Ref | Part No. | Qty. | Description |
|---|---|---|---|
| 1 | 340-157 | 1 | Fitting-HYD, Tee |
| 1:1 | 237-79 | 1 | O-Ring |
| 1:2 | 237-30 | 2 | O-Ring |
| 2 | 340-129 | 1 | Fitting-HYD, 90 DEG |
| 2:1 | 237-146 | 1 | O-Ring |
| 2:2 | 340-65 | 1 | O-Ring |
| 3 | 100-5558 | 1 | Manifold-Filter |
| 4 | 104-5480 | 1 | Fitting-Hose, Straight |
| 4:1 | 237-123 | 1 | O-Ring |
| 5 | 340-2 | 1 | Fitting-Straight, HYD |
| 5:1 | 237-22 | 1 | O-Ring |
| 5:2 | 237-42 | 1 | O-Ring |
| 6 | 340-155 | 1 | Fitting-HYD, Straight |
| 6:1 | 237-79 | 1 | O-Ring |
| 6:2 | 237-151 | 1 | O-Ring |
| 7 | 340-98 | 1 | Fitting-HYD, 90 DEG |
| 7:1 | 237-79 | 1 | O-Ring |
| 7:2 | 237-30 | 1 | O-Ring |
| 8 | 104-3797 | 2 | Fitting-HYD, Straight |
| 8:1 | 237-146 | 1 | O-Ring |
| 8:2 | 340-65 | 1 | O-Ring |
| 9 | 100-4890 | 1 | Fitting-Check |
| 9:1 | 237-79 | 1 | O-Ring |
| 9:2 | 237-30 | 1 | O-Ring |

| Ref | Part No. | Qty. | Description |
|---|---|---|---|
| 10 | 340-9 | 2 | Fitting-HYD, Straight |
| 10:1 | 237-58 | 1 | O-Ring |
| 10:2 | 237-81 | 1 | O-Ring |
| 11 | 340-4 | 1 | Fitting-HYD, Straight |
| 11:1 | 237-30 | 1 | O-Ring |
| 11:2 | 237-79 | 1 | O-Ring |
| 13 | 105-9875 | 1 | 4Wd Manifold ASM |
| 14 | 354-77 | 2 | Fitting-Quick |
| 14:1 | 237-78 | 1 | O-Ring |
| 15 | 354-79 | 2 | Cap-Dust |
| 16 | 353-990 | 1 | Plug |
| 16:1 | 237-78 | 1 | O-Ring |
| 17 | 94-2628 | 1 | Adapter-HYD |
| 17:1 | 237-79 | 1 | O-Ring |
| 17:2 | 237-30 | 1 | O-Ring |




# Filter Manifold Assembly No. 100-5558


| Ref | Part No. | Qty. | Description |
|---|---|---|---|
| ❷1 | | 1 | Manifold |
| 2 | 104-4292 | 1 | Valve-Check |
| 3 | 104-4293 | 1 | Valve-Check |
| 4 | 104-4294 | 1 | Valve-Check |
| 5 | 353-990 | 4 | Plug |
| 5:1 | 237-78 | 1 | O-Ring |
| 6 | 353-989 | 3 | Plug-Hex, Hollow |
| 6:1 | 237-42 | 1 | O-Ring |
| 7 | 354-137 | 1 | Plug |
| 7:1 | 237-86 | 1 | O-Ring |
| 8 | 94-2621 | 1 | Element-Filter |
| ❷9 | | 1 | Nipple-Filter |
| 10 | 354-70 | 1 | Plug-Hex, Hollow |
| 10:1 | 237-80 | 1 | O-Ring |
| 11 | 99-5504 | 2 | Seal Kit |
| 12 | 99-5503 | 1 | Seal Kit |




# 4 Wheel Drive Manifold Assembly No. 105-9875

| Ref | Part No. | Qty. | Description |
|---|---|---|---|
| ❷1 | | 1 | Manifold |
| 2 | 104-8603 | 1 | Valve-Solenoid |
| 2:1 | 99-5505 | 1 | Seal Kit |
| 3 | 104-8604 | 1 | Valve-Check |
| 3:1 | 99-5506 | 1 | Seal Kit |
| 5 | 104-8605 | 2 | Valve-Control |
| 5:1 | 99-5507 | 1 | Seal Kit |
| 7 | 105-9847 | 1 | Valve-Relief |
| 7:1 | 99-5503 | 1 | Seal Kit |
| 8 | 105-9848 | 1 | Valve-Reducing |
| 8:1 | 104-4266 | 1 | Seal Kit |
| 9 | 353-991 | 7 | Plug-Hex, Hollow |
| 9:1 | 237-156 | 1 | O-Ring |
| 10 | 354-137 | 8 | Plug |
| 10:1 | 237-86 | 1 | O-Ring |
| ❷11 | | 5 | Plug-Expander |
| ❷12 | | 5 | Plug-Expander |
| 13 | 353-989 | 6 | Plug-Hex, Hollow |
| 13:1 | 237-42 | 1 | O-Ring |
| 14 | 353-990 | 3 | Plug |
| 14:1 | 237-78 | 1 | O-Ring |
| 15 | 354-70 | 3 | Plug-Hex, Hollow |
| 15:1 | 237-80 | 1 | O-Ring |
| 16 | 104-4264 | 1 | Coil-Solenoid |


| Ref | Part No. | Qty. | Description |
|---|---|---|---|
| 22 | 106-6766 | 1 | Plug-Orifice |




# Traction Hydraulic Line Assembly

| Ref | Part No. | Qty. | Description |
|---|---|---|---|
| 1 | 92-7536 | 1 | Hose ASM |
| 2 | 105-9818 | 1 | Hose ASM |
| 3 | 104-5476 | 1 | Tube ASM |
| ❶3:1 | 340-65 | 1 | O-Ring |
| 4 | 104-5478 | 1 | Tube ASM |
| ❶4:1 | 340-65 | 1 | O-Ring |
| 5 | 105-3864 | 1 | Hose ASM |
| 6 | 69-8950 | 2 | Spacer |
| 7 | 240-2 | 2 | Grommet-Rubber |
| 8 | 69-8920 | 4 | Washer |
| 9 | 104-5472 | 1 | Tube ASM |
| ❶9:1 | 340-65 | 1 | O-Ring |
| 10 | 105-3861 | 1 | Tube ASM |
| 11 | 105-3915 | 1 | Tube ASM |
| 12 | 104-5489 | 1 | Tube ASM |
| 14 | 105-3866 | 1 | Tube ASM |
| 15 | 104-5470 | 1 | Tube ASM |
| 16 | 105-3984 | 1 | Tube ASM |
| 17 | 105-3865 | 1 | Tube ASM |
| 18 | 104-5462 | 1 | Tube ASM |
| 19 | 104-5468 | 1 | Tube ASM |
| 20 | 104-5473 | 1 | Tube ASM |
| ❶20:1 | 340-65 | 1 | O-Ring |
| 21 | 92-7534 | 1 | Hose ASM |


| Ref | Part No. | Qty. | Description |
|---|---|---|---|
| 22 | 104-5464 | 2 | Hose ASM |
| 23 | 105-3985 | 1 | Hose ASM |
| 24 | 105-9863 | 1 | Tube-HYD |
| ❶24:1 | 237-22 | 1 | O-Ring |
| 25 | 86-5480 | 1 | Nipple-Test |
| 26 | 59-7410 | 1 | Tip-Nipple, Diagnostic |
| 26:1 | 237-42 | 1 | O-Ring |
| 27 | 340-126 | 2 | Nut-Bulkhead |
| 28 | 340-128 | 2 | Nut-Bulkhead |
| 29 | 340-70 | 1 | Nut-Lock |
| 30 | 56-7973 | 2 | Clamp-Tube |
| 31 | 322-6 | 1 | Screw-HH |
| 32 | 3256-23 | 2 | Washer-Flat |
| 33 | 3296-29 | 1 | Nut-Lock, NI |
| 34 | 354-79 | 2 | Cap-Dust |




# Steering Hydraulic Line Assembly

| Ref | Part No. | Qty. | Description |
|---|---|---|---|
| 1 | 105-3871 | 1 | Tube ASM |
| ❶1:1 | 237-22 | 1 | O-Ring |
| 2 | 105-3870 | 1 | Tube ASM |
| ❶2:1 | 237-22 | 1 | O-Ring |
| 3 | 105-3887 | 1 | Tube ASM |
| 4 | 340-68 | 1 | Fitting-Tee, Bulkhead |
| 4:1 | 237-22 | 3 | O-Ring |
| 5 | 105-3886 | 1 | Tube ASM |
| 6 | 94-3060 | 1 | HYD Tube ASM |
| 6:1 | 237-22 | 1 | O-Ring |
| 7 | 94-3071 | 1 | HYD Tube ASM |
| 7:1 | 237-22 | 1 | O-Ring |
| 8 | 94-3059 | 1 | HYD Tube ASM |
| 8:1 | 237-22 | 1 | O-Ring |
| 9 | 94-3061 | 1 | HYD Tube ASM |
| 9:1 | 237-22 | 1 | O-Ring |
| 10 | 94-3062 | 1 | HYD Tube ASM |
| 11 | 104-5485 | 1 | Tube ASM |
| 12 | 92-7606-03 | 1 | Bracket-Bulkhead |
| 13 | 105-9817 | 1 | Hose ASM |
| 14 | 92-7539 | 1 | Hose ASM |
| 15 | 105-3873-03 | 1 | Bracket-Mount, Clamp |
| 16 | 340-117 | 1 | Cap |
| 19 | 340-70 | 7 | Nut-Lock |


| Ref | Part No. | Qty. | Description |
|---|---|---|---|
| 20 | 56-7973 | 14 | Clamp-Tube |
| 31 | 32144-11 | 2 | Screw-HWHTF |
| 32 | 322-6 | 3 | Screw-HH |
| 33 | 322-7 | 4 | Screw-HH |
| 34 | 3296-47 | 1 | Nut-Lock, NI |
| 37 | 32128-20 | 2 | Nut-HF |
| 38 | 3234-5 | 7 | Screw-HHF |
| 39 | 3256-23 | 7 | Washer-Flat |
| 40 | 3296-29 | 4 | Nut-Lock, NI |




# Mow Block Hydraulic Line Assembly


| Ref | Part No. | Qty. | Description |
|---|---|---|---|
| 1 | 104-5483 | 2 | Hose ASM |
| 2 | 104-5488 | 1 | Tube ASM |
| ❶2:1 | 340-65 | 1 | O-Ring |
| 5 | 105-9862 | 1 | Tube ASM |
| 5:1 | 237-22 | 2 | O-Ring |
| 6 | 105-3895 | 1 | Tube ASM |
| ❶6:1 | 237-65 | 1 | O-Ring |
| 7 | 105-3885 | 1 | Tube ASM |
| 8 | 105-3893 | 1 | Tube ASM |
| ❶8:1 | 237-65 | 1 | O-Ring |
| 9 | 105-3894 | 1 | Tube ASM |
| ❶9:1 | 237-65 | 1 | O-Ring |
| 10 | 69-9000 | 9 | Spacer |
| 11 | 240-3 | 9 | Grommet-Rubber |
| 12 | 340-74 | 9 | Locknut-Bulkhead |
| 13 | 69-9010 | 18 | Washer |
| 14 | 340-68 | 1 | Fitting-Tee, Bulkhead |
| 14:1 | 237-22 | 3 | O-Ring |
| 15 | 105-3914 | 1 | Tube ASM |
| ❶15:1 | 237-22 | 1 | O-Ring |
| 16 | 105-3913 | 1 | Tube ASM |
| ❶16:1 | 237-22 | 2 | O-Ring |
| 17 | 105-3902 | 1 | Tube ASM |
| ❶17:1 | 237-65 | 1 | O-Ring |

| Ref | Part No. | Qty. | Description |
|---|---|---|---|
| 18 | 105-3911 | 1 | Tube ASM |
| 19 | 105-3901 | 1 | Tube ASM |
| ❶19:1 | 237-65 | 2 | O-Ring |
| 21 | 105-3900 | 1 | Tube ASM |
| ❶21:1 | 237-65 | 2 | O-Ring |
| 23 | 104-5481 | 1 | Tube ASM |
| ❶23:1 | 340-65 | 1 | O-Ring |
| 24 | 340-154 | 2 | Union-Bulkhead |
| 24:1 | 237-22 | 2 | O-Ring |
| 25 | 56-7971 | 4 | Clamp-Tube |
| 26 | 340-128 | 2 | Nut-Bulkhead |
| 27 | 340-70 | 1 | Nut-Lock |
| 28 | 322-8 | 1 | Screw-HH |
| 29 | 3256-23 | 4 | Washer-Flat |
| 30 | 3296-29 | 2 | Nut-Lock, NI |
| 31 | 322-13 | 1 | Screw-HH |
| 32 | 56-7973 | 2 | Clamp-Tube |





# Lift Hydraulic Line Assembly

| Ref | Part No. | Qty. | Description |
|---|---|---|---|
| 1 | 105-9238 | 4 | Hose ASM |
| 2 | 105-3988 | 1 | Tube ASM |
| 2:1 | 237-22 | 1 | O-Ring |
| 6 | 105-3860 | 1 | Tube ASM |
| 7 | 105-3989 | 1 | Tube ASM |
| 7:1 | 237-22 | 1 | O-Ring |
| 8 | 105-3928 | 1 | Tube ASM |
| 9 | 105-3916 | 1 | Tube ASM |
| 10 | 105-3917 | 1 | Tube ASM |
| 12 | 105-9249 | 1 | Tube ASM |
| 15 | 105-3990-03 | 1 | Bracket-Support, Tube |
| 16 | 105-3993-03 | 1 | Bracket-Support, Tube |
| 17 | 340-70 | 2 | Nut-Lock |
| 18 | 105-9838 | 1 | Hose ASM |
| 19 | 3334-945 | 1 | Tie-Cable |
| 20 | 32144-14 | 2 | Screw-HWH |
| 21 | 2412-138 | 1 | R-Clamp |
| 22 | 56-7973 | 2 | Clamp-Tube |
| 23 | 322-7 | 1 | Screw-HH |
| 24 | 3256-23 | 1 | Washer-Flat |
| 25 | 3296-29 | 1 | Nut-Lock, NI |
| 26 | 3234-11 | 2 | Screw-HHF |
| 27 | 104-8301 | 2 | Nut-Flange, NI |





# Lift Valve and Counter Balance Assembly

| Ref | Part No. | Qty. | Description |
|---|---|---|---|
| 1 | 104-5495 | 1 | Manifold ASM |
| 2 | 340-5 | 1 | Fitting-Straight |
| 2:1 | 237-42 | 1 | O-Ring |
| 2:2 | 237-30 | 1 | O-Ring |
| 3 | 340-2 | 3 | Fitting-Straight, HYD |
| 3:1 | 237-22 | 1 | O-Ring |
| 3:2 | 237-42 | 1 | O-Ring |
| 4 | 93-6810 | 1 | Fitting-Tee |
| 4:1 | 237-30 | 2 | O-Ring |
| 5 | 104-5494 | 1 | Valve-Spool, Single |
| 7 | 340-3 | 2 | Adapter |
| 7:1 | 237-22 | 1 | O-Ring |
| 7:2 | 237-79 | 1 | O-Ring |
| 8 | 105-9807 | 1 | Orifice |
| 9 | 86-5480 | 1 | Nipple-Test |
| 10 | 354-79 | 1 | Cap-Dust |
| 11 | 340-77 | 1 | Fitting-HYD, 90 DEG |
| 11:1 | 237-22 | 1 | O-Ring |
| 11:2 | 237-42 | 1 | O-Ring |
| 12 | 321-11 | 2 | Screw-HH |
| 13 | 340-97 | 1 | Fitting-HYD, 90 DEG |
| 13:1 | 237-22 | 1 | O-Ring |
| 13:2 | 237-78 | 1 | O-Ring |
| 14 | 32128-33 | 2 | Nut-HF |




# Manifold Assembly No. 104-5495


| Ref | Part No. | Qty. | Description |
|---|---|---|---|
| 2 | 105-9161 | 1 | Relief-Operated, Pilot |
| ❶2:1 | 105-9151 | 1 | Seal Kit |
| 4 | 105-9162 | 1 | Relief-Operated, Pilot |
| ❶4:1 | 105-9151 | 1 | Seal Kit |
| 5 | 105-9163 | 1 | Valve-Pilot Sequence, EXT |
| ❶5:1 | 105-9164 | 1 | Seal Kit |
| 7 | 105-9844 | 1 | Valve-Relief |
| ❶7:2 | 105-9156 | 1 | Seal Kit |




# Single Spool Valve Assembly No. 104-5494


| Ref | Part No. | Qty. | Description |
|---|---|---|---|
| 1 | 84-6420 | 1 | Plunger |
| 2 | 99-3589 | 1 | Seal Kit |
| 2:1 | 58-6290 | 2 | Poppet |
| 2:2 | 58-6320 | 1 | Wiper |
| 2:3 | 60-5720 | 2 | O-Ring |
| 2:4 | 58-6340 | 2 | O-Ring |
| 2:5 | 93-6314 | 1 | O-Ring |
| 2:6 | 58-6370 | 2 | Washer |
| 2:7 | 58-6450 | 2 | O-Ring |
| 2:8 | 58-6460 | 1 | Ring-Retaining |
| 3 | 58-6310 | 1 | Spacer |
| ❷4 | | 1 | Spool |
| 5 | 58-6330 | 1 | Seat |
| 5:1 | 58-6340 | 1 | O-Ring |
| 6 | 58-6350 | 1 | Plug |
| 6:1 | 60-5720 | 1 | O-Ring |
| 6:2 | 58-6370 | 1 | Washer |
| 7 | 69-1800 | 1 | Plug ASM |
| 7:1 | 60-5720 | 1 | O-Ring |
| 7:2 | 58-6370 | 1 | Washer |
| 8 | 58-6400 | 1 | Bushing |
| 9 | 69-1810 | 1 | Spring |
| 10 | 58-6420 | 1 | Cap |
| 11 | 58-6770 | 1 | Plunger |

| Ref | Part No. | Qty. | Description |
|---|---|---|---|
| ❷12 | | 1 | Body |
| 13 | 58-6780 | 1 | Plug |
| 13:1 | 58-6790 | 1 | O-Ring |
| 14 | 58-6730 | 1 | Spring |
| 17 | 58-6760 | 1 | Spring |
| 18 | 60-6450 | 1 | Disc |
| 19 | 353-508 | 1 | Plug |
| 19:1 | 237-42 | 1 | O-Ring |
| 20 | 65-2770 | 1 | Washer |





# Crankcase Assembly

| Ref | Part No. | Qty. | Description |
|---|---|---|---|
| 010 | 100-9150 | 1 | Crankcase |
| 020 | 98-7486 | 2 | Plug |
| 030 | 98-7487 | 6 | Plug |
| 040 | 98-7488 | 2 | Plug |
| 050 | 98-7489 | 3 | Plug |
| 060 | 98-7490 | 1 | Plug |
| 070 | 98-7500 | 6 | Cap-Sealing |
| 080 | 98-7501 | 2 | Cap-Sealing |
| 090 | 98-7502 | 2 | Pin-Straight |
| 100 | 98-7503 | 2 | Pin-Straight |
| 110 | 98-7504 | 2 | Pin-Straight |
| 120 | 98-7505 | 1 | Pin-Straight |
| 130 | 98-7506 | 1 | Pin-Pipe |
| 140 | 98-7509 | 1 | O-Ring |
| 150 | 100-9153 | 1 | Pipe-Return, Water |
| 160 | 105-2883 | 1 | Cap-Sealing |





# Oil Pan Assembly

| Ref | Part No. | Qty. | Description |
|---|---|---|---|
| 010 | 98-7520 | 1 | Pan-Oil |
| 020 | 98-7521 | 1 | Gasket |
| 030 | 98-7522 | 24 | Bolt-Flange |
| 040 | 98-9386 | 1 | Plug |
| 050 | 98-7524 | 1 | Gasket |
| 060 | 98-7529 | 1 | Plug-Drain |
| 070 | 98-7527 | 1 | O-Ring |
| 080 | 98-7525 | 1 | Filter-Oil |
| 090 | 98-7526 | 1 | Bolt |
| 100 | 98-7528 | 1 | O-Ring |




# Cylinder Head Assembly


| Ref | Part No. | Qty. | Description |
|---|---|---|---|
| 010 | 98-7530 | 1 | Hook-Engine |
| 020 | 98-7531 | 1 | Hook-Engine |
| 030 | 98-7526 | 1 | Bolt |
| 040 | 98-7533 | 1 | Stud |
| 050 | 100-1559 | 1 | Nut-Manifold, Exhaust |
| 060 | 99-8339 | 1 | Washer-Spring |
| 070 | 98-7536 | 1 | Washer-Plain |
| 080 | 100-9159 | 1 | Head-Cylinder |
| 090 | 98-7538 | 12 | Cap-Sealing |
| 100 | 98-7539 | 1 | Cap-Sealing |
| 110 | 98-7540 | 2 | Plug |
| 120 | 98-7541 | 4 | Guide-Valve, Intake |
| 130 | 98-7542 | 4 | Guide-Valve, Exhaust |
| 150 | 98-7543 | 18 | Bolt-Head, Cylinder |
| 160 | 100-9160 | 1 | Gasket-Head, Cylinder |
| 170 | 98-7509 | 1 | O-Ring |




# Gear Case Assembly


| Ref | Part No. | Qty. | Description |
|---|---|---|---|
| 010 | 100-9161 | 1 | Gearcase ASM |
| 020 | 98-7546 | 2 | Plug |
| 030 | 98-7547 | 2 | O-Ring |
| 040 | 98-7548 | 1 | O-Ring |
| 050 | 98-7549 | 1 | O-Ring |
| 060 | 98-7550 | 1 | Pin-Spring, Start |
| 070 | 98-7504 | 2 | Pin-Straight |
| 080 | 98-7552 | 1 | Packing-Case, Gear |
| 090 | 98-7553 | 2 | Bolt |
| 100 | 99-8336 | 5 | Bolt |
| 110 | 98-7555 | 1 | Bolt |
| 120 | 98-7556 | 2 | Bolt |
| 130 | 98-7557 | 3 | Bolt |
| 140 | 98-7558 | 2 | Bolt |
| 150 | 99-8339 | 9 | Washer-Spring |
| 160 | 98-7536 | 1 | Washer-Plain |
| 190 | 98-7563 | 1 | Spring |
| 200 | 98-7564 | 1 | Seat-Valve |
| 210 | 98-7565 | 1 | Ball |
| 220 | 98-7566 | 1 | Flange-Return, Water |
| 230 | 98-7567 | 1 | Gasket |
| 240 | 98-7568 | 3 | Bolt |
| 250 | 98-7569 | 1 | Cover |
| 260 | 98-7570 | 1 | Gasket-Unit, H/Meter |

| Ref | Part No. | Qty. | Description |
|---|---|---|---|
| 270 | 98-7571 | 4 | Stud |
| 280 | 98-7572 | 4 | Nut |
| 290 | 98-7699 | 4 | Washer-Spring |
| 300 | 100-9162 | 1 | Flange-Filter, Oil |
| 310 | 100-9163 | 1 | Gasket |
| 320 | 98-7571 | 1 | Stud |
| 330 | 100-9164 | 1 | Stud |
| 340 | 100-9165 | 1 | Collar |
| 350 | 98-7496 | 2 | Bolt |
| 360 | 98-7699 | 2 | Washer-Spring |
| 370 | 98-7572 | 2 | Nut |
| 380 | 98-7429 | 1 | Plug-Filter, Oil |
| 390 | 98-7430 | 1 | O-Ring |





# Head Cover Assembly

| Ref | Part No. | Qty. | Description |
|---|---|---|---|
| 010 | 98-7425 | 1 | Cover-Head, Cylinder |
| 020 | 98-7426 | 1 | Gasket-Cover, Head |
| 030 | 98-7427 | 4 | Nut-Cap |
| 040 | 98-7428 | 4 | Gasket |
| 050 | 98-7429 | 1 | Plug-Filter, Oil |
| 060 | 98-7430 | 1 | O-Ring |





# Oil Filter Assembly

| Ref | Part No. | Qty. | Description |
|---|---|---|---|
| 010 | 98-7431 | 1 | Cartridge-Filter, Oil |
| 020 | 100-9166 | 1 | Connector |
| 030 | 100-9167 | 1 | Collar |





# Dipstick and Guide Assembly

| Ref | Part No. | Qty. | Description |
|---|---|---|---|
| 010 | 105-4579 | 1 | Gauge-Oil |
| 020 | 100-9169 | 1 | Plug-Gauge, Oil |
| 030 | 105-4580 | 1 | Guide |





# Oil Pump Assembly

| Ref | Part No. | Qty. | Description |
|---|---|---|---|
| 010 | 100-9170 | 1 | Oil Pump ASM |
| 020 | 98-7513 | 1 | Gasket-Pump, Oil |
| 030 | 98-7514 | 4 | Bolt |
| 040 | 98-7699 | 4 | Washer-Spring |
| 050 | 98-7516 | 1 | Gear-Drive, Oil Pump |
| 060 | 98-7517 | 1 | Key-Feather |
| 070 | 98-7518 | 1 | Nut-Flange |





# Breather Assembly

| Ref | Part No. | Qty. | Description |
|---|---|---|---|
| 010 | 98-7417 | 1 | Plate-Element |
| 020 | 98-7418 | 1 | Plate-Element |
| 030 | 98-7419 | 1 | Element-Breather |
| 040 | 98-7420 | 1 | Shield-Breather, Oil |
| 050 | 98-7421 | 2 | Screw W/Washer |
| 060 | 98-7422 | 1 | Joint-Pipe, Breather |
| 070 | 98-7423 | 1 | Pipe-Breather |
| 080 | 98-7424 | 1 | Clamp-Pipe |





# Main Bearing Case

| Ref | Part No. | Qty. | Description |
|---|---|---|---|
| 010 | 100-9172 | 1 | Wheel Bearing Case ASM |
| 020 | 100-9173 | 1 | Bearing Case ASM |
| 030 | 98-7434 | 2 | Bolt-Case, Bearing |
| 040 | 98-7435 | 1 | Gasket-Case, Bearing |
| 050 | 98-7436 | 1 | Cover-Case, Bearing |
| 060 | 98-7437 | 1 | Gasket-Case Cover, Bearing |
| 070 | 98-7438 | 8 | Bolt |
| 080 | 98-7439 | 8 | Bolt |
| 090 | 98-7440 | 1 | Seal-Oil |
| 100 | 100-9174 | 1 | Main Bearing Case ASM |
| 110 | 100-9175 | 1 | Bearing Case ASM |
| 120 | 98-7434 | 2 | Bolt-Case, Bearing |
| 130 | 100-9176 | 1 | Main Bearing Case ASM |
| 140 | 100-9177 | 1 | Bearing Case ASM |
| 150 | 98-7434 | 2 | Bolt-Case, Bearing |
| 170 | 100-9178 | 1 | Bearing Case ASM |
| 180 | 98-7434 | 2 | Bolt-Case, Bearing |
| 190 | 98-7444 | 3 | Bolt-Case, Bearing |




# Camshaft and Idler Gear Shaft Assembly


| Ref | Part No. | Qty. | Description |
|---|---|---|---|
| 010 | 98-7445 | 8 | Tappet |
| 020 | 98-7446 | 8 | Rod-Push |
| 030 | 100-9179 | 1 | Camshaft ASM |
| 040 | 100-9180 | 1 | Camshaft |
| 050 | 98-7449 | 1 | Screw-Set |
| 060 | 98-7450 | 1 | Gear-Camshaft |
| 070 | 98-7451 | 1 | Key-Feather |
| 080 | 98-7452 | 1 | Stopper-Camshaft |
| 090 | 98-7453 | 2 | Bolt |
| 100 | 98-7454 | 1 | Gear-Idler, Complete |
| 110 | 98-7455 | 1 | Bushing-Gear, Idler |
| 120 | 98-7456 | 1 | Collar |
| 130 | 98-7457 | 1 | Collar |
| 140 | 98-7458 | 1 | Clip-Cir., External |
| 150 | 98-7459 | 1 | Shaft-Gear, Idler |
| 160 | 98-7453 | 3 | Bolt |




# Piston and Crankshaft Assembly


| Ref | Part No. | Qty. | Description |
|---|---|---|---|
| 010 | 99-5435 | 1 | Piston (.50Mm) |
| 010 | 100-9181 | 4 | Piston-STD |
| 020 | 100-9182 | 4 | Piston Ring ASM (STD) |
| 020 | 99-5436 | 1 | Piston Ring ASM (0.50Mm) |
| 030 | 98-7464 | 4 | Pin-Piston |
| 040 | 98-7465 | 8 | Clip-Pin, Piston |
| 050 | 98-7466 | 4 | Connecting Rod ASM |
| 060 | 98-7467 | 4 | Bushing-Pin, Piston |
| 070 | 98-7468 | 8 | Bolt-Rod, Connecting |
| 080 | 98-7471 | 4 | Metal-Crankpin (-0.40Mm) |
| 080 | 98-7470 | 4 | Metal-Crankpin (-0.20Mm) |
| 080 | 98-7469 | 4 | Metal-Crankpin (STD) |
| 090 | 98-7472 | 1 | Crankshaft-Complete |
| 100 | 98-7473 | 4 | Ball |
| 110 | 98-7474 | 1 | Sleeve-Crankshaft |
| 120 | 98-7475 | 1 | Gear-Crankshaft |
| 130 | 98-7451 | 1 | Key-Feather |
| 140 | 98-7476 | 1 | Slinger-Oil |
| 150 | 98-7477 | 1 | Collar-Crankshaft |
| 160 | 98-7478 | 1 | O-Ring |
| 170 | 98-7479 | 1 | Nut-Crankshaft |
| 180 | 98-7483 | 1 | Metal-Crankshaft (-0.40Mm) |
| 180 | 98-7482 | 1 | Metal-Crankshaft (-0.20Mm) |
| 180 | 98-7481 | 1 | Metal-Crankshaft (STD) |

| Ref | Part No. | Qty. | Description |
|---|---|---|---|
| 190 | 99-6863 | 4 | Metal-Crankshaft (-0.40Mm) |
| 190 | 99-6862 | 4 | Metal-Crankshaft (-0.20Mm) |
| 190 | 98-7484 | 4 | Metal-Crankshaft (STD) |
| 200 | 98-9415 | 2 | Bearing-Thrust (0.4Mm) |
| 200 | 98-9414 | 2 | Bearing-Thrust (0.2Mm) |
| 200 | 99-6864 | 2 | Metal-Side (STD) |
| 210 | 99-6869 | 2 | Metal-Side, O/S (0.4Mm) |
| 210 | 98-9689 | 2 | Bearing-Thrust (0.2Mm) |
| 210 | 99-6867 | 2 | Metal-Side (STD) |
| 220 | 98-7480 | 1 | Seal-Oil |





# Flywheel Assembly

| Ref | Part No. | Qty. | Description |
|---|---|---|---|
| 010 | 98-7532 | 1 | Flywheel |
| 020 | 98-7560 | 1 | Gear-Ring |
| 030 | 98-7573 | 6 | Bolt-Flywheel |
| 040 | 98-7559 | 1 | Housing-Flywheel |
| 070 | 98-7883 | 1 | Cover |
| 080 | 98-7886 | 1 | Gasket |
| 090 | 105-4577 | 2 | Bolt |
| 100 | 98-7885 | 11 | Bolt |
| 110 | 98-7546 | 1 | Plug |
| 120 | 100-9194 | 1 | Washer-Plain |





# Fuel Camshaft and Governor Shaft Assembly

| Ref | Part No. | Qty. | Description |
|---|---|---|---|
| 010 | 98-7551 | 1 | Fuel Camshaft ASM |
| 020 | 98-7508 | 1 | Camshaft-Fuel |
| 030 | 98-7595 | 1 | Bearing-Ball |
| 040 | 98-7574 | 1 | Gear-Pump, Injection |
| 050 | 98-7575 | 1 | Key-Feather |
| 060 | 98-7576 | 1 | Clip-Cir., External |
| 070 | 98-7577 | 1 | Sleeve-Governor |
| 080 | 98-7578 | 1 | Clip-Cir., Governor Sleeve |
| 090 | 98-7579 | 1 | Case-Ball, Governor |
| 100 | 98-7580 | 39 | Ball |
| 110 | 98-7581 | 1 | Clip-Cir. |
| 120 | 98-7582 | 7 | Ball |
| 130 | 98-7583 | 1 | Bearing-Ball |
| 140 | 98-7584 | 1 | Stopper |
| 150 | 100-9195 | 2 | Bolt |
| 160 | 98-7588 | 1 | Gasket |
| 170 | 98-7586 | 1 | Cover-Fuel, Camshaft |
| 180 | 98-7587 | 1 | Collar |
| 190 | 98-7589 | 1 | Clip-Cir., External |
| 200 | 98-7590 | 4 | Bolt |





# Engine Stop Lever Assembly

| Ref | Part No. | Qty. | Description |
|---|---|---|---|
| 010 | 98-7591 | 1 | I/D Appartus ASM |
| 020 | 98-7592 | 1 | Adjusting Bolt ASM |
| 030 | 98-7593 | 1 | Nut |
| 040 | 98-7594 | 1 | Nut-Cap |
| 050 | 98-7428 | 2 | Gasket |
| 060 | 98-7596 | 1 | Cap |
| 070 | 100-9198 | 1 | Engine Stop Lever ASM |
| 080 | 98-7598 | 1 | Cover-Pump, Injection |
| 090 | 100-9200 | 1 | Shaft-Lever |
| 100 | 98-7600 | 1 | Lever-Stop, Engine |
| 110 | 98-7601 | 1 | Seal-Oil |
| 120 | 98-7602 | 1 | Pin-Spring |
| 130 | 98-7603 | 1 | Spring-Return |
| 140 | 98-7604 | 1 | Gasket-Cover, Pump |
| 150 | 98-7605 | 4 | Bolt |





# Injection Pump Assembly

| Ref | Part No. | Qty. | Description |
|---|---|---|---|
| 010 | 100-9201 | 1 | Injection Pump ASM |
| 020 | 98-7607 | 1 | Shim |
| 030 | 98-7608 | 1 | Shim |
| 040 | 98-7609 | 1 | Shim-Pump, Injection |
| 050 | 98-7610 | 4 | Bolt |
| 060 | 100-1558 | 2 | Stud-Manifold, Exhaust |
| 070 | 98-7534 | 2 | Nut |
| 080 | 99-8339 | 2 | Washer-Spring |
| 090 | 100-9202 | 1 | Jet Start Cock ASM |
| 100 | 98-7617 | 1 | Joint |





# Injection Pump Component Parts Assembly

| Ref | Part No. | Qty. | Description |
|---|---|---|---|
| 010 | 100-9201 | 1 | Injection Pump ASM |
| 020 | 98-7619 | 4 | Plunger-Pump |
| 030 | 98-7620 | 4 | Valve-Delivery |
| 040 | 98-7621 | 4 | Spring-Valve, Delivery |
| 050 | 98-7622 | 4 | Gasket-Valve, Delivery |
| 060 | 98-7623 | 4 | Holder-Valve, Delivery |
| 070 | 98-7624 | 2 | Lock Plate ASM |
| 080 | 98-7625 | 4 | Tappet ASM |
| 090 | 98-7626 | 4 | Pin-Guide, Tappet |
| 100 | 98-7627 | 2 | Plate |
| 110 | 98-7628 | 4 | Spring-Plunger |
| 120 | 98-7629 | 4 | Seat-Spring, Upper |
| 130 | 98-7630 | 4 | Seat-Spring, Lower |
| 140 | 98-7631 | 4 | Shim |
| 150 | 98-7632 | 1 | Rack-Control |
| 160 | 98-7634 | 4 | Sleeve-Control |
| 170 | 98-7635 | 1 | Screw |
| 180 | 98-7636 | 2 | Gasket |
| 190 | 98-7637 | 4 | O-Ring |





# Governor Assembly

| Ref | Part No. | Qty. | Description |
|---|---|---|---|
| 010 | 98-7638 | 1 | Lever-Governor |
| 020 | 100-9204 | 1 | Lever-Fork |
| 030 | 100-9205 | 1 | Lever-Fork |
| 040 | 100-9206 | 1 | Lever-Fork |
| 050 | 98-7640 | 1 | Shaft-Lever, Fork |
| 060 | 98-7641 | 1 | Bolt-Shaft, Lever |
| 070 | 98-7699 | 2 | Washer-Spring |
| 080 | 98-7643 | 1 | Holder-Lever, Fork |
| 090 | 98-7644 | 1 | Bolt |
| 100 | 98-7645 | 2 | Bolt |
| 110 | 98-7646 | 1 | Bolt |
| 120 | 98-7536 | 2 | Washer-Plain |
| 130 | 98-7648 | 1 | Washer-Plain |
| 140 | 100-9207 | 1 | Spring-Start |
| 150 | 100-9208 | 1 | Spring-Governor |
| 160 | 98-7651 | 1 | Spring-Governor |





# Speed Control Plate Assembly


| Ref | Part No. | Qty. | Description |
|---|---|---|---|
| 010 | 98-7652 | 1 | Bolt-Adjusting |
| 020 | 98-7653 | 1 | Nut |
| 030 | 98-7654 | 2 | Gasket |
| 040 | 98-7655 | 1 | Nut-Cap |
| 060 | 98-7657 | 1 | Lever-Control, Speed |
| 070 | 98-7658 | 1 | Key-Feather |
| 080 | 98-7659 | 1 | O-Ring |
| 090 | 98-7698 | 1 | Washer-Plain |
| 100 | 98-7661 | 2 | Nut |
| 110 | 98-7662 | 1 | Collar |
| 120 | 98-7663 | 1 | Plate-Control, Speed |
| 130 | 98-7664 | 1 | Gasket |
| 140 | 98-7568 | 2 | Bolt |
| 150 | 98-7571 | 2 | Stud |
| 160 | 98-7699 | 2 | Washer-Spring |
| 170 | 98-7572 | 4 | Nut |




# Nozzle Holder and Glow Plug Assembly


| Ref | Part No. | Qty. | Description |
|---|---|---|---|
| 010 | 100-9213 | 1 | Overflow Pipe ASM |
| 020 | 98-7670 | 1 | Overflow Pipe ASM |
| 030 | 98-7671 | 1 | Clip-Pipe |
| 040 | 98-7672 | 1 | Clip-Pipe |
| 050 | 98-7673 | 1 | Clamp-Cord |
| 060 | 100-9214 | 1 | Nozzle Holder Kit |
| 065 | 100-9215 | 4 | Piece-Nozzle |
| 070 | 98-7676 | 4 | Gasket |
| 080 | 98-7677 | 4 | Seal |
| 090 | 100-9216 | 1 | Pipe-Injection |
| 100 | 100-9217 | 1 | Pipe-Injection |
| 110 | 100-9218 | 1 | Pipe-Injection |
| 120 | 100-9219 | 1 | Pipe-Injection |
| 130 | 98-7682 | 3 | Clamp-Pipe |
| 140 | 98-7683 | 3 | Clamp-Pipe |
| 150 | 98-9364 | 3 | Screw (W/Washer) |
| 160 | 98-7685 | 4 | Plug-Glow |
| 170 | 98-7686 | 1 | Cord-Plug, Glow |
| 180 | 99-8377 | 4 | Nut-Flange |





# Fuel Filter

| Ref | Part No. | Qty. | Description |
|---|---|---|---|
| 010 | 104-5215 | 1 | Pump-Fuel, Electric |
| 110 | 98-7612 | 1 | Filter-Fuel |




# Alternator and Pulley Assembly


| Ref | Part No. | Qty. | Description |
|---|---|---|---|
| 010 | 98-7693 | 1 | Alternator ASM |
| 020 | 98-7695 | 1 | Bolt |
| 040 | 98-9366 | 1 | Washer-Plain |
| 050 | 98-7697 | 1 | Bolt |
| 060 | 100-9233 | 1 | Washer-Plain |
| 070 | 98-7572 | 1 | Nut |
| 080 | 98-7699 | 1 | Washer-Spring |
| 090 | 105-2872 | 1 | Bracket-Alternator |
| 100 | 98-7701 | 1 | Cover-Belt |
| 110 | 106-2044 | 1 | Pulley-Drive, Fan |
| 120 | 98-7451 | 1 | Key-Feather |
| 130 | 98-7705 | 1 | V-Belt |




# Alternator Component Parts Assembly


| Ref | Part No. | Qty. | Description |
|---|---|---|---|
| 010 | 98-7693 | 1 | Alternator ASM |
| 020 | 98-7707 | 1 | Pulley-Alternator |
| 030 | 98-7708 | 1 | Nut |
| 040 | 98-7709 | 1 | Collar |
| 050 | 98-7710 | 1 | Rotor |
| 060 | 98-7711 | 1 | Cover-Bearing |
| 070 | 98-7712 | 1 | Bearing-Ball |
| 080 | 98-7713 | 1 | Washer-Thrust |
| 090 | 98-7714 | 1 | Frame-End, Drive |
| 100 | 98-7715 | 1 | Plate-Retainer |
| 110 | 98-7716 | 4 | Screw-Head, Round |
| 120 | 98-7717 | 2 | Bolt-Through |
| 130 | 98-7718 | 1 | Bearing-Ball |
| 140 | 98-7719 | 1 | Frame-End |
| 150 | 98-7720 | 1 | Cover-End |
| 160 | 98-7721 | 1 | Rectifier ASM |
| 170 | 98-7722 | 1 | Bushing-Insulation |
| 180 | 98-7723 | 1 | Holder-Brush |
| 190 | 98-7724 | 2 | Brush |
| 200 | 98-7725 | 2 | Spring-Brush |
| 210 | 98-7726 | 2 | Screw-Head, Round |
| 220 | 98-7727 | 6 | Screw-Head, Round |
| 230 | 98-7728 | 1 | Screw-Head, Round |
| 240 | 98-7729 | 3 | Bolt |

| Ref | Part No. | Qty. | Description |
|---|---|---|---|
| 250 | 98-7730 | 2 | Nut |
| 260 | 98-7731 | 2 | Bolt |
| 270 | 98-7732 | 1 | Nut |
| 280 | 98-7733 | 1 | Regulator ASM |




# Starter Assembly


| Ref | Part No. | Qty. | Description |
|---|---|---|---|
| 010 | 100-9237 | 1 | Starter ASM |
| 020 | 98-7735 | 1 | Stud |
| 030 | 98-7736 | 1 | Bolt |
| 040 | 98-7737 | 1 | Nut |
| 050 | 98-9368 | 1 | Washer-Spring |
| 060 | 98-7739 | 1 | Nut |
| 070 | 99-8339 | 1 | Washer-Spring |




# Starter Component Parts Assembly


| Ref | Part No. | Qty. | Description |
|---|---|---|---|
| 010 | 100-9237 | 1 | Starter ASM |
| 020 | 104-8608 | 1 | Yoke ASM |
| 030 | 98-7742 | 1 | Armature ASM |
| 040 | 98-7744 | 1 | Bearing |
| 050 | 98-7743 | 1 | Bearing |
| 060 | 98-7745 | 1 | Clutch-Running, Over |
| 065 | 105-2887 | 1 | Pinion-Bevel |
| 070 | 98-7746 | 1 | Frame-End, Drive |
| 080 | 100-9239 | 1 | Magentic Switch ASM |
| 090 | 98-7748 | 1 | Frame-End |
| 100 | 98-7749 | 1 | Brush Holder ASM |
| 110 | 98-7750 | 4 | Spring-Brush |
| 120 | 98-7751 | 1 | Gear |
| 130 | 98-7752 | 1 | Retainer |
| 140 | 98-7753 | 5 | Roller |
| 150 | 98-7755 | 1 | Ball |
| 160 | 98-7754 | 1 | Spring |
| 170 | 98-7756 | 2 | Bolt |
| 180 | 98-7757 | 2 | O-Ring |
| 190 | 98-7758 | 2 | Bolt ASM |
| 200 | 98-7759 | 1 | Pipe-Drain |
| 210 | 105-2873 | 1 | Nut |
| 220 | 99-8375 | 1 | Cover |
| 230 | 100-9240 | 2 | Bolt |

| Ref | Part No. | Qty. | Description |
|---|---|---|---|
| 240 | 99-8376 | 1 | Nut-Hex |
| 250 | 98-9711 | 1 | Cord-Solenoid, Stop |
| 270 | 105-2886 | 1 | Cover ASM |





# Oil Switch / Thermometer and Plug Assembly

| Ref | Part No. | Qty. | Description |
|---|---|---|---|
| 010 | 98-7764 | 1 | Switch-Oil |
| 020 | 99-3582 | 1 | Thermoswitch |





# Water Flange and Thermostat Assembly

| Ref | Part No. | Qty. | Description |
|---|---|---|---|
| 005 | 105-4578 | 1 | Water Flange ASM |
| 030 | 105-2874 | 2 | Plug |
| 040 | 105-2875 | 3 | Bolt-Flange |
| 050 | 98-7767 | 1 | Gasket-Flange, Water |
| 060 | 98-7610 | 2 | Bolt |
| 070 | 100-1558 | 1 | Stud-Manifold, Exhaust |
| 080 | 105-2877 | 1 | Bolt |
| 090 | 98-7534 | 1 | Nut |
| 100 | 99-8339 | 1 | Washer-Spring |
| 110 | 105-2878 | 1 | Pipe-Return, Water |
| 120 | 98-9714 | 1 | Clamp-Hose |
| 130 | 105-2879 | 1 | Clamp-Hose |
| 140 | 100-9244 | 1 | Cover-Thermostat |
| 150 | 105-2880 | 1 | Gasket-Cover, Thermostat |
| 160 | 98-7777 | 2 | Bolt |
| 170 | 105-2881 | 1 | Thermostat ASM |





# Water Pump Assembly

| Ref | Part No. | Qty. | Description |
|---|---|---|---|
| 010 | 100-9245 | 1 | Water Pump ASM |
| 020 | 98-7780 | 1 | Bearing-Ball |
| 030 | 98-7781 | 1 | Impeller-Pump, Water |
| 040 | 105-2882 | 1 | Mechanical Seal ASM |
| 050 | 98-7783 | 1 | Flange-Pump, Water |
| 060 | 98-9577 | 1 | Pipe-Return, Water |
| 070 | 98-7784 | 1 | Gasket-Pump, Water |
| 080 | 98-7439 | 2 | Bolt |
| 090 | 98-7786 | 2 | Stud |
| 100 | 99-8339 | 2 | Washer-Spring |
| 110 | 98-7534 | 2 | Nut |
| 120 | 98-7605 | 6 | Bolt |
| 130 | 98-7568 | 2 | Bolt |
| 140 | 100-9246 | 1 | Indicator-Timing |





# Water Pipe Assembly

| Ref | Part No. | Qty. | Description |
|---|---|---|---|
| 010 | 100-9278 | 1 | Pipe-Water |
| 020 | 100-9279 | 1 | Pipe-Water |
| 030 | 100-9280 | 1 | Pipe-Cooler, Oil |
| 040 | 98-9579 | 4 | Band-Pipe |





# Fan Assembly

| Ref | Part No. | Qty. | Description |
|---|---|---|---|
| 010 | 98-7702 | 1 | Pulley-Fan |
| 020 | 99-8363 | 4 | Bolt-Flange |





# Valve and Rocker Arm Assembly

| Ref | Part No. | Qty. | Description |
|---|---|---|---|
| 010 | 98-7791 | 4 | Valve-Inlet |
| 020 | 100-9281 | 4 | Valve-Exhaust |
| 030 | 98-7793 | 8 | Spring-Valve |
| 040 | 98-7794 | 8 | Retainer-Spring, Valve |
| 050 | 98-7795 | 8 | Collet-Spring, Valve |
| 060 | 98-7796 | 8 | Seal-Stem, Valve |
| 070 | 98-7797 | 8 | Cap-Valve |
| 080 | 98-7798 | 1 | Rocker Arm Shaft ASM |
| 090 | 98-7799 | 2 | Screw-Set |
| 100 | 98-7800 | 4 | Bracket-Arm, Rocker |
| 110 | 98-7801 | 4 | Stud |
| 120 | 98-7534 | 4 | Nut |
| 130 | 99-8339 | 4 | Washer-Spring |
| 140 | 98-7535 | 4 | Washer-Spring |
| 150 | 98-7805 | 1 | Pin-Spring |
| 160 | 98-7806 | 2 | Washer |
| 170 | 98-7807 | 3 | Spring-Arm, Rocker |
| 180 | 98-7808 | 2 | Clip-Cir., External |
| 190 | 98-7809 | 8 | Rocker Arm ASM |
| 200 | 98-7810 | 8 | Screw-Adjusting |
| 210 | 98-7811 | 8 | Nut |





# Inlet Manifold Assembly

| Ref | Part No. | Qty. | Description |
|---|---|---|---|
| 010 | 100-9283 | 1 | Inlet-Manifold |
| 020 | 100-9284 | 1 | Gasket-Manifold, Intake |
| 030 | 98-7610 | 7 | Bolt |





# Exhaust Manifold Assembly

| Ref | Part No. | Qty. | Description |
|---|---|---|---|
| 010 | 100-9285 | 1 | Manifold-Exhaust |
| 020 | 98-7802 | 1 | Gasket |
| 025 | 98-7803 | 1 | Gasket |
| 030 | 98-7533 | 6 | Stud |
| 040 | 100-9288 | 8 | Nut |
| 050 | 100-9289 | 2 | Stud |





# Turbo Charger Assembly

| Ref | Part No. | Qty. | Description |
|---|---|---|---|
| 010 | 100-9313 | 1 | Turbo Charger ASM |
| 020 | 100-9314 | 1 | Gasket |
| 030 | 99-8341 | 4 | Stud |
| 040 | 98-7534 | 4 | Nut |
| 050 | 99-8339 | 4 | Washer-Spring |
| 060 | 100-9315 | 1 | Flange-Muffler |
| 070 | 100-9316 | 1 | Gasket |
| 090 | 98-7697 | 4 | Bolt |
| 100 | 100-9230 | 1 | Bolt |
| 110 | 100-9318 | 1 | Hose-Inlet |
| 120 | 100-9319 | 1 | Band-Pipe |
| 130 | 99-8322 | 1 | Band-Pipe |





# Oil Pipe (Turbo Charger) Assembly


| Ref | Part No. | Qty. | Description |
|---|---|---|---|
| 010 | 100-9320 | 1 | Pipe-Oil |
| 020 | 100-9321 | 1 | Bolt-Joint, Eye |
| 030 | 98-7428 | 2 | Gasket |
| 040 | 98-9418 | 1 | Bolt-Joint, Eye |
| 050 | 99-8346 | 2 | Gasket |
| 060 | 100-9322 | 1 | Pipe-Oil |
| 070 | 98-9435 | 1 | Gasket-Oil Return, Turbo |
| 080 | 98-7568 | 2 | Bolt |
| 090 | 100-9323 | 1 | Pipe-Oil |
| 100 | 98-9721 | 1 | Pipe-Oil |
| 110 | 98-9714 | 2 | Clamp-Hose |
| 120 | 100-9324 | 1 | Clamp-Pipe |
| 130 | 98-9591 | 1 | Pin-Band |




# Oil Cooler Assembly


| Ref | Part No. | Qty. | Description |
|---|---|---|---|
| 010 | 100-9325 | 1 | Oil Cooler ASM |
| 020 | 100-9326 | 1 | Hose-Cooler, Oil |
| 030 | 98-7774 | 1 | Band-Pipe |
| 040 | 100-9327 | 1 | Band-Pipe |





# Muffler Gasket and Glow Controller

| Ref | Part No. | Qty. | Description |
|---|---|---|---|
| 010 | 100-9333 | 1 | Gasket-Muffler |
| 020 | 98-7611 | 1 | Controller-Glow |




# Operators Manual

| Ref | Part No. | Qty. | Description |
|---|---|---|---|
| 010 | 100-9335 | 1 | Manual-Instruction |




# Gasket Kit

| Ref | Part No. | Qty. | Description |
|---|---|---|---|
| 010 | 100-9337 | 1 | Upper Gasket Kit |
| 160 | 98-7888 | 1 | Lower Gasket Kit |


TORO®