Form No. 3351–776 Rev A

Rear Roller Scraper Kit

27” Rotary Cutting Unit

Model No. 30829

Installation Instructions

1. Position the machine on a level surface, lower cutting decks, stop engine, engage the parking brake and remove key from ignition switch.
2. Loosely mount each end of scraper and a scraper plate to each roller mount with (2) capscrews and a jam nut (Fig. 1). The longer capscrew and jam nut are to be installed in the lower mounting hole.

Note: If there are grease fittings on the roller mounts (Fig. 2) they must be removed and used instead of the longer capscrews and jam nuts when mounting the roller scraper.




Figure 1

1. Rear roller
2. Scraper
3. Roller mount
4. Scraper plate
5. Longer capscrew & jam nut




Figure 2

1. Roller scraper
2. Mounting screw
3. Grease fitting

3. Slide the scraper up or down until a gap of .020–.040 in. is achieved between the rod and the roller. Tighten the capscrews/grease fittings to lock adjustment. Torque to 30 ft.-lb. (41 N·m). Tighten the jam nut against the scraper plate, if applicable.

© 2004, 2007 by The Toro Company
8111 Lyndale Avenue South
Bloomington, MN 55420-1196

All Rights Reserved
Printed in the USA