
FORM NO. 3316–969A

TORO®

MODEL NO. 38170–5900001 Thru 6900001 & UP
MODEL NO. 38175–5900001 Thru 6900001 & UP

PARTS CATALOG

CCR POWERLITE® RECOIL
CCR POWERLITE® ELECTRIC



C–2100

CHUTE ASSEMBLY


Ref. No.	Part No.	Description	No. Used
1	46–8094	Screw – Hex Washer Hd.	4
2	75–9160	Detent – Chute	1
3	75–9170	Spring – Compression	2
4	75–8670	Handle – Chute	1
5	75–8770	Deflector – Chute	1
6	3256–68	Washer – Flat	2
7	3290–340	Washer – Belleville	2
8	3296–29	Nut – Lock	2
9	321–3	Screw	2
10	32115–15	Retainer	3
11	3230–2	Screw – Carriage	2
12	75–8760	Chute – Discharge	1
13	80–0640	Washer – Rubber	2

Ref. No.	Part No.	Description	No. Used
14	233–67	Knob	1
15	3256–81	Washer – Flat	2
16	3296–56	Nut – Lock	2
17	55–3573	Gas Cap Assembly	1
18	44–3173	Hose	1
19	44–2750	Body – Primer	1
20	23–7470	Guide – Rope	1
21	63–8360	Key – Ignition	1
22	32144–53	Screw – Acorn Slotted Hd.	2
23	75–9031	Panel – Control (Model No. 38170 Only)	1
*	75–9030	Panel – Control (Model No. 38175 Only)	1

*Not Illustrated

© The TORO Company –1994 / 1995 Rev.
All Rights Reserved

TPS




CHUTE ASSEMBLY (CONTINUED)

Ref. No.	Part No.	Description	No. Used
24	66-7460	Bulb - Primer	1
25	40-5940	Switch - On/Off	1
26	49-1490	J-Nut	2
27	32144-89	Screw - Hex Hd.	2
24	66-7460	Bulb - Primer	1
25	40-5940	Switch - On/Off	1
26	49-1490	J-Nut	2
27	32144-89	Screw - Hex Hd.	2
28	3250-32	Screw - Pan Hd.	2
29	3256-1	Washer - Flat	4
30	75-8800	Shroud - Upper	1
31	75-8660	Housing	1

Ref. No.	Part No.	Description	No. Used
32	3296-42	Nut - Lock	2
33	75-8650	Retainer - Chute	1
35	3229-11	Bolt - Carriage	1
36	84-5420	Decal - Control Panel (Model No. 38170 only)	1
*	84-5430	Decal - Control Panel (Model No. 38175 only)	1
37	80-0680	Decal - Powerlite (Model No. 38170 Only)	1
*	80-0690	Decal - Powerlite E (Model No. 38175 Only)	1


*Not Illustrated



ENGINE & WHEEL ASSEMBLY

Ref. No.	Part No.	Description	No. Used
1	92–6019	Screw – Thread Forming	3
2	3296–16	Nut – Lock	1
3	3256–58	Washer – Flat	1
4	80–0650	Spacer	1
5	80–0620	Ring – Isolator	1
6	75–8980	Support – Engine	1
7	3256–1	Washer – Flat	6
8	3296–42	Nut – Lock	4
9	75–9100	Bushing – Isolation	1
10	49–2483	Hose – Fuel	1
11	32144–27	Screw (Model No. 38175 Only)	2
12	77–0402	Motor Switch Housing Ass'y (Model No. 38175 Only)	1
13	2412–98	Clamp – Hose	2
14	32144–10	Screw – Hex Washer Hd. (Model No. 38175 Only)	1
15	2412–91	Clamp – Cable (38175 Only)	1
16		Engine (HSK 600–1680S)	1

Ref. No.	Part No.	Description	No. Used
17	250–7	Strap – Motor (Model No. 38175 Only)	1
18	77–0402	Starter Motor Assembly (Model No. 38175 Only)	1
19	80–0700	Screw (Model No. 38175 Only)	2
20	75–8910	Bracket – Wheel L.H.	1
21	321–10	Screw – Hex. Hd.	4
22	23–3250	Wheel	2
23	3290–320	Nut – Push On	2
24	27–0062	Axle	1
25	3–7501	Washer – Curved	2
26	3296–2	Nut – Lock	1
27	3256–14	Washer – Flat	1
28	75–8820	Sideplate – R.H.	1
29	32105–23	Screw – Hex. Washer Hd.	1
30	46–8094	Screw – Hex. Washer Hd.	3
31	75–8900	Bracket – Wheel R.H.	1
32	92–6012	Bracket & Stud Assembly	1




PULLEY & BELT COVER ASSEMBLY

Ref. No.	Part No.	Description	No. Used
1	3257–3	Key – Woodruff	1
2	75–8810	Sideplate – L.H.	1
3	32144–4	Screw – Hex Hd.	4
4	75–8870	Bracket – Belt Cover	1
5	71–5050	Hub – Half Sheave	1
6	71–5290	Plate Engine	2
7	75–9020	Spring – Idler	1
8	75–8720	Pin – Idler	1
9	3296–29	Nut – Lock	5
10	71–5060	Cap – Half Sheave	1
11	3256–71	Washer – Flat	1
12	3235–6	Screw – Hex Hd. Cap	1
13	75–8830	Cover – Belt	1
14	80–0630	Decal – Hot	1
15	3256–1	Washer – Flat	2

Ref. No.	Part No.	Description	No. Used
16	46–8094	Screw – Hex Washer Hd.	3
17	32105–23	Screw – Hex Hd.	1
18	3296–59	Nut – Lock	1
19	71–5260	Pulley – Idler	1
20	75–9050	Arm – Idler	1
21	75–8700	Bushing – Idler	1
22	3296–38	Nut – Lock	1
23	3256–25	Washer – Flat	1
24	75–8750	Pulley – Driven	1
25	75–9010	V–Belt – Drive	1
26	25–5640	Washer	1
27	75–8740	Hub – Driven Pulley	1
28	3230–23	Screw – Carriage	1
29	3256–14	Washer – Flat	1
30	3296–2	Nut – Lock	1

3316–969A




C–0626

AUGER ASSEMBLY

Ref. No.	Part No.	Description	No. Used
1	75–9180	Washer – Rubber	1
2	75–8690	Nut – Rotor Shaft	1
3	38–7820	Bearing – Ball	2
4	75–9080	Flange – Bearing	2
5	75–8840	Rotor	1
6	75–8880	Support – Rotor	2
7	3296–56	Nut – Lock	12
8	3229–5	Screw – Carriage	2
9	75–9040	Washer – Square	2
10	3234–33	Screw – Hex Hd. Cap	7

Ref. No.	Part No.	Description	No. Used
11	3–7501	Washer – Curved	2
12	3296–42	Nut – Lock	2
13	321–3	Screw – Hex Hd. Cap	3
14	32115–19	U–Nut	3
15	75–8780	Scraper	1
16	3256–14	Washer – Flat	3
17	32144–34	Screw – Hex Hd.	3
18	75–8710	Spacer – Auger Shaft	1
19	84–1980	Blade – Rotor	2
20	84–1970	Screw – Countersunk Oval	8




C–0627

HANDLE ASSEMBLY

Ref. No.	Part No.	Description	No. Used
1	75–9060	Tube – Frame	1
2	75–9070	Handle – Upper	1
3	19–4050	Knob – Handle Release	2
4	75–9130	Washer – PM	2
5	17–9426	Screw – Handle	2

Ref. No.	Part No.	Description	No. Used
6	75–8790	Shroud – Lower	1
7	3290–453	Nut – Push	2
8	3256–14	Washer – Flat	2
9	32144–34	Screw – Hex Hd.	2
10	32115–17	Nut – Push	2




STARTER MOTOR ASSEMBLY & SWITCH HOUSING

Ref. No.	Part No.	Description	No. Used
1	61–4680	Ring – Lock	1
2	61–4670	Stop – Pinion	1
3	61–4690	Spring – Anti – Drift	1
4	84–5240	Pinion Assembly	1
5	70–7810	Housing – Upper Starter	1
6	36–8340	Switch – Starter	1
7	36–8350	Boot – Switch	1
8	80–3740	Cap – Switch Housing	1
9	36–8370	Plug – Power	1
10	80–3730	Base – Switch Housing	1
11	3296–2	Nut – Lock	2

Ref. No.	Part No.	Description	No. Used
12	70–7820	Housing – Lower Starter	1
13	70–7802	Motor	1
14	70–7900	Bushing – Upper	1
15	70–7850	Cover – Gear	1
16	92–6003	Gear & Shaft Assembly	1
17	32144–101	Screw – Machine	2
18	70–7890	Cap – Pinion	1
19	250–7	Cable Tie	1
*	77–0402	Starter Motor Assembly (Incl. Ref.# 1–5,11–18 & 20)	1
*	28–9170	Cord – 7 Ft.	1

*Not Illustrated


ENGINE TECUMSEH MODEL NO. HSK600 TYPE 1680S



ENGINE TECUMSEH MODEL NO. HSK600 TYPE 1680S

Ref. No.	Part No.	Description	No. Used
1		Block Ass'y – Cylinder (Order short block if replacement is required)	1
16B	490291A	Vane Ass'y – Air	1
19	570707	Spring – Governor	1
24	530110	Bearing – Ball	1
27	510319	Seal – Crankshaft	2
29	530150	Bearing & Liner Set – Needle (37 Needles)	1
29A	530104A	Bearing – Cartridge	1
30	290602	Crankshaft	1
33A	570644	Plate – Cover	1
34	650579	Screw – Pan Flex Hd.	4
41	310283A	Piston & Pin Ass'y (Incl. ref. #43)	1
42	310190	Ring Set – Piston	1
43	310167	Ring – Piston Pin Retaining	2
45	310235B	Rod Ass'y – Connecting (Incl. ref. #29, 29A & 46)	1
46	650633	Screw – Connecting Rod	2
69	*510292A	Gasket – Cylinder Cover	1
69A	*510323A	Gasket – Cover Plate	1
77	530105	Bearing – Needle	1
89A	611032	Sleeve – Flywheel	1
90	611066	Flywheel	1
92	650815	Washer – Belleville	1
93	650390	Nut – Flywheel	1
100	34443A	Solid State Ass'y (Incl. Ref. #101)	1
101	610118	Cover – Spark Plug	1
103	650814	Screw – Hex. Hd. Sems	2
105A	650796	Stud – Cylinder	4
119	*510274A	Gasket – Cylinder Head	1
120	250240B	Head – Cylinder	1
131	650477	Screw – Pan Flex Hd.	5
135	611049	Plug – Spark (RCJ–8Y or equivalent)	1
163	650838	Washer – Flat	1
169	*510325A	Gasket – Cover	1
172A	570708	Cover Ass'y – Compression Release	1
174	650579	Screw – Torx. Hd.	1
177	650959	Screw	2
184	*510326A	Gasket – Carburetor	2
186	490322	Link – Governor	1
187	570438A	Spacer	1
216	570645	Level – Adjusting	1
239	35815	Gasket – Filter Base	1
257	650911	Screw – Torx Pan Hd.	4
258	350422	Base Ass'y – Blower Housing (Incl ref. #27)	1
260	350437	Housing – Blower	1
261	650737	Screw – Hex. Washer Hd.	3
274	*510207A	Gasket – Exhaust	1
275	390332	Muffler (Incl. Ref. #274 & 277)	1
277	650869	Screw – Torx Pan Hd.	2
285	590551	Cup – Starter	1
287	650926	Screw	3
325A	29443	Clip – Spring	1
330	611131A	Harness – Wire	1
370	35977	Decal – Caution	1
380	632641	Carburetor (Incl. ref. #184)	1
383	570434	Baffle – Air	1
384	650229	Screw – Pan Hd. Sems	2
390	590652	Starter Ass'y – Rewind	1
400	510324B	Gasket Set	1
422	730227A	Oil – 2 Cycle (8 oz.)	1

*Indicates parts included in Gasket Set ref. #400




c–1748

CARBURETOR NO. 632641

Ref. No.	Part No.	Description	No. Used
1	632166	Throttle Shaft & Lever Assy.	1
2	632169	Spring – Throttle Return	1
4	631184	Washer – Steel	1
5	631183	Washer – Felt	1
6	631621	Shutter – Throttle	1
7	650506	Screw – Shutter	2
10	632553	Choke Shaft & Lever Assy.	1
14	631815	Shutter – Choke	1
15	630735	Spring – Choke Positioning	1
16	632164	Fitting – Fuel Inlet	1
25	631700	Bowl – Float	1

Ref. No.	Part No.	Description	No. Used
26	632386	Spring – Float Shaft	1
27	631024	Shaft – Float	1
28	632019	Float – Carburetor	1
29	631028	Seal – O–Ring	1
30	631021	Inlet Needle, Seat & Clip (Incl. ref. #31)	1
31	631022	Clip – Spring	1
40	632385	Nut – Float Bowl	1
44	631334	Gasket – Bowl	1
48	631027	Plug – Welch	1



RECOIL STARTER NO. 590652

Ref. No.	Part No.	Description	No. Used
1	590599A	Pin – Spring (Incl. Ref. #4)	1
2	590600	Washer	1
3	590615	Retainer	1
4	590601	Washer	1
5	590598	Spring – Brake	1
6	590616	Dog – Starter	2
7	590617	Spring – Dog	2

Ref. No.	Part No.	Description	No. Used
8	590413A	Pulley Assembly (Incl. Ref. #9 & 10)	1
9	590619	Spring – Rewind	1
10	590620	Cover – Spring	1
11	590643	Starter Housing Assembly	1
12	590535	Rope – Starter	1
13	590452	Handle – Starter	1

TORO PART NUMBER INDEX

Part No.	Description	Pg. No.	Ref. No.	Qty.
3–7501	Washer – Curved	5	11	2
3–7501	Washer – Curved	3	25	2
17–9426	Screw – Handle	6	5	2
19–4050	Knob – Handle Release	6	3	2
23–3250	Wheel	3	22	2
23–7470	Guide – Rope	1	20	1
25–5640	Washer	4	26	1
27–0062	Axle	3	24	1
28–9170	Cord – 7 Ft.	7	*	1
36–8340	Switch – Starter	7	6	1
36–8350	Boot – Switch	7	7	1
36–8370	Plug – Power	7	9	1
38–7820	Bearing – Ball	5	3	2
40–5940	Switch – On/Off	2	25	1
40–5940	Switch – On/Off	2	25	1
44–2750	Body – Primer	1	19	1
44–3173	Hose	1	18	1
46–8094	Screw – Hex Washer Hd.	1	1	4
46–8094	Screw – Hex Washer Hd.	4	16	3
46–8094	Screw – Hex. Washer Hd.	3	30	3
49–1490	J–Nut	2	26	2
49–1490	J–Nut	2	26	2
49–2483	Hose – Fuel	3	10	1
55–3573	Gas Cap Assembly	1	17	1
61–4670	Stop – Pinion	7	2	1
61–4680	Ring – Lock	7	1	1
61–4690	Spring – Anti – Drift	7	3	1
63–8360	Key – Ignition	1	21	1
66–7460	Bulb – Primer	2	24	1
66–7460	Bulb – Primer	2	24	1
70–7802	Motor	7	13	1
70–7810	Housing – Upper Starter	7	5	1
70–7820	Housing – Lower Starter	7	12	1
70–7850	Cover – Gear	7	15	1
70–7890	Cap – Pinion	7	18	1
70–7900	Bushing – Upper	7	14	1
71–5050	Hub – Half Sheave	4	5	1
71–5060	Cap – Half Sheave	4	10	1
71–5260	Pulley – Idler	4	19	1
71–5290	Plate Engine	4	6	2
75–8650	Retainer – Chute	2	33	1
75–8660	Housing	2	31	1
75–8670	Handle – Chute	1	4	1
75–8690	Nut – Rotor Shaft	5	2	1
75–8700	Bushing – Idler	4	21	1
75–8710	Spacer – Auger Shaft	5	18	1
75–8720	Pin – Idler	4	8	1
75–8740	Hub – Driven Pulley	4	27	1
75–8750	Pulley – Driven	4	24	1
75–8760	Chute – Discharge	1	12	1
75–8770	Deflector – Chute	1	5	1
75–8780	Scraper	5	15	1
75–8790	Shroud – Lower	6	6	1
75–8800	Shroud – Upper	2	30	1
75–8810	Sideplate – L.H.	4	2	1
75–8820	Sideplate – R.H.	3	28	1
75–8830	Cover – Belt	4	13	1
75–8840	Rotor	5	5	1
75–8870	Bracket – Belt Cover	4	4	1
75–8880	Support – Rotor	5	6	2
75–8900	Bracket – Wheel R.H.	3	31	1
75–8910	Bracket – Wheel L.H.	3	20	1
75–8980	Support – Engine	3	6	1
75–9010	V–Belt – Drive	4	25	1
75–9020	Spring – Idler	4	7	1
75–9030	Panel – Control	1	*	1
75–9031	Panel – Control	1	23	1
75–9040	Washer – Square	5	9	2
75–9050	Arm – Idler	4	20	1
75–9060	Tube – Frame	6	1	1
75–9070	Handle – Upper	6	2	1
75–9080	Flange – Bearing	5	4	2
75–9100	Bushing – Isolation	3	9	1
75–9130	Washer – PM	6	4	2
75–9160	Detent – Chute	1	2	1
75–9170	Spring – Compression	1	3	2
75–9180	Washer – Rubber	5	1	1
77–0402	Motor Switch Housing Ass'y	3	12	1
77–0402	Starter Motor Assembly	7	*	1
77–0402	Starter Motor Assembly	3	18	1
80–0620	Ring – Isolator	3	5	1
80–0630	Decal – Hot	4	14	1
80–0640	Washer – Rubber	1	13	2
80–0650	Spacer	3	4	1
80–0680	Decal – Powerlite	2	37	1
80–0690	Decal – Powerlite E	2	*	1
80–0700	Screw	3	19	2
80–3730	Base – Switch Housing	7	10	1
80–3740	Cap – Switch Housing	7	8	1
84–1970	Screw – Countersunk Oval	5	20	8
84–1980	Blade – Rotor	5	19	2
84–5240	Pinion Assembly	7	4	1
84–5420	Decal – Control Panel	2	36	1
84–5430	Decal – Control Panel	2	*	1
92–6003	Gear & Shaft Assembly	7	16	1
92–6012	Bracket & Stud Assembly	3	32	1
92–6019	Screw – Thread Forming	3	1	3
233–67	Knob	1	14	1
2412–91	Clamp – Cable)	3	15	1
2412–98	Clamp – Hose	3	13	2
250–7	Cable Tie	7	19	1
250–7	Strap – Motor	3	17	1
321–3	Screw	1	9	2
321–3	Screw – Hex Hd.	5	13	3
321–10	Screw – Hex. Hd.	3	21	4
3229–5	Screw – Carriage	5	8	2
3229–11	Bolt – Carriage	2	35	1
3230–2	Screw – Carriage	1	11	2
3230–23	Screw – Carriage	4	28	1
3234–33	Screw – Hex Hd.	5	10	7
3235–6	Screw – Hex Hd.	4	12	1
3250–32	Screw – Pan Hd.	2	28	2
3256–1	Washer – Flat	3	7	6
3256–1	Washer – Flat	4	15	2
3256–1	Washer – Flat	2	29	4
3256–14	Washer – Flat	6	8	2
3256–14	Washer – Flat	5	16	3
3256–14	Washer – Flat	3	27	1
3256–14	Washer – Flat	4	29	1
3256–25	Washer – Flat	4	23	1

*Not Illustrated

TORO PART NUMBER INDEX (Cont.)

Part No.	Description	Pg. No.	Ref. No.	Qty.
3256–58	Washer – Flat	3	3	1
3256–68	Washer – Flat	1	6	2
3256–71	Washer – Flat	4	11	1
3256–81	Washer – Flat	1	15	2
3257–3	Key – Woodruff	4	1	1
3290–320	Nut – Push On	3	23	2
3290–340	Washer – Belleville	1	7	2
3290–453	Nut – Push	6	7	2
3296–2	Nut – Lock	7	11	2
3296–2	Nut – Lock	3	26	1
3296–2	Nut – Lock	4	30	1
3296–16	Nut – Lock	3	2	1
3296–29	Nut – Lock	1	8	2
3296–29	Nut – Lock	4	9	5
3296–38	Nut – Lock	4	22	1
3296–42	Nut – Lock	3	8	4
3296–42	Nut – Lock	5	12	2
3296–42	Nut – Lock	2	32	2
3296–56	Nut – Lock	5	7	12
3296–56	Nut – Lock	1	16	2
3296–59	Nut – Lock	4	18	1
32105–23	Screw – Hex Hd.	4	17	1
32105–23	Screw – Hex. Washer Hd.	3	29	1
32115–15	Retainer	1	10	3
32115–17	Nut – Push	6	10	2
32115–19	U–Nut	5	14	3
32144–4	Screw – Hex Hd.	4	3	4
32144–10	Screw – Hex Washer Hd.	3	14	1
32144–27	Screw	3	11	2
32144–34	Screw – Hex Hd.	6	9	2
32144–34	Screw – Hex Hd.	5	17	3
32144–53	Screw – Acorn Slotted Hd.	1	22	2
32144–89	Screw – Hex Hd.	2	27	2
32144–89	Screw – Hex Hd.	2	27	2
32144–101	Screw – Machine	7	17	2

*Not Illustrated

PRODUCT CHANGES

In an effort to make improvements available to TORO owners as quickly as possible, minor changes are incorporated into Toro's products from time to time that do not become immediately shown in the Parts Catalog. If such a change has been made in your unit, which is not reflected in your manual, see your TORO Distributor or his Authorized TORO Service Dealer for information and part numbers.

COUNTRIES OTHER THAN THE UNITED STATES OR CANADA

Customers who have purchased TORO products exported from the United States or Canada should contact their Toro Distributor (Dealer) to obtain guarantee policies for your country, province or state. If for any reason you are dissatisfied with your Distributor's service or have difficulty obtaining guarantee information, contact the TORO importer. If all other remedies fail, you may contact us at The Toro Company.

MAINTENANCE RECORD

Date								

Compliance with Radio Interference Regulations Certified.
Certifie Conforme au Reglement sur le Brouillage Radioelectrique.

Litho in U.S.A.

3316–969A

MAINTENANCE RECORD

Date								

3316−969A

MAINTENANCE RECORD

Date								

Litho in U.S.A.
GG−95384