
FORM NO. 3317–268

TORO®

MODEL NO. 03530–50001 & UP

PARTS CATALOG

REELMASTER® 5300D 2WD
TRACTION UNIT




FRAME & BODY ASSEMBLY

Ref. No.	Part No.	Description	No. Used
1	62–5550	Decal – TORO	1
2	75–1420	Cover – Steering Tower	1
3	75–3840	Fender – R.H.	1
‡4	85–4730	Decal – Hydraulic Oil (English)	1
5	65–5100	Handle	2
6	237–141	Bumper	2
7	46–8091	Screw – Cap Hex. Hd.	4
8	93–0000	Hood W.A.	1
9	93–0081	Strip – Seal	1
10	92–5549	Decal – Reelmaster® 5300D	2
11	3272–4	Pin – Cotter	2
12	93–0011	Grill – Hood	1
13	3296–42	Nut – Lock	7
14	3256–1	Washer – Flat	10
15	321–39	Screw – Cap Hex. Hd.	7
16	62–7400	Decal – TORO	1
17	63–6900	Hinge – Hood L.H.	1
*	63–6890	Hinge – Hood R.H.	1
18	3256–23	Washer – Flat	6
19	322–5	Screw – Cap Hex. Hd.	4
20	3253–4	Washer – Lock	4
21	75–0570	Cable – Hood	1
22	75–6280	Bracket – Hose	1
23	92–5751	Decal – Hood Trim L.H.	1
*	92–5752	Decal – Hood Trim R.H.	1
‡24	75–1280	Decal – Warning (English)	1
‡25	93–3601	Decal – Instructions (English)	1
26	75–5810	W.A. – Tool Box	1
27	93–0096	Decal – A.C.E.	2
‡28	52–1320	Decal – Fuel (English)	1
29	75–3860	Fender – L.H.	1
30	322–3	Screw – Cap Hex. Hd.	4

‡For different language versions of this part, see International Parts Reference.
*Not Illustrated

© The TORO Company – 1994
All Rights Reserved

3317−268




FRAME & BODY ASSEMBLY (Continued)

Ref. No.	Part No.	Description	No. Used
31	3256−3	Washer − Flat	4
‡32	75−5190	Decal − No Riders (English)	2
33	3234−14	Screw − Hex. Washer Hd.	14
‡34	88−6700	Decal − ANSI (English) (For Reference Only)	1
35	75−0650	Tread − Footrest L.H.	1
*	75−0640	Tread − Footrest R.H.	1
36	75−1410	Panel − Floor	1
37	75−0630	Tread − Foot Center	1
38	75−1390	Panel − Access	1
39	75−0620	Tread − Foot L.H.	1
*	75−0610	Tread − Foot R.H.	1

Ref. No.	Part No.	Description	No. Used
40	322−4	Screw − Cap Hex. Hd.	2
41	93−3626	Bracket − Hose	1
42	75−6840	Knob − Knurled	4
43	93−0012	Assembly − Frame	1
44	74−5950	Assembly − Swell Latch	3
45	32128−33	Nut − Flange Head	3
46	3258−166	Screw − Phillips Hd.	3
47	75−6260	Cover − Tool Box	1
‡48	93−3639	Decal − Warning (English)	1
49	49−2040	Screw − Hex. Washer Hd.	2
50	2412−107	R−Clamp	1

*Not Illustrated

‡For different language versions of this part, see International Parts Reference.



T–1044


STEERING TOWER ASSEMBLY

Ref. No.	Part No.	Description	No. Used
1	32144–26	Screw – Self–Tapping	2
2	3253–4	Washer – Lock	2
3	75–2810	Clamp – Steering Valve	1
4	75–0560	Assembly – Steering Wheel (Incl. Ref. #6–8)	1
5	68–5370	Decal – TORO	1
6	32144–21	Screw	1
7	68–5140	Cap – Steering Wheel	1
8	3220–6	Nut – Steering Wheel	1
9	233–17	Knob – Parking Brake	1
‡10	93–3139	Panel – Tower	1
11	3256–22	Washer – Flat	4
12	3–3251	Spring – Compression	1
13	75–1490	Rod – Parking Brake	1
14	237–22	O–Ring	5
15	3256–23	Washer – Flat	6
16	3296–20	Nut – Lock	4

Ref. No.	Part No.	Description	No. Used
17	3272–5	Pin – Cotter	3
18	75–6230	Hose – Hydraulic RT	1
19	75–6240	Hose – Hydraulic IN	1
20	63–7900	Rack – Parking Brake	1
21	3272–10	Pin – Cotter	1
22	3256–26	Washer – Flat	1
23	75–5940	Hose – Hydraulic AUX	1
24	75–6220	Hose – Hydraulic LT	1
25	75–6250	Hose – Hydraulic OUT	1
26	75–0600	Assembly – Steering Valve (Incl. Ref. #14)	1
27	21–9260	Seal – Shaft	1
28	3258–166	Screw – Phillips Hd.	2
29	3256–1	Washer – Flat	2
30	3296–42	Nut – Lock	2
31	3255–8	Washer – Lock ETLW	1
*	3290–378	Tie – Cable	3

*Not Illustrated

‡For different language versions of this part, see International Parts Reference.




STEERING VALVE ASSEMBLY No. 75–0600

Ref. No.	Part No.	Description	No. Used
1		Ring – Seal	5
2		Ring – Valve	1
3		Plate – Valve	1
4		Spring	3
5		Pin – Alignment	9
6		Manifold – Isolation	1
7		Ring – Metering	1
8		Hex Drive Asm.	1
9		Link – Drive	1
10		Screw – Hex Socket Hd.	11
11		Seal – Commutator	1
12		Cover – Commutator	1
13		Commutator	1
14		Ring – Commutator	1
15		Stator	1
16		Rotor	1
17		Spacer – Drive Link	1
18		Plug	1
19		O–Ring	1
20		Ball	1
21		Nut – Hex	4
22		Cover – Port	1
23		O–Ring	5
24		Manifold – Port	1
25		Spring	3

Ref. No.	Part No.	Description	No. Used
26		Plate – Cover, Upper	1
27	3220–6	Nut	1
28	66–9770	Seal	1
29	66–9780	Bushing	1
30		Spacer – Bearing, Thrust	1
31		Spacer – Seal	1
33		Seal – Face	1
34		Bearing – Thrust	1
35		Plate – Drive	1
36	93–3609	Bolt – Special	4
37	66–9860	Upper Cover & Jacket	1
38	66–9870	Plate – Retaining	1
39	66–9880	Washer – Retaining Plate	1
40	66–9890	Ring – Retaining	1
41	66–9900	Shaft – Input	1
*	66–9970	Spring Kit (Incl. Ref. #4 & 25)	1
*	66–9980	Seal – Kit (Incl. Ref. #1, 11, 19, 23 & 33)	1
*	66–9990	Needle Roller Kit (Incl. Ref. #5)	1
*	75–0600	Valve – Power Steering (Incl. Ref. #1–26 & 30–36)	1

*Not Illustrated




TRACTION & BRAKE PEDALS ASSEMBLY

Ref. No.	Part No.	Description	No. Used
1	3220–3	Nut – Jam	2
2	2411–36	Bearing – Rod End	1
3	323–9	Screw – Cap Hex. Hd.	1
4	3256–24	Washer – Flat	1
5	3272–2	Pin – Cotter	2
6	3256–22	Washer – Flat	2
7	75–6580	Cable – Pedal	1
8	75–3270	Lever – Traction Pivot	1
9	32121–6	Pin – Roll	1
10	32121–45	Pin – Roll	2
11	49–6440	Plate – Traction Pedal	1
12	74–9100	Pad – Forward	1
13	75–2970	Pedal – Traction	1
14	74–9110	Pad – Reverse	1
16	75–6510	Lever – Bracket	1
17	75–6550	Disc – Friction	1
‡18	75–6710	Decal – Fast/Slow (English)	1
19	233–42	Knob	1
20	75–6490	Lever – Pedal Stop	1
21	3290–461	Washer – Belleville	1
22	3296–59	Nut – Lock	1

Ref. No.	Part No.	Description	No. Used
23	3296–29	Nut – Lock	8
24	256–236	Bearing – Flange	4
25	322–3	Screw – Cap Hex. Hd.	8
26	7–3900	Pad – Brake	2
28	63–7880	Pin – Brake Latch	1
29	63–7733	Cable – Brake L.H.	1
*	63–7732	Cable – Brake R.H.	1
30	283–58	Pin – Clevis	4
31	3256–69	Washer – Thrust	3
32	32121–16	Pin – Roll	1
33	75–1440	Pedal – Brake L.H.	1
34	256–42	Bushing – Sleeve	2
35	75–1430	Assembly – Brake Pedal R.H. (Incl. Ref. #34 & 39)	1
36	75–1470	Shaft – Brake Pedal	1
37	75–2170	Tube – Pump Control	1
38	3296–39	Nut – Lock	1
39	302–5	Fitting – Grease	1
40	3272–10	Pin – Cotter	4
41	32121–50	Pin – Roll	1
42	5–0652	Spacer	1

*Not Illustrated
‡For different language versions of this part, see International Parts Reference.

3317−268




T−1891

SEAT & THROTTLE ASSEMBLY

Ref. No.	Part No.	Description	No. Used
1	351−78	Edging	1
2	323−4	Screw − Cap Hex. Hd.	2
3	75−4370	Bracket − Switch (Seat)	1
4	3296−54	Nut − Lock	4
5	92−8753	Magnet − Reed Switch	1
6	92−8001	Sensor − Reed Switch	1
7	3250−29	Screw − Cap Hex. Hd.	4
8	75−4360	Bracket − Switch	1
9	3296−39	Nut − Lock	3
10	93−0140	Grommet	1
11	74−0720	Tube − Manual	1
12	3256−23	Washer − Flat	8
13	3253−4	Washer − Lock	4
14	322−3	Screw − Cap Hex. Hd.	9
15	75−3400	Shaft − Seat Pivot	1
16	93−0141	Assembly − Seat Plate (Incl. Ref. #10)	1
‡17	85−4530	Decal − Danger (English)	1
18	2412−93	Clamp − R	1
19	3256−24	Washer − Flat	3
20	75−3680	Rod − Seat	1
21	3272−10	Pin − Cotter	2
22	32121−38	Pin − Roll	1
23	3296−29	Nut − Lock	9
24	93−0073	Cable − Throttle	1

Ref. No.	Part No.	Description	No. Used
25	25−8640	Screw − Hex. Head	2
26	93−0021	Asm. − Throttle Cable Swivel	2
27	3296−3	Nut − Lock	3
28	93−0018	Frame − Seat	1
29	3−6657	Clamp − Cable	1
30	3253−3	Washer − Lock	1
31	321−4	Screw − Cap Hex. Hd.	2
32	66−2920	Washer − Friction	2
33	75−3430	Rod − Throttle	1
34	233−42	Knob − Throttle	1
35	3296−59	Nut − Lock	2
36	5−0838	Washer − Flat	4
37	75−5270	Spacer − Locking Knob	2
38	75−5260	Knob − Locking	2
39		Asm. − Seat Suspension	1
‡40	83−7440	Decal − Knob (English)	1
‡41	85−4610	Decal − Instruction	1
42	2412−133	Clamp − R	2
43	92−6534	Shell − Seat	1
44	92−6533	Kit − Cushion, Replacement	1
45	92−1180	Assembly − Seat	1
46	63−9920	Decal − EEC 105	1
47	92−5524	Decal − Noise Rating, 90	1
48	2412−72	R−Clamp	1
49	93−3641	Plate − Idler Stop	1

‡For different language versions of this part, see International Parts Reference.




SEAT SUSPENSION ASSEMBLY

Ref. No.	Part No.	Description	No. Used
1	80–4860	Pin – Clevis	1
2	75–3580	Plate – Mounting, Seat	1
3	75–3530	Spring – Compression	1
4	3256–5	Washer – Flat	1
5	3256–24	Washer	1
6	75–3540	Pin – Roll	1
7	75–3550	Bumper – Seat	2
8	76–2940	Bumper – Rubber	2
9	76–1920	Bushing – Sleeve	4
10	66–8610	Weldment – Lower	1
11	66–8560	Nut – Push	4
12	76–1910	Shaft – Pivot	2
13	82–9060	Adjuster W/Handle	1
14	76–1940	Spring – Extension	2
15	66–9290	Spacer	6
16	66–8530	Adjuster	1

Ref. No.	Part No.	Description	No. Used
17	66–8520	Bumper – Down–stop	2
18	77–2870	Weldment – Hanger	1
19	76–1930	Knob – Tension Adjustment	1
20	3256–46	Washer – Flat	1
21	32128–26	Nut – Flange	4
22	3296–44	Nut – Lock	1
23	75–3480	Weldment – Upper	1
24	3256–26	Washer – Flat	2
25	3253–6	Washer – Lock	2
26	75–3510	Bolt – Shoulder	2
27	93–3164	Cap	2
28	93–3163	Spring	2
29	93–3165	Bracket	1
30	322–6	Screw – Cap Hex Head	1
31	3253–33	Washer – Lock	1
32	3217–6	Nut – Hex	1

3317–268



T–1458


DIAGNOSTIC–ACE DISPLAY ASSEMBLY

Ref. No.	Part No.	Description	No. Used
‡1	85–4760	Decal – Diagnostic–ACE RM 5300D V 1.0	1


Ref. No.	Part No.	Description	No. Used
2	85–4750	Display – Diagnostic–ACE	1

‡For different language versions of this part, see International Parts Reference.

ELECTRICAL SCHEMATIC



3317–268




T–1501B

CONTROL CONSOLE ASSEMBLY

Ref. No.	Part No.	Description	No. Used
1	66–2940	Gauge – Fuel	1
2	85–4420	Gauge – Speedometer	1
3	3290–489	Knob – Lift Control	1
4	218–498	Nut – Hex.	4
5	74–5950	Assembly – Swell Latch	1
6	44–2210	Assembly – Warning Light (Incl. Ref. #29 & 30)	1
*	218–533	Lens – Red	1
▪		Bulb – #1815	1
7	66–2960	Cluster – Warning	1
8	63–7430	Gauge – Temperature	1
9	63–8360	Key – Ignition	1
10	218–446	Nut – Locking	1
11	218–447	Washer – E.T.L.W.	1
12	3258–166	Screw – Phillips Hd.	5
13	3256–1	Washer – Flat	5
‡14	93–3140	Panel – Control	1
15	75–6270	Cover – Control Box	1
16	75–1010	Assembly – Toggle Switch (Incl. Ref. #4)	2
17	32105–13	Screw – Cap Hex. Hd.	2
18	3296–2	Nut – Lock	3
19	27–2360	Assembly – Ignition Switch (Incl. Ref. #9–11)	1

Ref. No.	Part No.	Description	No. Used
†20	218–573	Fuse – 5A	1
*†	218–578	Fuse – 10A	3
†21	67–7160	Block – Fuse	1
22	3296–42	Nut – Lock	4
23	85–4450	Bracket – Fuse Block	1
24	75–5740	Box – Control	1
25	85–4480	Knob	1
26	321–39	Screw – Cap Hex. Hd.	2
‡27	85–4720	Decal – Instruction (English)	1
28	75–4710	Warning Light Harness (Incl. Ref. #51 & 52)	1
*	219–17	Bulb – Light	4
29	218–536	Washer – Lock	1
30	218–535	Nut – Lock	1
31	92–5720	Controller – Electronic Note: This part must be programmed by distributor before installation.	1
32	3253–3	Washer – Lock	3
33	321–15	Screw – Cap Hex. Hd.	3
34	3256–3	Washer – Flat	4
35	322–3	Screw – Cap Hex. Hd.	3
36	3290–354	Plate – Nut	2

*Not Illustrated †Included in main wire harness assembly. ▪Obtain Locally.
‡For different language versions of this part, see International Parts Reference.




CONTROL CONSOLE ASSEMBLY (Continued)

Ref. No.	Part No.	Description	No. Used
}37	75–3420	Assembly – Lift Control (Incl. Ref. #3, 36 & 38–40)	1
38	218–590	Switch – Micro	2
39	3290–93	Screw – Cap Hex. Hd.	4
40	3290–488	Boot – Lift Control	1
41	32144–1	Screw – Cap Hex. Hd.	2
42	69–4780	Clamp – Light Cluster	1
43	32105–1	Screw – Cap Hex. Hd.	1
44	85–4470	Assembly – Potentiometer (Incl. Ref. #48 & 49) Note: Replacement of this part requires recalibration of electronic controller by distributor after installation.	1
45	3273–26	Screw – Hex. Socket Hd.	2
46	32144–18	Screw – Cap Hex. Hd.	2
47	75–6820	Meter – Hour	1


Ref. No.	Part No.	Description	No. Used
48		Nut – Lock	1
49		Washer – Lock	1
50	85–4460	Decal – HOC Selector	1
51		Nut – Lock	1
52		Washer – Lock	1
53	2412–126	Clamp–R	1
54	322–5	Screw – Cap Hex. Hd.	1
55	32128–33	Nut – Lock, Flange Hd.	3
56	93–0080	Asm. – Main Wire Harness	1
†57	85–4491	Lamp – Diagnostic	1
58	93–3625	Spring – Joystick Return	1
*†	70–8570	Breaker – Circuit	2
*†	86–7560	Connector – Cover (3 Way)	3
*†	86–7550	Connector – Cover (2 Way)	2
*†	85–4650	Connector – Loop Back	1
*	93–1358	Software – ECU RM5300D	1
*	219–19	Bulb – Light	1

*Not Illustrated †Included in main wire harness assembly.
‡For different language versions of this part, see International Parts Reference.

HYDRAULIC SCHEMATIC



T–1144A




T–1048

HYDRAULIC RESERVOIR ASSEMBLY

Ref. No.	Part No.	Description	No. Used
1	92–8785	Reservoir – Hydraulic	1
2	68–6150	Breather – Hydraulic Tank	1
3	61–2790	Screen – Filler	1
4	75–3710	Dipstick	1
5		Retainer – Tether	1
6	321–2	Screw – Cap Hex. Hd.	1
7	75–0540	Assembly – Tether (Incl. Ref. #5)	1
‡8	93–3103	Cap – Hydraulic Reservoir	1
9	75–6130	Hose – Hydraulic	1
10	237–65	O–Ring	5
11	340–8	Fitting – Hydraulic Straight (Incl. Ref. #10 & 12)	2
12	237–81	O–Ring	4
13	321–23	Screw – Cap Hex. Hd.	2
14	92–9098	Manifold – Tank	1
15	3296–42	Nut – Lock	2
16	354–74	Fitting – Hydraulic Plug (Incl. Ref. #12)	1
17	75–6250	Hose – Hydraulic	1
18	2412–34	Clamp – Hose	3
19	75–5720	Hose – Hydraulic	1
20	353–682	Fitting – Hydraulic Straight	1
21	93–0119	Hose – Hydraulic	1
22	340–77	Fitting – Hydraulic 90° (Incl. Ref. #23 & 25)	1
23	237–22	O–Ring	6
24	354–73	Fitting – Hydraulic Straight (Incl. Ref. #12)	2
25	237–42	O–Ring	4
27	340–87	Fitting – Hydraulic 45° (Incl. Ref. #25 & 23)	1
28	75–6870	Hose – Hydraulic Suction	1
29	75–0550	Strainer – Suction	1
30	93–0077	Hose – Hydraulic	1
31	75–1300	Asm. – Hydraulic Filter Head	1
32	2412–93	Clamp – R	2
33	32144–10	Screw – Hex. Washer Hd.	2
34	75–1310	Element – Hydraulic Filter	1
35	340–139	Fitting – Hydraulic 90° (Incl. Ref. #10 & 12)	1
36	323–5	Screw – Cap Hex. Hd.	3
37	63–8410	Washer – Flat	3
39	240–11	Grommet	3
41	3256–24	Washer – Flat	2
42	3253–21	Washer – Lock	2
43	323–4	Screw – Cap Hex. Hd.	2
44	353–550	Fitting – Plug (Incl. Ref. #45)	1
45	237–79	O–Ring	1
46	92–9096	Assembly – Hose	1
47	340–82	Fitting – Hydraulic 90° (Incl. Ref. #23 & 25)	2
48	88–9460	Hose – Hydraulic	1

‡For different language versions of this part, see International Parts Reference.

3317–268




T–1094A

HYDRAULIC CONTROL MANIFOLD ASSEMBLY

Ref. No.	Part No.	Description	No. Used
1	237–22	O–Ring	4
2	340–18	Fitting – Hydraulic 90° (Incl. Ref. #1 & 9)	2
4	92–1725	Hose – Hydraulic	1
5	340–3	Fitting – Hydraulic Straight (Incl. Ref. #1 & 9)	1
6	93–3611	Asm. – Control Manifold	1
7	237–78	O–Ring	6
9	237–79	O–Ring	6
10	340–101	Fitting – Hydraulic 45° (Incl. Ref. #9 & 13)	2
11	354–77	Fitting – Test Port (Incl. Ref. #7)	2
12	354–79	Cap – Test Port	2
13	237–30	O–Ring	4
14	86–9190	Hose – Hydraulic	2
17	340–92	Fitting – Hydraulic Straight (Incl. Ref. #7 & 18)	2
18	237–21	O–Ring	4
19	340–13	Fitting – Hydraulic Straight (Incl. Ref. #18)	2
20	75–6640	Fitting – Hydraulic 90° (Incl. Ref. #7)	2

Ref. No.	Part No.	Description	No. Used
21	93–0078	Hose – Hydraulic	1
22	237–65	O–Ring	1
23	340–139	Fitting – Hydraulic 90° (Incl. Ref. #22 & 26)	1
24	92–1721	Hose – Hydraulic	1
25	93–3612	Fitting – Hydraulic 90° (Incl. Ref. #1 & 9)	1
26	237–81	O–Ring	1
27	92–1723	Hose – Hydraulic	1
28	322–3	Screw – Cap Hex. Hd.	4
29	3253–4	Washer – Lock	4
30	75–5900	Hose – Hydraulic	1
31	82–8270	Valve – Flow Control	1
32	340–143	Fitting – Hydraulic 90° (Incl. Ref. #7)	1
33	93–0118	Hose – Hydraulic	1
35	75–5890	Hose – Hydraulic	1
37	92–1728	Hose – Hydraulic	1
38	93–3642	Tube – Hydraulic	1
39	93–3643	Tube – Hydraulic	1




T−1503

CONTROL MANIFOLD ASSEMBLY

Ref. No.	Part No.	Description	No. Used
1	237−78	O−Ring	12
2	353−990	Plug (Incl. Ref. #1)	11
3	88−7020	Cartridge − N.O. (Use Seal Kit #75−2080)	2
4	88−9190	Solenoid − 20 Watt	6
5	237−42	O−Ring	2
6	353−989	Plug (Incl. Ref. #5)	2
7	88−6990	Cartridge − N.C. (Use Seal Kit #75−2080)	3
8	88−9200	Solenoid − 28 Watt	5
9	88−6970	Cartridge − N.O. (Use Seal Kit #75−2080)	2
10	237−79	O−Ring	1
11	340−101	Fitting − Hydraulic 45° (Incl. Ref. #10 & 12)	1
12	237−30	O−Ring	1
13	75−0920	Cartridge − Relief 3000 psi (Use Seal Kit #75−2080)	1

Ref. No.	Part No.	Description	No. Used
14	75−2010	Cartridge − Relief 2000 psi (Use Seal Kit #75−2080)	1
15		Body − Manifold	1
16	237−156	O−Ring	2
17	353−991	Plug (Incl. Ref. #16)	2
18	340−143	Fitting − Hydraulic 90° (Incl. Ref. #1)	1
19	88−6960	Cartridge − 4W/2P (Use Seal Kit #75−2090)	3
20	237−80	O−Ring	1
21	354−70	Plug (Incl. Ref. #20)	1
22	92−6315	Cartridge − N.C. (Use Seal Kit #75−2080)	1
*	75−2080	Kit − Seal	10
*	75−2090	Kit − Seal	3

*Not Illustrated




FRONT HYDRAULIC MANIFOLDS

Ref. No.	Part No.	Description	No. Used
1	92–1722	Hose – Hydraulic	1
2	237–21	O–Ring	7
3	340–132	Fitting – Hydraulic 90° (Incl. Ref. #2 & 4)	3
4	237–78	O–Ring	7
5	321–11	Screw – Cap Hex. Hd.	2
6	88–0440	Decal – Floor Plate	1
7	85–4730	Decal – Oil	1
8	38–3400	Guard – Rubber	2
9	75–5940	Hose – Hydraulic	1
10	75–5890	Hose – Hydraulic	1
11	75–5910	Hose – Hydraulic	1
12	93–0118	Hose – Hydraulic	1
13	93–0119	Hose – Hydraulic	1
14	237–22	O–Ring	2
15	340–2	Fitting – Hydraulic Straight (Incl. Ref. #14 & 16)	2

Ref. No.	Part No.	Description	No. Used
16	237–42	O–Ring	2
17	93–0139	Manifold – Hydraulic	1
18	93–0143	Cartridge – Relief 250 psi (Use Seal Kit #75–2080)	1
19	75–5300	Rod – Hose Support	2
20	49–2040	Screw – Hex. Washer Hd.	4
21	3296–42	Nut – Lock	4
22	92–9096	Hose – Hydraulic	1
23	75–1180	Manifold – Hydraulic	1
24	92–1726	Hose – Hydraulic	1
25	92–1729	Hose – Hydraulic	1
26	340–92	Fitting – Hydraulic Straight (Incl. Ref. #2 & 4)	4
27	340–77	Fitting – Hydraulic 90° (Incl. Ref. #14 & 16)	1
28	321–18	Screw – Cap Hex. Hd.	2

*Not Illustrated




T–1095

REAR HYDRAULIC MANIFOLDS

Ref. No.	Part No.	Description	No. Used
1	75–6180	Hose – Hydraulic	2
2	237–21	O–Ring	7
3	340–92	Fitting – Hydraulic Straight (Incl. Ref. #2 & 4)	4
4	237–78	O–Ring	8
5	353–512	Fitting – Hydraulic Plug (Incl. Ref. #4)	2
6	321–11	Screw – Cap Hex. Hd.	4
7	75–1180	Manifold	2
8	340–132	Fitting – Hydraulic 90° (Incl. Ref. #2 & 4)	1


Ref. No.	Part No.	Description	No. Used
9	93–0118	Hose – Hydraulic	2
10	32128–33	Nut – Lock	4
11	340–143	Fitting – Hydraulic 90° (Incl. Ref. #4)	1
12	340–13	Fitting – Hydraulic Straight (Incl. Ref. #2)	2
13	82–8270	Valve – Flow Control	1
14	75–6080	Hose – Hydraulic	1
15	75–6070	Hose – Hydraulic	1



CUTTING UNIT HYDRAULIC COMPONENTS

Ref. No.	Part No.	Description	No. Used
1	92–1724	Hose – Hydraulic	1
2	237–78	O–Ring	5
3	340–103	Fitting – Hydraulic 45° (Incl. Ref. #2 & 4)	5
4	237–21	O–Ring	8
5	92–1722	Hose – Hydraulic	1
6	92–1725	Hose – Hydraulic	1
7	340–18	Fitting – Hydraulic 90° (Incl. Ref. #18 & 19)	10
8	92–1719	Hose – Hydraulic	1
9	91–1717	Hose – Hydraulic	1
10	92–1723	Hose – Hydraulic	1

Ref. No.	Part No.	Description	No. Used
11	88–9460	Hose – Hydraulic	1
12	92–1718	Hose – Hydraulic	1
13	340–21	Fitting – Hydraulic Tee (Incl. Ref. #4)	1
14	92–1721	Hose – Hydraulic	1
15	92–1727	Hose – Hydraulic	1
16	92–1726	Hose – Hydraulic	1
17	92–1728	Hose – Hydraulic	1
18	237–79	O–Ring	10
19	237–22	O–Ring	10
20	92–1729	Hose – Hydraulic	1
21	93–1375	Motor – Hydraulic	5




REEL MOTOR ASSEMBLY NO. 93–1375

Ref. No.	Part No.	Description	No. Used
1	354–50	Screw–Hex Socket Hd.	4
2	354–51	Washer	4
3	353–599	Pin–Dowel	2
4	93–3614	Assembly – Cover (Incl. Ref. #5)	1
†5		Bearing–Needle	5
6	93–3616	Assembly – Idler Gear	1
7	93–3615	Assembly – Drive Shaft	1
8	354–46	Ring–Seal	1

Ref. No.	Part No.	Description	No. Used
9	74–3810	Assembly – Load Plate	1
10	92–8795	Assembly – Body (Incl. Ref. #5)	1
†11		Spacer	1
†12		Seal–Shaft	1
13	32151–41	Ring – Retaining	1
14	92–8796	Pin – Dowel	2
*	92–8863	Repair Kit (Incl. Ref. #8, & 11–13)	1

*Not Illustrated

3317–268




FUEL TANK ASSEMBLY

Ref. No.	Part No.	Description	No. Used
1	63–7610	Hose – Fuel	1
2	53–8150	Assembly – Fuel Pump (Incl. Ref. #5 & 33–34)	1
3	3296–42	Nut – Lock	2
4	3256–22	Washer – Flat	2
†5		Mount – Rubber	2
6	321–8	Screw – Cap Hex. Hd.	2
7	62–7650	Gasket – Sending Unit	1
8	63–7640	Unit – Sending	1
9	3253–15	Washer – Lock	5
10	32122–24	Screw – Round Hd.	5
11	27–5340	Hose – Fuel	1
12	2412–108	Clamp – Hose	11
13	75–4700	Hose – Fuel	1
14	354–22	Fitting – Fuel, Straight	2
15	354–20	Fitting – Fuel Tee	1
16	75–4701	Hose – Fuel	1
17	354–21	Fitting – Fuel Straight	1
18	44–2670	Hose – Fuel	1

Ref. No.	Part No.	Description	No. Used
19	66–8121	Standpipe – Elbow 90°	1
20	46–6550	Connector – Fuel, Elbow 90°	1
21	46–6560	Grommet	2
22	93–3102	Cap – Fuel Tank	1
23	92–8780	Assembly – Fuel Tank (Incl. Ref. #24–25)	1
24	2412–36	Clamp – Drain	1
25	304–46	Fitting – Drain	1
26	323–5	Screw – Cap Hex. Hd.	3
27	63–8410	Washer – Flat	3
28	240–11	Grommet	3
29	63–7628	Hose – Fuel	1
30	353–781	Fitting – 90°	2
31	321–6	Screw – Cap Hex. Hd.	2
32	63–7650	Filter – Fuel	1
33	70–8530	Wire – Fuel Pump	1
34	218–579	Wire – Fuel Pump	1
35	67–1690	Fitting – Fuel Elbow 90°	2
36	32128–33	Nut – Lock Flange	2

*Not Illustrated
†Not Serviced Separately




FRONT AXLE & TRANSMISSION ASSEMBLY

Ref. No.	Part No.	Description	No. Used
1	76–8730	Decal – Bolt Torque	2
2	23–7270	Nut – Lug	10
3	232–27	Stem – Valve	2
4	3296–56	Nut – Lock	2
5	85–4350	Sensor – Gear Tooth	1
6	321–2	Screw – Cap Hex. Hd.	1
7	3253–3	Washer – Lock	1
8	32144–112	Screw – Cap Hex. Hd.	8
9	85–4330	Cover – Gear	1
10	92–5797	Gasket – Axle	1
11	85–4340	Plate – Sensor Mounting	1
12	32108–9	Screw – Machine	1
13	325–7	Screw – Cap Hex. Hd.	2
14	75–3110	Collar – Transmission	1
15	92–4808	Sleeve – Trans. Pilot	1
16	3296–23	Nut – Lock	2
‡17	77–0490	Decal – Bolt (English)	1
18	237–79	O–Ring	2
19	340–3	Fitting – Hydraulic, Straight (Incl. Ref. #18 & 20)	2
20	237–22	O–Ring	2
21	93–0076	Hose – Hydraulic	1
22	237–78	O–Ring	1
23	354–77	Fitting – Hydraulic Test Port (Incl. Ref. #22)	1

Ref. No.	Part No.	Description	No. Used
24	354–79	Cap – Test Port	1
25	237–81	O–Ring	2
26	75–4720	Fitting – Hydraulic 90° (Incl. Ref. #25)	1
27	2412–129	Clamp – Hose	2
28	75–6350	Hose	1
29	324–7	Screw – Cap Hex. Hd.	4
30	93–0075	Hose – Hydraulic	1
31	75–1330	Filter – Oil	1
32	323–12	Screw – Cap Hex. Hd.	2
33	3253–21	Washer – Lock	2
34	75–0012	Assembly – Transmission	1
35	3296–39	Nut – Lock	2
36	237–161	O–Ring	1
37	86–7220	Gear – Pinion	1
38	32151–62	Ring – Retaining	1
39	92–4846	Asm. – Trans. Support (Incl. Ref. #14 & 15)	1
40	354–75	Fitting – Hydraulic 90° (Incl. Ref. #25)	1
41	75–6340	Strainer – In–Line	1
42	354–72	Fitting – Hydraulic 45°	1
43	42–6080	Shim – Axle	A/R
44	66–6480	Washer – Flat	4
45	3296–48	Nut – Lock	4

‡For different language versions of this part, see International Parts Reference.


3317−268



FRONT AXLE & TRANSMISSION ASSEMBLY (Continued)

Ref. No.	Part No.	Description	No. Used
46	93−0084	Assembly − Front Axle	1
47	75−6850	Tube − Oil Fill	1
48	27−3710	Dipstick − Axle	1
49	323−20	Screw − Cap Hex. Hd.	2

Ref. No.	Part No.	Description	No. Used
50	3218−1	Nut − Jam	1
51	237−181	O−Ring	1
52	217−120	Rim	2
53	231−134	Tire	2




T–1315A

FRONT AXLE ASSEMBLY NO. 93–0084

Ref. No.	Part No.	Description	No. Used
1	32144–5	Nut	8
3	21–8270	Pin–Dowel	2
4	21–7720	Washer–Thrust	2
5	24–8790	Gear–Bevel, Differential	2
6	21–7690	Gear–Pinion	2
7	21–7730	Washer–Thrust	2
†8		Pinion–Drive	1
9	43–6760	Cone–Bearing, tapered	1
10	43–6750	Cup–Bearing, Tapered	1
11	92–1773	Screw–Cap, Hex Hd.	4
13	32144–112	Screw–Thread Forming	8
14	86–7230	Gear–Spur	1
15	43–6710	Diff. Adjust. Shim .003	A/R
16	43–6711	Diff. Adjust. Shim .005	A/R
17	43–6712	Diff. Adjust. Shim .010	A/R
18	43–6713	Diff. Adjust. Shim .030	A/R
19	3210–8	Screw – Cap, Hex Hd.	8
20	71–4350	Nut	1
21	83–5130	Spacer – Pinion	1
22	72–3570	Shim .094 – Diff. Adjust.	A/R
*	72–3571	Shim .096 – Diff. Adjust.	A/R
*	72–3572	Shim .098 – Diff. Adjust.	A/R
22	72–3573	Shim .100 – Diff. Adjust.	A/R

Ref. No.	Part No.	Description	No. Used
*	72–3574	Shim .102 – Diff. Adjust.	A/R
*	72–3575	Shim .104 – Diff. Adjust.	A/R
*	72–3576	Shim .106 – Diff. Adjust.	A/R
*	72–3577	Shim .108 – Diff. Adjust.	A/R
*	72–3578	Shim .110 – Diff. Adjust.	A/R
*	72–3580	Shim .112 – Diff. Adjust.	A/R
*	72–3581	Shim .114 – Diff. Adjust.	A/R
*	72–3582	Shim .116 – Diff. Adjust.	A/R
*	72–3583	Shim .118 – Diff. Adjust.	A/R
*	72–3584	Shim .120 – Diff. Adjust.	A/R
*	72–3585	Shim .125 – Diff. Adjust.	A/R
*	72–3586	Shim .127 – Diff. Adjust.	A/R
*	72–3587	Shim .129 – Diff. Adjust.	A/R
*	72–3588	Shim .131 – Diff. Adjust.	A/R
*	72–3590	Shim .133 – Diff. Adjust.	A/R
*	72–3591	Shim .135 – Diff. Adjust.	A/R
*	72–3592	Shim .137 – Diff. Adjust.	A/R
*	72–3593	Shim .139 – Diff. Adjust.	A/R
*	72–3594	Shim .141 – Diff. Adjust.	A/R
*	72–3595	Shim .143 – Diff. Adjust.	A/R
*	72–3596	Shim .145 – Diff. Adjust.	A/R
*	72–3597	Shim .147 – Diff. Adjust.	A/R
*	72–3598	Shim .149 – Diff. Adjust.	A/R

*Not Illustrated
†Not Serviced Separately




T–1315A

FRONT AXLE ASSEMBLY NO. 93–0084 (Continued)

Ref. No.	Part No.	Description	No. Used
22	72–3600	Shim .151 – Diff. Adjust.	A/R
23	254–91	Cone–Bearing	1
24	21–8390	Cup–Bearing	1
25	21–8020	Spacer–Front Pinion	1
26	93–3619	Upper Housing (Incl. Ref. #11)	1
27	254–66	Cup–Tapered Bearing	2
28	254–65	Cone–Tapered Bearing	2
†29		Gear–Ring	1
30	21–7710	Pin–Roll	1
31	21–7700	Shaft–Pinion Mate	1
32	21–7770	Screw–Drive Gear	5
33	21–7670	Case–Differential	1

Ref. No.	Part No.	Description	No. Used
34	75–0721	Housing–Lower	1
35	21–8120	Diff. Adjust. Shim .030	A/R
36	21–8110	Diff. Adjust. Shim .010	A/R
37	21–8100	Diff. Adjust. Shim .005	A/R
38	21–8090	Diff. Adjust. Shim .003	A/R
39	72–9420	Vent Tube Assembly	1
40	83–4910	Coupler – Pinion	1
41	71–4330	Seal	1
*	93–3618	Gear & Pinion Assembly (Incl. Ref. #8 & 29)	1
*	93–3617	Assembly – Differential (Incl. Ref. #4–10, 14–33, 35–38, 40 & 41)	1

*Not Illustrated
†Not Serviced Separately




T–0421A

BRAKE ASSEMBLY

Ref. No.	Part No.	Description	No. Used
1	27–6862	Shaft–Axle, Flanged L.H.	1
*	27–6852	Shaft–Axle, Flanged R.H.	1
2	92–1774	Seal–Oil	2
3	21–8180	Bearing	2
4	24–9180	Lever, Brake, Parking	2
5	21–9450	Shield–Dust	2
6	43–6810	Spider–Torque	2
7	21–9430	Spring–Shoe Return, R.H.	2
8	28–0670	Seal–Oil	2
9	84–8590	Assembly – Shoe & Lining	4
10	21–9460	Retainer–Brake, Parking	4
11	242–34	Stud–Flange, Axle	10

Ref. No.	Part No.	Description	No. Used
12	21–8360	Clip–Retaining	2
13	28–0680	Drum–Brake	2
14	21–9440	Spring–Adjusting Screw	2
15	21–9390	Socket–Adjusting Screw	2
16	21–9370	Screw–Adjusting	2
17	21–9380	Nut–Pivot	2
18	43–6800	Nut–Lock	8
19	21–9420	Spring–Shoe Return, L.H.	2
21	28–0660	Screw–Cap, Hex Hd.	8
22	24–8840	Ring–Bearing, Wheel	2
*	84–8600	Set of Lined Brake Shoes	1
*	92–8775	Gasket – Kit, Liquid	1

*Not Illustrated




TRANSMISSION ASSEMBLY NO. 75–0012

Ref. No.	Part No.	Description	No. Used
1	75–0430	Ring – Retaining	1
2	75–0150	Guide – Seal	1
3	75–0410	O–Ring	1
4	75–0520	Bearing – Ball	1
5	75–0020	Housing	1
6	75–0210	O–Ring	2
7	86–7520	Asm. – Trunnion Cover R.H.	1
8	75–0230	Seal – Lip	1
9	75–0090	Screw – Cap Hex Hd.	8
10	75–0480	Pin	2
11	86–7540	Shaft – Pump	1
12	75–0390	Plate – Swash	1
13	75–0400	Plate – Thrust	2
14	75–0470	Cylinder Block Kit	2
15	75–0380	Plate – Valve	1
16	75–0500	Bearing – Needle	2
17	75–0510	Pin	1
18	75–0040	Center Section	1
19	75–0170	Plug – Straight Thread	4
20	75–0060	Plug	4
21	75–0240	O–Ring	6
22	75–0290	Spring	2
23	75–0260	Valve – Relief	4
24	75–0130	Screw – Cap Hex Head	3
25	93–0097	Valve – SCR	1
26	75–0140	Spring – Conical	1
27	75–0190	Plug – Special	2

Ref. No.	Part No.	Description	No. Used
28	75–0120	Screw – Cap Hex Hd.	1
29	75–0370	O–Ring	1
30	75–0360	Gerotor	1
31	75–0350	Pin	1
32	83–4780	Housing – Charge Pump	1
33	75–0340	Bearing – Needle	1
34	75–0330	Seal – Lip	1
35	75–0110	Screw – Cap Hex Hd.	2
36	75–0180	Screw – Cap Hex Hd.	2
37	75–0320	Nipple	1
38	75–0200	Plug – Straight Thread	2
39	75–0270	Spring	1
40	75–0310	Shim	1
41	75–0070	Plug	1
42	75–0280	Spring	1
44	93–0083	Plate – Valve	1
45	75–0440	Shaft – Motor	1
46	75–0030	Gasket – Housing	1
47	75–0160	Plug – Pipe	1
48	75–0220	Pin	2
49	86–7530	Asm. – Trunnion Cover L.H.	1
50	75–0450	Collar	1
51	75–0460	Bearing – Ball	2
52	75–6930	Valve – SCR	1
53	32120–74	Ring – Retaining	1
54	75–0250	Pin – Slotted	1

*Not Illustrated




T–1051

TRACTION CONTROL ASSEMBLY

Ref. No.	Part No.	Description	No. Used
1	3272–10	Pin – Cotter	1
2	3256–26	Washer – Flat	1
3	322–10	Screw – Cap Hex. Hd.	1
4	32105–21	Screw	2
6	29–6162	Switch – Neutral	1
7	75–4130	Plate – Switch	1
8	76–9430	Spring – Extension	1
9	3296–29	Nut – Lock	4
10	322–7	Screw – Cap Hex. Hd.	1
11	251–259	Bearing – Ball	2
12	75–5470	Spacer	2
13	32144–22	Screw – Cap Hex. Hd.	4
15	75–4080	Plate – Traction	1
16	85–9900	Plate – Spring Anchor	1

Ref. No.	Part No.	Description	No. Used
17	3253–4	Washer – Lock	2
18	322–3	Screw – Cap Hex. Hd.	2
19	256–113	Bushing – Flange	2
20	302–5	Fitting – Grease	1
21	92–2581	Assembly – Switch Arm (Incl. Ref. #19 & 20)	1
22	3–6498	Washer – Thrust	2
23	76–8640	Stud – Traction	1
24	3296–9	Nut – Hex.	2
25	75–4100	Control – Pump	1
26	23–2270	Bushing – Rubber	1
27	85–9910	Eyebolt	1
28	3217–6	Nut – Hex.	1




T–1928

GEAR PUMP INSTALLATION ASSEMBLY

Ref. No.	Part No.	Description	No. Used
1	75–6870	Hose – Suction	1
2	2412–34	Clamp – Hose	1
3	354–78	Fitting – Hydraulic	1
4	323–12	Screw – Cap Hex. Hd.	2
5	3253–5	Washer – Lock	2
6	93–3604	Gasket	1
7	93–1396	Coupler W.A. – Trans.	1
8	75–4400	Adaptor – Transmission	1
9	237–163	O–Ring	1
10	340–4	Fitting – Hydraulic Straight (Incl. Ref. #11 & 17)	2

Ref. No.	Part No.	Description	No. Used
11	237–30	O–Ring	2
12	93–3643	Tube – Hydraulic	1
13	93–3642	Tube – Hydraulic	1
14	75–6240	Hose – Hydraulic	1
15	237–22	O–Ring	1
16	340–3	Fitting – Hydraulic Straight (Incl. Ref. #15 & 17)	1
17	237–79	O–Ring	3
18	93–1376	Assembly – Pump, Gear	1
19	237–146	O–Ring	1




HYDRAULIC PUMP No. 93–1376

Ref. No.	Part No.	Description	No. Used
1		Ring – Retaining	1
2		Seal – Shaft	1
3		Flange	1
4	93–4278	Pin – Dowel	4
5		Housing	1
6		O–Ring	2
7		Gear – Idler	1
8		Gear – Drive	1
9	93–4280	Coupling	2
10		Bearing	2
11		E–Seal	2
12		Ring – Backup	2
13	93–4279	Plate – Distance	2
14		Housing	1
15		Gear – Idler	1
16		Gear – Idler	1
17	93–4283	Bolt	4

Ref. No.	Part No.	Description	No. Used
18	93–4282	Block – Valve	1
19	93–4277	Kit – Valve	1
20		Gear – Idler	1
21		Housing	1
22	93–4281	Pin – Dowel	4
*	93–4268	Kit – Flange (Incl. Ref. #1–3)	1
*	93–4269	Kit – Housing, Section 1 (Incl. Ref. #6, 7, 10–12, 14 & 15)	1
*	93–4270	Kit – Housing, Section 2 (Incl. Ref. #5–8, & 10–12)	1
*	93–4271	Kit – Housing, Section 3 (Incl. Ref. #6,10–12, 16, & 20–21)	1
*	93–4272	Kit – Individual Pieces (Incl. Ref. #2, 6, 11, & 12)	1

*Not Illustrated




RADIATOR ASSEMBLY

Ref. No.	Part No.	Description	No. Used
1	93–1374	Latch – Swell	2
2	93–0032	Hsg. W.A. – Front Screen	1
3	3234–5	Screw – Whiz Lock	6
4	93–0090	Bracket – Mount RH, Cooler	1
*4	93–0089	Bracket – Mount LH, Cooler	1
5	3269–15	Rivet – Pop	8
6	75–0930	Hook – Oil Cooler	4
7	93–0038	Support W.A. – Radiator	1
8	32128–20	Nut – Whiz	6
9	93–0030	Asm. – Cooler Mount R.H. (Incl. Ref. #4–6)	1
*	93–0071	Asm. – Cooler Mount L.H. (Incl. Ref. #*4–6)	1
10	304–46	Drain – Radiator	1
11	93–0005	Strip – Foam, Top	1
12	93–0020	Radiator	1
13	66–3240	Cap – Radiator	1
14	92–2379	Clamp – Hose	2
15	2412–34	Clamp – Hose	2
16	75–2851	Hose – Expansion Tank	1
17	3290–378	Tie – Cable	1
18	93–0023	Hose – Radiator Upper	1
19	93–0022	Shroud – Fan	1

Ref. No.	Part No.	Description	No. Used
20	3290–271	Rivet – Pop	2
‡21	76–8750	Plate – Caution	1
22	3256–22	Washer – Flat	4
23	321–4	Screw – Cap Hex. Hd.	7
24	93–0024	Hose – Radiator Lower	1
25	3296–42	Nut – Lock	7
26	66–3180	Tube – Vent	1
27	2412–3	Clamp – Hose	2
28	75–4701	Hose – Fuel Vent	1
29	2412–103	Clamp – R	2
30	3269–10	Washer – Back–up	7
32	3269–13	Rivet – Pop	17
33	93–0025	Shield W.A. – Radiator	1
34	32148–7	Nut – Clinch	2
35	93–3626	Bracket – Hose	1
36	322–4	Screw – Cap Hex. Hd.	2
38	3256–23	Washer – Flat	4
39	3253–4	Washer – Lock	4
42	63–7590	Relay – Starter	1
43	322–2	Screw – Cap Hex. Hd.	2
44	75–1020	Switch – Backlap (Incl. Ref. #54)	1
45	24–0760	Exchanger – Heat	1

*Not Illustrated
‡For different language versions of this part, see International Parts Reference.




RADIATOR ASSEMBLY (Continued)

Ref. No.	Part No.	Description	No. Used
46	93–0076	Hose – Trans. to Cooler	1
*	93–0075	Hose – Trans. to Cooler	1
47	237–22	O–Ring	2
48	340–124	Fitting – Straight	2
49	93–0077	Hose – Cooler, R.H.	1
*	93–0078	Hose – Cooler, L.H.	1
50	237–65	O–Ring	2
51	92–4999	Fitting – Hydraulic 90° (Incl. Ref. #50)	2
52	75–1040	Cooler – Oil	1
‡53	75–0750	Decal – Backlap Switch (English)	1

Ref. No.	Part No.	Description	No. Used
54	218–498	Nut – Lock	2
55	75–3390	Bracket – Backlap	1
56	66–8800	Relay – Glow Plug	1
57	240–3	Grommet	2
58	93–0082	Grommet	2
59	3296–29	Nut – Lock	2
60	322–5	Screw – Cap Hex. Hd.	4
61	93–3623	Strip – Sealing, Radiator	2
62	93–3624	Plate – Retaining	2

*Not Illustrated
‡For different language versions of this part, see International Parts Reference.

3317–268




MUFFLER & PUMP DRIVE ASSEMBLY

Ref. No.	Part No.	Description	No. Used
1	54–9040	Yoke – End	1
2	322–9	Screw – Cap Hex. Hd.	2
3	93–0047	Yoke – Shaft	1
4	93–0045	Yoke – Slip Tube	1
5	302–5	Fitting – Grease	1
6	66–9303	Screw – Cap Hex. Hd.	3
7	86–3040	Coupling – Driveshaft	1
8	43–2740	Gasket	1
9	43–2750	Nut – Lock	1
10	63–7440	Solenoid – Stop	1
11	3234–17	Screw – Cap Hex. Hd.	1
12	3256–70	Washer – Flat	6
13	93–0044	Muffler	1
*	75–6880	Screen – Spark Arrester (Optional)	1
14	3296–29	Nut – Lock	2

Ref. No.	Part No.	Description	No. Used
15	93–3423	Gasket – Muffler	1
16	42–9850	Washer – Lock	6
17	48–7930	Nut – Lock	4
18	32128–20	Nut – Flange Head	1
19	66–9302	Screw – Cap Hex. Hd.	3
20	48–7710	Screw – Cap Hex. Hd.	2
21	2412–4	Clamp – R	1
22	93–3644	Guard W.A. – Flywheel	1
23	3296–44	Nut – Lock	3
24	62–3820	Fitting – Grease	1
25	54–9180	Kit – U–Joint	1
*	93–0047	Assembly – U–Joint (Incl. Ref. 1, 3, & 24–25)	1

*Not Illustrated




ENGINE INSTALLATION ASSEMBLY

Ref. No.	Part No.	Description	No. Used
1	74–5520	Clutch – Fan	1
2	75–3780	Fan	1
3	75–6380	Shaft – Fan	1
4	32121–2	Pin – Roll	2
5	75–6390	Pulley – Fan	1
6	47–0110	Spacer – Spindle	1
7	251–318	Bearing – Ball	2
8	75–5310	Spacer – Bearing	1
9	75–4450	Hub – Fan Drive	1
10	67–1630	Spacer – Fan	1
11	323–6	Screw – Cap Hex. Hd.	2
12	321–4	Screw – Cap Hex. Hd.	1
13	3–6657	Clamp – Cable	1
14	322–3	Screw – Cap Hex. Hd.	4
15	3230–2	Bolt – Carriage	1
16	2412–4	Clamp	2
17	3256–23	Washer – Flat	6
18	322–4	Screw – Cap Hex. Hd.	2
19	93–0048	Hose – Air Cleaner	1
20	2412–92	Clamp – Hose	1
21	48–7700	Screw – Cap Hex. Hd.	1
22	3255–8	Washer – Lock	2
23	75–1360	Cable – Battery (Ground)	1

Ref. No.	Part No.	Description	No. Used
24	93–0049	Assembly – Engine	1
25	3256–78	Washer – Flat	1
26	43–5930	Washer – Lock	1
27	48–7890	Nut – Hex.	1
28	42–9850	Washer – Lock	1
29	93–0050	Bracket – Engine L.H. Rear	1
*	93–0063	Bracket – Engine R.H. Rear	1
30	93–0092	Mount – Rubber, Rear	2
31	3213–2	Screw – Cap Hex. Hd.	8
32	3253–7	Washer – Lock	8
33	93–0093	Bracket – Eng. Left Rear	1
*	93–3621	Bracket – Eng. Right Rear	1
34	63–7400	Washer – Flat	4
35	3253–21	Washer – Lock	1
36	323–12	Screw – Cap Hex. Hd.	1
37	57–6390	Nut – Lock	2
38	3296–39	Nut – Lock	4
39	48–8070	Washer – Lock	10
40	42–9250	Screw – Cap Hex. Hd.	10
41	70–8220	Cable – Ground	1
43	3296–29	Nut – Lock	10
44	323–14	Screw – Cap Hex. Hd.	3
45	93–0095	Bracket – Eng. Front	2

*Not Illustrated


3317–268



ENGINE INSTALLATION ASSEMBLY (Continued)

Ref. No.	Part No.	Description	No. Used
46	53–9680	Mount – Engine	2
47	322–6	Screw – Cap Hex. Hd.	8
48	93–0051	Bracket – Engine L.H. Front	1
49	3255–9	Washer – Lock E.T.L.W.	1
50	3256–24	Washer – Flat	4
51	2412–71	Clamp – R	1
52	93–0054	Bracket W.A. – Fan	1
53	27–9560	Spacer	1
54	3296–59	Nut – Lock	1
55	93–0043	Bracket – Fan Idler	1
56	93–0062	Belt – V	1

Ref. No.	Part No.	Description	No. Used
57	323–7	Screw – Cap Hex. Hd.	1
58	63–8140	Pulley – Idler	1
59	32149–1	Nut – Lock	1
60	3253–4	Washer – Lock	4
61	322–2	Screw – Cap Hex. Hd.	4
62	93–0074	Support – Cable	1
63	3296–42	Nut – Lock	1
64	42–9300	Screw – Cap Hex. Hd.	1
65	42–9600	Washer – Flat	1
66	3256–40	Washer – Flat	4



T–1892


TIMING GEAR, PISTON, FLYWHEEL & CRANKSHAFT

Ref. No.	Part No.	Description	No. Used
1	93–3351	Gear – Pump, Injection	1
2	93–3352	Assembly – Idler, Gear (Incl. Ref. #36)	1
3	93–3364	Ball – Steel	1
4	93–3363	Assembly – Shaft, Idler (Incl. Ref. #3)	1
5	42–7190	Bushing	2
6	42–9440	Bolt W/Washer	4
7	93–3360	Cover	1
8	93–3361	Gasket – Cover	1
9	93–3365	Pin – Dowel	2
10	93–3366	Cap – Sealing	1
11	93–3356	Nut	1
12	93–3355	Washer – Spring	1
13	42–9810	Washer – Plain	1
14	93–3357	Pulley – Crankshaft	1
15	93–3359	Gear – Crankshaft	1
16	93–3370	Bearing – Con–Rod	6
17	93–3373	Bolt – Connecting	6
18	93–3374	Pin – Piston	3
19	93–3375	Ring Set – Piston	3
20	93–3596	Pipe – Oil Inlet	3

Ref. No.	Part No.	Description	No. Used
22	93–3376	Piston – Std.	3
*	93–3377	Piston – O.S. 0.25	3
*	93–3378	Piston – O.S. 0.50	3
23	93–3371	Asm. – Rod, Connecting (Incl. Ref. #16, 17 & 29–30)	3
24	43–1810	Ring – Gear	1
25	93–3358	Assembly – Sub, Flywheel (Incl. Ref. #24)	1
26	54–8670	Bolt	4
27	93–3354	Crankshaft	1
28	42–7730	Key – Woodruff	2
29		Cap – Rod, Connecting	3
30	93–3372	Nut	6
31	93–3369	Cap – Sealing	2
32	93–3367	Plug – Taper	1
33	93–3368	Bolt	4
34	93–3362	Bushing – Camshaft	1
35	93–3350	Gear – Camshaft	1
36	93–3353	Bushing – Idler	1
*	93–3379	Set – Ring, Piston O.S. 0.25	3
*	93–3380	Set – Ring, Piston O.S. 0.50	3

*Not Illustrated

3317–268




T–1893

CYLINDER BLOCK AND BEARING ASSEMBLY

Ref. No.	Part No.	Description	No. Used
1	56–0220	Pin – Dowel	2
2	93–3381	Cap – Sealing	2
3	67–2570	Plug – Taper	1
4	93–3382	Cap – Sealing	1
5	42–7180	Bushing	4
6	56–1230	Shaft	1
7	93–3383	Seal – Side	4
8	56–0100	Plug – Taper	1
9	93–3385	Cap – Metal	1
10	42–9210	Bolt – Cap, Bearing	8

Ref. No.	Part No.	Description	No. Used
14	93–3387	Bearing – Set Std.	1
*	93–3597	Bearing – Set U.S. 0.25 mm	1
*	93–3388	Bearing – Set U.S. 0.50 mm	1
*	93–3389	Bearing – Set U.S. 0.75 mm	1
15	93–3386	Cap – Sealing	3
16	72–6950	Retainer	1
17	42–7200	Bushing	1
18	42–7160	Pin – Dowel	1
19	42–7170	Plug – Expansion	1
20	93–3384	Cylinder Block Assembly (Incl. Ref. # 2, 9, & 10. Also #31, 32, & 34 on Page 36)	1

*Not Illustrated



T−1894


VALVE, CAMSHAFT AND ROCKER ASSEMBLY

Ref. No.	Part No.	Description	No. Used
1	42−7990	Ring − Snap	2
2		Shaft − Rocker	1
3		Rocker	6
4	93−3401	Screw − Rocker	6
5	70−2970	Nut − Jam	6
6	93−3403	Bracket − Shaft, Rocker	2
7	93−3406	Spring − Rocker	2
8	93−3405	Cap − Sealing	2
9	93−3399	Bolt	1
10	93−3407	Bolt − Bracket, Rocker	3
11	93−3402	Bracket, Shaft, Rocker	1
12	93−3397	Cap − Valve	6
13	42−7860	Seal	6
14	67−3100	Retainer	6
15	92−1961	Seal	6
16	93−3396	Spring − Valve	6
17	93−3410	Bolt W/Washer	1
18	42−9820	Washer	1

Ref. No.	Part No.	Description	No. Used
19	93−3409	Bearing	1
20	42−7840	Key − Sunk	1
21	93−3408	Shaft − Pump, Fuel Inject.	1
22	93−3411	Rod − Push	6
23	42−7890	Tappet	6
24	93−3412	Camshaft	1
25	42−7730	key − Woodruff	1
26	60−7390	Plate − Thrust	1
27	67−2340	Bolt W/Washer	2
28	93−3395	Valve − Exhaust	3
29	93−3394	Valve − Inlet	3
*	93−3398	Asm. − Rocker & Shaft (Incl. Ref. #1−11)	1
*	93−3404	Assembly − Shaft (Incl. Ref. #2 & 8)	1
*	93−3400	Assembly − Rocker (Incl. Ref. #3−5)	1

*Not Illustrated

3317−268




T−1895

OIL PAN, PUMP RELIEF VALVE

Ref. No.	Part No.	Description	No. Used
1	93−3418	Gauge − Level, Oil	1
2	42−8830	O−Ring	1
3	93−7013	Guide − Gauge, Oil Level	1
4	93−4295	Assembly − Filter, Oil	1
5	56−1310	Switch − Oil	1
6	92−1920	Plug − Drain	1
7	92−1921	Gasket − Plug, Drain	1
8		Pan − Oil	1
9	93−3422	Assembly − Pan, Oil (Incl. Ref. #6 − 8)	1
10	67−2340	Bolt W/Washer	15
11	93−3414	Gasket	1
12	48−1990	Nut − Jam	1
13	93−3413	Assembly − Strainer (Incl. Ref. #12)	1
14	93−3421	Bolt	3
15	93−3420	Assembly − Pump, Oil	1
16	93−3417	Gasket	1
17	93−3416	Housing	1
18	67−2500	Plunger	1

Ref. No.	Part No.	Description	No. Used
19	42−8930	Spring	1
20	42−7290	Gasket	1
21	67−2520	Plug	1
22	93−3415	Assembly − Valve, Relief (Incl. Ref. #16−21)	1
23	93−4291	Fitting − Pump, Water	1
24	93−4296	Clamp−R	1
25	93−4290	Connector − Cooler	1
26	93−4285	Cooler − Oil, Engine	1
27	93−4297	Clamp − Hose	4
28	93−4289	Hose − Cooler, Outlet	1
29	93−4288	Fitting − Block, Engine	1
30	93−4287	O−Ring	1
31	93−4284	Spacer − Cooler, Engine	1
32	93−4286	O−Ring	1
33	93−4294	Hose − Cooler, Inlet	1
34	42−9440	Bolt with Washer	1
35	93−4292	Cover − Spiral Tube	1
*	93−3599	Gasket − Liquid (for Oil Pan)	1

* Not Illustrated.



T–1896


CYLINDER HEAD, MANIFOLD & COVER ASSEMBLY

Ref. No.	Part No.	Description	No. Used
1	67–4580	Bolt	2
2	60–7280	Bolt	4
3	42–9570	Stud	4
4	93–3423	Gasket	1
5	93–3424	Gasket – Cover, Rocker	1
6	42–7440	Hanger – Engine	2
7	42–7080	Cap – Sealing	5
8	93–3425	Guide – Valve, In	3
9	93–3435	Bolt W/Washer	4
10	42–7420	Cap – Oil	1
11	93–3433	Assy. – Cover, Rocker (Ref. #12)	1
12	42–7510	Pipe	1
13	93–3594	Hose – Breather	1
14	93–3426	Bolt – Head, Cylinder	11
15	93–3427	Guide – Valve	3
16	67–2570	Plug – Taper	1

Ref. No.	Part No.	Description	No. Used
17	93–3428	Cylinder Head Assembly (Ref. #7, 8, 15. 28 & 29)	1
18	93–3434	Gasket – Cover, Inlet	1
19	93–3598	Cap – Sealing	1
20	93–3438	Assy. – Cover, Inlet (Ref. #19)	1
21	93–3440	Pipe – Inlet	1
22	92–2143	Bolt W/Washer	5
23	93–3442	Bolt W/Washer	1
24	93–3443	Bolt W/Washer	1
25	93–3441	Gasket – Pipe, Inlet	1
26	93–3431	Gasket – Head, Cylinder	1
27	93–3432	Bolt W/Washer	2
28	93–3430	Jet – Combustion	3
29	93–3429	Cap – Sealing	1
30	93–3436	Gasket – Exhaust	1
31	93–3437	Asm. – Manifold, Exhaust	1
32	93–3595	Clip – Hose	1

*Not Illustrated

3317–268




T–1897

TIMING GEAR CASE

Ref. No.	Part No.	Description	No. Used
1	93–3444	Cap – Filler	1
2	93–3445	Gasket – Gear	1
3	67–2340	Bolt W/Washer	7
4	93–3446	Plate – Front	1

Ref. No.	Part No.	Description	No. Used
5	93–3447	Gasket – Plate, Front	1
6	93–3448	Case – Gear	1
7	42–7390	Seal – Oil	1
8	93–3449	Bolt	8




T–1898

WATER PUMP ASSEMBLY

Ref. No.	Part No.	Description	No. Used
1	93–3459	Bolt W/Washer	4
2	93–3458	Pulley – Pump, Water	1
3	93–3460	V–Belt	1
4	93–3456	Bolt W/Washer	3
5	93–3452	Joint	1
6	93–3451	Bolt W/Washer	2

Ref. No.	Part No.	Description	No. Used
7	93–3450	Assembly – Pump, Water (Incl. Ref. #5–6 & 8–9)	1
8	93–3453	Gasket	1
9	93–3454	Plate	1
10	93–3455	Gasket – Pump, Water	1
11	93–3457	Bolt W/Washer	1

3317–268




T–1899

FUEL INJECTION PUMP ASSEMBLY

Ref. No.	Part No.	Description	No. Used
1	72–0270	Nut – Retaining	3
2	93–3503	Assembly – Nozzle	3
3	72–0280	Piece – Distance	3
4	93–3502	Pin – Pressure	3
5	93–3501	Spring – Pressure	3
6	93–3491	Washer – 1.25 mm	A/R
*	93–3492	Washer – 1.3 mm	A/R
*	93–3493	Washer – 1.35 mm	A/R
*	93–3494	Washer – 1.4 mm	A/R
*	93–3495	Washer – 1.45 mm	A/R
*	93–3496	Washer – 1.5 mm	A/R
*	93–3497	Washer – 1.55 mm	A/R
*	93–3498	Washer – 1.6 mm	A/R
*	93–3499	Washer – 1.65 mm	A/R
*	93–3500	Washer – 1.7 mm	A/R
7	93–3490	Assembly – Sub, Body	3
8	93–3480	Screw – Bleeder, Air	1
9	93–3481	Washer – Union , Pipe	1
10	93–3479	Screw – Hollow	1
11	93–3467	Assembly – Sub, Element	3
12	93–3466	Assembly – Sub, Valve	3
13	93–3465	Gasket – Delivery, Valve	3
14	93–3464	Spring – Delivery, Valve	3
15	93–3474	O–Ring	3
16	93–3463	Holder – Delivery, Valve	3
17	93–3488	Rivet	2

Ref. No.	Part No.	Description	No. Used
18	93–3487	Plate – Name	1
19	93–3478	Bolt – Washer Head	2
20	93–3477	Plate – Adjusting	2
21	93–3475	Pin – Guide, Tappet	3
22	93–3476	Plate	1
23	93–3472	Assembly – Control, Rack	1
24	93–3468	Sleeve – Control	3
25	93–3469	Seat – Spring, Upper	3
26	93–3470	Spring – Plunger	3
27	93–3473	Seat – Spring, Lower	3
28	70–3970	Plate – Shim .6 mm	A/R
*	70–4070	Plate – Shim .2 mm	A/R
*	70–4080	Plate – Shim .3 mm	A/R
*	70–4090	Plate – Shim .4 mm	A/R
*	70–4100	Plate – Shim .5 mm	A/R
*	93–3482	Plate – Shim .25 mm	A/R
*	93–3483	Plate – Shim .35 mm	A/R
*	93–3484	Plate – Shim .45 mm	A/R
*	93–3485	Plate – Shim .55 mm	A/R
*	93–3486	Plate – Shim .65 mm	A/R
29	93–3471	Assembly – Sub, Tappet	3
30	93–3462	Assembly – Sub, Housing	1
*	93–3461	Assembly – Pump, Fuel (Incl. Ref. #8–30)	1
*	93–3489	Assembly – Nozzle & Holder (Incl. Ref. #1–7)	1

*Not Illustrated




T–1900

THERMOSTAT AND ALTERNATOR MOUNT ASSEMBLY

Ref. No.	Part No.	Description	No. Used
1	93–3523	Assembly – Hose, Fuel (Incl. Ref. #20)	1
2	93–3528	Plug	1
3	93–3525	Gauge	1
4	56–2020	Bolt W/Washer	2
5	56–1360	Fitting – Outlet, Water	1
6	42–7550	Gasket	1
7	93–3524	Thermostat	1
8	93–3521	Gasket – Case, Thermostat	1
9	93–3527	Gasket	1
10	93–3526	Switch	1
11	93–3519	Assembly – Case, Therm. (Incl. Ref. #21)	1

Ref. No.	Part No.	Description	No. Used
12	93–3509	Nut	1
13	93–3510	Washer – Spring	1
14	93–3511	Washer – Plain	1
15	93–3512	Bolt – Alternator	1
16	93–3508	Plate – Adjusting	1
17	54–8660	Washer	1
18	67–4660	Bolt – Flange Head	1
19	93–3522	Bolt W/Washer	3
20	56–1400	Clip	2
21	93–3520	Pipe	1

3317–268




T–1901

FUEL AND STARTER SYSTEM ASSEMBLY

Ref. No.	Part No.	Description	No. Used
1	42–9830	Washer – Seal	2
2	93–3518	Nipple – Swivel	1
3	93–3517	Bolt	4
4	67–3390	Gasket – Holder	3
5	42–8010	Shim – 0.2 mm	A/R
*	42–8020	Shim – 0.3 mm	A/R
*	42–8030	Shim – 0.4 mm	A/R
*	42–8040	Shim – 0.5 mm	A/R
*	42–8050	Shim – 0.6 mm	A/R
*	42–8060	Shim – 0.7 mm	A/R
*	42–8070	Shim – 0.8 mm	A/R
*	42–8080	Shim – 0.9 mm	A/R
*	42–8090	Shim – 1.0 mm	A/R
6	93–3507	Plate – Connection	1
7	93–3513	Pipe – Injector No.1	1
8	56–0750	Clamp A	2
9	43–2860	Bolt W/Washer	2
10	93–3514	Pipe – Injector No.2	1
11	93–3515	Pipe – Injector No.3	1
12	56–0760	Clamp B	2

Ref. No.	Part No.	Description	No. Used
13	67–3430	Nut	3
14	67–3440	Gasket – Return, Fuel	3
15	93–3516	Pipe – Leak Off, Fuel	1
16	93–3506	Plug – Glow	3
18	93–3393	Bolt	5
19	93–3390	Case – Seal, Oil	1
20	93–3392	Seal – Oil	1
21	93–3391	Gasket – Seal, Oil	1
22	93–3504	Assembly – Solenoid	1
23	43–2750	Nut	1
24	93–3505	Bracket – Starter	1
25	42–9240	Bolt W/Washer	3
26	67–2440	Bolt W/Washer	2
27	43–2580	Magnet	1
28	43–2560	Gasket	1
29	43–2550	Filter	1
30	43–2570	Gasket	1
*	53–8150	Assembly – Pump, Electric (Incl. Ref. #27–30)	1

*Not Illustrated




T–1902

GOVERNOR

Ref. No.	Part No.	Description	No. Used
1	93–3529	Assembly – Case, Governor	1
2	67–4240	Cap	1
3	93–3554	Bolt – Case, Governor	1
4	93–3553	Bolt	3
5	42–8690	Metal	1
6	93–3552	Wire	1
7	67–4180	Nut	1
8	67–4200	Nut	1
9	67–4220	Screw – Adjusting	1
10	93–3537	Spring – Torque	2
11	93–3536	Stopper	1
12	67–4210	Case	1
13	93–3535	Spring Set – Torque (Incl. Ref. #7–12)	1
14	93–3547	Spring – Rod, Tie	1
15	93–3546	Rod – Tie	1
16	93–3534	Spring – Governor	1
17	93–3542	Lever – Spring, Governor	1
18	93–3530	Pin – Spring	1

Ref. No.	Part No.	Description	No. Used
19	93–3543	Lever – Tension	1
20	42–7310	Bearing – Needle	2
21	93–3538	Spring – Start	1
22	93–3544	Lever – Governor	1
23	93–3539	Shim – Shaft, Governor	1
24	93–3545	Shaft – Governor	1
25	93–3531	O–Ring	1
26	93–3549	Shaft – Sleeve, Sliding	1
27	93–3550	Sleeve – Sliding	1
28	93–3551	Weight	1
29	93–3548	Gasket – Case, Governor	1
30	42–8810	Pin – Grooved	1
31	93–3533	Bolt – Speed Set	2
32	67–4290	Nut	2
33	93–3532	Nut – Jam	1
34	67–3260	Washer – Spring	1
35	93–3540	Lever – Speed	1
36	93–3541	Case – Governor	1




T–1903

STARTER ASSEMBLY

Ref. No.	Part No.	Description	No. Used
1	93–3576	Stopper Set	1
2	93–3567	Pinion Set (Incl. Ref. #1)	1
3	93–3556	Screw Set (Incl. Ref. #19)	1
4	93–3557	Assembly – Bracket, Front	1
5	93–3558	Assembly – Lever	1
6	93–3559	Spring Set	1
7	93–3560	Assembly – Bracket, Center	1
8	93–3561	Assembly – Switch	1
9	93–3572	Bolt Set	1
10	93–3570	Cover Set	1
11	93–3569	Gear	1
12	67–4790	Assembly – Shaft, Pinion	1
13	93–3563	Bearing – Front	1
14	93–3564	Bearing – Rear	1

Ref. No.	Part No.	Description	No. Used
15	93–3571	Assembly – Yoke	1
16	93–3573	Assembly – Holder (Incl. Ref. 20)	1
17	93–3575	Assembly – Bracket, Rear	1
18	93–3565	Bolt Set	2
19	93–3556	Screw	1
20	93–3574	Spring – Brush	4
21	93–3568	Gear Set (Incl. Ref. #11–12)	1
*	93–3566	Assembly – Shaft, Clutch (Incl. Ref. #2, 10 & 21)	1
*	93–3562	Armature Set (Incl. Ref. #13–14)	1
*	93–3555	Assembly – Starter (Incl. Ref. #1–21)	1

*Not Illustrated



T–1904


ALTERNATOR ASSEMBLY

Ref. No.	Part No.	Description	No. Used
1	93–3578	Nut – Set	1
2	93–3579	Assembly – Pulley	1
3	93–3582	Screw Set	1
4	93–3580	Bolt Set	1
5	93–3583	Bearing – Front	1
6	93–3585	Bearing – Rear	1
7	93–3584	Assembly – Rotor	1
8	93–3591	Nut – Set	1

Ref. No.	Part No.	Description	No. Used
9	93–3590	Assembly – Rectifier	1
10	93–3581	Assembly – Bracket, Front	1
11	93–3589	Brush	2
12	93–3586	Assembly – Stator	1
13	93–3588	Regulator Set	1
14	93–3587	Assembly – Bracket, Rear	1
*	93–3577	Assembly – Alternator (Incl. Ref. #1–14)	1

*Not Illustrated

OVERHAUL GASKET KIT




OVERHAUL GASKET KIT

Ref. No.	Part No.	Description	No. Used
101	93–3417	Gasket	1
102	42–7550	Gasket	1
104	67–3440	Gasket – Fuel Return	3
105	67–3390	Gasket – Holder	3
106	92–1961	Seal – Valve Stem	6
107	42–8830	O–Ring	1
108	93–3414	Gasket	1
109	93–3527	Gasket	1
110	93–3455	Gasket – Water Pump	1
111	93–3361	Gasket – Tie Rod Cover	1
112	93–3453	Gasket – Water Pump	1
113	93–3423	Gasket	1
114	93–3383	Seal – Side	4
115	93–3391	Gasket – Oil Seal Case	1
116	93–3447	Gasket – Front Plate	1
117	93–3445	Gasket – Gear	1
118	93–3441	Gasket – Inlet Pipe	1
119	93–3593	Packing – Body	1
120	93–3521	Gasket – Thermo Case	1
121	93–3548	Gasket – Governor Case	1
122	93–3431	Gasket – Cylinder Head	1
123	93–3424	Gasket – Rocker	1
124	93–3434	Gasket – Inlet Cover	1
125	93–3436	Gasket – Exhaust	1
*	93–3592	Kit– Gasket, Complete	1

*Not Illustrated

3317–268




T–1881

ENGINE COMPONENTS ASSEMBLY

Ref. No.	Part No.	Description	No. Used
1	2412–42	Clamp – Hose	1
2	48–4220	Assembly – Air Cleaner (Incl. Ref. #4)	1
‡3	67–1700	Decal – Starting Fluid (English)	1
‡4	27–7160	Decal – Instructions	1
5	75–2851	Hose – Expansion Tank	1
6	92–2379	Clamp – Hose	1
7	63–7380	Assembly – Expansion Tank (Incl. Ref. #8)	1
8	71–1520	Cap – Expansion Tank	1
9	321–3	Screw – Cap Hex. Hd.	1
10	66–2330	Base – Battery	1
11	322–4	Screw – Cap Hex. Hd.	3
12		Battery (Type 26, 530 Amp.)	1
13	75–1370	Asm. – Battery Cable (+) (Incl. Ref. #14)	1

Ref. No.	Part No.	Description	No. Used
14	28–1280	Boot – Cable	1
15	323–9	Screw – Cap Hex. Hd.	1
16	3253–21	Washer – Lock	1
17	3256–24	Washer – Flat	1
18	66–2490	Clamp – Battery	1
19	32128–20	Nut – Lock	3
20	3296–42	Nut – Lock	3
21	75–4250	Bracket – Expansion Tank	1
22	321–6	Screw – Cap Hex. Hd.	2
23	2412–93	Clamp – R	1
24	75–3140	Bracket – Air Cleaner	1
25	3256–23	Washer – Flat	2
26	322–3	Screw – Cap Hex. Hd.	6
27	3296–29	Nut – Lock	4
28	3290–378	Tie – Cable	1

‡For different language versions of this part, see International Parts Reference.



T–0126


AIR CLEANER ASSEMBLY

Ref. No.	Part No.	Description	No. Used
1	27–7150	Assembly – Cup	1
2	27–7140	Baffle	1
3	27–7120	Nut	1
4	27–7130	Assembly – Clamp	1
5	32107–11	Nut–Square	2
6	3258–19	Screw – Machine	2
7	27–7170	Assembly – Band (Incl. Ref. #5 & 6)	2
8	27–7110	Assembly – Element	1

Ref. No.	Part No.	Description	No. Used
9†		Housing	1
10	62–6300	Assembly – Sleeve	1
11	33–1270	Bowl	1
12	33–1260	Assembly – Cover	1
*	48–7430	Assembly – Pre–Cleaner (Incl. Ref. #10–12)	1
*	48–4220	Assembly – Air Filter (Incl. Ref. #1–4, 8–9)	1
*	27–7220	Air Cleaner Soap	1

*Not Illustrated
†Not Serviceable Separately

3317−268




T−1934

FUEL FILTER ASSEMBLY

Ref. No.	Part No.	Description	No. Used
1	63−8280	Head−Filter, Fuel (Incl. Ref. #2)	1
2	63−8290	Vent−Air	1
3	63−8300	Element−Spin−On (Incl. Ref. #4)	1

Ref. No.	Part No.	Description	No. Used
4	63−8310	Valve−Drain	1
*	63−8300	Assembly − Fuel Filter	1

*Not Illustrated




REAR AXLE ASSEMBLY

Ref. No.	Part No.	Description	No. Used
1	323–7	Screw – Cap Hex. Hd.	4
2	3256–24	Washer – Flat	2
3	327–2	Screw – Cap Hex. Hd.	1
4	93–0064	Support – Rear Axle	1
5	3296–39	Nut – Lock	2
6	32153–6	Nut – Lock	2
7	32151–36	Ring – Retaining	2
8	5–1226	Washer – Shim	A/R
9	10–8110	Washer – Thrust	2
10	67–1751	Bushing – Sleeve	6
11	302–5	Fitting – Grease	4
12	256–121	Washer – Thrust	2
13	67–7250	Spacer – Cylinder	1
14	3220–3	Nut – Jam	8
15	93–7001	Spindle – Rear L.H.	1
*	93–7000	Spindle – Rear R.H.	1
16	254–94	Cone – Bearing	4
17	254–72	Cup – Bearing	4
18	21–2820	Hub – Rear Wheel	2
19	231–141	Tire	2
20	217–121	Rim	2
21	232–35	Stem – Valve	2
22	93–0309	Washer – Tab	2

Ref. No.	Part No.	Description	No. Used
23	3220–7	Nut – Jam	2
24	241–119	Cap – Dust	2
25	3272–13	Pin – Cotter	2
26	242–50	Nut – Lug	10
27	10–6830	Stud – Drive	10
28	253–129	Seal – Grease	2
29	67–9410	Washer – Thrust	2
30	328–25	Screw – Cap Hex. Hd.	1
31	237–78	O–Ring	2
32	340–103	Fitting – Hydraulic 45° (Incl. Ref. #31 & 33)	2
33	237–21	O–Ring	2
34	75–6220	Hose – Hydraulic	1
35	21–0140	Joint – Ball	2
36	3220–5	Nut – Jam	2
37	75–3130	Rod – Tie	2
38	3220–12	Nut – Jam L.H. Thread	2
39	21–0151	Joint – Ball L.H. Thread	2
40	32151–77	Ring – Retaining	1
41	76–2980	Washer – Thrust	1
42	75–4410	Assembly – Pivot Plate (Incl. Ref. #11 & 43)	1
43	76–2970	Bushing – Sleeve	2

*Not Illustrated


3317–268



REAR AXLE ASSEMBLY (Continued)

Ref. No.	Part No.	Description	No. Used
44	75–4180	Pin – Rear Axle Pivot	1
45	75–2900	Assembly – Rear Axle (Incl. Ref. #10 & 11)	1
46	237–165	Grommet	2
47	75–1200	Asm. – Hydraulic Cylinder	1

Ref. No.	Part No.	Description	No. Used
48	5–1226	Washer – Thrust	1
49	328–27	Screw – Cap Hex. Hd.	1
50	75–6230	Hose – Hydraulic	1
51	66–2990	Cap – Spindle	2
52	3234–13	Screw – Cap Flange Hd.	2




T–0996

HYDRAULIC CYLINDER NO. 75–1200

Ref. No.	Part No.	Description	No. Used
†1		Assembly – Barrel	1
2	75–1210	Nut–Lock	1
3	75–1220	Piston	1
4	75–1260	Head–Internal	1
5	75–1230	Assembly – Piston Rod	1
6	75–1250	Seal Kit	1
7	302–5	Fitting – Grease	2

†Not Serviced Separately




FRONT LIFT ARMS ASSEMBLY

Ref. No.	Part No.	Description	No. Used
1	75–5450	Assembly – Lift Arm R.H. (Incl. Ref. #9 & 11)	1
2	49–2040	Screw – Thread Forming	8
3	237–78	O–Ring	6
4	340–132	Fitting – Hydraulic 90° (Incl. Ref. #3 & 5)	5
5	237–21	Seal – O–Ring	8
7	83–7480	Asm. – Hydraulic Cylinder	1
8	75–5330	Clamp – Hose	2
9	67–1750	Bushing – Sleeve	12
10	84–8320	Insert – Hinge	4
11	302–5	Fitting – Grease	6
12	92–8002	Sensor – Reed Switch	1
13	328–12	Screw – Cap Hex. Hd.	2
14	3290–379	Tie – Cable	3
15	283–6	Pin – Clevis	3
16	75–5210	Bracket – Spring Center	1
*	75–5200	Bracket – Spring R.H.	1
*	75–5220	Bracket – Spring L.H.	1
17	3272–10	Pin – Cotter	3
18	328–7	Screw – Cap Hex. Hd.	4
19	3296–51	Nut – Lock	6
20	32151–48	Ring – Retaining	3

Ref. No.	Part No.	Description	No. Used
21	282–4	Clevis – Spring	3
22	5–0743	Spring – Extension	3
23	3296–44	Nut – Lock	4
24	3256–24	Washer – Flat	3
25	3256–23	Washer – Flat	3
26	322–5	Screw – Cap Hex. Hd.	3
27	75–4550	Shaft – Center Arm Pivot	1
28	75–5890	Hose – Hydraulic	2
29	32120–93	Ring – Retaining	6
30	3–6498	Washer – Thrust	6
31	75–5350	Pin – Cylinder Rod End	3
32	75–5460	Assembly – Lift Arm L.H. (Incl. Ref. #9 & 11)	1
‡33	55–4300	Decal – Warning (English)	3
34	3256–22	Washer – Flat	2
35	321–4	Screw – Cap Hex. Hd.	2
36	75–5370	Mount – Clamp	1
37	3296–42	Nut – Lock	2
38	75–5380	Bracket – Clamp	1
39	323–11	Screw – Cap Hex. Hd.	1
40	75–5420	Assembly – Lift Arm, Center (Incl. Ref. #9 & 11)	1
41	256–115	Washer – Thrust	11

*Not Illustrated

‡For different language versions of this part, see International Parts Reference.




FRONT LIFT ARMS ASSEMBLY (Continued)

Ref. No.	Part No.	Description	No. Used
43	83–6790	Pin – Cylinder (Short)	1
44	75–3040	Assembly – Carrier Frame (Incl. Ref. #9 & 11)	1
45	3296–29	Nut – Lock	3
46	85–9880	Asm. – Hydraulic Cylinder	1
47	75–5900	Hose – Hydraulic	1
48	32104–76	Screw – Thread Forming	2
49	75–6370	Cover – Sensor	1
51	92–8754	Actuator – Reed Switch	1
52	3296–39	Nut – Lock	2
53	75–5410	Bracket – Arm	2
54	75–3010	Joint – Arm	3
55	32121–122	Pin – Roll	3
56	323–12	Screw – Cap Hex. Hd.	2
57	3256–6	Washer – Flat	6

Ref. No.	Part No.	Description	No. Used
58	3253–7	Washer – Lock	6
59	325–4	Screw – Cap Hex. Hd.	6
60	75–5910	Hose – Hydraulic	1
61	83–6780	Pin – Cylinder (Long)	2
‡62	36–3400	Decal – No Step (English)	2
63	75–5300	Rod – Hose Support	1
64	340–13	Fitting – Straight (Incl. Ref. #5)	2
65	82–6490	Hose – Hydraulic	1
66	32144–14	Screw – Self Tapping	3
67	83–7490	Hydraulic Cylinder Asm.	1
68	3290–378	Tie – Cable	5
69	92–9097	Set Screw	3
70	340–143	Fitting – Hydraulic 90°	1
71	82–8270	Valve – Flow Control	1

‡For different language versions of this part, see International Parts Reference.

3317−268




REAR LIFT ARMS ASSEMBLY

Ref. No.	Part No.	Description	No. Used
1	3290−379	Tie − Cable	1
2	5−0743	Spring − Counterbalance	2
3	282−4	Clevis − Spring	2
4	3272−10	Pin − Cotter	2
5	32151−48	Ring − Retaining	2
6	322−5	Screw − Cap Hex. Hd.	3
7	3256−23	Washer − Flat	10
8	75−4690	Bracket − Spring Rear R.H.	1
*	75−4650	Bracket − Spring Rear L.H.	1
9	3296−29	Nut − Lock	8
10	283−6	Pin − Clevis	2
11	75−6070	Hose − Hydraulic L.H. (Cap)	1
*	75−6080	Hose − Hydraulic L.H. (Rod)	1
12	237−78	O−Ring	4
13	340−103	Fitting − Hydraulic 45° (Incl. Ref. #12 & 14)	1
14	237−21	O−Ring	4
15	75−3810	Bracket − Roller	2
16	3253−4	Washer − Lock	2
17	322−6	Screw − Cap Hex. Hd.	4
18	32151−61	Ring − Retaining	4
19	75−5400	Shaft − Roller	2
20	75−5390	Roller	2

Ref. No.	Part No.	Description	No. Used
21	75−6180	Hose − Hydraulic R.H.	2
22	340−132	Fitting − Hydraulic 90° (Incl. Ref. #12 & 14)	3
23	75−5350	Pin − Cylinder Rod End	2
24	3−6498	Washer − Thrust	4
25	32120−93	Ring − Retaining	4
26	256−115	Washer − Thrust	8
27	67−1750	Bushing − Sleeve	8
28	93−0066	Asm. − Lift Arm Rear R.H. (Incl. Ref. #27, 29 & 38)	1
*	93−0068	Asm. − Lift Arm Rear L.H. (Incl. Ref. #27, 29 & 38)	1
29	302−5	Fitting − Grease	4
30	3256−24	Washer − Flat	4
31	3296−39	Nut − Lock	6
32	322−12	Screw − Cap Hex. Hd.	2
33	5−1096	Chain − Cutting Unit	2
34	75−4590	Rod − Pivot	2
35	325−4	Screw − Cap Hex. Hd.	4
36	93−0142	Bushing − Straight	2
37	75−4520	Spring − Torsion R.H.	1
*	75−4530	Spring − Torsion L.H.	1
38	256−287	Bushing − Flange	4

*Not Illustrated
‡For different language versions of this part, see International Parts Reference.




REAR LIFT ARMS ASSEMBLY (Continued)

Ref. No.	Part No.	Description	No. Used
39	3253–7	Washer – Lock	4
40	3256–6	Washer – Flat	4
41	75–3010	Joint – Arm	2
42	3290–378	Tie – Cable	3
43	92–9097	Set Screw	2
44	32121–122	Pin – Roll	2
‡45	55–4300	Decal – Warning (English)	2
46	49–2040	Screw – Thread Forming	5
47	32151–36	Ring – Retaining	4
48	93–0079	Asm. – Hydraulic Cylinder	2
49	75–5360	Pin – Cylinder Cap End	2

Ref. No.	Part No.	Description	No. Used
50	75–5330	Clamp – Hydraulic Line	2
51	2412–107	Clamp – R (Used on left rear cutting unit lift arm only)	1
52	93–0069	Pin – Pivot	2
53	2412–74	Clamp–R	2
54	92–5791	Spacer	2
55	32144–49	Screw – Hex. Washer Hd.	2
56	93–3640	Stop – Reel	1
*	83–5170	Stop – Reel	1
57	323–6	Screw – Hex Head	2

*Not Illustrated




T–1879

HYDRAULIC CYLINDER NO. 93–0079

Ref. No.	Part No.	Description	No. Used
†1	93–3134	Assembly – Barrel	1
2	32152–10	Nut	1
†3		Uni–ring	1
4	70–2780	Piston	1
†5		O–Ring	1
†6		Seal – Rod	1
†7		O–Ring	1
†8		Backup	1

Ref. No.	Part No.	Description	No. Used
9	84–1670	Head	1
†10		Seal – Dust	1
11	84–1680	Ring – Retaining	1
12	75–3790	Clevis	1
13	302–5	Fitting – Grease	1
*	86–7330	Seal repair Kit (Incl. Ref. #3, 5–8 & 10)	1

*Not Illustrated
†Not Serviced Separately




T–1032

HYDRAULIC CYLINDER NO. 85–9880

Ref. No.	Part No.	Description	No. Used
†1		Assembly – Barrel	1
2	32152–10	Nut	1
†3		Uni–ring	1
4	70–2780	Piston	1
†5		O–Ring	1
†6		Seal – Rod	1
†7		O–Ring	1
†8		Backup	1

Ref. No.	Part No.	Description	No. Used
9	84–1670	Head	1
†10		Seal – Dust	1
11	84–1680	Ring – Retaining	1
12	75–3790	Clevis	1
13	302–5	Fitting – Grease	1
*	86–7330	Seal repair Kit (Incl. Ref. #3, 5–8 & 10)	1

*Not Illustrated
†Not Serviced Separately




T–1032

HYDRAULIC CYLINDER NO. 83–7480

Ref. No.	Part No.	Description	No. Used
†1		Assembly – Barrel	1
2	32152–10	Nut	1
†3		Uni–ring	1
4	84–1710	Piston	1
†5		O–Ring	1
†6		Seal – Rod	1
†7		O–Ring	1
†8		Backup	1
9	84–1720	Head	1
†10		Seal–Dust	1
11	84–1730	Ring – Retaining	1
12	84–1740	Clevis	1
13	302–5	Fitting – Grease	1
*	84–1760	Seal repair Kit (Incl. Ref. #3, 5–8 & 10)	1

*Not Illustrated
†Not Serviced Separately




T–1032

HYDRAULIC CYLINDER NO. 83–7490

Ref. No.	Part No.	Description	No. Used
†1		Assembly – Barrel	1
2	32152–10	Nut	1
†3		Uni–ring	1
4	70–2780	Piston	1
†5		O–Ring	1
†6		Seal – Rod	1
†7		O–Ring	1
†8		Backup	1

Ref. No.	Part No.	Description	No. Used
9	84–1670	Head	1
†10		Seal–Dust	1
11	84–1680	Ring – Retaining	1
12	75–2120	Clevis	1
13	302–5	Fitting – Grease	1
*	86–7330	Seal Repair Kit (Incl. Ref. #3, 5–8 & 10)	1

*Not Illustrated
†Not Serviced Separately



T–1304

R.O.P.S. ASSEMBLY (Optional)


Ref. No.	Part No.	Description	No. Used
1	83–7410	Roll – Bar	1
‡2	85–9980	Decal – R.O.P.S.	1
‡3	83–7430	Decal – Danger (English)	1
4	3256–26	Washer – Flat	9
5	3253–7	Washer – Lock	9

Ref. No.	Part No.	Description	No. Used
6	325–5	Screw – Cap Hex. Hd.	9
7	3217–9	Nut – Lock	3
*	21–4191	Assembly – Seat Belt	1
*	3212–4	Screw – Cap Hex. Hd.	2
*	3253–6	Washer – Lock	2

*Not Illustrated
‡For different language versions of this part, see International Parts Reference.

SPECIAL TOOLS

AXLE TOOL NO. *TOR859920



T–1325

Ref. No.	Part No.	Description	No. Used
1		Tool – Axle	1

*Obtain these items directly from OTC 2013 4th St. Owatonna, MN. 55060 1–800–533–0492 (in Minnesota and Canada 1–507–455–7050) Fax. 507–455–7011.

INTERNATIONAL PARTS REFERENCE
EUROPEAN PARTS KIT NO. 93–7184

DESCRIPTION	LOCATION	PART NUMBER	
		ENGLISH	EUROPEAN
Decal No Step	Lift Arms	36–3400	93–6687
Decal Diesel Only	Left Fender	52–1320	93–6680
Decal Spring Loaded	Lift Arms	55–4300	93–6696
Decal Instructions	Air Cleaner	27–7160	93–8052
Decal No Starting Fluid	Air Cleaner	67–1700	93–6692
Decal Hydraulic Oil	Right Fender & Frame	85–4730	93–6686
Decal Floor Plate	Main Frame	88–0440	93–6693
Decal Bolt	Frame	77–0490	93–6691
Cap Hydraulic Oil	Hydraulic Reservoir	93–3103	93–7160
Decal Backlap	Backlap Bracket	75–0750	93–6684
Decal Towing	Tool Box Cover	75–1280	93–6698
Decal No Riders	Fenders	75–5190	93–6689
Decal Fast/Slow	Steering Tower	75–6710	93–6699
Panel Tower	Steering Tower	93–3139	93–6682
Decal Clip	Under Seat Plate	85–4610	DANISH 92–1125 DUTCH 92–1126 ITALIAN 92–1127 SPANISH 92–1128 GERMAN 92–1129 FRENCH 92–1130 SWEDISH 92–1131 PORTUGESE 93–8057 NORWEGIAN 93–8058 FINNISH 93–8059
Decal Reels	Under Seat Plate	85–4530	93–8061
Decal Knobs	Seat Plate	83–7440	93–6694

DESCRIPTION	LOCATION	PART NUMBER	
		ENGLISH	EUROPEAN
Decal Slopes	Tool Box	93–3639	93–8057
Decal This End Down	Radiator Screen	83–7450	93–8056
Plate Warning	Fan Shroud	76–8750	93–6681
Guard Fan	Fan & Alternator Area	–	93–7182
Decal Fuses	Inside Control Box	85–4720	93–6695
Panel Console	Control Console	93–3140	93–6683
Kit Lift Control	Control Console	–	93–7183
Decal Service Instructions	Inside Tool Box	93–3601	DANISH 93–8091 DUTCH 93–8092 ITALIAN 93–8093 SPANISH 93–8094 GERMAN 93–8095 FRENCH 93–8096 SWEDISH 93–8097 PORTUGESE 93–8098 NORWEGIAN 93–8099 FINNISH 93–7154
Decal Hands/Feet	Cutting Unit Frames	67–7960	93–6688
Decal Seat Belts	R.O.P.S. Roof	83–7430	93–8050
Decal R.O.P.S.	R.O.P.S. Roof	85–9980	93–8055
Decal HOC Instructions	Under Control Console	85–4460	93–6690
Decal Diagnostic	A.C.E. Display	85–4760	DANISH 92–8078 DUTCH 93–8079 ITALIAN 93–8080 SPANISH 93–8081 GERMAN 93–8082 FRENCH 93–8083 SWEDISH 93–8084 PORTUGESE 93–8085 NORWEGIAN 93–8086 FINNISH 93–8087
Decal Lubrication	4WD Rear Axle Tube	70–2560	93–6697
Decal C.E.	Hood	–	93–7252

INTERNATIONAL PARTS REFERENCE (Continued)

JAPANESE PARTS KIT NO. 83–6880

DESCRIPTION	LOCATION	PART NUMBER	
		ENGLISH	JAPANESE
Decal No Step	Lift Arms	36–3400	84–2780
Decal Diesel Only	Left Fender	52–1320	84–2860
Decal Spring Loaded	Lift Arms	55–4300	84–2940
Decal Instructions	Air Cleaner	27–7160	93–8052
Decal No Starting Fluid	Air Cleaner	67–1700	84–3100
Decal Hydraulic Oil	Right Fender & Frame	85–4730	88–1980
Decal Bolt	Frame	77–0490	80–4880
Cap Hydraulic Oil	Hydraulic Reservoir	93–3103	93–7160
Decal Backlap	Backlap Bracket	75–0750	84–3260
Decal Towing	Tool Box Cover	75–1280	84–3340
Decal No Riders	Fenders	75–5190	84–3420
Decal Fast/Slow	Steering Tower	75–6710	84–3500
Panel Tower	Steering Tower	93–3139	93–6682
Decal Clip	Under Seat Plate	85–4610	92–1124
Decal Reels	Under Seat Plate	85–4530	92–1108
Decal Knobs	Seat Plate	83–7440	84–3900

DESCRIPTION	LOCATION	PART NUMBER	
		ENGLISH	JAPANESE
Decal Slopes	Tool Box	93–3639	84–3660
Decal This End Down	Radiator Screen	83–7450	84–3820
Plate Warning	Fan Shroud	76–8750	93–6681
Guard Fan	Fan & Alternator Area	–	93–7182
Decal Fuses	Inside Control Box	85–4720	84–4060
Panel Console	Control Console	93–3140	93–6683
Kit Lift Control	Control Console	–	93–7183
Decal Service Instructions	Inside Tool Box	93–3601	92–1116
Decal Hands/Feet	Cutting Unit Frames	67–7960	84–4220
Decal Seat Belts	R.O.P.S. Roof	83–7430	84–4300
Decal R.O.P.S.	R.O.P.S. Roof	85–9980	93–8055
Decal HOC Instructions	Under Control Console	85–4460	92–1132
Decal Floor Plate	Main Frame	88–0440	88–1900
Decal Diagnostic	A.C.E. Display	85–4760	93–8089
Decal Lubrication	4WD Rear Axle Tube	70–2560	93–6697

TORO PART NUMBER INDEX

Part No.	Description	Pg. No.	Ref. No.	Qty.
3–3251	Spring – Compression	3	12	1
3–6498	Washer – Thrust	27	22	2
3–6498	Washer – Thrust	58	24	4
3–6498	Washer – Thrust	56	30	6
3–6657	Clamp – Cable	33	13	1
3–6657	Clamp – Cable	6	29	1
5–0652	Spacer	5	42	1
5–0743	Spring – Counterbalance	58	2	2
5–0743	Spring – Extension	56	22	3
5–0838	Washer – Flat	6	36	4
5–1096	Chain – Cutting Unit	58	33	2
5–1226	Washer – Shim	53	8	A/R
5–1226	Washer – Thrust	54	48	1
7–3900	Pad – Brake	5	26	2
10–6830	Stud – Drive	53	27	10
10–8110	Washer – Thrust	53	9	2
21–0140	Joint – Ball	53	35	2
21–0151	Joint – Ball L.H. Thread	53	39	2
21–2820	Hub – Rear Wheel	53	18	2
21–4191	Assembly – Seat Belt	64	*	1
21–7670	Case–Differential	24	33	1
21–7690	Gear–Pinion	23	6	2
21–7700	Shaft–Pinion Mate	24	31	1
21–7710	Pin–Roll	24	30	1
21–7720	Washer–Thrust	23	4	2
21–7730	Washer–Thrust	23	7	2
21–7770	Screw–Drive Gear	24	32	5
21–8020	Spacer–Front Pinion	24	25	1
21–8090	Diff. Adjust. Shim .003	24	38	A/R
21–8100	Diff. Adjust. Shim .005	24	37	A/R
21–8110	Diff. Adjust. Shim .010	24	36	A/R
21–8120	Diff. Adjust. Shim .030	24	35	A/R
21–8180	Bearing	25	3	2
21–8270	Pin–Dowel	23	3	2
21–8360	Clip–Retaining	25	12	2
21–8390	Cup–Bearing	24	24	1
21–9260	Seal – Shaft	3	27	1
21–9370	Screw–Adjusting	25	16	2
21–9380	Nut–Pivot	25	17	2
21–9390	Socket–Adjusting Screw	25	15	2
21–9420	Spring–Shoe Return, L.H.	25	19	2
21–9430	Spring–Shoe Return, R.H.	25	7	2
21–9440	Spring–Adjusting Screw	25	14	2
21–9450	Shield–Dust	25	5	2
21–9460	Retainer–Brake, Parking	25	10	4
23–2270	Bushing – Rubber	27	26	1
23–7270	Nut – Lug	21	2	10
24–0760	Exchanger – Heat	30	45	1
24–8790	Gear–Bevel, Differential	23	5	2
24–8840	Ring–Bearing, Wheel	25	22	2
24–9180	Lever, Brake, Parking	25	4	2
25–8640	Screw – Hex. Head	6	25	2
27–2360	Assembly – Ignition Switch	10	19	1
27–3710	Dipstick – Axle	22	48	1
27–5340	Hose – Fuel	20	11	1
27–6852	Shaft–Axle, Flanged R.H.	25	*	1
27–6862	Shaft–Axle, Flanged L.H.	25	1	1
27–7110	Assembly – Element	51	8	1
27–7120	Nut	51	3	1
27–7130	Assembly – Clamp	51	4	1
27–7140	Baffle	51	2	1
27–7150	Assembly – Cup	51	1	1
27–7160	Decal – Instructions	50	4	1
27–7170	Assembly – Band	51	7	2
27–7220	Air Cleaner Soap	51	*	1
27–9560	Spacer	34	53	1
28–0660	Screw–Cap, Hex Hd.	25	21	8
28–0670	Seal–Oil	25	8	2
28–0680	Drum–Brake	25	13	2
28–1280	Boot – Cable	50	14	1
29–6162	Switch – Neutral	27	6	1
33–1260	Assembly – Cover	51	12	1
33–1270	Bowl	51	11	1
36–3400	Decal – No Step (English)	57	62	2
38–3400	Guard – Rubber	16	8	2
42–6080	Shim – Axle	21	43	A/R
42–7080	Cap – Sealing	39	7	5
42–7160	Pin – Dowel	36	18	1
42–7170	Plug – Expansion	36	19	1
42–7180	Bushing	36	5	4
42–7190	Bushing	35	5	2
42–7200	Bushing	36	17	1
42–7290	Gasket	38	20	1
42–7310	Bearing – Needle	45	20	2
42–7390	Seal – Oil	40	7	1
42–7420	Cap – Oil	39	10	1
42–7440	Hanger – Engine	39	6	2
42–7510	Pipe	39	12	1
42–7550	Gasket	43	6	1
42–7550	Gasket	49	102	1
42–7730	Key – Woodruff	35	28	2
42–7730	key – Woodruff	37	25	1
42–7840	Key – Sunk	37	20	1
42–7860	Seal	37	13	6
42–7890	Tappet	37	23	6
42–7990	Ring – Snap	37	1	2
42–8010	Shim – 0.2 mm	44	5	A/R
42–8020	Shim – 0.3 mm	44	*	A/R
42–8030	Shim – 0.4 mm	44	*	A/R
42–8040	Shim – 0.5 mm	44	*	A/R
42–8050	Shim – 0.6 mm	44	*	A/R
42–8060	Shim – 0.7 mm	44	*	A/R
42–8070	Shim – 0.8 mm	44	*	A/R
42–8080	Shim – 0.9 mm	44	*	A/R
42–8090	Shim – 1.0 mm	44	*	A/R
42–8690	Metal	45	5	1
42–8810	Pin – Grooved	45	30	1
42–8830	O–Ring	38	2	1
42–8830	O–Ring	49	107	1
42–8930	Spring	38	19	1
42–9210	Bolt – Cap, Bearing	36	10	8
42–9240	Bolt W/Washer	44	25	3
42–9250	Screw – Cap Hex. Hd.	33	40	10
42–9300	Screw – Cap Hex. Hd.	34	64	1
42–9440	Bolt W/Washer	35	6	4
42–9440	Bolt with Washer	38	34	1
42–9570	Stud	39	3	4
42–9600	Washer – Flat	34	65	1
42–9810	Washer – Plain	35	13	1
42–9820	Washer	37	18	1
42–9830	Washer – Seal	44	1	2
42–9850	Washer – Lock	32	16	6
42–9850	Washer – Lock	33	28	1
43–1810	Ring – Gear	35	24	1
43–2550	Filter	44	29	1
43–2560	Gasket	44	28	1
43–2570	Gasket	44	30	1
43–2580	Magnet	44	27	1
43–2740	Gasket	32	8	1
43–2750	Nut	44	23	1
43–2750	Nut – Lock	32	9	1
43–2860	Bolt W/Washer	44	9	2
43–5930	Washer – Lock	33	26	1
43–6710	Diff. Adjust. Shim .003	23	15	A/R
43–6711	Diff. Adjust. Shim .005	23	16	A/R
43–6712	Diff. Adjust. Shim .010	23	17	A/R
43–6713	Diff. Adjust. Shim .030	23	18	A/R
43–6750	Cup–Bearing, Tapered	23	10	1
43–6760	Cone–Bearing, tapered	23	9	1
43–6800	Nut–Lock	25	18	8
43–6810	Spider–Torque	25	6	2
44–2210	Assembly – Warning Light	10	6	1

*Not Illustrated

TORO PART NUMBER INDEX (Cont.)

Part No.	Description	Pg. No.	Ref. No.	Qty.
44–2670	Hose – Fuel	20	18	1
46–6550	Connector – Fuel, Elbow 90°	20	20	1
46–6560	Grommet	20	21	2
46–8091	Screw – Cap Hex. Hd.	1	7	4
47–0110	Spacer – Spindle	33	6	1
48–1990	Nut – Jam	38	12	1
48–4220	Assembly – Air Cleaner	50	2	1
48–4220	Assembly – Air Filter	51	*	1
48–7430	Assembly – Pre–Cleaner	51	*	1
48–7700	Screw – Cap Hex. Hd.	33	21	1
48–7710	Screw – Cap Hex. Hd.	32	20	2
48–7890	Nut – Hex.	33	27	1
48–7930	Nut – Lock	32	17	4
48–8070	Washer – Lock	33	39	10
49–2040	Screw – Hex. Washer Hd.	16	20	4
49–2040	Screw – Hex. Washer Hd.	2	49	2
49–2040	Screw – Thread Forming	56	2	8
49–2040	Screw – Thread Forming	59	46	5
49–6440	Plate – Traction Pedal	5	11	1
52–1320	Decal – Fuel (English)	1	28	1
53–8150	Assembly – Fuel Pump	20	2	1
53–8150	Assembly – Pump, Electric	44	*	1
53–9680	Mount – Engine	34	46	2
54–8660	Washer	43	17	1
54–8670	Bolt	35	26	4
54–9040	Yoke – End	32	1	1
54–9180	Kit – U–Joint	32	25	1
55–4300	Decal – Warning (English)	56	33	3
55–4300	Decal – Warning (English)	59	45	2
56–0100	Plug – Taper	36	8	1
56–0220	Pin – Dowel	36	1	2
56–0750	Clamp A	44	8	2
56–0760	Clamp B	44	12	2
56–1230	Shaft	36	6	1
56–1310	Switch – Oil	38	5	1
56–1360	Fitting – Outlet, Water	43	5	1
56–1400	Clip	43	20	2
56–2020	Bolt W/Washer	43	4	2
57–6390	Nut – Lock	33	37	2
60–7280	Bolt	39	2	4
60–7390	Plate – Thrust	37	26	1
61–2790	Screen – Filler	13	3	1
62–3820	Fitting – Grease	32	24	1
62–5550	Decal – TORO	1	1	1
62–6300	Assembly – Sleeve	51	10	1
62–7400	Decal – TORO	1	16	1
62–7650	Gasket – Sending Unit	20	7	1
63–6890	Hinge – Hood R.H.	1	*	1
63–6900	Hinge – Hood L.H.	1	17	1
63–7380	Assembly – Expansion Tank	50	7	1
63–7400	Washer – Flat	33	34	4
63–7430	Gauge – Temperature	10	8	1
63–7440	Solenoid – Stop	32	10	1
63–7590	Relay – Starter	30	42	1
63–7610	Hose – Fuel	20	1	1
63–7628	Hose – Fuel	20	29	1
63–7640	Unit – Sending	20	8	1
63–7650	Filter – Fuel	20	32	1
63–7732	Cable – Brake R.H.	5	*	1
63–7733	Cable – Brake L.H.	5	29	1
63–7880	Pin – Brake Latch	5	28	1
63–7900	Rack – Parking Brake	3	20	1
63–8140	Pulley – Idler	34	58	1
63–8280	Head–Filter, Fuel	52	1	1
63–8290	Vent–Air	52	2	1
63–8300	Assembly – Fuel Filter	52	*	1
63–8300	Element–Spin–On	52	3	1
63–8310	Valve–Drain	52	4	1
63–8360	Key – Ignition	10	9	1
63–8410	Washer – Flat	20	27	3
63–8410	Washer – Flat	13	37	3
63–9920	Decal – EEC 105	6	46	1
65–5100	Handle	1	5	2
66–2330	Base – Battery	50	10	1
66–2490	Clamp – Battery	50	18	1
66–2920	Washer – Friction	6	32	2
66–2940	Gauge – Fuel	10	1	1
66–2960	Cluster – Warning	10	7	1
66–2990	Cap – Spindle	54	51	2
66–3180	Tube – Vent	30	26	1
66–3240	Cap – Radiator	30	13	1
66–6480	Washer – Flat	21	44	4
66–8121	Standpipe – Elbow 90°	20	19	1
66–8520	Bumper – Down–stop	7	17	2
66–8530	Adjuster	7	16	1
66–8560	Nut – Push	7	11	4
66–8610	Weldment – Lower	7	10	1
66–8800	Relay – Glow Plug	31	56	1
66–9290	Spacer	7	15	6
66–9302	Screw – Cap Hex. Hd.	32	19	3
66–9303	Screw – Cap Hex. Hd.	32	6	3
66–9770	Seal	4	28	1
66–9780	Bushing	4	29	1
66–9860	Upper Cover & Jacket	4	37	1
66–9870	Plate – Retaining	4	38	1
66–9880	Washer – Retaining Plate	4	39	1
66–9890	Ring – Retaining	4	40	1
66–9900	Shaft – Input	4	41	1
66–9970	Spring Kit	4	*	1
66–9980	Seal – Kit	4	*	1
66–9990	Needle Roller Kit	4	*	1
67–1630	Spacer – Fan	33	10	1
67–1690	Fitting – Fuel Elbow 90°	20	35	2
67–1700	Decal – Starting Fluid	50	3	1
67–1750	Bushing – Sleeve	56	9	12
67–1750	Bushing – Sleeve	58	27	8
67–1751	Bushing – Sleeve	53	10	6
67–2340	Bolt W/Washer	40	3	7
67–2340	Bolt W/Washer	38	10	15
67–2340	Bolt W/Washer	37	27	2
67–2440	Bolt W/Washer	44	26	2
67–2500	Plunger	38	18	1
67–2520	Plug	38	21	1
67–2570	Plug – Taper	36	3	1
67–2570	Plug – Taper	39	16	1
67–3100	Retainer	37	14	6
67–3260	Washer – Spring	45	34	1
67–3390	Gasket – Holder	44	4	3
67–3390	Gasket – Holder	49	105	3
67–3430	Nut	44	13	3
67–3440	Gasket – Fuel Return	49	104	3
67–3440	Gasket – Return, Fuel	44	14	3
67–4180	Nut	45	7	1
67–4200	Nut	45	8	1
67–4210	Case	45	12	1
67–4220	Screw – Adjusting	45	9	1
67–4240	Cap	45	2	1
67–4290	Nut	45	32	2
67–4580	Bolt	39	1	2
67–4660	Bolt – Flange Head	43	18	1
67–4790	Assembly – Shaft, Pinion	46	12	1
67–7160	Block – Fuse	10	21	1
67–7250	Spacer – Cylinder	53	13	1
67–9410	Washer – Thrust	53	29	2
68–5140	Cap – Steering Wheel	3	7	1
68–5370	Decal – TORO	3	5	1
68–6150	Breather – Hydraulic Tank	13	2	1
69–4780	Clamp – Light Cluster	11	42	1
70–2780	Piston	60	4	1
70–2780	Piston	61	4	1
70–2780	Piston	63	4	1
70–2970	Nut – Jam	37	5	6

*Not Illustrated

TORO PART NUMBER INDEX (Cont.)

Part No.	Description	Pg. No.	Ref. No.	Qty.
70–3970	Plate – Shim .6 mm	42	28	A/R
70–4070	Plate – Shim .2 mm	42	*	A/R
70–4080	Plate – Shim .3 mm	42	*	A/R
70–4090	Plate – Shim .4 mm	42	*	A/R
70–4100	Plate – Shim .5 mm	42	*	A/R
70–8220	Cable – Ground	33	41	1
70–8530	Wire – Fuel Pump	20	33	1
70–8570	Breaker – Circuit	11	*	2
71–1520	Cap – Expansion Tank	50	8	1
71–4330	Seal	24	41	1
71–4350	Nut	23	20	1
72–0270	Nut – Retaining	42	1	3
72–0280	Piece – Distance	42	3	3
72–3570	Shim .094 – Diff. Adjust.	23	22	A/R
72–3571	Shim .096 – Diff. Adjust.	23	*	A/R
72–3572	Shim .098 – Diff. Adjust.	23	*	A/R
72–3573	Shim .100 – Diff. Adjust.	23	22	A/R
72–3574	Shim .102 – Diff. Adjust.	23	*	A/R
72–3575	Shim .104 – Diff. Adjust.	23	*	A/R
72–3576	Shim .106 – Diff. Adjust.	23	*	A/R
72–3577	Shim .108 – Diff. Adjust.	23	*	A/R
72–3578	Shim .110 – Diff. Adjust.	23	*	A/R
72–3580	Shim .112 – Diff. Adjust.	23	*	A/R
72–3581	Shim .114 – Diff. Adjust.	23	*	A/R
72–3582	Shim .116 – Diff. Adjust.	23	*	A/R
72–3583	Shim .118 – Diff. Adjust.	23	*	A/R
72–3584	Shim .120 – Diff. Adjust.	23	*	A/R
72–3585	Shim .125 – Diff. Adjust.	23	*	A/R
72–3586	Shim .127 – Diff. Adjust.	23	*	A/R
72–3587	Shim .129 – Diff. Adjust.	23	*	A/R
72–3588	Shim .131 – Diff. Adjust.	23	*	A/R
72–3590	Shim .133 – Diff. Adjust.	23	*	A/R
72–3591	Shim .135 – Diff. Adjust.	23	*	A/R
72–3592	Shim .137 – Diff. Adjust.	23	*	A/R
72–3593	Shim .139 – Diff. Adjust.	23	*	A/R
72–3594	Shim .141 – Diff. Adjust.	23	*	A/R
72–3595	Shim .143 – Diff. Adjust.	23	*	A/R
72–3596	Shim .145 – Diff. Adjust.	23	*	A/R
72–3597	Shim .147 – Diff. Adjust.	23	*	A/R
72–3598	Shim .149 – Diff. Adjust.	23	*	A/R
72–3600	Shim .151 – Diff. Adjust.	24	22	A/R
72–6950	Retainer	36	16	1
72–9420	Vent Tube Assembly	24	39	1
74–0720	Tube – Manual	6	11	1
74–3810	Assembly – Load Plate	19	9	1
74–5520	Clutch – Fan	33	1	1
74–5950	Assembly – Swell Latch	10	5	1
74–5950	Assembly – Swell Latch	2	44	3
74–9100	Pad – Forward	5	12	1
74–9110	Pad – Reverse	5	14	1
75–0012	Assembly – Transmission	21	34	1
75–0020	Housing	26	5	1
75–0030	Gasket – Housing	26	46	1
75–0040	Center Section	26	18	1
75–0060	Plug	26	20	4
75–0070	Plug	26	41	1
75–0090	Screw – Cap Hex Hd.	26	9	8
75–0110	Screw – Cap Hex Hd.	26	35	2
75–0120	Screw – Cap Hex Hd.	26	28	1
75–0130	Screw – Cap Hex Head	26	24	3
75–0140	Spring – Conical	26	26	1
75–0150	Guide – Seal	26	2	1
75–0160	Plug – Pipe	26	47	1
75–0170	Plug – Straight Thread	26	19	4
75–0180	Screw – Cap Hex Hd.	26	36	2
75–0190	Plug – Special	26	27	2
75–0200	Plug – Straight Thread	26	38	2
75–0210	O–Ring	26	6	2
75–0220	Pin	26	48	2
75–0230	Seal – Lip	26	8	1
75–0240	O–Ring	26	21	6
75–0250	Pin – Slotted	26	54	1
75–0260	Valve – Relief	26	23	4
75–0270	Spring	26	39	1
75–0280	Spring	26	42	1
75–0290	Spring	26	22	2
75–0310	Shim	26	40	1
75–0320	Nipple	26	37	1
75–0330	Seal – Lip	26	34	1
75–0340	Bearing – Needle	26	33	1
75–0350	Pin	26	31	1
75–0360	Gerotor	26	30	1
75–0370	O–Ring	26	29	1
75–0380	Plate – Valve	26	15	1
75–0390	Plate – Swash	26	12	1
75–0400	Plate – Thrust	26	13	2
75–0410	O–Ring	26	3	1
75–0430	Ring – Retaining	26	1	1
75–0440	Shaft – Motor	26	45	1
75–0450	Collar	26	50	1
75–0460	Bearing – Ball	26	51	2
75–0470	Cylinder Block Kit	26	14	2
75–0480	Pin	26	10	2
75–0500	Bearing – Needle	26	16	2
75–0510	Pin	26	17	1
75–0520	Bearing – Ball	26	4	1
75–0540	Assembly – Tether	13	7	1
75–0550	Strainer – Suction	13	29	1
75–0560	Assembly – Steering Wheel	3	4	1
75–0570	Cable – Hood	1	21	1
75–0600	Assembly – Steering Valve	3	26	1
75–0600	Valve – Power Steering	4	*	1
75–0610	Tread – Foot R.H.	2	*	1
75–0620	Tread – Foot L.H.	2	39	1
75–0630	Tread – Foot Center	2	37	1
75–0640	Tread – Footrest R.H.	2	*	1
75–0650	Tread – Footrest L.H.	2	35	1
75–0721	Housing–Lower	24	34	1
75–0750	Decal – Backlap Switch	31	53	1
75–0920	Cartridge – Relief 3000 psi	15	13	1
75–0930	Hook – Oil Cooler	30	6	4
75–1010	Assembly – Toggle Switch	10	16	2
75–1020	Switch – Backlap	30	44	1
75–1040	Cooler – Oil	31	52	1
75–1180	Manifold	17	7	2
75–1180	Manifold – Hydraulic	16	23	1
75–1200	Asm. – Hydraulic Cylinder	54	47	1
75–1210	Nut–Lock	55	2	1
75–1220	Piston	55	3	1
75–1230	Assembly – Piston Rod	55	5	1
75–1250	Seal Kit	55	6	1
75–1260	Head–Internal	55	4	1
75–1280	Decal – Warning (English)	1	24	1
75–1300	Asm. – Hydraulic Filter Head	13	31	1
75–1310	Element – Hydraulic Filter	13	34	1
75–1330	Filter – Oil	21	31	1
75–1360	Cable – Battery (Ground)	33	23	1
75–1370	Asm. – Battery Cable (+)	50	13	1
75–1390	Panel – Access	2	38	1
75–1410	Panel – Floor	2	36	1
75–1420	Cover – Steering Tower	1	2	1
75–1430	Assembly – Brake Pedal R.H.	5	35	1
75–1440	Pedal – Brake L.H.	5	33	1
75–1470	Shaft – Brake Pedal	5	36	1
75–1490	Rod – Parking Brake	3	13	1
75–2010	Cartridge – Relief 2000 psi	15	14	1
75–2080	Kit – Seal	15	*	10
75–2090	Kit – Seal	15	*	3
75–2120	Clevis	63	12	1
75–2170	Tube – Pump Control	5	37	1
75–2810	Clamp – Steering Valve	3	3	1
75–2851	Hose – Expansion Tank	50	5	1

*Not Illustrated

TORO PART NUMBER INDEX (Cont.)

Part No.	Description	Pg. No.	Ref. No.	Qty.
75–2851	Hose – Expansion Tank	30	16	1
75–2900	Assembly – Rear Axle	54	45	1
75–2970	Pedal – Traction	5	13	1
75–3010	Joint – Arm	59	41	2
75–3010	Joint – Arm	57	54	3
75–3040	Assembly – Carrier Frame	57	44	1
75–3110	Collar – Transmission	21	14	1
75–3130	Rod – Tie	53	37	2
75–3140	Bracket – Air Cleaner	50	24	1
75–3270	Lever – Traction Pivot	5	8	1
75–3390	Bracket – Backlap	31	55	1
75–3400	Shaft – Seat Pivot	6	15	1
75–3420	Assembly – Lift Control	11	37	1
75–3430	Rod – Throttle	6	33	1
75–3480	Weldment – Upper	7	23	1
75–3510	Bolt – Shoulder	7	26	2
75–3530	Spring – Compression	7	3	1
75–3540	Pin – Roll	7	6	1
75–3550	Bumper – Seat	7	7	2
75–3580	Plate – Mounting, Seat	7	2	1
75–3680	Rod – Seat	6	20	1
75–3710	Dipstick	13	4	1
75–3780	Fan	33	2	1
75–3790	Clevis	60	12	1
75–3790	Clevis	61	12	1
75–3810	Bracket – Roller	58	15	2
75–3840	Fender – R.H.	1	3	1
75–3860	Fender – L.H.	1	29	1
75–4080	Plate – Traction	27	15	1
75–4100	Control – Pump	27	25	1
75–4130	Plate – Switch	27	7	1
75–4180	Pin – Rear Axle Pivot	54	44	1
75–4250	Bracket – Expansion Tank	50	21	1
75–4360	Bracket – Switch	6	8	1
75–4370	Bracket – Switch (Seat)	6	3	1
75–4400	Adaptor – Transmission	28	8	1
75–4410	Assembly – Pivot Plate	53	42	1
75–4450	Hub – Fan Drive	33	9	1
75–4520	Spring – Torsion R.H.	58	37	1
75–4530	Spring – Torsion L.H.	58	*	1
75–4550	Shaft – Center Arm Pivot	56	27	1
75–4590	Rod – Pivot	58	34	2
75–4650	Bracket – Spring Rear L.H.	58	*	1
75–4690	Bracket – Spring Rear R.H.	58	8	1
75–4700	Hose – Fuel	20	13	1
75–4701	Hose – Fuel	20	16	1
75–4701	Hose – Fuel Vent	30	28	1
75–4710	Warning Light Harness	10	28	1
75–4720	Fitting – Hydraulic 90°	21	26	1
75–5190	Decal – No Riders (English)	2	32	2
75–5200	Bracket – Spring R.H.	56	*	1
75–5210	Bracket – Spring Center	56	16	1
75–5220	Bracket – Spring L.H.	56	*	1
75–5260	Knob – Locking	6	38	2
75–5270	Spacer – Locking Knob	6	37	2
75–5300	Rod – Hose Support	16	19	2
75–5300	Rod – Hose Support	57	63	1
75–5310	Spacer – Bearing	33	8	1
75–5330	Clamp – Hose	56	8	2
75–5330	Clamp – Hydraulic Line	59	50	2
75–5350	Pin – Cylinder Rod End	58	23	2
75–5350	Pin – Cylinder Rod End	56	31	3
75–5360	Pin – Cylinder Cap End	59	49	2
75–5370	Mount – Clamp	56	36	1
75–5380	Bracket – Clamp	56	38	1
75–5390	Roller	58	20	2
75–5400	Shaft – Roller	58	19	2
75–5410	Bracket – Arm	57	53	2
75–5420	Assembly – Lift Arm, Center	56	40	1
75–5450	Assembly – Lift Arm R.H.	56	1	1
75–5460	Assembly – Lift Arm L.H.	56	32	1
75–5470	Spacer	27	12	2
75–5720	Hose – Hydraulic	13	19	1
75–5740	Box – Control	10	24	1
75–5810	W.A. – Tool Box	1	26	1
75–5890	Hose – Hydraulic	16	10	1
75–5890	Hose – Hydraulic	56	28	2
75–5890	Hose – Hydraulic	14	35	1
75–5900	Hose – Hydraulic	14	30	1
75–5900	Hose – Hydraulic	57	47	1
75–5910	Hose – Hydraulic	16	11	1
75–5910	Hose – Hydraulic	57	60	1
75–5940	Hose – Hydraulic	16	9	1
75–5940	Hose – Hydraulic AUX	3	23	1
75–6070	Hose – Hydraulic	17	15	1
75–6070	Hose – Hydraulic L.H. (Cap)	58	11	1
75–6080	Hose – Hydraulic	17	14	1
75–6080	Hose – Hydraulic L.H. (Rod)	58	*	1
75–6130	Hose – Hydraulic	13	9	1
75–6180	Hose – Hydraulic	17	1	2
75–6180	Hose – Hydraulic R.H.	58	21	2
75–6220	Hose – Hydraulic	53	34	1
75–6220	Hose – Hydraulic LT	3	24	1
75–6230	Hose – Hydraulic	54	50	1
75–6230	Hose – Hydraulic RT	3	18	1
75–6240	Hose – Hydraulic	28	14	1
75–6240	Hose – Hydraulic IN	3	19	1
75–6250	Hose – Hydraulic	13	17	1
75–6250	Hose – Hydraulic OUT	3	25	1
75–6260	Cover – Tool Box	2	47	1
75–6270	Cover – Control Box	10	15	1
75–6280	Bracket – Hose	1	22	1
75–6340	Strainer – In–Line	21	41	1
75–6350	Hose	21	28	1
75–6370	Cover – Sensor	57	49	1
75–6380	Shaft – Fan	33	3	1
75–6390	Pulley – Fan	33	5	1
75–6490	Lever – Pedal Stop	5	20	1
75–6510	Lever – Bracket	5	16	1
75–6550	Disc – Friction	5	17	1
75–6580	Cable – Pedal	5	7	1
75–6640	Fitting – Hydraulic 90°	14	20	2
75–6710	Decal – Fast/Slow	5	18	1
75–6820	Meter – Hour	11	47	1
75–6840	Knob – Knurled	2	42	4
75–6850	Tube – Oil Fill	22	47	1
75–6870	Hose – Hydraulic Suction	13	28	1
75–6870	Hose – Suction	28	1	1
75–6880	Screen – Spark Arrester	32	*	1
75–6930	Valve – SCR	26	52	1
76–1910	Shaft – Pivot	7	12	2
76–1920	Bushing – Sleeve	7	9	4
76–1930	Knob – Tension Adjustment	7	19	1
76–1940	Spring – Extension	7	14	2
76–2940	Bumper – Rubber	7	8	2
76–2970	Bushing – Sleeve	53	43	2
76–2980	Washer – Thrust	53	41	1
76–8640	Stud – Traction	27	23	1
76–8730	Decal – Bolt Torque	21	1	2
76–8750	Plate – Caution	30	21	1
76–9430	Spring – Extension	27	8	1
77–0490	Decal – Bolt (English)	21	17	1
77–2870	Weldment – Hanger	7	18	1
80–4860	Pin – Clevis	7	1	1
82–6490	Hose – Hydraulic	57	65	1
82–8270	Valve – Flow Control	17	13	1
82–8270	Valve – Flow Control	14	31	1
82–8270	Valve – Flow Control	57	71	1
82–9060	Adjuster W/Handle	7	13	1
83–4780	Housing – Charge Pump	26	32	1
83–4910	Coupler – Pinion	24	40	1
83–5130	Spacer – Pinion	23	21	1

*Not Illustrated

TORO PART NUMBER INDEX (Cont.)

Part No.	Description	Pg. No.	Ref. No.	Qty.
83–5170	Stop – Reel	59	*	1
83–6780	Pin – Cylinder (Long)	57	61	2
83–6790	Pin – Cylinder (Short)	57	43	1
83–7410	Roll – Bar	64	1	1
83–7430	Decal – Danger (English)	64	3	1
83–7440	Decal – Knob (English)	6	40	1
83–7480	Asm. – Hydraulic Cylinder	56	7	1
83–7490	Hydraulic Cylinder Asm.	57	67	1
84–1670	Head	60	9	1
84–1670	Head	61	9	1
84–1670	Head	63	9	1
84–1680	Ring – Retaining	60	11	1
84–1680	Ring – Retaining	61	11	1
84–1680	Ring – Retaining	63	11	1
84–1710	Piston	62	4	1
84–1720	Head	62	9	1
84–1730	Ring – Retaining	62	11	1
84–1740	Clevis	62	12	1
84–1760	Seal repair Kit	62	*	1
84–8320	Insert – Hinge	56	10	4
84–8590	Assembly – Shoe & Lining	25	9	4
84–8600	Set of Lined Brake Shoes	25	*	1
85–4330	Cover – Gear	21	9	1
85–4340	Plate – Sensor Mounting	21	11	1
85–4350	Sensor – Gear Tooth	21	5	1
85–4420	Gauge – Speedometer	10	2	1
85–4450	Bracket – Fuse Block	10	23	1
85–4460	Decal – HOC Selector	11	50	1
85–4470	Assembly – Potentiometer	11	44	1
85–4480	Knob	10	25	1
85–4491	Lamp – Diagnostic	11	57	1
85–4530	Decal – Danger (English)	6	17	1
85–4610	Decal – Instruction	6	41	1
85–4650	Connector – Loop Back	11	*	1
85–4720	Decal – Instruction	10	27	1
85–4730	Decal – Hydraulic Oil	1	4	1
85–4730	Decal – Oil	16	7	1
85–4750	Display – Diagnostic–ACE	8	2	1
85–4760	Decal – Diagnostic–ACE	8	1	1
85–9880	Asm. – Hydraulic Cylinder	57	46	1
85–9900	Plate – Spring Anchor	27	16	1
85–9910	Eyebolt	27	27	1
85–9980	Decal – ROPS	64	2	1
86–3040	Coupling – Driveshaft	32	7	1
86–7220	Gear – Pinion	21	37	1
86–7230	Gear–Spur	23	14	1
86–7330	Seal Repair Kit	63	*	1
86–7330	Seal repair Kit	60	*	1
86–7330	Seal repair Kit	61	*	1
86–7520	Asm. – Trunnion Cover R.H.	26	7	1
86–7530	Asm. – Trunnion Cover L.H.	26	49	1
86–7540	Shaft – Pump	26	11	1
86–7550	Connector – Cover (2 Way)	11	*	2
86–7560	Connector – Cover (3 Way)	11	*	3
86–9190	Hose – Hydraulic	14	14	2
88–0440	Decal – Floor Plate	16	6	1
88–6700	Decal – ANSI (English)	2	34	1
88–6960	Cartridge – 4W/2P	15	19	3
88–6970	Cartridge – N.O.	15	9	2
88–6990	Cartridge – N.C.	15	7	3
88–7020	Cartridge – N.O.	15	3	2
88–9190	Solenoid – 20 Watt	15	4	6
88–9200	Solenoid – 28 Watt	15	8	5
88–9460	Hose – Hydraulic	18	11	1
88–9460	Hose – Hydraulic	13	48	1
91–1717	Hose – Hydraulic	18	9	1
92–1180	Assembly – Seat	6	45	1
92–1718	Hose – Hydraulic	18	12	1
92–1719	Hose – Hydraulic	18	8	1
92–1721	Hose – Hydraulic	18	14	1
92–1721	Hose – Hydraulic	14	24	1
92–1722	Hose – Hydraulic	16	1	1
92–1722	Hose – Hydraulic	18	5	1
92–1723	Hose – Hydraulic	18	10	1
92–1723	Hose – Hydraulic	14	27	1
92–1724	Hose – Hydraulic	18	1	1
92–1725	Hose – Hydraulic	14	4	1
92–1725	Hose – Hydraulic	18	6	1
92–1726	Hose – Hydraulic	18	16	1
92–1726	Hose – Hydraulic	16	24	1
92–1727	Hose – Hydraulic	18	15	1
92–1728	Hose – Hydraulic	18	17	1
92–1728	Hose – Hydraulic	14	37	1
92–1729	Hose – Hydraulic	18	20	1
92–1729	Hose – Hydraulic	16	25	1
92–1773	Screw–Cap, Hex Hd.	23	11	4
92–1774	Seal–Oil	25	2	2
92–1920	Plug – Drain	38	6	1
92–1921	Gasket – Plug, Drain	38	7	1
92–1961	Seal	37	15	6
92–1961	Seal – Valve Stem	49	106	6
92–2143	Bolt W/Washer	39	22	5
92–2379	Clamp – Hose	50	6	1
92–2379	Clamp – Hose	30	14	2
92–2581	Assembly – Switch Arm	27	21	1
92–4808	Sleeve – Trans. Pilot	21	15	1
92–4846	Asm. – Trans. Support	21	39	1
92–4999	Fitting – Hydraulic 90°	31	51	2
92–5524	Decal – Noise Rating, 90	6	47	1
92–5549	Decal – Reelmasterr 5300D	1	10	2
92–5720	Controller – Electronic	10	31	1
92–5751	Decal – Hood Trim L.H.	1	23	1
92–5752	Decal – Hood Trim R.H.	1	*	1
92–5791	Spacer	59	54	2
92–5797	Gasket – Axle	21	10	1
92–6315	Cartridge – N.C.	15	22	1
92–6533	Kit – Cushion, Replacement	6	44	1
92–6534	Shell – Seat	6	43	1
92–8001	Sensor – Reed Switch	6	6	1
92–8002	Sensor – Reed Switch	56	12	1
92–8753	Magnet – Reed Switch	6	5	1
92–8754	Actuator – Reed Switch	57	51	1
92–8775	Gasket – Kit, Liquid	25	*	1
92–8780	Assembly – Fuel Tank	20	23	1
92–8785	Reservoir – Hydraulic	13	1	1
92–8795	Assembly – Body	19	10	1
92–8796	Pin – Dowel	19	14	2
92–8863	Repair Kit	19	*	1
92–9096	Assembly – Hose	13	46	1
92–9096	Hose – Hydraulic	16	22	1
92–9097	Set Screw	59	43	2
92–9097	Set Screw	57	69	3
92–9098	Manifold – Tank	13	14	1
93–0000	Hood W.A.	1	8	1
93–0005	Strip – Foam, Top	30	11	1
93–0011	Grill – Hood	1	12	1
93–0012	Assembly – Frame	2	43	1
93–0018	Frame – Seat	6	28	1
93–0020	Radiator	30	12	1
93–0021	Asm. – Throttle Cable Swivel	6	26	2
93–0022	Shroud – Fan	30	19	1
93–0023	Hose – Radiator Upper	30	18	1
93–0024	Hose – Radiator Lower	30	24	1
93–0025	Shield W.A. – Radiator	30	33	1
93–0030	Asm. – Cooler Mount R.H.	30	9	1
93–0032	Hsg. W.A. – Front Screen	30	2	1
93–0038	Support W.A. – Radiator	30	7	1
93–0043	Bracket – Fan Idler	34	55	1
93–0044	Muffler	32	13	1
93–0045	Yoke – Slip Tube	32	4	1
93–0047	Assembly – U–Joint	32	*	1
93–0047	Yoke – Shaft	32	3	1

*Not Illustrated

TORO PART NUMBER INDEX (Cont.)

Part No.	Description	Pg. No.	Ref. No.	Qty.
93–0048	Hose – Air Cleaner	33	19	1
93–0049	Assembly – Engine	33	24	1
93–0050	Bracket – Engine L.H. Rear	33	29	1
93–0051	Bracket – Engine L.H. Front	34	48	1
93–0054	Bracket W.A. – Fan	34	52	1
93–0062	Belt – V	34	56	1
93–0063	Bracket – Engine R.H. Rear	33	*	1
93–0064	Support – Rear Axle	53	4	1
93–0066	Asm. – Lift Arm Rear R.H.	58	28	1
93–0068	Asm. – Lift Arm Rear L.H.	58	*	1
93–0069	Pin – Pivot	59	52	2
93–0071	Asm. – Cooler Mount L.H.	30	*	1
93–0073	Cable – Throttle	6	24	1
93–0074	Support – Cable	34	62	1
93–0075	Hose – Hydraulic	21	30	1
93–0075	Hose – Trans. to Cooler	31	*	1
93–0076	Hose – Hydraulic	21	21	1
93–0076	Hose – Trans. to Cooler	31	46	1
93–0077	Hose – Cooler, R.H.	31	49	1
93–0077	Hose – Hydraulic	13	30	1
93–0078	Hose – Cooler, L.H.	31	*	1
93–0078	Hose – Hydraulic	14	21	1
93–0079	Asm. – Hydraulic Cylinder	59	48	2
93–0080	Asm. – Main Wire Harness	11	56	1
93–0081	Strip – Seal	1	9	1
93–0082	Grommet	31	58	2
93–0083	Plate – Valve	26	44	1
93–0084	Assembly – Front Axle	22	46	1
93–0089	Bracket – Mount LH, Cooler	30	*4	1
93–0090	Bracket – Mount RH, Cooler	30	4	1
93–0092	Mount – Rubber, Rear	33	30	2
93–0093	Bracket – Eng. Left Rear	33	33	1
93–0095	Bracket – Eng. Front	33	45	2
93–0096	Decal – A.C.E.	1	27	2
93–0097	Valve – SCR	26	25	1
93–0118	Hose – Hydraulic	17	9	2
93–0118	Hose – Hydraulic	16	12	1
93–0118	Hose – Hydraulic	14	33	1
93–0119	Hose – Hydraulic	16	13	1
93–0119	Hose – Hydraulic	13	21	1
93–0139	Manifold – Hydraulic	16	17	1
93–0140	Grommet	6	10	1
93–0141	Assembly – Seat Plate	6	16	1
93–0142	Bushing – Straight	58	36	2
93–0143	Cartridge – Relief 250 psi	16	18	1
93–0309	Washer – Tab	53	22	2
93–1358	Software – ECU RM5300D	11	*	1
93–1374	Latch – Swell	30	1	2
93–1375	Motor – Hydraulic	18	21	5
93–1376	Assembly – Pump, Gear	28	18	1
93–1396	Coupler W.A. – Trans.	28	7	1
93–3102	Cap – Fuel Tank	20	22	1
93–3103	Cap – Hydraulic Reservoir	13	8	1
93–3134	Assembly – Barrel	60	1	1
93–3139	Panel – Tower	3	10	1
93–3140	Panel – Control	10	14	1
93–3163	Spring	7	28	2
93–3164	Cap	7	27	2
93–3165	Bracket	7	29	1
93–3350	Gear – Camshaft	35	35	1
93–3351	Gear – Pump, Injection	35	1	1
93–3352	Assembly – Idler, Gear	35	2	1
93–3353	Bushing – Idler	35	36	1
93–3354	Crankshaft	35	27	1
93–3355	Washer – Spring	35	12	1
93–3356	Nut	35	11	1
93–3357	Pulley – Crankshaft	35	14	1
93–3358	Assembly – Sub, Flywheel	35	25	1
93–3359	Gear – Crankshaft	35	15	1
93–3360	Cover	35	7	1
93–3361	Gasket – Cover	35	8	1
93–3361	Gasket – Tie Rod Cover	49	111	1
93–3362	Bushing – Camshaft	35	34	1
93–3363	Assembly – Shaft, Idler	35	4	1
93–3364	Ball – Steel	35	3	1
93–3365	Pin – Dowel	35	9	2
93–3366	Cap – Sealing	35	10	1
93–3367	Plug – Taper	35	32	1
93–3368	Bolt	35	33	4
93–3369	Cap – Sealing	35	31	2
93–3370	Bearing – Con–Rod	35	16	6
93–3371	Asm. – Rod, Connecting	35	23	3
93–3372	Nut	35	30	6
93–3373	Bolt – Connecting	35	17	6
93–3374	Pin – Piston	35	18	3
93–3375	Ring Set – Piston	35	19	3
93–3376	Piston – Std.	35	22	3
93–3377	Piston – O.S. 0.25	35	*	3
93–3378	Piston – O.S. 0.50	35	*	3
93–3379	Set – Ring, Piston O.S. 0.25	35	*	3
93–3380	Set – Ring, Piston O.S. 0.50	35	*	3
93–3381	Cap – Sealing	36	2	2
93–3382	Cap – Sealing	36	4	1
93–3383	Seal – Side	36	7	4
93–3383	Seal – Side	49	114	4
93–3384	Cylinder Block Assembly	36	20	1
93–3385	Cap – Metal	36	9	1
93–3386	Cap – Sealing	36	15	3
93–3387	Bearing – Set Std.	36	14	1
93–3388	Bearing – Set U.S. 0.50 mm	36	*	1
93–3389	Bearing – Set U.S. 0.75 mm	36	*	1
93–3390	Case – Seal, Oil	44	19	1
93–3391	Gasket – Oil Seal Case	49	115	1
93–3391	Gasket – Seal, Oil	44	21	1
93–3392	Seal – Oil	44	20	1
93–3393	Bolt	44	18	5
93–3394	Valve – Inlet	37	29	3
93–3395	Valve – Exhaust	37	28	3
93–3396	Spring – Valve	37	16	6
93–3397	Cap – Valve	37	12	6
93–3398	Asm. – Rocker & Shaft	37	*	1
93–3399	Bolt	37	9	1
93–3400	Assembly – Rocker	37	*	1
93–3401	Screw – Rocker	37	4	6
93–3402	Bracket, Shaft, Rocker	37	11	1
93–3403	Bracket – Shaft, Rocker	37	6	2
93–3404	Assembly – Shaft	37	*	1
93–3405	Cap – Sealing	37	8	2
93–3406	Spring – Rocker	37	7	2
93–3407	Bolt – Bracket, Rocker	37	10	3
93–3408	Shaft – Pump, Fuel Inject.	37	21	1
93–3409	Bearing	37	19	1
93–3410	Bolt W/Washer	37	17	1
93–3411	Rod – Push	37	22	6
93–3412	Camshaft	37	24	1
93–3413	Assembly – Strainer	38	13	1
93–3414	Gasket	38	11	1
93–3414	Gasket	49	108	1
93–3415	Assembly – Valve, Relief	38	22	1
93–3416	Housing	38	17	1
93–3417	Gasket	38	16	1
93–3417	Gasket	49	101	1
93–3418	Gauge – Level, Oil	38	1	1
93–3420	Assembly – Pump, Oil	38	15	1
93–3421	Bolt	38	14	3
93–3422	Assembly – Pan, Oil	38	9	1
93–3423	Gasket	39	4	1
93–3423	Gasket	49	113	1
93–3423	Gasket – Muffler	32	15	1
93–3424	Gasket – Cover, Rocker	39	5	1
93–3424	Gasket – Rocker	49	123	1
93–3425	Guide – Valve, In	39	8	3

*Not Illustrated

TORO PART NUMBER INDEX (Cont.)

Part No.	Description	Pg. No.	Ref. No.	Qty.
93–3426	Bolt – Head, Cylinder	39	14	11
93–3427	Guide – Valve	39	15	3
93–3428	Cylinder Head Assembly	39	17	1
93–3429	Cap – Sealing	39	29	1
93–3430	Jet – Combustion	39	28	3
93–3431	Gasket – Cylinder Head	49	122	1
93–3431	Gasket – Head, Cylinder	39	26	1
93–3432	Bolt W/Washer	39	27	2
93–3433	Assy. – Cover, Rocker	39	11	1
93–3434	Gasket – Cover, Inlet	39	18	1
93–3434	Gasket – Inlet Cover	49	124	1
93–3435	Bolt W/Washer	39	9	4
93–3436	Gasket – Exhaust	39	30	1
93–3436	Gasket – Exhaust	49	125	1
93–3437	Asm. – Manifold, Exhaust	39	31	1
93–3438	Assy. – Cover, Inlet	39	20	1
93–3440	Pipe – Inlet	39	21	1
93–3441	Gasket – Inlet Pipe	49	118	1
93–3441	Gasket – Pipe, Inlet	39	25	1
93–3442	Bolt W/Washer	39	23	1
93–3443	Bolt W/Washer	39	24	1
93–3444	Cap – Filler	40	1	1
93–3445	Gasket – Gear	40	2	1
93–3445	Gasket – Gear	49	117	1
93–3446	Plate – Front	40	4	1
93–3447	Gasket – Front Plate	49	116	1
93–3447	Gasket – Plate, Front	40	5	1
93–3448	Case – Gear	40	6	1
93–3449	Bolt	40	8	8
93–3450	Assembly – Pump, Water	41	7	1
93–3451	Bolt W/Washer	41	6	2
93–3452	Joint	41	5	1
93–3453	Gasket	41	8	1
93–3453	Gasket – Water Pump	49	112	1
93–3454	Plate	41	9	1
93–3455	Gasket – Pump, Water	41	10	1
93–3455	Gasket – Water Pump	49	110	1
93–3456	Bolt W/Washer	41	4	3
93–3457	Bolt W/Washer	41	11	1
93–3458	Pulley – Pump, Water	41	2	1
93–3459	Bolt W/Washer	41	1	4
93–3460	V–Belt	41	3	1
93–3461	Assembly – Pump, Fuel	42	*	1
93–3462	Assembly – Sub, Housing	42	30	1
93–3463	Holder – Delivery, Valve	42	16	3
93–3464	Spring – Delivery, Valve	42	14	3
93–3465	Gasket – Delivery, Valve	42	13	3
93–3466	Assembly – Sub, Valve	42	12	3
93–3467	Assembly – Sub, Element	42	11	3
93–3468	Sleeve – Control	42	24	3
93–3469	Seat – Spring, Upper	42	25	3
93–3470	Spring – Plunger	42	26	3
93–3471	Assembly – Sub, Tappet	42	29	3
93–3472	Assembly – Control, Rack	42	23	1
93–3473	Seat – Spring, Lower	42	27	3
93–3474	O–Ring	42	15	3
93–3475	Pin – Guide, Tappet	42	21	3
93–3476	Plate	42	22	1
93–3477	Plate – Adjusting	42	20	2
93–3478	Bolt – Washer Head	42	19	2
93–3479	Screw – Hollow	42	10	1
93–3480	Screw – Bleeder, Air	42	8	1
93–3481	Washer – Union , Pipe	42	9	1
93–3482	Plate – Shim .25 mm	42	*	A/R
93–3483	Plate – Shim .35 mm	42	*	A/R
93–3484	Plate – Shim .45 mm	42	*	A/R
93–3485	Plate – Shim .55 mm	42	*	A/R
93–3486	Plate – Shim .65 mm	42	*	A/R
93–3487	Plate – Name	42	18	1
93–3488	Rivet	42	17	2
93–3489	Assembly – Nozzle & Holder	42	*	1
93–3490	Assembly – Sub, Body	42	7	3
93–3491	Washer – 1.25 mm	42	6	A/R
93–3492	Washer – 1.3 mm	42	*	A/R
93–3493	Washer – 1.35 mm	42	*	A/R
93–3494	Washer – 1.4 mm	42	*	A/R
93–3495	Washer – 1.45 mm	42	*	A/R
93–3496	Washer – 1.5 mm	42	*	A/R
93–3497	Washer – 1.55 mm	42	*	A/R
93–3498	Washer – 1.6 mm	42	*	A/R
93–3499	Washer – 1.65 mm	42	*	A/R
93–3500	Washer – 1.7 mm	42	*	A/R
93–3501	Spring – Pressure	42	5	3
93–3502	Pin – Pressure	42	4	3
93–3503	Assembly – Nozzle	42	2	3
93–3504	Assembly – Solenoid	44	22	1
93–3505	Bracket – Starter	44	24	1
93–3506	Plug – Glow	44	16	3
93–3507	Plate – Connection	44	6	1
93–3508	Plate – Adjusting	43	16	1
93–3509	Nut	43	12	1
93–3510	Washer – Spring	43	13	1
93–3511	Washer – Plain	43	14	1
93–3512	Bolt – Alternator	43	15	1
93–3513	Pipe – Injector No.1	44	7	1
93–3514	Pipe – Injector No.2	44	10	1
93–3515	Pipe – Injector No.3	44	11	1
93–3516	Pipe – Leak Off, Fuel	44	15	1
93–3517	Bolt	44	3	4
93–3518	Nipple – Swivel	44	2	1
93–3519	Assembly – Case, Therm.	43	11	1
93–3520	Pipe	43	21	1
93–3521	Gasket – Case, Thermostat	43	8	1
93–3521	Gasket – Thermo Case	49	120	1
93–3522	Bolt W/Washer	43	19	3
93–3523	Assembly – Hose, Fuel	43	1	1
93–3524	Thermostat	43	7	1
93–3525	Gauge	43	3	1
93–3526	Switch	43	10	1
93–3527	Gasket	43	9	1
93–3527	Gasket	49	109	1
93–3528	Plug	43	2	1
93–3529	Assembly – Case, Governor	45	1	1
93–3530	Pin – Spring	45	18	1
93–3531	O–Ring	45	25	1
93–3532	Nut – Jam	45	33	1
93–3533	Bolt – Speed Set	45	31	2
93–3534	Spring – Governor	45	16	1
93–3535	Spring Set – Torque	45	13	1
93–3536	Stopper	45	11	1
93–3537	Spring – Torque	45	10	2
93–3538	Spring – Start	45	21	1
93–3539	Shim – Shaft, Governor	45	23	1
93–3540	Lever – Speed	45	35	1
93–3541	Case – Governor	45	36	1
93–3542	Lever – Spring, Governor	45	17	1
93–3543	Lever – Tension	45	19	1
93–3544	Lever – Governor	45	22	1
93–3545	Shaft – Governor	45	24	1
93–3546	Rod – Tie	45	15	1
93–3547	Spring – Rod, Tie	45	14	1
93–3548	Gasket – Case, Governor	45	29	1
93–3548	Gasket – Governor Case	49	121	1
93–3549	Shaft – Sleeve, Sliding	45	26	1
93–3550	Sleeve – Sliding	45	27	1
93–3551	Weight	45	28	1
93–3552	Wire	45	6	1
93–3553	Bolt	45	4	3
93–3554	Bolt – Case, Governor	45	3	1
93–3555	Assembly – Starter	46	*	1
93–3556	Screw	46	19	1
93–3556	Screw Set	46	3	1

*Not Illustrated

TORO PART NUMBER INDEX (Cont.)

Part No.	Description	Pg. No.	Ref. No.	Qty.
93–3557	Assembly – Bracket, Front	46	4	1
93–3558	Assembly – Lever	46	5	1
93–3559	Spring Set	46	6	1
93–3560	Assembly – Bracket, Center	46	7	1
93–3561	Assembly – Switch	46	8	1
93–3562	Armature Set	46	*	1
93–3563	Bearing – Front	46	13	1
93–3564	Bearing – Rear	46	14	1
93–3565	Bolt Set	46	18	2
93–3566	Assembly – Shaft, Clutch	46	*	1
93–3567	Pinion Set	46	2	1
93–3568	Gear Set	46	21	1
93–3569	Gear	46	11	1
93–3570	Cover Set	46	10	1
93–3571	Assembly – Yoke	46	15	1
93–3572	Bolt Set	46	9	1
93–3573	Assembly – Holder	46	16	1
93–3574	Spring – Brush	46	20	4
93–3575	Assembly – Bracket, Rear	46	17	1
93–3576	Stopper Set	46	1	1
93–3577	Assembly – Alternator	47	*	1
93–3578	Nut – Set	47	1	1
93–3579	Assembly – Pulley	47	2	1
93–3580	Bolt Set	47	4	1
93–3581	Assembly – Bracket, Front	47	10	1
93–3582	Screw Set	47	3	1
93–3583	Bearing – Front	47	5	1
93–3584	Assembly – Rotor	47	7	1
93–3585	Bearing – Rear	47	6	1
93–3586	Assembly – Stator	47	12	1
93–3587	Assembly – Bracket, Rear	47	14	1
93–3588	Regulator Set	47	13	1
93–3589	Brush	47	11	2
93–3590	Assembly – Rectifier	47	9	1
93–3591	Nut – Set	47	8	1
93–3592	Kit– Gasket, Complete	49	*	1
93–3593	Packing – Body	49	119	1
93–3594	Hose – Breather	39	13	1
93–3595	Clip – Hose	39	32	1
93–3596	Pipe – Oil Inlet	35	20	3
93–3597	Bearing – Set U.S. 0.25 mm	36	*	1
93–3598	Cap – Sealing	39	19	1
93–3599	Gasket – Liquid	38	*	1
93–3601	Decal – Instructions	1	25	1
93–3604	Gasket	28	6	1
93–3609	Bolt – Special	4	36	4
93–3611	Asm. – Control Manifold	14	6	1
93–3612	Fitting – Hydraulic 90°	14	25	1
93–3614	Assembly – Cover	19	4	1
93–3615	Assembly – Drive Shaft	19	7	1
93–3616	Assembly – Idler Gear	19	6	1
93–3617	Assembly – Differential	24	*	1
93–3618	Gear & Pinion Assembly	24	*	1
93–3619	Upper Housing	24	26	1
93–3621	Bracket – Eng. Right Rear	33	*	1
93–3623	Strip – Sealing, Radiator	31	61	2
93–3624	Plate – Retaining	31	62	2
93–3625	Spring – Joystick Return	11	58	1
93–3626	Bracket – Hose	30	35	1
93–3626	Bracket – Hose	2	41	1
93–3640	Stop – Reel	59	56	1
93–3641	Plate – Idler Stop	6	49	1
93–3642	Tube – Hydraulic	28	13	1
93–3642	Tube – Hydraulic	14	38	1
93–3643	Tube – Hydraulic	28	12	1
93–3643	Tube – Hydraulic	14	39	1
93–3644	Guard W.A. – Flywheel	32	22	1
93–4268	Kit – Flange	29	*	1
93–4269	Kit – Housing, Section 1	29	*	1
93–4270	Kit – Housing, Section 2	29	*	1
93–4271	Kit – Housing, Section 3	29	*	1
93–4272	Kit – Individual Pieces	29	*	1
93–4277	Kit – Valve	29	19	1
93–4278	Pin – Dowel	29	4	4
93–4279	Plate – Distance	29	13	2
93–4280	Coupling	29	9	2
93–4281	Pin – Dowel	29	22	4
93–4282	Block – Valve	29	18	1
93–4283	Bolt	29	17	4
93–4284	Spacer – Cooler, Engine	38	31	1
93–4285	Cooler – Oil, Engine	38	26	1
93–4286	O–Ring	38	32	1
93–4287	O–Ring	38	30	1
93–4288	Fitting – Block, Engine	38	29	1
93–4289	Hose – Cooler, Outlet	38	28	1
93–4290	Connector – Cooler	38	25	1
93–4291	Fitting – Pump, Water	38	23	1
93–4292	Cover – Spiral Tube	38	35	1
93–4294	Hose – Cooler, Inlet	38	33	1
93–4295	Assembly – Filter, Oil	38	4	1
93–4296	Clamp–R	38	24	1
93–4297	Clamp – Hose	38	27	4
93–7000	Spindle – Rear R.H.	53	*	1
93–7001	Spindle – Rear L.H.	53	15	1
93–7013	Guide – Gauge, Oil Level	38	3	1
217–120	Rim	22	52	2
217–121	Rim	53	20	2
218–446	Nut – Locking	10	10	1
218–447	Washer – E.T.L.W.	10	11	1
218–498	Nut – Hex.	10	4	4
218–498	Nut – Lock	31	54	2
218–533	Lens – Red	10	*	1
218–535	Nut – Lock	10	30	1
218–536	Washer – Lock	10	29	1
218–573	Fuse – 5A	10	20	1
218–578	Fuse – 10A	10	*	3
218–579	Wire – Fuel Pump	20	34	1
218–590	Switch – Micro	11	38	2
219–17	Bulb – Light	10	*	4
219–19	Bulb – Light	11	*	1
231–134	Tire	22	53	2
231–141	Tire	53	19	2
232–27	Stem – Valve	21	3	2
232–35	Stem – Valve	53	21	2
233–17	Knob – Parking Brake	3	9	1
233–42	Knob	5	19	1
233–42	Knob – Throttle	6	34	1
237–21	O–Ring	16	2	7
237–21	O–Ring	17	2	7
237–21	O–Ring	18	4	8
237–21	O–Ring	58	14	4
237–21	O–Ring	14	18	4
237–21	O–Ring	53	33	2
237–21	Seal – O–Ring	56	5	8
237–22	O–Ring	14	1	4
237–22	O–Ring	16	14	2
237–22	O–Ring	3	14	5
237–22	O–Ring	28	15	1
237–22	O–Ring	18	19	10
237–22	O–Ring	21	20	2
237–22	O–Ring	13	23	6
237–22	O–Ring	31	47	2
237–30	O–Ring	28	11	2
237–30	O–Ring	15	12	1
237–30	O–Ring	14	13	4
237–42	O–Ring	15	5	2
237–42	O–Ring	16	16	2
237–42	O–Ring	13	25	4
237–65	O–Ring	13	10	5
237–65	O–Ring	14	22	1
237–65	O–Ring	31	50	2
237–78	O–Ring	15	1	12

*Not Illustrated

TORO PART NUMBER INDEX (Cont.)

Part No.	Description	Pg. No.	Ref. No.	Qty.
237–78	O–Ring	18	2	5
237–78	O–Ring	56	3	6
237–78	O–Ring	16	4	7
237–78	O–Ring	17	4	8
237–78	O–Ring	14	7	6
237–78	O–Ring	58	12	4
237–78	O–Ring	21	22	1
237–78	O–Ring	53	31	2
237–79	O–Ring	14	9	6
237–79	O–Ring	15	10	1
237–79	O–Ring	28	17	3
237–79	O–Ring	18	18	10
237–79	O–Ring	21	18	2
237–79	O–Ring	13	45	1
237–80	O–Ring	15	20	1
237–81	O–Ring	13	12	4
237–81	O–Ring	21	25	2
237–81	O–Ring	14	26	1
237–141	Bumper	1	6	2
237–146	O–Ring	28	19	1
237–156	O–Ring	15	16	2
237–161	O–Ring	21	36	1
237–163	O–Ring	28	9	1
237–165	Grommet	54	46	2
237–181	O–Ring	22	51	1
240–3	Grommet	31	57	2
240–11	Grommet	20	28	3
240–11	Grommet	13	39	3
241–119	Cap – Dust	53	24	2
242–34	Stud–Flange, Axle	25	11	10
242–50	Nut – Lug	53	26	10
2411–36	Bearing – Rod End	5	2	1
2412–3	Clamp – Hose	30	27	2
2412–4	Clamp	33	16	2
2412–4	Clamp – R	32	21	1
2412–34	Clamp – Hose	28	2	1
2412–34	Clamp – Hose	30	15	2
2412–34	Clamp – Hose	13	18	3
2412–36	Clamp – Drain	20	24	1
2412–42	Clamp – Hose	50	1	1
2412–71	Clamp – R	34	51	1
2412–72	R–Clamp	6	48	1
2412–74	Clamp–R	59	53	2
2412–92	Clamp – Hose	33	20	1
2412–93	Clamp – R	6	18	1
2412–93	Clamp – R	50	23	1
2412–93	Clamp – R	13	32	2
2412–103	Clamp – R	30	29	2
2412–107	Clamp – R	59	51	1
2412–107	R–Clamp	2	50	1
2412–108	Clamp – Hose	20	12	11
2412–126	Clamp–R	11	53	1
2412–129	Clamp – Hose	21	27	2
2412–133	Clamp – R	6	42	2
251–259	Bearing – Ball	27	11	2
251–318	Bearing – Ball	33	7	2
253–129	Seal – Grease	53	28	2
254–65	Cone–Tapered Bearing	24	28	2
254–66	Cup–Tapered Bearing	24	27	2
254–72	Cup – Bearing	53	17	4
254–91	Cone–Bearing	24	23	1
254–94	Cone – Bearing	53	16	4
256–42	Bushing – Sleeve	5	34	2
256–113	Bushing – Flange	27	19	2
256–115	Washer – Thrust	58	26	8
256–115	Washer – Thrust	56	41	11
256–121	Washer – Thrust	53	12	2
256–236	Bearing – Flange	5	24	4
256–287	Bushing – Flange	58	38	4
282–4	Clevis – Spring	58	3	2
282–4	Clevis – Spring	56	21	3
283–6	Pin – Clevis	58	10	2
283–6	Pin – Clevis	56	15	3
283–58	Pin – Clevis	5	30	4
302–5	Fitting – Grease	32	5	1
302–5	Fitting – Grease	55	7	2
302–5	Fitting – Grease	53	11	4
302–5	Fitting – Grease	56	11	6
302–5	Fitting – Grease	60	13	1
302–5	Fitting – Grease	61	13	1
302–5	Fitting – Grease	62	13	1
302–5	Fitting – Grease	63	13	1
302–5	Fitting – Grease	27	20	1
302–5	Fitting – Grease	58	29	4
302–5	Fitting – Grease	5	39	1
304–46	Drain – Radiator	30	10	1
304–46	Fitting – Drain	20	25	1
321–2	Screw – Cap Hex. Hd.	13	6	1
321–2	Screw – Cap Hex. Hd.	21	6	1
321–3	Screw – Cap Hex. Hd.	50	9	1
321–4	Screw – Cap Hex. Hd.	33	12	1
321–4	Screw – Cap Hex. Hd.	30	23	7
321–4	Screw – Cap Hex. Hd.	6	31	2
321–4	Screw – Cap Hex. Hd.	56	35	2
321–6	Screw – Cap Hex. Hd.	50	22	2
321–6	Screw – Cap Hex. Hd.	20	31	2
321–8	Screw – Cap Hex. Hd.	20	6	2
321–11	Screw – Cap Hex. Hd.	16	5	2
321–11	Screw – Cap Hex. Hd.	17	6	4
321–15	Screw – Cap Hex. Hd.	10	33	3
321–18	Screw – Cap Hex. Hd.	16	28	2
321–23	Screw – Cap Hex. Hd.	13	13	2
321–39	Screw – Cap Hex. Hd.	1	15	7
321–39	Screw – Cap Hex. Hd.	10	26	2
322–2	Screw – Cap Hex. Hd.	30	43	2
322–2	Screw – Cap Hex. Hd.	34	61	4
322–3	Screw – Cap Hex. Hd.	33	14	4
322–3	Screw – Cap Hex. Hd.	6	14	9
322–3	Screw – Cap Hex. Hd.	27	18	2
322–3	Screw – Cap Hex. Hd.	5	25	8
322–3	Screw – Cap Hex. Hd.	50	26	6
322–3	Screw – Cap Hex. Hd.	14	28	4
322–3	Screw – Cap Hex. Hd.	1	30	4
322–3	Screw – Cap Hex. Hd.	10	35	3
322–4	Screw – Cap Hex. Hd.	50	11	3
322–4	Screw – Cap Hex. Hd.	33	18	2
322–4	Screw – Cap Hex. Hd.	30	36	2
322–4	Screw – Cap Hex. Hd.	2	40	2
322–5	Screw – Cap Hex. Hd.	58	6	3
322–5	Screw – Cap Hex. Hd.	1	19	4
322–5	Screw – Cap Hex. Hd.	56	26	3
322–5	Screw – Cap Hex. Hd.	11	54	1
322–5	Screw – Cap Hex. Hd.	31	60	4
322–6	Screw – Cap Hex Head	7	30	1
322–6	Screw – Cap Hex. Hd.	34	47	8
322–6	Screw – Cap Hex. Hd.	58	17	4
322–7	Screw – Cap Hex. Hd.	27	10	1
322–9	Screw – Cap Hex. Hd.	32	2	2
322–10	Screw – Cap Hex. Hd.	27	3	1
322–12	Screw – Cap Hex. Hd.	58	32	2
323–4	Screw – Cap Hex. Hd.	6	2	2
323–4	Screw – Cap Hex. Hd.	13	43	2
323–5	Screw – Cap Hex. Hd.	20	26	3
323–5	Screw – Cap Hex. Hd.	13	36	3
323–6	Screw – Cap Hex. Hd.	33	11	2
323–6	Screw – Hex Head	59	57	2
323–7	Screw – Cap Hex. Hd.	53	1	4
323–7	Screw – Cap Hex. Hd.	34	57	1
323–9	Screw – Cap Hex. Hd.	5	3	1
323–9	Screw – Cap Hex. Hd.	50	15	1
323–11	Screw – Cap Hex. Hd.	56	39	1
323–12	Screw – Cap Hex. Hd.	28	4	2

*Not Illustrated

TORO PART NUMBER INDEX (Cont.)

Part No.	Description	Pg. No.	Ref. No.	Qty.
323–12	Screw – Cap Hex. Hd.	21	32	2
323–12	Screw – Cap Hex. Hd.	33	36	1
323–12	Screw – Cap Hex. Hd.	57	56	2
323–14	Screw – Cap Hex. Hd.	33	44	3
323–20	Screw – Cap Hex. Hd.	22	49	2
324–7	Screw – Cap Hex. Hd.	21	29	4
325–4	Screw – Cap Hex. Hd.	58	35	4
325–4	Screw – Cap Hex. Hd.	57	59	6
325–5	Screw – Cap Hex. Hd.	64	6	9
325–7	Screw – Cap Hex. Hd.	21	13	2
327–2	Screw – Cap Hex. Hd.	53	3	1
328–7	Screw – Cap Hex. Hd.	56	18	4
328–12	Screw – Cap Hex. Hd.	56	13	2
328–25	Screw – Cap Hex. Hd.	53	30	1
328–27	Screw – Cap Hex. Hd.	54	49	1
3210–8	Screw – Cap, Hex Hd.	23	19	8
3212–4	Screw – Cap Hex. Hd.	64	*	2
3213–2	Screw – Cap Hex. Hd.	33	31	8
3217–6	Nut – Hex	7	32	1
3217–6	Nut – Hex.	27	28	1
3217–9	Nut – Lock	64	7	3
3220–3	Nut – Jam	5	1	2
3220–3	Nut – Jam	53	14	8
3220–5	Nut – Jam	53	36	2
3220–6	Nut	4	27	1
3220–6	Nut – Steering Wheel	3	8	1
3220–7	Nut – Jam	53	23	2
3220–12	Nut – Jam L.H. Thread	53	38	2
3230–2	Bolt – Carriage	33	15	1
3234–5	Screw – Whiz Lock	30	3	6
3234–13	Screw – Cap Flange Hd.	54	52	2
3234–14	Screw – Hex. Washer Hd.	2	33	14
3234–17	Screw – Cap Hex. Hd.	32	11	1
3250–29	Screw – Cap Hex. Hd.	6	7	4
3253–3	Washer – Lock	21	7	1
3253–3	Washer – Lock	6	30	1
3253–3	Washer – Lock	10	32	3
3253–4	Washer – Lock	3	2	2
3253–4	Washer – Lock	6	13	4
3253–4	Washer – Lock	58	16	2
3253–4	Washer – Lock	27	17	2
3253–4	Washer – Lock	1	20	4
3253–4	Washer – Lock	14	29	4
3253–4	Washer – Lock	30	39	4
3253–4	Washer – Lock	34	60	4
3253–5	Washer – Lock	28	5	2
3253–6	Washer – Lock	64	*	2
3253–6	Washer – Lock	7	25	2
3253–7	Washer – Lock	64	5	9
3253–7	Washer – Lock	33	32	8
3253–7	Washer – Lock	59	39	4
3253–7	Washer – Lock	57	58	6
3253–15	Washer – Lock	20	9	5
3253–21	Washer – Lock	50	16	1
3253–21	Washer – Lock	21	33	2
3253–21	Washer – Lock	33	35	1
3253–21	Washer – Lock	13	42	2
3253–33	Washer – Lock	7	31	1
3255–8	Washer – Lock	33	22	2
3255–8	Washer – Lock ETLW	3	31	1
3255–9	Washer – Lock E.T.L.W.	34	49	1
3256–1	Washer – Flat	10	13	5
3256–1	Washer – Flat	1	14	10
3256–1	Washer – Flat	3	29	2
3256–3	Washer – Flat	2	31	4
3256–3	Washer – Flat	10	34	4
3256–5	Washer – Flat	7	4	1
3256–6	Washer – Flat	59	40	4
3256–6	Washer – Flat	57	57	6
3256–22	Washer – Flat	20	4	2
3256–22	Washer – Flat	5	6	2
3256–22	Washer – Flat	3	11	4
3256–22	Washer – Flat	30	22	4
3256–22	Washer – Flat	56	34	2
3256–23	Washer – Flat	58	7	10
3256–23	Washer – Flat	6	12	8
3256–23	Washer – Flat	3	15	6
3256–23	Washer – Flat	33	17	6
3256–23	Washer – Flat	1	18	6
3256–23	Washer – Flat	50	25	2
3256–23	Washer – Flat	56	25	3
3256–23	Washer – Flat	30	38	4
3256–24	Washer	7	5	1
3256–24	Washer – Flat	53	2	2
3256–24	Washer – Flat	5	4	1
3256–24	Washer – Flat	50	17	1
3256–24	Washer – Flat	6	19	3
3256–24	Washer – Flat	56	24	3
3256–24	Washer – Flat	58	30	4
3256–24	Washer – Flat	13	41	2
3256–24	Washer – Flat	34	50	4
3256–26	Washer – Flat	27	2	1
3256–26	Washer – Flat	64	4	9
3256–26	Washer – Flat	3	22	1
3256–26	Washer – Flat	7	24	2
3256–40	Washer – Flat	34	66	4
3256–46	Washer – Flat	7	20	1
3256–69	Washer – Thrust	5	31	3
3256–70	Washer – Flat	32	12	6
3256–78	Washer – Flat	33	25	1
3258–19	Screw – Machine	51	6	2
3258–166	Screw – Phillips Hd.	10	12	5
3258–166	Screw – Phillips Hd.	3	28	2
3258–166	Screw – Phillips Hd.	2	46	3
3269–10	Washer – Back–up	30	30	7
3269–13	Rivet – Pop	30	32	17
3269–15	Rivet – Pop	30	5	8
3272–2	Pin – Cotter	5	5	2
3272–4	Pin – Cotter	1	11	2
3272–5	Pin – Cotter	3	17	3
3272–10	Pin – Cotter	27	1	1
3272–10	Pin – Cotter	58	4	2
3272–10	Pin – Cotter	56	17	3
3272–10	Pin – Cotter	3	21	1
3272–10	Pin – Cotter	6	21	2
3272–10	Pin – Cotter	5	40	4
3272–13	Pin – Cotter	53	25	2
3273–26	Screw – Hex. Socket Hd.	11	45	2
3290–93	Screw – Cap Hex. Hd.	11	39	4
3290–271	Rivet – Pop	30	20	2
3290–354	Plate – Nut	10	36	2
3290–378	Tie – Cable	3	*	3
3290–378	Tie – Cable	30	17	1
3290–378	Tie – Cable	50	28	1
3290–378	Tie – Cable	59	42	3
3290–378	Tie – Cable	57	68	5
3290–379	Tie – Cable	58	1	1
3290–379	Tie – Cable	56	14	3
3290–461	Washer – Belleville	5	21	1
3290–488	Boot – Lift Control	11	40	1
3290–489	Knob – Lift Control	10	3	1
3296–2	Nut – Lock	10	18	3
3296–3	Nut – Lock	6	27	3
3296–9	Nut – Hex.	27	24	2
3296–20	Nut – Lock	3	16	4
3296–23	Nut – Lock	21	16	2
3296–29	Nut – Lock	27	9	4
3296–29	Nut – Lock	58	9	8
3296–29	Nut – Lock	32	14	2
3296–29	Nut – Lock	5	23	8
3296–29	Nut – Lock	6	23	9
3296–29	Nut – Lock	50	27	4

*Not Illustrated

TORO PART NUMBER INDEX (Cont.)

Part No.	Description	Pg. No.	Ref. No.	Qty.
3296–29	Nut – Lock	33	43	10
3296–29	Nut – Lock	57	45	3
3296–29	Nut – Lock	31	59	2
3296–39	Nut – Lock	53	5	2
3296–39	Nut – Lock	6	9	3
3296–39	Nut – Lock	58	31	6
3296–39	Nut – Lock	21	35	2
3296–39	Nut – Lock	33	38	4
3296–39	Nut – Lock	5	38	1
3296–39	Nut – Lock	57	52	2
3296–42	Nut – Lock	20	3	2
3296–42	Nut – Lock	1	13	7
3296–42	Nut – Lock	13	15	2
3296–42	Nut – Lock	50	20	3
3296–42	Nut – Lock	16	21	4
3296–42	Nut – Lock	10	22	4
3296–42	Nut – Lock	30	25	7
3296–42	Nut – Lock	3	30	2
3296–42	Nut – Lock	56	37	2
3296–42	Nut – Lock	34	63	1
3296–44	Nut – Lock	7	22	1
3296–44	Nut – Lock	32	23	3
3296–44	Nut – Lock	56	23	4
3296–48	Nut – Lock	21	45	4
3296–51	Nut – Lock	56	19	6
3296–54	Nut – Lock	6	4	4
3296–56	Nut – Lock	21	4	2
3296–59	Nut – Lock	5	22	1
3296–59	Nut – Lock	6	35	2
3296–59	Nut – Lock	34	54	1
32104–76	Screw – Thread Forming	57	48	2
32105–1	Screw – Cap Hex. Hd.	11	43	1
32105–13	Screw – Cap Hex. Hd.	10	17	2
32105–21	Screw	27	4	2
32107–11	Nut–Square	51	5	2
32108–9	Screw – Machine	21	12	1
32120–74	Ring – Retaining	26	53	1
32120–93	Ring – Retaining	58	25	4
32120–93	Ring – Retaining	56	29	6
32121–2	Pin – Roll	33	4	2
32121–6	Pin – Roll	5	9	1
32121–16	Pin – Roll	5	32	1
32121–38	Pin – Roll	6	22	1
32121–45	Pin – Roll	5	10	2
32121–50	Pin – Roll	5	41	1
32121–122	Pin – Roll	59	44	2
32121–122	Pin – Roll	57	55	3
32122–24	Screw – Round Hd.	20	10	5
32128–20	Nut – Flange Head	32	18	1
32128–20	Nut – Lock	50	19	3
32128–20	Nut – Whiz	30	8	6
32128–26	Nut – Flange	7	21	4
32128–33	Nut – Flange Head	2	45	3
32128–33	Nut – Lock	17	10	4
32128–33	Nut – Lock Flange	20	36	2
32128–33	Nut – Lock, Flange Hd.	11	55	3
32144–1	Screw – Cap Hex. Hd.	11	41	2
32144–5	Nut	23	1	8
32144–10	Screw – Hex. Washer Hd.	13	33	2
32144–14	Screw – Self Tapping	57	66	3
32144–18	Screw – Cap Hex. Hd.	11	46	2
32144–21	Screw	3	6	1
32144–22	Screw – Cap Hex. Hd.	27	13	4
32144–26	Screw – Self–Tapping	3	1	2
32144–49	Screw – Hex. Washer Hd.	59	55	2
32144–112	Screw – Cap Hex. Hd.	21	8	8
32144–112	Screw–Thread Forming	23	13	8
32148–7	Nut – Clinch	30	34	2
32149–1	Nut – Lock	34	59	1
32151–36	Ring – Retaining	53	7	2
32151–36	Ring – Retaining	59	47	4
32151–41	Ring – Retaining	19	13	1
32151–48	Ring – Retaining	58	5	2
32151–48	Ring – Retaining	56	20	3
32151–61	Ring – Retaining	58	18	4
32151–62	Ring – Retaining	21	38	1
32151–77	Ring – Retaining	53	40	1
32152–10	Nut	60	2	1
32152–10	Nut	61	2	1
32152–10	Nut	62	2	1
32152–10	Nut	63	2	1
32153–6	Nut – Lock	53	6	2
340–2	Fitting – Hydraulic Straight	16	15	2
340–3	Fitting – Hydraulic Straight	14	5	1
340–3	Fitting – Hydraulic Straight	28	16	1
340–3	Fitting – Hydraulic, Straight	21	19	2
340–4	Fitting – Hydraulic Straight	28	10	2
340–8	Fitting – Hydraulic Straight	13	11	2
340–13	Fitting – Hydraulic Straight	17	12	2
340–13	Fitting – Hydraulic Straight	14	19	2
340–13	Fitting – Straight	57	64	2
340–18	Fitting – Hydraulic 90°	14	2	2
340–18	Fitting – Hydraulic 90°	18	7	10
340–21	Fitting – Hydraulic Tee	18	13	1
340–77	Fitting – Hydraulic 90°	13	22	1
340–77	Fitting – Hydraulic 90°	16	27	1
340–82	Fitting – Hydraulic 90°	13	47	2
340–87	Fitting – Hydraulic 45°	13	27	1
340–92	Fitting – Hydraulic Straight	17	3	4
340–92	Fitting – Hydraulic Straight	14	17	2
340–92	Fitting – Hydraulic Straight	16	26	4
340–101	Fitting – Hydraulic 45°	14	10	2
340–101	Fitting – Hydraulic 45°	15	11	1
340–103	Fitting – Hydraulic 45°	18	3	5
340–103	Fitting – Hydraulic 45°	58	13	1
340–103	Fitting – Hydraulic 45°	53	32	2
340–124	Fitting – Straight	31	48	2
340–132	Fitting – Hydraulic 90°	16	3	3
340–132	Fitting – Hydraulic 90°	56	4	5
340–132	Fitting – Hydraulic 90°	17	8	1
340–132	Fitting – Hydraulic 90°	58	22	3
340–139	Fitting – Hydraulic 90°	14	23	1
340–139	Fitting – Hydraulic 90°	13	35	1
340–143	Fitting – Hydraulic 90°	17	11	1
340–143	Fitting – Hydraulic 90°	15	18	1
340–143	Fitting – Hydraulic 90°	14	32	1
340–143	Fitting – Hydraulic 90°	57	70	1
351–78	Edging	6	1	1
353–512	Fitting – Hydraulic Plug	17	5	2
353–550	Fitting – Plug	13	44	1
353–599	Pin–Dowel	19	3	2
353–682	Fitting – Hydraulic Straight	13	20	1
353–781	Fitting – 90°	20	30	2
353–989	Plug	15	6	2
353–990	Plug	15	2	11
353–991	Plug	15	17	2
354–20	Fitting – Fuel Tee	20	15	1
354–21	Fitting – Fuel Straight	20	17	1
354–22	Fitting – Fuel, Straight	20	14	2
354–46	Ring–Seal	19	8	1
354–50	Screw–Hex Socket Hd.	19	1	4
354–51	Washer	19	2	4
354–70	Plug	15	21	1
354–72	Fitting – Hydraulic 45°	21	42	1
354–73	Fitting – Hydraulic Straight	13	24	2
354–74	Fitting – Hydraulic Plug	13	16	1
354–75	Fitting – Hydraulic 90°	21	40	1
354–77	Fitting – Hydraulic Test Port	21	23	1
354–77	Fitting – Test Port	14	11	2
354–78	Fitting – Hydraulic	28	3	1
354–79	Cap – Test Port	14	12	2
354–79	Cap – Test Port	21	24	1

*Not Illustrated

TABLE OF CONTENTS

Description	Page
Frame & Body Assembly	1–2
Steering Tower Assembly	3
Steering Valve Assembly No. 75–0600	4
Traction & Brake Pedals Assembly	5
Seat & Throttle Assembly	6
Seat Suspension Assembly	7
Diagnostic–ACE Display Assembly	8
Electrical Schematic	9
Control Console Assembly	10–11
Hydraulic Schematic	12
Hydraulic Reservoir Assembly	13
Hydraulic Control Manifold Assembly	14
Control Manifold Assembly	15
Front Hydraulic Manifolds	16
Rear Hydraulic Manifolds	17
Cutting Unit Hydraulic Components	18
Reel Motor Assembly No. 93–1375	19
Fuel Tank Assembly	20
Front Axle & Transmission Assembly	21–22
Front Axle Assembly No. 93–0084	23–24
Brake Assembly	25
Transmission Assembly No. 75–0012	26
Traction Control Assembly	27
Gear Pump Installation Assembly	28
Hydraulic Pump Assembly No. 93–1376	29
Radiator Assembly	30–31
Muffler & Pump Drive Assembly	32
Engine Installation Assembly	333–34
Timing Gear, Piston, Flywheel & Crankshaft	35
Cylinder Block And Bearing Assembly	36
Valve, Camshaft And Rocker Assembly	37
Oil Pan, Pump Relief Valve	38
Cylinder Head, Manifold & Cover Assembly	39
Timing Gear Case	40
Water Pump Assembly	41
Fuel Injection Pump Assembly	42
Thermostat And Alternator Mount Assembly	43
Fuel And Starter System Assembly	44
Governor	45
Starter Assembly	46
Alternator Assembly	47
Overhaul Gasket Kit	48–49
Engine Components Assembly	50
Air Cleaner Assembly	51
Fuel Filter Assembly	52
Rear Axle Assembly	53–54
Hydraulic Cylinder No. 75–1200	55
Front Lift Arms Assembly	56–57
Rear Lift Arms Assembly	58–59
Hydraulic Cylinder Assembly No. 93–0079	60
Hydraulic Cylinder Assembly No. 85–9880	61
Hydraulic Cylinder Assembly No. 83–7480	62
Hydraulic Cylinder Assembly No. 83–7490	63
R.O.P.S. Assembly (Optional)	64
Special Tools	65
International Parts Reference	66–67
Part Number Index	68–78

PRODUCT CHANGES

In an effort to make improvements available to TORO owners as quickly as possible, minor changes are incorporated into Toro's products from time to time that do not become immediately shown in the Parts Catalog. If such a change has been made in your unit, which is not reflected in your manual, see your TORO Distributor or his Authorized TORO Service Dealer for information and part numbers.

IDENTIFICATION AND ORDERING

MODEL AND SERIAL NUMBERS

The Reelmaster® 5300D has two identification numbers; a model number and a serial number. The two numbers are stamped on a decal which is located on the traction unit frame under the seat. In any correspondence concerning the Reelmaster 5300D, supply model and serial numbers to assure that correct information and replacement parts are obtained.

To order replacement parts from an Authorized TORO Service Dealer, supply the following information:

1. Model and serial number of the Reelmaster 5300D.
2. Part number, description, and the quantity of part(s) desired.

NOTE: Do not order by reference number if a parts catalog is being used; use the PART NUMBER.

COUNTRIES OTHER THAN THE UNITED STATES OR CANADA

Customers who have purchased TORO products exported from the United States or Canada should contact their ToroDistributor (Dealer) to obtain guarantee policies for your country, province or state.

MAINTENANCE RECORD

Date								