Form No. 3370-571 Rev B

TORO®

Count on it.

Parts Catalog

Pro Control™ Spray System Upgrade Kit

2010 Multi-Pro® 5700 Turf Sprayer

Model No. 41009—Serial No. 312000001 and Up

Ordering Replacement Parts

To order replacement parts, please supply the part number, the quantity, and the description of each part desired.

Understanding Reference Numbers

Each identified part in an illustration has a reference number. The reference number for a part also appears in the parts list, along with other information about the part.

This catalog uses two special reference number formats, one to indicate parts in a service assembly and another to indicate the quantity of a given part in an illustration.

Service Assembly Reference Numbers

Parts in service assemblies have reference numbers in the form a:b. The a represents the reference number of the entire service assembly and the b represents a sequential number unique to each part within the service assembly.

For example, a wheel assembly might be identified by reference number 6, the tire by 6:1, the valve by 6:2, and the wheel by 6:3. When you order the assembly identified by reference number 6, you receive all parts identified by reference numbers 6:1,6:2, and 6:3. However, you may also order any part individually. Reference numbers of this type appear in illustration and in parts lists.

Reference Numbers Indicating Quantity

In an illustration, if a reference number indicates more than one part, the reference number has the form nX y. The n represents the quantity of the part, the X is the multiplication symbol, and the y represents the reference number.

For example, in an illustration, the reference number 2X 37 means that two of the parts identified by reference number 37 are indicated.

List of Abbreviations

AR: as required

ASM: assembly

BBC: blade brake control

BHTF: button head thread forming

CARR: carriage

CCW: counter clockwise

CW: clockwise

DEG: degrees

DPA: Dual Point Adjustment

ECM: electronic control module

EXT: external

FH: flat head

GA: gauge

HD: heavy-duty

HF: hex flange

HH: hex head

HHF: hex head flange

HHFTF: hex head flange thread forming

HJ: hex jam

HLH: hex lag head

HOC: height-of-cut

HSBH: hex socket button head

HSFH: hex socket flat head

HSH: hex socket head

HWH: hex washer head

HWHTF: hex washer head thread forming

HYD: hydraulic

LH: left hand

LP: Liquid Propane

NI: nylon insert

NPTF: national pipe thread fine

PFH: phillips flat head

PPH: phillips pan head

PPHTF: phillips pan head thread forming

PRH: phillips round head

PTH: phillips truss head

PTO: power-take-off

RH: right hand

ROPS: roll-over protection system

RRB: rear roller brush

SFH: slotted fillister head

SHH: slotted hex head

SHWH: slotted hex washer head

SPH: slotted pan head

SQH: square head

SRH: slotted round head

STD: standard

TAP: self tapping


TTH: torx truss head

Contents

Pro Control Spray System Upgrade Kit 4
Agitation Valve Assembly No. 120-8542 5
Bypass Valve Assembly No. 119-0456 6

© 2011—The Toro® Company
8111 Lyndale Avenue South
Bloomington, MN 55420


Contact us at www.Toro.com.
Printed in the USA.
All Rights Reserved



Pro Control Spray System Upgrade Kit

Ref.	*Part Number*	*Qty.*	*Description*
1	120-8542	1	Agitation Valve ASM
2	117-7928	1	Adapter ASM
2:2	100-6989	1	O-Ring
3	106-4947	1	Connector
3:1	100-8637	2	O-Ring
4	100-6704	1	Tee
5	106-4933	1	Hosebarb ASM
5:1	100-8637	1	O-Ring
6	106-4936	1	Hosebarb
6:1	100-8637	1	O-Ring
7	100-8635	4	Fork
8	119-0480	1	Hose-Valve, Agitation


Ref.	*Part Number*	*Qty.*	*Description*
9	120-8556	1	Chip-Pro Control Xp, Upgrade
10	120-8553	1	Valve-Ball
11	120-8552	2	Fitting-Straight
12	120-8555	2	O-Ring
13	2412-34	4	Clamp-Hose
14	94-7100	1	Tee
15	94-7103	2	Nipple
16	108-3573	2	Elbow-90 DEG
17	100-6705	1	Nozzle-Agitation
18	99-0766	1	Nut
20	106-4988	1	Tool-Extractor



Agitation Valve Assembly No. 120-8542

Ref.	*Part Number*	*Qty.*	*Description*
1	119-0456	1	Valve (W/Bypass)
2	119-0459	2	Elbow-90 DEG, Flynut
3	119-0531	1	Adapter-Cover
4	119-0522	1	Adapter
5	117-7879	2	Nut-Fly
6	119-0464	1	Hosebarb
7	117-7975	2	Bracke Mounting Kit
8	119-4871	6	Washer
9	119-0497	1	Valve-Balancing

Ref.	*Part Number*	*Qty.*	*Description*
10	119-4863	1	Fork
11	119-4862	2	Fork
12	119-4866	4	Screw-HH
13	33024-00	4	Nut-Lock
14	119-4870	3	O-Ring
15	119-0463	1	Adapter-Male-Male
16	119-4868	2	O-Ring
17	119-4869	1	O-Ring
18	117-7922	2	0-Ring



Bypass Valve Assembly No. 119-0456

Ref.	*Part Number*	*Qty.*	*Description*
1	119-9397	1	Motor Valve Cover ASM
2	119-4868	2	O-Ring
3	119-4862	1	Fork
4	120-7645	1	Seal-Piston, Valve
5	120-7646	1	Piston Valve ASM

Notes:



Count on it.