Form No. 3321-871

# Dingo 320-D

## Traction Unit

**Model Number 22303—990001 & Up**

# Operator’s Manual

# Introduction

Thank you for purchasing a Toro product.

All of us at Toro want you to be completely satisfied with your new product, so feel free to contact your local Authorized Service Dealer for help with service, genuine replacement parts, or other information you may require.

Whenever you contact your Authorized Service Dealer or the factory, always know the model and serial numbers of your product. These numbers will help the Service Dealer or Service Representative provide exact information about your specific product. The two numbers are stamped into a plate mounted on left rear side of frame.

For your convenience, write the product model and serial numbers in the space below.

**Model No:** _____

**Serial No.** _____

Read this manual carefully to learn how to operate and maintain your product correctly. Reading this manual will help you and others avoid personal injury and damage to the product. Although we design, produce and market safe, state-of-the-art products, you are responsible for using the product properly and safely. You are also responsible for training persons, who you allow to use the product, about safe operation.

The warning system in this manual identifies potential hazards and has special safety messages that help you and others avoid personal injury, even death. DANGER, WARNING and CAUTION are signal words used to identify the level of hazard. However, regardless of the hazard, be extremely careful.

**DANGER** signals an extreme hazard that will cause serious injury or death if the recommended precautions are not followed.

**WARNING** signals a hazard that may cause serious injury or death if the recommended precautions are not followed.

**CAUTION** signals a hazard that may cause minor or moderate injury if the recommended precautions are not followed.

Two other words are also used to highlight information. “Important” calls attention to special mechanical information and “Note” emphasizes general information worthy of special attention.

The left and right side of the machine is determined by standing on the platform in the normal operator’s position.

**⚠ WARNING: ⚠**

**The engine exhaust from this product contains chemicals known to the State of California to cause cancer, birth defects, or other reproductive harm.**

©**The Toro Company – 1999**

**8111 Lyndale Ave. South**
**Bloomington, MN 55420–1196**

All Rights Reserved
Printed in the USA

# Contents


| | Page |
|---|---|
| Safety | 2 |
| Safe Operating Practices | 2 |
| Slope Chart | 5 |
| Safety and Instruction Decals | 6 |
| Assembly | 7 |
| Loose Parts | 7 |
| Installing the Valve Lever | 7 |
| Activating the Battery | 7 |
| Specifications | 10 |
| Attachments | 10 |
| Stability Data | 11 |
| Before Operating | 12 |
| Adding Fuel | 12 |
| Draining Water from the Fuel Filter | 13 |
| Checking the Oil Level | 13 |
| Checking the Cooling System | 14 |
| Removing Debris from the Traction Unit | 14 |
| Checking the Hydraulic Fluid | 15 |
| Tire pressure | 15 |

| | Page |
|---|---|
| Operation | 17 |
| Traction Unit Overview | 17 |
| Controls | 18 |
| Indicator Lights | 20 |
| Starting and Stopping the Engine | 20 |
| Driving Forward or Backward | 21 |
| Stopping the Traction Unit | 21 |
| Moving a Non-functioning Traction Unit | 22 |
| Using the Cylinder Locks | 22 |
| Installing and Removing Attachments | 23 |
| Securing the Traction Unit for Transport | 24 |
| Maintenance | 25 |
| Service Interval Chart | 25 |
| Opening the Access Covers | 26 |
| Servicing the Air Cleaner | 27 |
| Servicing the Engine Oil | 28 |
| Greasing the Traction Unit | 29 |
| Changing the Fuel Filter | 30 |
| Bleeding the Fuel System | 31 |
| Draining the Fuel Tank | 31 |
| Servicing the Hydraulic System | 32 |
| Servicing the Battery | 33 |
| Cleaning and Storage | 34 |
| Troubleshooting | 36 |
| Warranty | Back Cover |


**THE ENCLOSED ENGINE OWNER'S MANUAL IS SUPPLIED FOR CALIFORNIA EMISSION CONTROL REGULATION INFORMATION ON EMISSION SYSTEMS, MAINTENANCE AND WARRANTY.**

**KEEP THIS ENGINE OWNER'S MANUAL WITH YOUR UNIT. SHOULD THIS ENGINE OWNER'S MANUAL BECOME DAMAGED OR ILLEGIBLE, REPLACE IMMEDIATELY. REPLACEMENTS MAY BE ORDERED THROUGH THE ENGINE MANUFACTURER.**

# Safety

**Improper use or maintenance by the operator or owner can result in injury. To reduce the potential for injury, comply with these safety instructions and always pay attention to the safety alert ⚠ symbol, which means CAUTION, WARNING, or DANGER—"personal safety instruction." Failure to comply with the instruction may result in personal injury or death.**

## Safe Operating Practices

This product is capable of amputating hands and feet. Always follow all safety instructions to avoid serious injury or death.

**⚠ WARNING**

**POTENTIAL HAZARD**

- **Engine exhaust contains carbon monoxide, which is an odorless, deadly poison.**

**WHAT CAN HAPPEN**

- **Carbon monoxide can kill you and is also known to the State of California to cause birth defects.**

**HOW TO AVOID THE HAZARD**

- **Do not run engine indoors or in an enclosed area.**

### General Operation

- Read, understand, and follow all instructions in the operator's manual, in the video, and on the traction unit before starting. Also, read all attachment manuals where supplied
- Allow only responsible adults who are familiar with the instructions to operate the traction unit.
- Always wear long pants and substantial shoes. Wearing safety glasses, safety shoes, hearing protection, and a hard hat are advisable and may be required by some local ordinances and insurance regulations.
- Ensure that the area is clear of other people before operating the traction unit. Stop the traction unit if anyone enters the area.
- Never carry passengers on attachments or on the traction unit.
- Always look down and behind before and while backing.
- Do not place your feet under the platform.
- Slow down before turning. Sharp turns on any terrain may cause loss of control.
- Never leave a running traction unit unattended. Always lower the loader arms, stop the engine, and remove the key before dismounting.
- Do not exceed the rated operating capacity, as the traction unit may become unstable which may result in loss of control.
- Do not carry a load with the arms raised. Always carry loads close to the ground. Do not step off of the platform with the load raised.
- Do not over-load the attachment and always keep the load level when raising the loader arms. Logs, boards, and other items could roll down the loader arms, injuring you.
- Never jerk the control levers; use a steady motion.
- Keep your hands, feet, hair, and loose clothing away from any moving parts.
- Operate only in daylight or good artificial light.
- Do not operate the traction unit while under the influence of alcohol or drugs.

- Watch for traffic when operating near or crossing roadways.
- Use extra care when loading or unloading the traction unit onto a trailer or truck.
- Do not touch parts which may be hot from operation. Allow them to cool before attempting to maintain, adjust, or service.

## Slope Operation

Slopes are a major factor related to loss-of-control and tip-over accidents, which can result in severe injury or death. All slopes require extra caution.

- Do not operate the traction unit on hillsides or slopes exceeding the angles recommended in the Stability Data section, page 11, and those in the attachment operator's manual. See also the slope chart on page 5.
- **Operate up and down slopes with the heavy end of the traction unit uphill.** Weight distribution changes. An empty bucket will make the rear of the traction unit the heavy end, and a full bucket will make the front of the traction unit the heavy end. Most other attachments will make the front of traction unit the heavy end.
- Raising the loader arms on a slope will affect the stability of the machine. Whenever possible, keep the loader arms in the lowered position when on slopes.
- Removing an attachment on a slope will make the rear of the traction unit heavy. Refer to the Stability Data section, page 11, to determine whether the attachment can be safely removed on the slope.
- Remove obstacles such as rocks, tree limbs, etc. from the work area. Watch for holes, ruts, or bumps, as uneven terrain could overturn the traction unit. Tall grass can hide obstacles.
- Use slow speed on slopes. Before starting the engine, put the pump selector lever in the slow (turtle) position so that you will not have to stop or shift while on the slope.
- Follow the recommendations in the attachment manuals for the use of counterweights to improve stability.
- Use only Toro approved attachments. Attachments can change the stability and the operating characteristics of the traction unit. Warranty may be voided if used with unapproved attachments.
- Keep all movements on slopes slow and gradual. Do not make sudden changes in speed or direction.
- Avoid starting or stopping on a slope. If tires lose traction, proceed slowly, straight down the slope.
- Check for overhead clearances (i.e. branches, doorways, electrical wires) before driving under any objects and do not contact them.
- Avoid turning on slopes. If you must turn, turn slowly and keep the heavy end of the traction unit uphill.
- Do not operate near drop-offs, ditches, or embankments. The traction unit could suddenly turn over if a wheel goes over the edge of a cliff or ditch, or if an edge caves in.
- Do not operate on wet grass. Reduced traction could cause sliding.
- Do not park the traction unit on a hillside or slope without lowering the attachment to the ground and chocking the wheels.
- Do not try to stabilize the traction unit by putting your foot on the ground.

## Children


Tragic accidents can occur if the operator is not alert to the presence of children. Children are often attracted to the traction unit and the work activity. Never assume that children will remain where you last saw them.

- Keep children out of the work area and under the watchful care of another responsible adult.
- Be alert and turn the traction unit off if children enter the area.
- Before and while backing, look behind and down for small children.
- Never carry children. They may fall off and be seriously injured or interfere with safe traction unit operation.
- Never allow children to operate the traction unit.
- Use extra care when approaching blind corners, shrubs, trees, the end of a fence, or other objects that may obscure vision.

## Service


- Stop the engine before performing any service, repairs, maintenance, or adjustments.
- If any maintenance or repair requires the loader arms to be in the raised position, secure the arms in the raised position with the hydraulic cylinder locks included with traction unit.
- Never run a traction unit inside a closed area.
- Keep nuts and bolts tight. Keep equipment in good condition.
- Never tamper with safety devices. Check safety systems for proper operation before each use.
- Keep the traction unit free of grass, leaves, or other debris build-up. Clean up oil or fuel spillage. Allow the traction unit to cool before storing.
- Use extra care when handling fuel. It is flammable and vapors are explosive.
    - Use only an approved container.
    - Never remove the fuel cap or add fuel when the engine is running. Allow the engine to cool before refueling. Do not smoke.
    - Never refuel the traction unit indoors.
    - Never store the traction unit or fuel container inside where there is an open flame, such as near a water heater or furnace.
    - Never fill a container while it is inside a vehicle, trunk, pick–up bed, or any surface other than the ground.
    - Keep container nozzle in contact with the tank during filling.
- Stop and inspect the equipment if you strike an object. Make any necessary repairs before restarting.
- Use only genuine replacement parts to ensure that original standards are maintained.
- Battery acid is poisonous and can cause burns. Avoid contact with skin, eyes, and clothing. Protect your face, eyes, and clothing when working with a battery.
- Battery gases can explode. Keep cigarettes, sparks and flames away from the battery.
- Keep your body and hands away from pin hole leaks or nozzles that eject high pressure hydraulic fluid. Use cardboard or paper to find hydraulic leaks. Hydraulic fluid escaping under pressure can penetrate skin and cause injury requiring surgery within a few hours by a qualified surgeon or gangrene may result.

# Slope Chart


ALIGN THIS EDGE WITH A VERTICAL SURFACE
(TREE, BUILDING, FENCEPOST, POLE ETC.)
THIS IS A 5° SLOPE
THIS IS A 10° SLOPE
THIS IS A 15° SLOPE
THIS IS A 20° SLOPE
FOLD ALONG APPROPRIATE LINE
EXAMPLE: COMPARE SLOPE WITH FOLDED EDGE
M−4402


# Safety and Instruction Decals

Safety decals and instructions are easily visible to the operator and are located near any area of potential danger. Replace any decal that is damaged or lost.




# 98-8219


# 98-8235




# 93-7814




# 93-6680




# 93-9084




# 85-4730





# 98-4682




# 98-4677




# 98–8220





# 93-6681




# 80-8010




# 98-9051




# 99-3157

**Figure 1**

1. Fast
2. Traction drive
3. Slow
4. Entanglement hazard
5. Stay away from moving parts
6. Use only diesel fuel
7. Lift point
8. Engine speed
9. Cutting hazard—moving fan

# Assembly

## Loose Parts

**Note:** Use the chart below to verify that all parts have been shipped.

| DESCRIPTION | QTY. | USE |
|---|---|---|
| Traction Unit | 1 | Install valve lever |
| Valve Lever | 1 | |
| Key | 2 | Start engine |

## Installing the Valve Lever

**1.** Thread the lever into the pump selector valve (Fig. 2).

**Note:** The lever should be installed with the bend toward the operator.

**2.** Tighten the jam nut on the lever to lock it in position.





**Figure 2**

1. Pump selector lever

## Activating the Battery

The traction unit is shipped with a dry battery. Bulk electrolyte with 1.260 specific gravity must be purchased from a local battery supply outlet.

**1.** Remove the four bolts securing the battery cover and remove the cover (Fig. 3)

**2.** Remove the nuts and bars securing the battery (Fig. 3).





**Figure 3**

1. Battery cover
2. Bolt
3. Battery
4. Bars
5. Nut
6. Positive cable
7. Negative cable

**3.** Lift the battery off of its platform.

## ⚠ DANGER

**POTENTIAL HAZARD**

- **Battery electrolyte contains sulfuric acid which is a deadly poison and it causes severe burns.**

**WHAT CAN HAPPEN**

- **If you drink electrolyte you could die, or, if it gets onto your skin, you will be burned.**

**HOW TO AVOID THE HAZARD**

- **Do not drink electrolyte and avoid contact with skin, eyes or clothing. Wear safety glasses to shield your eyes and rubber gloves to protect your hands.**
- **Fill the battery where clean water is always available for flushing the skin.**
- **Follow all instructions and comply with all safety messages on the electrolyte container.**

**4.** Remove the filler caps from the battery.

**5.** Slowly pour electrolyte into each cell until the electrolyte level is up to the lower part of the tube (Fig. 4).





**Figure 4**

1. Filler caps
2. Electrolyte
3. Lower part of the tube

**6.** Leave the covers off and connect a 3 to 4 amp battery charger to the battery posts (Fig. 5).





**Figure 5**

1. Positive post
2. Negative post
3. Charger red (+) wire
4. Charger black (–) wire

**7.** Charge the battery at a rate of 4 amperes or less for 4 hours (12 volts).

## ⚠ WARNING

**POTENTIAL HAZARD**

- **Charging the battery produces gasses.**

**WHAT CAN HAPPEN**

- **Battery gasses can explode.**

**HOW TO AVOID THE HAZARD**

- **Keep cigarettes, sparks, and flames away from the battery.**

**8.** When the battery is fully charged, disconnect the charger from the electrical outlet and from the negative and positive battery posts (Fig. 5).

**9.** Slowly pour electrolyte into each cell until the level is once again up to the upper line on the battery case (Fig. 4) and install the covers.

**10.** Install the battery onto its platform (Fig. 3).

**11.** Secure the battery in the chassis with the bars and nuts removed previously (Fig. 3).

**12.** Connect the positive (red) cable to the positive (+) battery post (Fig. 3). Slide the rubber cover over the battery post.

**13.** Connect the negative (black) cable to the negative (–) battery post (Fig. 3).

**Note:** Ensure that the battery cables do not contact any sharp edges or each other.

**14.** Install the battery cover (Fig. 3).

# Specifications

**Note:** Specifications and design are subject to change without notice.

| | |
|---|---|
| Width | 40.5 inches (103 cm) |
| Length | 60 inches (152 cm) |
| Height | 49 inches (125 cm) |
| Weight | 1722 lbs (781 Kg) |
| Operating capacity (with a 200 lb operator) | 515 lbs (234 Kg) |
| Tipping capacity (with a 200 lb operator) | 1030 lbs (467 Kg) |
| Wheelbase | 28 inches (71 cm) |
| Dump height (with standard bucket) | 48.75 inches (124 cm) |
| Reach—fully raised (with the standard bucket) | 26 inches (66 cm) |
| Height to hinge pin (with the standard bucket fully raised) | 66 inches (168 cm) |


## Attachments

Many attachments are available for use with the traction unit. These attachments allow you to to perform many different functions with the traction unit such as hauling materials, digging holes, grading, and more. Contact your Toro dealer for a list of all approved SiteWork Systems attachments and accessories.

**IMPORTANT: Use only Toro approved attachments.**

# Stability Data

The following table lists the maximum slope recommended for the traction unit in the positions listed in the table. Slopes over the listed degree may cause the traction unit to become unstable. The data in the table assumes that the loader arms are fully lowered and that the factory installed tires are on the traction unit, inflated to the recommended pressure; raised arms and other tire types or pressure may affect the stability.

| **Configuration** | **Maximum Recommended Slope when Operating with:** | | |
|---|---|---|---|
| | **Front Uphill**  | **Rear Uphill**  | **Side Uphill**  |
| Traction unit without attachment | 7° | 20° | 17° |
| Traction unit with counterweight, without attachment | 5° | 21° | 17° |
| Traction unit with an attachment rated with one of the following stability ratings for each slope position:* | | | |
| **A** | 25° | 25° | 20° |
| **B** | 18° | 19° | 18° |
| **C** | 15° | 16° | 14° |
| **D** | 10° | 10° | 9° |
| **E** | 5° | 5° | 5° |

* In each attachment manual is a set of three stability ratings, one for each hill position. To determine the maximum slope you can traverse with the attachment installed, find the degree of slope that corresponds to the stabilities ratings of the attachment.

Example: If the attachment installed on the traction unit has a Front Uphill rating of B, a Rear Uphill rating of D, and a Side Uphill rating of C, then you could drive forward up an 18° slope, rearward up a 10° slope, or sideways on a 14° slope, as listed in the above table.

# Before Operating

Before operating, check the fuel and oil level, remove debris from the traction unit, and check the tire pressure. Also, ensure that the area is clear of people and debris. You should also know and have marked the locations of all utility lines.

## Adding Fuel

The engine runs on clean, fresh diesel fuel with a minimum cetane rating of 40. Purchase fuel in quantities that can be used within 30 days to ensure fuel freshness.

Use summer grade diesel fuel (No. 2–D) at temperatures above 20˚ F (–7˚ C) and winter grade diesel fuel (No. 1–D or No. 1–D/2–D blend) below 20˚ F (–7˚ C). Use of winter grade diesel fuel at lower temperatures provides lower flash point and pour point characteristics, allowing easier starts and lessening the chances of chemical separation of the fuel due to lower temperatures.

Use of summer grade diesel fuel above 20˚ F (–7˚ C) will contribute toward longer life of the fuel pump components.

**IMPORTANT: Do not use kerosene or gasoline in place of diesel fuel. Failure to observe this caution will damage the engine.**

1. Park the traction unit on a level surface, lower the loader arms, and stop the engine.
2. Remove the key and allow the engine to cool.
3. Clean around the fuel tank cap and remove the cap.
4. Use a funnel and add diesel fuel to the fuel tank, until the level is 1/4 to 1/2 inch (6 mm to 13 mm) below the bottom of the filler neck.

   **Note:** This space in the tank allows fuel to expand. Do not fill the fuel tank completely full.

5. Install the fuel tank cap securely. Wipe up any fuel that may have spilled.

If possible, fill the fuel tank after each use. This will minimize possible buildup of condensation inside the fuel tank.

**⚠ DANGER**

**POTENTIAL HAZARD**

- **Under certain conditions fuel is extremely flammable and highly explosive.**

**WHAT CAN HAPPEN**

- **A fire or explosion from fuel can burn you, others, and cause property damage.**

**HOW TO AVOID THE HAZARD**

- **Fill the fuel tank outdoors, in an open area, when the engine is cold. Wipe up any fuel that spills.**
- **Do not fill the fuel tank completely full. Add fuel to the fuel tank until the level is 1/4 to 1/2 in. (6 to 13 mm) below the bottom of the filler neck. This empty space in the tank allows fuel to expand.**
- **Never smoke when handling fuel, and stay away from an open flame or where fuel fumes may be ignited by a spark.**
- **Store fuel in an approved container and keep it out of the reach of children. Never buy more than a 30-day supply.**

## Draining Water from the Fuel Filter

Drain water or other contaminants from the fuel filter daily.

1. Stop the engine and remove the key.
2. Open the rear access cover; refer to Opening the Rear Access Cover, page 26.
3. Turn the drain valve until the water runs out of the filter (Fig. 6).

   **Note:** The fuel filter is located near the bottom of the fuel tank.





**Figure 6**

1. Fuel filter
2. Drain valve

4. Close the valve.
5. Close the rear access cover.

## Checking the Oil Level

1. Park the traction unit on a level surface, lower the loader arms, and stop the engine.
2. Remove the key and allow the engine to cool.
3. Open the rear access cover; refer to Opening the Rear Access Cover, page 26.
4. Clean around the oil dipstick (Fig. 7).
5. Pull out the dipstick and wipe the metal end clean (Fig. 7).
6. Slide the dipstick fully into the dipstick tube (Fig. 7).
7. Pull the dipstick out and look at the metal end.
8. If the oil level is low, clean around the oil filler cap and remove the cap (Fig. 7).
9. Slowly pour only enough oil into the valve cover to raise the level to the F (full) mark.

   **IMPORTANT: If you overfill the crankcase with oil, the excess oil may damage the engine.**

10. Replace the filler cap and dipstick.





**Figure 7**

1. Oil dipstick
2. Filler cap
3. Valve cover
4. Metal end

11. Close the rear access cover.

## Checking the Cooling System

The cooling system is filled with a 50/50 solution of water and permanent ethylene glycol anti–freeze. Check the level of coolant at the beginning of each day, before starting the engine.

**⚠ DANGER**

**POTENTIAL HAZARD**
- **Coolant is hot and pressurized.**

**WHAT CAN HAPPEN**
- **Discharge of hot pressurized coolant can cause severe burns.**

**HOW TO AVOID THE HAZARD**
- **Do not remove the radiator cap when the engine is hot. Always allow the engine to cool at least 15 minutes or until the radiator cap is cool enough to touch without burning your hand before removing it.**

1. Park the traction unit on a level surface, lower the loader arms, and stop the engine. Remove the key.
2. Allow the engine to cool.
3. Remove the radiator filler cap and check the coolant level (Fig. 8). The coolant should be up to filler neck.
4. If coolant level is low, replenish the system.

   **IMPORTANT: Do not over fill the radiator.**
5. Replace the radiator filler cap, ensuring that it is tightly sealed.





**Figure 8**

1. Filler Cap

## Removing Debris from the Traction Unit

**IMPORTANT: Operating the engine with a blocked radiator, may result in engine damage from overheating.**

1. Park the traction unit on a level surface, raise the loader arms, and install the cylinder locks; refer to Using the Cylinder Locks, page 22.
2. Stop the engine and remove the key.
3. Remove the front access cover, refer to Removing the Front Access Cover, page 26.
4. Clean any debris from the grill.
5. Open the rear access cover; refer to Opening the Rear Access Cover, page 26.
6. Wipe away debris from the air cleaner.
7. Clean any debris build–up on the engine with a brush or blower before each use.

   **IMPORTANT: It is preferable to blow dirt out, rather than washing it out. If water is used, keep it away from electrical items and hydraulic valves. Do not use a high-pressure washer. High-pressure washing can damage the electrical system and hydraulic valves or deplete grease.**
8. Replace and secure the front and rear access covers.

**9.** Remove and store the cylinder locks (refer to Using the Cylinder Locks, page 22), and lower the loader arms.

## Checking the Hydraulic Fluid

Check the hydraulic fluid level before the engine is first started and after every 25 operating hours.

Hydraulic Tank Capacity: 17.25 gal. (67 l)

Use only Group 1 ISO type 46/68 anti–wear hydraulic fluids, recommended for ambient temperatures consistently below 100°F (38°C), such as Toro Hy–Pro, Mobil Fluid 424, or other equivalent fluid.

**IMPORTANT: Use only the group 1 ISO type 46/68 anti–wear hydraulic fluids. Other fluids could cause system damage.**

**1.** Remove the attachment, if one is installed; refer to Removing an Attachment, page 24.

**2.** Park the traction unit on a level surface, raise the loader arms, and install the cylinder locks; refer to Using the Cylinder Locks, page 22.

**3.** Stop the engine and remove the key.

**4.** Remove the front access cover, refer to Removing the Front Access Cover, page 26.

**5.** Clean the area around the filler neck of the hydraulic tank (Fig. 9).

**6.** Remove the cap from the filler neck and check the fluid level on the dipstick (Fig. 9).

The fluid level should be 1/2 to 3/8 inches (10 to 15 mm) below the mark on the dipstick when the loader arms are raised. If the loader arms are lowered, the fluid level should be at the mark on the dipstick.





**Figure 9**

1. Filler neck cap
2. Dipstick

**7.** If the level is low, add enough fluid to raise it to the proper level.

**8.** Install the cap on the filler neck.

**9.** Install the front access cover.

**10.** Remove and store the cylinder locks (refer to Using the Cylinder Locks, page 22) and lower the loader arms.

## Tire pressure

Maintain the air pressure in the tires as specified. Check the tires when they are cold to get the most accurate reading.

Pressure: 15–20 psi (103–138 kPa)

**Note:** Use a lower tire pressure (15 psi/ 103 kPa) when operating in sandy soil conditions to provide better traction in the loose soil.





**Figure 10**

1. Valve stem

# Operation

## Traction Unit Overview

Figure 11 contains a front and back view of the traction unit. Familiarize yourself with all of the traction unit components listed in Figure 11.





**Figure 11**

1. Mount plate
2. Tilt cylinder
3. Auxiliary hydraulic couplers
4. Loader arms
5. Front access cover
6. Fuel tank
7. Wheel
8. Lift cylinder
9. Operator platform
10. Rear access cover (open)
11. Engine
12. Air filter
13. Control panel
14. Lift points
15. Handle
16. Battery
17. Indicator lights

---

**⚠ CAUTION**

**POTENTIAL HAZARD**

- **The operator could fall off of the platform.**

**WHAT CAN HAPPEN**

- **The operator could be seriously injured.**

**HOW TO AVOID THE HAZARD**

- **Do not move any of the control levers unless standing with both feet on the platform and with hands holding the handles.**

# Controls

Become familiar with all the controls (Fig. 12) before you start the engine and operate the traction unit.





**Figure 12**

1. Traction control levers
2. Attachment tilt lever
3. Loader arm lever
4. Auxiliary hydraulics lever
5. Speed selector lever
6. Throttle lever
7. Key switch

## Key Switch

The key switch, used to start and stop the engine, has three positions: stop, run, and start.

To start the engine, rotate the key to the start position. Release the key when engine starts and it will move automatically to the run position.

To stop the engine, rotate the key to the stop position.

## Throttle Lever

Move the control forward to increase the engine speed and rearward to decrease speed.

## Traction Control Levers

To move forward, move the traction control levers forward. To move rearward, move the traction control levers rearward.

To go straight, move both traction control levers equally.

To turn, move the lever located on the side you want to turn back toward the neutral position while keeping the other lever engaged.

The farther you move the traction control levers in either direction, the faster the traction unit will move in that direction.

To slow or stop, move the traction control levers to neutral.

## Attachment Tilt Lever

To tilt the attachment forward, slowly push the attachment tilt lever forward.

To tilt the attachment rearward, slowly pull the attachment tilt lever rearward.

## Loader Arm Lever

To lower the loader arms, slowly push the loader arm lever forward.

To raise the loader arms, slowly pull the loader arm lever rearward.

## Auxiliary Hydraulics Lever

To operate a hydraulic attachment in a forward direction, slowly pull the auxiliary hydraulics lever rearward.

To operate a hydraulic attachment in a reverse direction, slowly push the auxiliary hydraulics lever forward.

## Speed Selector Lever

Move the speed selector lever to the fast (rabbit) position to set the traction drive, loader arms, and attachment tilt to high speed and the auxiliary hydraulics to low speed.

Move the speed selector lever to the slow (turtle) position to set the auxiliary hydraulics to high speed and the traction drive, loader arms, and attachment tilt to low speed.

**⚠ WARNING**

**POTENTIAL HAZARD**

- **If the speed selector lever is moved while the traction unit is in motion, the traction unit will either stop suddenly or accelerate quickly.**
- **If the traction unit is operated with the speed selector lever in an intermediate position, the traction unit will operate erratically and may be damaged.**

**WHAT CAN HAPPEN**

- **You could be thrown forward or backwards, resulting in injury.**
- **If the traction unit accelerates quickly, you could loose control of the traction unit and injure bystanders or yourself.**
- **You could loose control of the traction unit, severely injuring yourself or others.**
- **The traction unit could be damaged.**

**HOW TO AVOID THE HAZARD**

- **Do not move the speed selector lever when the traction unit is in motion.**
- **Do not operate the traction unit when the speed selector is in any intermediate position (i.e., any position other than fully forward or fully rearward).**

## Flow Divider Control

The traction unit hydraulics (i.e., the traction drive, loader arms, and attachment tilt) work on a separate hydraulic circuit from the auxiliary hydraulics for powering attachments; however, the two systems share the same hydraulic pumps. Using the flow divider control (Fig. 13), you can vary the speed of the traction unit hydraulics by diverting hydraulic flow to the auxiliary hydraulics circuit. The flow divider allows you to divide the flow of fluid in varying degrees to slow the traction unit. Thus, the more hydraulic flow you divert to the auxiliary hydraulics, the slower the traction unit hydraulics will move.

**Note:** The flow divider position (i.e., 9–12 o'clock) is determined when standing in the normal operator's position. Figure 13 shows the flow divider from the front.





**Figure 13**

1. Flow divider control
2. Knob
3. 12 o'clock position
4. 10 to 11 o'clock position
5. 9 o'clock position

- Move the flow divider control to the twelve–o'clock position to provide maximum speed to the traction unit hydraulics.

  Use this setting for fast operation of the traction unit.

- Move the flow divider control between the twelve–o'clock and nine–o'clock positions to slow the traction unit hydraulics and fine tune the speed.

  Use a setting in this range with attachments with hydraulics where you need to both run the attachment and move the traction unit hydraulics, such as the auger, boring unit, hydraulic blade, and tiller.

- Move the control to the nine–o'clock position to transfer all hydraulic flow to the auxiliary hydraulics of the attachment.

  In this setting, the traction unit hydraulics will not work. Use this setting with hydraulic attachments that do not required the traction unit hydraulics. There are currently no attachments that require the nine–o'clock position; however,

the trencher does work best if you set it close to nine–o'clock so that the traction unit will creep slowly when trenching.

**Note:** The flow divider control can be fixed in place by turning the knob on the control clockwise until it contacts the dial (Fig. 13).

# Indicator Lights

The indicator lights warn you in the case of a system malfunction and, in the case of the glow plug light, indicate that the glow plugs are on. Figure 14 illustrates the four indicator lights.





**Figure 14**

1. Engine temperature light
2. Oil pressure light
3. Battery light
4. Glow plug light

## Engine Temperature Light

If the engine temperature light is on, the engine is overheating. Stop the engine and allow the traction unit to cool down. Check the coolant level and the belts to the fan and water pump. Fill the coolant as required and replace any worn or slipping belts. If the problem persists, contact your Authorized Toro Dealer for diagnostics and repair.

## Oil Pressure Light

This light is on for a few seconds whenever you start the engine. If the oil pressure light is on while the engine is running, the engine oil pressure is low. Stop the engine and allow the traction unit to cool down. Check the oil level and fill the crankcase with oil as needed. If the problem persists, contact your Authorized Toro Dealer for diagnostics and repair.

## Battery Light

This light is on for a few seconds whenever you start the engine. If the battery light is on while the engine is running, the alternator, battery, or electrical system is broken. Contact your Authorized Toro Dealer for diagnostics and repair.

## Glow Plug Light

This light is on when the key is turned to run before starting the engine. The glow plug light will remain on for up to 10 seconds, indicating that the glow plugs are warming the engine. If the glow plug light is on while the engine is running, the glow plugs are broken. Contact your Authorized Toro Dealer for diagnostics and repair.

# Starting and Stopping the Engine

## Starting the Engine

**1.** Stand on the platform.

**2.** Move the auxiliary hydraulics valve lever to neutral.

**3.** Move the throttle lever midway between slow (turtle) and fast (rabbit) positions.

**4.** Insert the key into the ignition and turn it to the run position.

**Note:** The battery, oil pressure, and glow plug lights will come on.

**5.** When the glow plug light turns off, turn the key to the start position. When the engine starts, release the key.

**Note:** A warm or hot engine may be started without waiting for the light to turn off.

**IMPORTANT: Do not engage the starter for more than 10 seconds at a time. If the engine fails to start, allow a 30 second cool-down period between attempts. Failure to follow these instructions can burn out the starter motor.**

6. Move the throttle lever to the desired setting.

**IMPORTANT: If the engine is run at high speeds when the hydraulic system is cold (i.e., when the ambient air temperature is around freezing or lower), hydraulic system damage could occur. When starting the engine in cold conditions, allow the engine to run in the middle throttle position for 2 to 5 minutes before moving the throttle to fast (rabbit).**

### Stopping the Engine

1. Move the throttle lever to the slow (turtle) position.
2. Lower the loader arms to the ground.
3. Turn the ignition key to the stop position.

**Note:** If the engine has been working hard or is hot, let it idle for a minute before stopping it. This helps to cool the engine. In an emergency, the engine may be stopped immediately.

## Driving Forward or Backward

The throttle control regulates the engine speed as measured in rpm (revolutions per minute). Place the throttle lever in the fast (rabbit) position for best performance.

**Note:** You can use a slower throttle position to operate the traction unit at slower speeds.

To drive the traction unit, complete the following actions as necessary:

- To move forward, move the traction control levers forward.
- To move rearward, move the traction control levers rearward.
- To go straight, move both traction control levers equally.
- To turn, move the lever located on the side you want to turn toward the neutral position while keeping the other lever engaged.
- To slow or stop, move the traction control levers to neutral.

**Note:** The farther you move the traction control levers in either direction, the faster the traction unit will move in that direction.

## Stopping the Traction Unit

To stop the traction unit, move the traction control levers to neutral and the throttle lever to slow (turtle), lower loader arms to the ground, and stop the engine. Remove the key.

**⚠ CAUTION**

**POTENTIAL HAZARD**
- **Someone could move or attempt to operate the traction unit while it is unattended.**

**WHAT CAN HAPPEN**
- **Children or bystanders may be injured if they use the traction unit.**

**HOW TO AVOID THE HAZARD**
- **Always remove the ignition key when leaving the traction unit, even if just for a few seconds.**

# Moving a Non-functioning Traction Unit

**IMPORTANT: Never tow or pull the traction unit. Rotating the wheels manually will cause damage to the hydraulic wheel motors.**

1. Stop the engine.
2. Lift the traction unit off the ground, using the two lift points (Fig. 15), and move it onto a trailer.





**Figure 15**

1. Lift points

# Using the Cylinder Locks

**⚠ WARNING**

**POTENTIAL HAZARD**
- **The loader arms may lower when in the raised position.**

**WHAT CAN HAPPEN**
- **Anyone under the loader arms may be injured or crushed.**

**HOW TO AVOID THE HAZARD**
- **Always install the cylinder locks when doing maintenance that requires raised loader arms.**

## Installing the Cylinder Locks

1. Start the engine.
2. Raise the loader arms to the fully raised position.
3. Stop the engine.
4. Position a loader arm cylinder lock over each lift cylinder rod (Fig. 16).
5. Secure each loader arm cylinder lock with a clevis pin and cotter pin (Fig. 16).





**Figure 16**

1. Cylinder lock
2. Lift cylinder
3. Hairpin cotter
4. Clevis pin
5. Lift cylinder rod

6. Start the engine.
7. Slowly lower the loader arms until cylinder locks contact the cylinder body and rod end.
8. Stop the engine.

## Removing/Storing the Cylinder Locks

1. Start the engine.
2. Raise the loader arms to the fully raised position.
3. Stop the engine.
4. Remove the clevis pin and cotter pin securing each cylinder lock.
5. Remove the cylinder locks.
6. Lower the loader arms.
7. Install the cylinder locks over the hydraulic hoses and secure them with the clevis pins and cotter pins (Fig. 17).





**Figure 17**

1. Hydraulic hoses
2. Cylinder locks
3. Hairpin cotter
4. Clevis pin

# Installing and Removing Attachments

## Connecting an Attachment

**IMPORTANT: Use only Toro approved attachments. Attachments can change the stability and the operating characteristics of the traction unit. The warranty of the traction unit may be voided if used with unapproved attachments.**

**IMPORTANT: Before installing the attachment, ensure that the mount plates are free of any dirt or debris.**

**1.** Position the attachment on a level surface with enough space behind it to accommodate the traction unit.

**2.** Move the speed selector lever to the turtle position.

**3.** Start the engine.

**4.** Slowly push the attachment tilt lever forward to tilt the attachment mount plate forward.

**5.** Position mount plate into the upper lip of the attachment receiver plate (Fig. 18).





**Figure 18**

1. Mount plate
2. Receiver plate

**6.** Raise the loader arms while tilting back the mount plate at the same time.

**IMPORTANT: The attachment should be raised enough to clear the ground, and the mount plate should be tilted all the way back.**

**7.** Stop the engine.

**8.** Engage the quick attach pins (Fig. 19).

**9.** Ensure that the cam collars are seated on top of the cast pin brackets (Fig. 19).





**Figure 19**

1. Quick attach pins (shown in engaged position)
2. Cam collars

## Connecting the Hydraulic Hoses

If the attachment requires hydraulics for operation, connect the hydraulic hoses as follows:

**1.** Stop the engine.

**2.** Move the auxiliary hydraulics lever forward, backward, and back to neutral to relieve pressure at the hydraulic couplers.

**IMPORTANT: Ensure that all foreign matter is cleaned from the hydraulic connections before making connections.**

3. Remove the protective covers from the hydraulic couplers on the traction unit. Connect the covers together to prevent contamination during operation.

4. Slide the collars back on the hydraulic couplers and connect the attachment couplers to the traction unit couplers.

**⚠ WARNING**

**POTENTIAL HAZARD**
- **Hydraulic fluid escaping under pressure can penetrate skin and cause injury.**

**WHAT CAN HAPPEN**
- **Fluid accidentally injected into the skin must be surgically removed within a few hours by a doctor familiar with this form of injury or gangrene may result.**

**HOW TO AVOID THE HAZARD**
- **Keep body and hands away from pin hole leaks or nozzles that eject high pressure hydraulic fluid.**
- **Use cardboard or paper to find hydraulic leaks, never use your hands.**

5. Confirm that the connection is secure by pulling on the hoses.

### Removing an Attachment

1. Lower the attachment to the ground

2. Stop the engine.

3. Disengage the quick attach pins by turning them to the outside.

4. If the attachment uses hydraulics, move the auxiliary hydraulics lever forward, backward, and back to neutral to relieve pressure at the hydraulic couplers.

5. If the attachment uses hydraulics, slide the collar back on the hydraulic couplers and disconnect them.

**IMPORTANT: Connect the attachment hoses together to prevent hydraulic system contamination during storage.**

6. Install the protective covers onto the hydraulic couplers on the traction unit.

7. Start the engine, tilt the mount plate forward, and back the traction unit away from the attachment.

## Securing the Traction Unit for Transport

When transporting the traction unit on a trailer, always use the following procedure:

**IMPORTANT: Do not operate or drive the traction unit on roadways.**

1. Lower the loader arms.

2. Stop the engine.

3. Secure the traction unit to the trailer with chains or straps using the operator platform support openings to secure the rear of the traction unit and the loader arms/mount plate to secure the front of the traction unit.

# Maintenance

## Service Interval Chart

| Service Operation | Each Use | 8 Hours | 25 Hours | 75 Hours | 100 Hours | 200 Hours | 400 Hours | Yearly |
|---|---|---|---|---|---|---|---|---|
| Hydraulic Fluid—check level | Initial | | X | | | | | |
| Hydraulic Fluid—change | | | | | | | X | |
| Hydraulic Filter—change | | Initial | | | | X | | |
| Engine Oil—check level | X | | | | | | | |
| Engine Oil—change[1] | | | | X (Initial at 50) | | | | |
| Engine Oil Filter—change (150 hours or every other oil change)[1] | | | | | 150 hrs | | | |
| Wheel Nuts—tighten | | Initial | | | | | | |
| Chassis—grease[2] | | X | | | | | | |
| Primary Air Filter—clean[1] or replace | | | | | | X | | |
| Safety Air Filter—replace[1] | | | | | | | | 600 hrs |
| Engine RPM (idle & full throttle)—check | | | | | | | X | |
| Fuel—drain[3] | | | | | | | | X |
| Hydraulic lines—check | | | | | X | | | |
| Battery–-check electrolyte | | | | | X | | | |
| Battery—charge, disconnect cables[3] | Initial | | | | | | | X |
| Fuel Filter—replace | | | | | | X | | |
| Fan and Water Pump Belt—check[6] | | | | | X | | | |
| Radiator Coolant Level—check | X | | | | | | | |
| Radiator—flush & change coolant[6] | | | | | | | | X |
| Tires—check pressure | X | | | | | | | |
| Fasteners—check/tighten | X | | | | | | | |
| Chipped Surfaces—paint[3] | | | | | | | | X |

[1] More often in dusty, dirty conditions, [2] Immediately after every washing, [3] Storage Service, [4] Immediately if water is present, [5] Replace moving lines every 2 years or 1500 operating hours, [5] Refer to your engine Operator's Manual or contact you Authorized Toro Dealer for service.

**⚠ CAUTION**

**POTENTIAL HAZARD**
- **If you leave the key in the ignition switch, someone could start the engine.**

**WHAT CAN HAPPEN**
- **Accidental starting of the engine could seriously injure you or other bystanders.**

**HOW TO AVOID THE HAZARD**
- **Remove the key from the ignition switch and and disconnect negative battery cable from battery before you do any maintenance.**

# Opening the Access Covers

## Removing the Front Access Cover

**1.** Raise the loader arms and install the cylinder locks; refer to Using the Cylinder Locks, page 22.

**Note:** In the case that you need to remove the front access cover without raising the loader arms, be very careful not to damage the cover or hydraulic hoses as you maneuver the cover out from under the arms.

**2.** Stop the engine and remove the key.

**3.** Release the four locking tabs (Fig. 20).

**4.** Pull the cover off of the traction unit (Fig. 20).





**Figure 20**

1. Front access cover
2. Locking tabs

**5.** When finished, replace the front access cover and secure it with the four locking tabs.

## Opening the Rear Access Cover

**1.** Stop the engine and remove the key.

**2.** Release the two locking tabs on top of the rear access cover (Fig. 21).

**3.** Grasping the handle, pull the cover up and back to swing it open (Fig. 21).





**Figure 21**

1. Rear access cover
2. Locking tabs

**4.** When finished, close the rear access cover by swinging it up and seating it in place. Secure it with the two locking tabs.

# Servicing the Air Cleaner

Primary Filter: Clean or replace every 200 operating hours.

Safety Filter: Replace after every 600 operating hours.

**Note:** Service the air cleaner more frequently if operating conditions are extremely dusty or sandy.

## Removing the Filter

**1.** Lower the loader arms and stop the engine. Remove the key.

**2.** Open the rear access cover; refer to Opening the Rear Access Cover, page 26.

**3.** Release the latches on the air cleaner and pull the air cleaner cover off of the air cleaner body (Fig. 22).

**4.** Clean the inside of the air cleaner cover with compressed air.

**5.** Gently slide the primary filter out of the air cleaner body (Fig. 22). Avoid knocking the filter into the side of the body. Do not remove the safety filter, unless you intend to replace it as well.

**6.** Inspect the primary filter for damage by looking into the filter while shining a bright light on the outside of the filter. Holes in the filter will appear as bright spots. If the filter is damaged, discard it; otherwise, clean it.

**IMPORTANT: Never attempt to clean the safety filter. If the safety filter is dirty, then the primary filter is damaged and you should replace both filters.**





**Figure 22**

1. Latches
2. Air cleaner cover
3. Air filter body
4. Primary filter
5. Safety filter

## Cleaning the Primary Filter

Blow compressed air from the inside to the outside of the primary filter.

**IMPORTANT: Do not exceed 100 psi (689.5 kPa) and keep the hose at least 2 inches (5 cm) from the filter.**

## Installing the Filters

**1.** If installing new filters, check each filter for shipping damage. Do not use a damaged filter.

2. If the safety filter is being replaced, carefully slide it into the filter body (Fig. 22).

3. Carefully slide the primary filter over the safety filter (Fig. 22). Ensure that it is fully seated by pushing on the outer rim of the filter while installing it.

   **IMPORTANT: Do not press on the soft inside area of the filter.**

4. Install the air cleaner cover with the side indicated as UP facing up and secure the latches (Fig. 22).

5. Close the rear access cover.

## Servicing the Engine Oil

Change oil after the first 50 operating hours and then every 75 operating hours thereafter.


**Note:** Change oil more frequently when operating conditions are extremely dusty or sandy.

Oil Type: MIL-L-2104C (API service CD or higher)

Crankcase Capacity: w/filter, 0.84 gal. (3.2 l)

Viscosity: See table below

**USE THESE SAE VISCOSITY OILS**




### Changing the Oil

1. Start the engine and let it run for five minutes. This warms the oil so it drains better.

2. Park the traction unit so that the drain side is slightly lower than the opposite side to ensure that the oil drains completely.

3. Lower the loader arms, chock the wheels, and stop the engine. Remove the key.

**⚠ CAUTION**

**POTENTIAL HAZARD**
- **Components will be hot if the traction unit has been running.**

**WHAT CAN HAPPEN**
- **Touching hot components can cause burns.**

**HOW TO AVOID THE HAZARD**
- **Allow the traction unit to cool before performing maintenance or touching any components.**

4. Place a pan under the oil drain tube (Fig. 23).

5. Loosen the clamp and remove the plug (Fig. 23).

6. When the oil has drained completely, replace the plug and tighten the clamp.

   **Note:** Dispose of the used oil at a certified recycling center.





**Figure 23**

1. Clamp
2. Oil drain tube
3. Plug

**7.** Open the rear access cover; refer to Opening the Rear Access Cover, page 26.

**8.** Remove the oil fill cap and slowly pour approximately 80% of the specified amount of oil in through the valve cover.

**9.** Check the oil level; refer to Checking the Oil Level, page 13.

**10.** Slowly add additional oil to bring the level to the F (full) mark on the dipstick.

**11.** Replace the fill cap.

**12.** Close the rear access cover.

### Changing the Oil Filter

Replace the oil filter every 150 hours or every other oil change.

**Note:** Change the oil filter more frequently when operating conditions are extremely hot, dusty, or sandy.

**1.** Drain the oil from the engine; refer to Changing the Oil, page 28.

**2.** Open the rear access cover; refer to Opening the Rear Access Cover, page 26.

**3.** Remove the old filter and wipe the filter adapter (Fig. 24) gasket surface.

**4.** Allow a minute or two for the oil to be absorbed by filter material, then pour off the excess oil.

**5.** Apply a thin coat of new oil to the rubber gasket on the replacement filter (Fig. 24).





**Figure 24**

1. Oil filter
2. Gasket
3. Adapter

**6.** Install the replacement oil filter to the filter adapter. Turn the oil filter clockwise until the rubber gasket contacts the filter adapter, then tighten the filter an additional 1/2 turn (Fig. 24).

**7.** Fill the crankcase with the proper type of new oil; refer to Changing the Oil, page 28.

**8.** Close the rear access cover.

## Greasing the Traction Unit

Grease all pivot joints every 8 operating hours and immediately after every washing.

Grease Type: General-purpose grease.

**1.** Lower the loader arms and stop the engine. Remove the key.

**2.** Clean the grease fittings with a rag.

**3.** Connect a grease gun to each fitting (Fig 25 and 26).





**Figure 25**





**Figure 26**

**4.** Pump grease into the fittings until grease begins to ooze out of the bearings (approximately 3 pumps).

**5.** Wipe up any excess grease.

## Changing the Fuel Filter

Change the fuel filter after every 200 operating hours or yearly, whichever occurs first.

Never re-install a dirty filter.

**1.** Lower the loader arms and stop the engine. Remove the key.

**2.** Shut off the fuel valve on the bottom of the fuel tank (Fig. 29).

**3.** Open the rear access cover; refer to Opening the Rear Access Cover, page 26.

**4.** Open the drain valve (Fig. 27) and drain the fuel from the fuel filter into a suitable container and dispose of it properly.

**5.** Remove the fuel filter with a filter wrench (Fig. 27).





**Figure 27**

1. Drain valve
2. Fuel filter

**6.** Clean the mounting surface.

**7.** Lubricate the gasket on the new filter with clean engine oil. Screw on the new filter by hand until the gasket contacts the housing. Then tighten it another 1/2 turn.

**8.** Open the fuel valve on the bottom of the fuel tank (Fig. 29).

**9.** Bleed the fuel system; refer to Bleeding the Fuel System, page 31.

**10.** Close the rear access cover.

**11.** Start the engine and check for leaks.

## Bleeding the Fuel System

Bleeding the air from the fuel system in any of the following situations:

- Initial start up of a new traction unit or a traction unit that has been stored.
- After the engine has ceased running due to lack of fuel.
- After maintenance has been performed on the fuel system components.

**1.** Open the rear access cover; refer to Opening the Rear Access Cover, page 26.

**2.** Open the bleed screw on top of the fuel filter to fill the bowl with fuel (Fig. 28).





**Figure 28**

1. Fuel filter
2. Bleed screw

**3.** Use the ignition to crank the engine until fuel comes out of the bleed screw in a steady stream.

**4.** Close the bleed screw.

**5.** On left side of the engine, locate the air vent plug on top of the fuel injection pump and open it.

**6.** Use the ignition to crank the engine until fuel comes out of the vent plug in a steady stream.

**7.** Close the vent plug.

**8.** Close the rear access cover.

## Draining the Fuel Tank

**⚠ DANGER**

**POTENTIAL HAZARD**

- **In certain conditions fuel is extremely flammable and highly explosive.**

**WHAT CAN HAPPEN**

- **A fire or explosion from fuel can burn you, others, and cause property damage.**

**HOW TO AVOID THE HAZARD**

- **Drain fuel from the fuel tanks when the engine is cold. Do this outdoors in an open area. Wipe up any fuel that spills.**
- **Never drain fuel near an open flame or where fumes may be ignited by a spark.**
- **Never smoke while handling fuel.**

**1.** Park the traction unit on a level surface, to ensure that the fuel tanks drain completely.

**2.** Lower the loader arms and stop the engine. Remove the key.

**3.** Shut off the fuel valve on the bottom of the fuel tank (Fig. 29).





**Figure 29**

1. Fuel valve

**4.** Open the rear access cover; refer to Opening the Rear Access Cover, page 26.

**5.** Loosen the hose clamp at the fuel filter and slide it up the fuel line away from the filter.

**6.** Pull the fuel line off of the fuel filter, open the fuel valves, and allow the fuel to drain into a fuel can or drain pan.

**Note:** Now is the best time to install a new fuel filter because the fuel tank is empty.

7. Install the fuel line onto the fuel filter.
8. Slide the hose clamp close to the fuel filter to secure the fuel line.
9. Close the rear access cover.
10. Open the fuel valve on the bottom of the fuel tank.

# Servicing the Hydraulic System

## Replacing the Hydraulic Filter

Change the hydraulic filter:

- After the first 8 operating hours.
- After every 200 operating hours.

1. Position traction unit on a level surface.
2. Raise the loader arms and install the cylinder locks; refer to Using the Cylinder Locks, page 22.
3. Stop the engine and remove the key.
4. Remove the front access cover, refer to Removing the Front Access Cover, page 26.

   **IMPORTANT: Do not substitute an automotive oil filter or severe hydraulic system damage may result.**

5. Place a drain pan under the filter.
6. Remove the old filter and wipe the filter adapter, gasket surface clean.
7. Apply a thin coat hydraulic fluid to the rubber gasket on the replacement filter (Fig. 30).
8. Install the replacement hydraulic filter onto the filter adapter. Tighten it clockwise until the rubber gasket contacts the filter adapter, then tighten the filter an additional 1/2 turn (Fig. 30).
9. Clean up any spilled fluid.
10. Start the engine and let it run for about two minutes to purge air from the system.
11. Stop the engine and check for leaks.
12. Check the fluid level in the hydraulic tank (refer to Checking the Hydraulic Fluid, page 15) and add fluid to raise the level to the mark on the dipstick. Do not over fill the tank.





**Figure 30**

1. Hydraulic filter
2. Gasket
3. Adapter

13. Install the front access cover.
14. Remove and store the cylinder locks (refer to Using the Cylinder Locks, page 22) and lower the loader arms.

## Changing the Hydraulic Fluid

Change the hydraulic fluid after every 400 operating hours.

1. Position traction unit on a level surface.
2. Raise the loader arms and install the cylinder locks; refer to Using the Cylinder Locks, page 22.
3. Stop the engine and remove the key.

4. Remove the front access cover, refer to Removing the front access cover, page 26.

   **IMPORTANT: Do not substitute automotive oil or severe hydraulic system damage may result.**

5. Place a large drain pan under the traction unit that can hold at least 17 gal. (67 l).

6. Remove the drain plug from the bottom of the hydraulic tank and allow the fluid to completely drain out.

7. Install the drain plug.

8. Fill the hydraulic tank with Toro Hy-Pro, Mobil Fluid 424, or equivalent; refer to Checking the Hydraulic Fluid, page 15.

   **Note:** Dispose of used oil at a certified recycling center.

9. Install the front access cover

10. Remove and store the cylinder locks (refer to Using the Cylinder Locks, page 22) and lower the loader arms.

### Checking Hydraulic Lines

After every 100 operating hours, check the hydraulic lines and hoses for leaks, loose fittings, kinked lines, loose mounting supports, wear, weather, and chemical deterioration. Replace all moving hydraulic hoses every 1500 hours or 2 years, which ever comes first. Make necessary repairs before operating.

**⚠ WARNING**

**POTENTIAL HAZARD**
- **Hydraulic fluid escaping under pressure can penetrate skin and cause injury.**

**WHAT CAN HAPPEN**
- **Fluid accidentally injected into the skin must be surgically removed within a few hours by a doctor familiar with this form of injury or gangrene may result.**

**HOW TO AVOID THE HAZARD**
- **Keep body and hands away from pin hole leaks or nozzles that eject high pressure hydraulic fluid.**
- **Use cardboard or paper to find hydraulic leaks, never use your hands.**

## Servicing the Battery

Check the electrolyte level in the battery every 100 hours. Always keep the battery clean and fully charged. Use a paper towel to clean the battery case. If the battery terminals are corroded, clean them with a solution of four parts water and one part baking soda. Apply a light coating of grease to the battery terminals to reduce corrosion.

Voltage: 12 v, 435 Cold Cranking Amps

### Checking the Electrolyte Level

1. Remove the battery cover (Fig. 3).

2. Open covers to see into the cells. The electrolyte must be up to the lower part of the tube (Fig. 31).

   **IMPORTANT: Do not allow the electrolyte to get below the plates. (Fig. 31).**





**Figure 31**

1. Filler caps
2. Lower part of tube
3. Plates

**3.** If the electrolyte is low, add the required amount of distilled water; refer to Adding Water to the Battery, below.

### Adding Water to the Battery

The best time to add distilled water to the battery is just before you operate the traction unit. This lets the water mix thoroughly with the electrolyte solution.

**1.** Clean the top of the battery with a paper towel.

**2.** Lift off the filler caps (Fig. 31).

**3.** Slowly pour distilled water into each battery cell until the level is up to the lower part of the tube (Fig. 31).

**IMPORTANT: Do not overfill the battery because electrolyte (sulfuric acid) can cause severe corrosion and damage to the chassis.**

**4.** Press the filler caps onto the battery.

### Charging the Battery

**IMPORTANT: Always keep the battery fully charged (1.260 specific gravity). This is especially important to prevent battery damage when the temperature is below 32°F (0°C).**

**1.** Check the electrolyte level; refer to Checking Electrolyte Level, page 33.

**2.** Remove the filler caps from the battery and connect a 3 to 4 amp battery charger to the battery posts. Charge the battery at a rate of 4 amperes or less for 4 hours (12 volts). Do not overcharge the battery.

**⚠ WARNING**

**POTENTIAL HAZARD**
- **Charging the battery produces gasses.**

**WHAT CAN HAPPEN**
- **Battery gasses can explode.**

**HOW TO AVOID THE HAZARD**
- **Keep cigarettes, sparks, and flames away from the battery.**

**3.** Install the filler caps after the battery is fully charged.

**4.** Replace the battery cover.

## Cleaning and Storage

**1.** Lower the loader arms and stop the engine. Remove the key.

**2.** Remove dirt and grime from the external parts of the entire traction unit, especially the engine. Clean dirt and chaff from the outside of the engine.

**IMPORTANT: You can wash the traction unit with mild detergent and water. Do not pressure wash the traction unit. Avoid excessive use of water, especially near the control panel, engine, hydraulic pumps, and motors.**

**3.** Service the air cleaner; refer to Servicing the Air Cleaner, page 27.

**4.** Grease the traction unit; refer to Greasing the Traction Unit, page 29.

**5.** Change the crankcase oil; refer to Servicing the Engine Oil, page 28.

6. Check the tire pressure; refer to Tire Pressure, page 15.

7. Charge the battery; refer to Servicing the Battery, page 33.

8. Flush the fuel tank with fresh, clean diesel fuel

9. Check and tighten all bolts, nuts, and screws. Repair or replace any part that is damaged.

10. Paint all scratched or bare metal surfaces. Paint is available from your Authorized Service Dealer.

11. Check anti–freeze protection and fill the radiator with a 50/50 solution of water and permanent ethylene glycol anti–freeze.

12. Store the traction unit in a clean, dry garage or storage area. Remove the key from the ignition switch and keep it in a memorable place.

13. Cover the traction unit to protect it and keep it clean.

# Troubleshooting

| PROBLEM | POSSIBLE CAUSES | CORRECTIVE ACTION |
|---|---|---|
| The starter does not crank. | 1. The electrical connections are corroded or loose. | 1. Check the electrical connections for good contact. |
| | 2. A fuse is blown or loose. | 2. Correct or replace the fuse. |
| | 3. The relay or switch is damaged. | 3. Contact your Authorized Service Dealer. |
| | 4. The battery is discharged. | 4. Charge the battery or replace it. |
| | 5. A damaged starter or starter solenoid. | 5. Contact your Authorized Service Dealer. |
| | 6. Seized internal engine components. | 6. Contact your Authorized Service Dealer. |
| The engine cranks, but will not start. | 1. Incorrect starting procedure. | 1. Refer to Starting and Stopping the Engine, page 20. |
| | 2. The fuel tank is empty. | 2. Fill with fresh fuel. |
| | 3. The fuel shut-off valve is closed. | 3. Open the fuel shut-off valve. |
| | 4. Dirt, water, stale fuel, or incorrect fuel is in the fuel system. | 4. Drain and flush the fuel system; add fresh fuel. |
| | 5. Clogged fuel line. | 5. Clean or replace. |
| | 6. There is air in the fuel | 6. Bleed the nozzles and check for air leaks at the fuel hose connections and fittings between the fuel tank and engine. |
| | 7. Inoperative glow plugs. | 7. Check the fuse, glow plugs and wiring. |

| PROBLEM | POSSIBLE CAUSES | CORRECTIVE ACTION |
|---|---|---|
| The engine cranks, but will not start (continued). | 8. Slow cranking speed. | 8. Check the battery, oil viscosity and starting motor (contact your Authorized Service Dealer). |
| | 9. The air cleaner element is dirty. | 9. Clean or replace. |
| | 10. Low compression. | 10. Contact your Authorized Service Dealer. |
| | 11. The injection nozzles are damaged. | 11. Contact your Authorized Service Dealer. |
| | 12. The fuel filter is clogged. | 12. Replace the fuel filter. |
| | 13. The injections pump timing is incorrect. | 13. Contact your Authorized Service Dealer. |
| | 14. The injection pump is broken. | 14. Contact your Authorized Service Dealer. |
| | 15. Improper fuel grade for cold weather use. | 15. Drain the fuel system and replace the fuel filter. Add fresh fuel of proper grade for ambient temperature conditions. You may need to warm the entire traction unit. |
| | 16. The ETR solenoid is broken. | 16. Contact your Authorized Service Dealer. |
| The engine starts, but does not keep running. | 1. The fuel tank vent is restricted. | 1. Loosen the cap. If the engine runs with the cap loosened, replace the cap. |
| | 2. Dirt or water is in the fuel system. | 2. Drain and flush the fuel system; add fresh fuel. |
| | 3. The fuel filter is clogged. | 3. Replace the fuel filter. |
| | 4. The fuel pump is damaged. | 4. Contact your Authorized Service Dealer. |
| | 5. There is air in the fuel. | 5. Bleed the nozzles and check for air leaks at fuel hose connections and fittings between the fuel tank and engine. |
| | 6. Improper fuel grade for cold weather use. | 6. Drain the fuel system and replace the fuel filter. Add fresh fuel of proper grade for ambient temperature conditions. |

| PROBLEM | POSSIBLE CAUSES | CORRECTIVE ACTION |
|---|---|---|
| The engine runs, but knocks or misses. | 1. Dirt, water, stale fuel, or incorrect fuel is in the fuel system. | 1. Drain and flush the fuel system; add fresh fuel. |
| | 2. Engine overheating. | 2. See ENGINE OVERHEATS. |
| | 3. There is air in the fuel. | 3. Bleed nozzles and check for air leaks at the fuel hose connections and fittings between the fuel tank and engine. |
| | 4. The injection nozzles are damaged. | 4. Contact your Authorized Service Dealer. |
| | 5. Low compression | 5. Contact your Authorized Service Dealer. |
| | 6. The injection pump timing is incorrect. | 6. Contact your Authorized Service Dealer. |
| | 7. Excessive carbon build–up. | 7. Contact your Authorized Service Dealer. |
| | 8. Internal wear or damage. | 8. Contact your Authorized Service Dealer. |
| The engine will not idle. | 1. The fuel tank vent is restricted. | 1. Loosen the cap. If the engine runs with the cap loosened, replace the cap. |
| | 2. Dirt, water, stale fuel, or incorrect fuel is in the fuel system. | 2. Drain and flush the fuel system; add fresh fuel. |
| | 3. The fuel pump is damaged. | 3. Contact your Authorized Service Dealer. |
| | 4. Low compression. | 4. Contact your Authorized Service Dealer. |
| | 5. The air cleaner element is dirty. | 5. Clean or replace. |
| | 6. The fuel filter is clogged. | 6. Replace the fuel filter. |
| | 7. There is air in the fuel. | 7. Bleed the nozzles and check for air leaks at the fuel hose connections and fittings between the fuel tank and engine. |

| PROBLEM | POSSIBLE CAUSES | CORRECTIVE ACTION |
|---|---|---|
| The engine overheats. | 1. More coolant is needed. | 1. Check and add coolant. |
| | 2. Restricted air flow to the radiator. | 2. Inspect and clean the radiator screen with every use. |
| | 3. The crankcase oil level is incorrect. | 3. Fill or drain to the full mark. |
| | 4. Excessive loading. | 4. Reduce load; use lower ground speed. |
| | 5. The thermostat is damaged. | 5. Contact your Authorized Service Dealer. |
| | 6. The fan belt is loose or broken. | 6. Contact your Authorized Service Dealer. |
| | 7. Incorrect fuel is in the fuel system. | 7. Drain and flush the fuel system; add fresh fuel. |
| | 8. Injection timing is incorrect. | 8. Contact your Authorized Service Dealer. |
| | 9. Coolant pump is damaged. | 9. Contact your Authorized Service Dealer. |
| The engine loses power. | 1. The crankcase oil level is incorrect. | 1. Fill or drain to the full mark. |
| | 2. The air cleaner element is dirty. | 2. Clean or replace. |
| | 3. Dirt, water, stale fuel, or incorrect fuel is in the fuel system. | 3. Drain and flush the fuel system; add fresh fuel. |
| | 4. The engine is overheated. | 4. See ENGINE OVERHEATS. |
| | 5. Low compression. | 5. Contact your Authorized Service Dealer. |
| | 6. The fuel tank vent is restricted. | 6. Contact your Authorized Service Dealer. |
| | 7. The engine load is excessive. | 7. Reduce ground speed. |
| | 8. There is air in the fuel. | 8. Bleed the nozzles and check for air leaks at the fuel hose connections and fittings between the fuel tank and engine. |
| | 9. The injection pump timing is incorrect. | 9. Contact your Authorized Service Dealer. |
| | 10. The injection pump is damaged. | 10. Contact your Authorized Service Dealer. |

| PROBLEM | POSSIBLE CAUSES | CORRECTIVE ACTION |
|---|---|---|
| Excessive black smoke from exhaust. | 1. The air cleaner element is dirty. | 1. Clean or replace. |
| | 2. The injection pump timing is incorrect. | 2. Contact your Authorized Service Dealer. |
| | 3. Incorrect fuel is in the fuel system. | 3. Drain the fuel system and refill with specified fuel. |
| | 4. The injection nozzles are damaged. | 4. Contact your Authorized Service Dealer. |
| | 5. The injection pump is damaged. | 5. Contact your Authorized Service Dealer. |
| | 6. Excessive loading. | 6. Reduce load; use lower ground speed. |
| Excessive white smoke from exhaust. | 1. The key was turned to the start position before the glow plug light turned off. | 1. Turn the key to the run position and allow the glow plug light to turn off before starting the engine. |
| | 2. The engine temperature is low. | 2. Check the thermostat. |
| | 3. The glow plugs are inoperative. | 3. Check the fuse, glow plugs and wiring. |
| | 4. The fuel injection nozzles are damaged. | 4. Contact your Authorized Service Dealer. |
| | 5. The injection pump timing is incorrect. | 5. Contact your Authorized Service Dealer. |
| | 6. Low compression. | 6. Contact your Authorized Service Dealer. |
| Traction unit does not drive. | 1. Traction pump drive coupler is loose or broken. | 1. Contact Authorized Service Dealer. |
| | 2. Hydro fluid level low. | 2. Add hydro fluid to reservoir. |
| | 3. Pump and/or wheel motor is damaged. | 3. Contact your Authorized Service Dealer. |
| | 4. Control valve is damaged. | 4. Contact your Authorized Service Dealer. |
| | 5. Relief valve is damaged. | 5. Contact your Authorized Service Dealer. |
| | 6. Flow divider valve lever is in 9 o'clock position. | 6. Move lever to 12 o'clock to 10 o'clock position. |

# The Toro SiteWork™ Systems Product Line
# One Year Limited Warranty

**The Toro Company warrants your Toro SiteWork™ Systems Product ("Product") to be free from defects in materials or workmanship for the period of time listed below. Where a warrantable condition exists, Toro will repair the Product at no cost to you including diagnosis, labor, parts, and transportation. This warranty begins on the date the Product is delivered to the original retail purchaser.**

**Warranty Duration: One year or 500 operational hours, whichever occurs first.**

### Owner Responsibilities:

As the Product owner, you are responsible for required maintenance and adjustments stated in your Owner's Manual. Failure to perform required maintenance and adjustments can be grounds for disallowing a warranty claim.

### Instructions for Obtaining Warranty Service:

You are responsible for notifying the Toro SiteWork Systems Distributor or Authorized Toro SiteWork™ Systems Dealer from whom you purchased the Product as soon as you believe a warrantable condition exists.

If you need help locating a Toro SiteWork™ Systems Distributor or Authorized Dealer, or if you have questions regarding your warranty rights or responsibilities, you may contact us at:

Toro LCE Division
8111 Lyndale Avenue South
Minneapolis, MN, 55420–1196
Telephone: (612) 888–8801
Facsimile: (612) 887–8258

### Maintenance Parts:

Parts scheduled for replacement as required maintenance ("Maintenance Parts"), are warranted for the period of time up to the scheduled replacement time for that part.

### Items/Conditions Not Covered:

Not all product failures or malfunctions that occur during the warranty period are defects in materials or workmanship. The items / conditions listed below are not covered by this warranty:

- Product failures which result from the use of non–Toro replacement parts, or from installation and use of add–on, modified, or unapproved accessories are not covered.
- Product failures which result from failure to perform required maintenance and/or adjustments are not covered.
- Product failures which result from operating the Product in an abusive, negligent or reckless manner are not covered.
- This warranty does not apply to parts subject to consumption through use unless found to be defective. Examples of parts which are consumed, or used up, during normal Product operation include, but are not limited to, digging teeth, tines, spark plugs, tires, filters, chains, etc.
- This warranty does not apply to failures caused by outside influence. Items considered to be outside influence include, but are not limited to, weather, storage practices, contamination, use of unapproved coolants, lubricants, additives, or chemicals, etc.
- This warranty does not apply to normal "wear and tear" items. Normal "Wear and Tear" includes, but is not limited to, worn painted surfaces, scratched decals or windows, etc.

### Other Legal Disclaimers:

The above remedy of product defects through repair by an authorized distributor or dealer is the purchaser's sole remedy for any defect. This warranty gives you specific legal rights, and you may also have other rights which vary from state to state.

**Except for the Emissions warranty referenced below, if applicable, there is no other express warranty. All implied warranties of merchantability and fitness for use are limited to the duration of the express warranty.**

Some states do not allow limitations on how long an implied warranty lasts, so the above limitation may not apply to you.

**The Toro Company is not liable for indirect, incidental or consequential damages in connection with the use of the Product, including any cost or expense of providing substitute Product or service during periods of malfunction or non–use.**

Some states do not allow the exclusion of incidental or consequential damages, so the above exclusion may not apply to you.

**Note to California residents:** The Emissions Control System on your Product may be covered by a separate warranty meeting requirements established by the U.S. Environmental Protection Agency (EPA), or the California Air Resources Board (CARB). The hour limitations set forth above do not apply to the Emissions Control System Warranty. Refer to the California Emission Control Warranty Statement printed in your Owner's Manual or contained in the engine manufacturer's documentation for details.