FORM NO. 3322-364

TORO®

ProLine Trimmers

Model No. 53002 — 895001 & Up
Model No. 53003 — 895001 & Up
Model No. 53010 — 895001 & Up
Model No. 53011 — 895001 & Up

Operator’s Manual

Contents

	Page
Introduction	2
Safety	3
Operator Safety	3
String Trimmer Safety	3
Fuel Safety	3
Power String Trimmer Operating Safety	4
Safety and Instruction Decals	5
Assembly	6
Installing Trimmer Head Shield	6
Installing Trimmer Head	7
Before Operation	7
Oil and Fuel	7
Mixing Gasoline And Oil	8
Starting And Stopping	9
Hot Restart	11
Operation	11
Operating Position	11
Cutting with Nylon Trimmer Line	12
Rewinding the Trimmer Spool	13

	Page
Maintenance	15
Air Filter	15
Fuel Filter	16
Idle Speed Adjustment	16
Spark Plug	17
Cylinder Cooling Fins	19
Spark Arrester	19
Gearcase Maintenance	21
General Cleaning and Tightening	21
Storage	21
Accessories	22
Troubleshooting	22
Specifications	23
53010/Commercial	23
53011/Commercial	23
53002/Industrial	23
53003/Industrial	23
Federal and California Emission Control Warranty Statement	24
Warranty	27

WARNING:

The engine exhaust from this product contains chemicals known to the State of California to cause cancer, birth defects, or other reproductive harm.

Introduction

Thank you for purchasing a Toro product.

All of us at Toro want you to be completely satisfied with your new product, so feel free to contact your local Authorized Service Dealer for help with service, genuine Toro parts, or other information you may require.

Whenever you contact your Authorized Service Dealer or the factory, always know the model and serial numbers of your product. These numbers will help the Service Dealer or Service Representative provide exact information about your specific product. You will find the model and serial number decal located in a unique place on the product (Fig. 1).




Figure 1

1. Trimmer Head
2. Gearcase
3. Shaft Assembly
4. Loop Handle
5. Attachment Ring for Shoulder Harness
6. Shaft Grip
7. Clutch Drum Housing
8. Engine
9. Model and Serial Number Decal (on rear of engine stand)
10. Air Filter
11. Trimmer Head Shield
12. Throttle Trigger and Stop Switch
13. Throttle Cable and Stop Switch Wire
14. Fuel Tank

For your convenience, write the product model and serial numbers in the space below.

Model No. _____

Serial No. _____

Read this manual carefully to learn how to operate and maintain your product correctly. Reading this manual will help you and others avoid personal injury and damage to the product. Although Toro designs, produces and markets safe, state-of-the-art products, you are responsible for using the product properly and safely. You are also responsible for training persons who you allow to use the product about safe operation.

The Toro warning system in this manual identifies potential hazards and has special safety messages that help you and others avoid personal injury, even death. DANGER, WARNING and CAUTION are signal words used to identify the level of hazard. However, regardless of the hazard, be extremely careful.

DANGER signals an extreme hazard that will cause serious injury or death if the recommended precautions are not followed.

WARNING signals a hazard that may cause serious injury or death if the recommended precautions are not followed.

CAUTION signals a hazard that may cause minor or moderate injury if the recommended precautions are not followed. Two other words are also used to highlight information. “Important” calls attention to special mechanical information and “Note” emphasizes general information worthy of special attention.

Safety

Operator Safety

1. Read and understand this Operator's Manual before using this product. Be thoroughly familiar with the proper use of this product.

2. Always wear eye protection that complies with ANSI (American National Standards Institute) Z87–1.



3. Always wear hearing protection.



4. Always wear heavy, long pants, boots and gloves. Do not wear loose clothing, jewelry, short pants, sandals, or go barefoot. Secure hair so it is above shoulder length.

5. Never operate this String Trimmer when you are tired, ill, or under the influence of alcohol, drugs or medication.

6. Never start or run the engine inside a closed room or building. Breathing exhaust fumes can cause death.



7. Keep handles clean of oil, fuel and dirt.

String Trimmer Safety

1. Make sure the Trimmer is assembled correctly and that the trimmer head is correctly installed and securely fastened as instructed in the Assembly section.

2. Inspect the String Trimmer before each use. Replace damaged parts. Check for fuel leaks. Make sure all fasteners are in place and tightened securely. Follow the maintenance instructions beginning on page 15.

3. Make sure the trimmer head does not rotate at engine idle speed. Refer to Idle Speed Adjustment, page 16.

4. Inspect the String Trimmer cutting head and replace any parts that are cracked, chipped or damaged before using the Trimmer.

5. Install the required shield before using the Trimmer.

6. Use only flexible, non–metallic, monofilament cutting line of the correct diameter. Never use wire, rope, string, etc.

7. Never use a cutting head or replacement parts that are not approved by Toro.

8. Maintain the String Trimmer according to the recommended maintenance intervals and procedures in the Maintenance section on page 15.

9. Shut off the engine and wait until the trimmer head has completely stopped moving before checking, performing maintenance on or working on the String Trimmer.

10. If running problems or excessive vibration occur, stop immediately and inspect the unit for the cause. If the cause cannot be determined or is beyond your ability to correct, return the String Trimmer to your servicing dealer for repair.

Fuel Safety

1. Gasoline is highly flammable and must be handled and stored carefully. Use a container approved for fuel for storing gasoline and/or fuel/oil mixture.

2. Mix and pour fuel outdoors and where there are no sparks or flames.

3. Do not smoke near fuel or String Trimmer, or while using the String Trimmer.

4. Do not overfill the fuel tank. Stop filling 1/4–1/2 inch (6mm–13mm) from the top of the tank.

5. Wipe up any spilled fuel before starting the engine.

6. Move the Trimmer at least 10 feet (3 m) away from the fueling location before starting the engine (Fig. 2).




Figure 2

1. 10 feet (3m) Minimum

7. Do not remove the Trimmer fuel tank cap while the engine is running, or right after stopping the engine.

8. Allow the engine to cool before refueling.

9. Drain the tank and run the engine dry before storing the unit.

10. Store fuel and String Trimmer away from open flame, sparks and excessive heat. Make sure fuel vapors cannot reach sparks or open flames from water heaters, furnaces, electric motors, etc.

Power String Trimmer Operating Safety

1. THIS STRING TRIMMER CAN CAUSE SERIOUS INJURIES. Read the instructions carefully. Be familiar with all controls and the proper use of the String Trimmer.

2. Inspect your work area before you begin. Remove objects such as broken glass, nails, wire and rocks which can become dangerous projectiles if thrown by the Trimmer. Remove string, rope or similar materials which can become entangled in the trimmer head.

3. This Trimmer will throw objects and cut. Keep children, bystanders and animals outside a 50 ft. (15 m) radius from the operator and Trimmer (Fig. 3). Beyond the 50 ft. (15 m) there still may be a risk of injury to bystanders from thrown objects. It is recommended that bystanders wear eye protection. A thrown object can ricochet.




Figure 3

1. 50 ft. (15 m) Minimum

4. If you are approached while operating the Trimmer, stop the engine and trimmer head rotation.

5. Never allow children to operate the Trimmer.

6. Use the Trimmer only in daylight or good artificial light.

7. Never operate the Trimmer without proper guards or other protective safety devices in place.

8. Always keep the Trimmer on the right side of your body (Fig. 4).



Figure 4

9. Do not raise the trimmer head above waist level.


10. Keep all parts of your body away from the rotating trimmer head and hot surfaces such as the muffler.

11. Keep firm footing and balance. Do not overreach.

12. Use the right tool for the job. Do not use the Trimmer for any job that is not recommended by Toro.

Safety and Instruction Decals

Safety decals and instructions are easily visible to the operator and are located near any area of potential danger. Replace any decal that is damaged or lost.



ON SHAFT
(Part No. M221501)



ON SHAFT
(Part No. M221502)



ON ENGINE
(Part No. M266291)

Assembly

Installing Trimmer Head Shield

⚠ CAUTION

POTENTIAL HAZARD
- **The cutoff blade is sharp.**

WHAT CAN HAPPEN
- **Contact with cutoff blade could cause serious cuts or personal injury.**

HOW TO AVOID THE HAZARD
- **Keep hands, feet and clothing away from cutoff blade.**

1. Fasten the string cutoff blade to the trimmer head shield with two M5 x 25 screws, lock washers and hex nuts as shown (Fig 5).




Figure 5

1. Gearcase
2. Trimmer Head Shield
3. M5 x 25 Screw (2)
4. Plate
5. Lock Washer
6. M5 x 12 Screw (4)
7. Hex Nut
8. String Cutoff Blade

⚠ WARNING

POTENTIAL HAZARD
- **Foreign objects can be thrown by Trimmer.**

WHAT CAN HAPPEN
- **Contact with thrown objects can cause personal injury.**

HOW TO AVOID THE HAZARD
- **Never operate the Trimmer without the trimmer head shield in place.**

2. Attach the trimmer head shield to the gearcase with the four M5 x 12 screws and lock washers as shown (Fig 5).

Installing Trimmer Head

IMPORTANT: Make sure the trimmer head is for LEFT-HAND ROTATION (counterclockwise) as viewed from the operator's position, and that the trimmer head adapter is a male, M8 x 1.25 left-hand thread.

1. Thread the trimmer head into the gearcase, tighten trimmer head firmly by hand (Fig. 6).




Figure 6

1. Gearcase
2. Trimmer Head

⚠ CAUTION

POTENTIAL HAZARD
- **If the trimmer head is not adequately tightened, it can come loose from the Trimmer during use.**

WHAT CAN HAPPEN
- **This may cause damage to property or personal injury.**

HOW TO AVOID THE HAZARD
- **Make sure the trimmer head is securely fastened to the splined shaft in the gearcase.**

Before Operation

Oil and Fuel

⚠ DANGER

POTENTIAL HAZARD
- **In certain conditions gasoline is extremely flammable and highly explosive.**

WHAT CAN HAPPEN
- **A fire or explosion from gasoline can burn you, others, and cause property damage.**

HOW TO AVOID THE HAZARD
- **Use a funnel and fill the fuel tank outdoors, in an open area, when the engine is cold. Wipe up any gasoline that spills.**
- **Do not fill the fuel tank completely full. Add gasoline to the fuel tank until the level is 1/4" to 1/2" (6 mm to 13 mm) below the bottom of the filler neck. This empty space in the tank allows gasoline to expand.**
- **Never smoke when handling gasoline, and stay away from an open flame or where gasoline fumes may be ignited by a spark.**
- **Store gasoline in an approved container and keep it out of the reach of children.**
- **Never buy more than a 30-day supply of gasoline.**

1. Do not smoke near fuel.

2. Mix and pour fuel outdoors and where there are no sparks or flames.

3. Always shut off the engine before refueling. Never remove the String Trimmer fuel tank cap while the engine is running or right after just stopping the engine.

⚠ WARNING

POTENTIAL HAZARD
- **Gasoline contains gasses that can build up pressure inside a gas tank.**

WHAT CAN HAPPEN
- **Fuel can be sprayed on you when removing gas cap.**

HOW TO AVOID THE HAZARD
- **Remove fuel cap slowly to avoid injury from fuel spray.**

4. Always open the fuel tank cap slowly to release any possible overpressure inside the tank.

5. Do not overfill the fuel tank. Stop filling 1/4–1/2 inch (6mm–13mm) from the top of the tank.

6. Tighten the tank fuel cap carefully but firmly after refilling.

7. Wipe up any spilled fuel before starting the engine.

8. Move the String Trimmer at least 10 feet (3 m) away from the fueling location and fuel storage container before starting the engine (Fig. 2).

Recommended Oil Type

Only use a two-cycle engine oil formulated for use in high-performance, air-cooled two-cycle engines. Toro brand 2-cycle oil is formulated for use in high-performance, air-cooled two-cycle engines.

IMPORTANT: Do not use National Marine Manufacturer's Association (NMMA) or BIA certified oils. This type of 2–cycle engine oil does not have the proper additives for air-cooled, 2–cycle engines and can cause engine damage.

Do not use automotive motor oil. This type of oil does not have the proper additives for air-cooled, 2–cycle engines and can cause engine damage.

Recommended Fuel Type

Use clean, fresh lead-free gasoline, including *oxygenated* or *reformulated* gasoline, with an octane rating of 85 or higher. To ensure freshness, purchase only the quantity of gasoline that can be used in 30 days. Use of lead-free gasoline results in fewer combustion chamber deposits and longer spark plug life. Use of premium grade fuel is not necessary or recommended.

Use Of Fuel Additives

IMPORTANT: NEVER USE <u>METHANOL</u>, GASOLINE CONTAINING <u>METHANOL</u>, GASOHOL CONTAINING MORE THAN 10% ETHANOL, PREMIUM GASOLINE, OR WHITE GAS BECAUSE ENGINE FUEL SYSTEM DAMAGE COULD RESULT.

DO NOT USE FUEL ADDITIVES OTHER THAN THOSE MANUFACTURED FOR FUEL STABILIZATION DURING STORAGE SUCH AS TORO'S STABILIZER/CONDITIONER OR A SIMILAR PRODUCT. TORO'S STABILIZER/CONDITIONER IS A PETROLEUM DISTILLATE BASED CONDITIONER/STABILIZER.

TORO DOES NOT RECOMMEND STABILIZERS WITH AN ALCOHOL BASE SUCH AS ETHANOL, METHANOL OR ISOPROPYL. ADDITIVES SHOULD NOT BE USED TO TRY TO ENHANCE THE POWER OR PERFORMANCE OF MACHINE.

Mixing Gasoline And Oil

IMPORTANT: The engine used on this String Trimmer is of a 2–cycle design. The internal moving parts of the engine, i.e., crankshaft bearings, piston pin bearings and piston to cylinder wall contact surfaces, require oil mixed with the gasoline for lubrication.

Failure to add oil to the gasoline or failure to mix oil with the gasoline at the appropriate ratio will cause major engine damage which will void your warranty.

For your fuel premix, only use a quality oil designed for 2–cycle air cooled engines. Toro 50:1 2–Cycle Oil is formulated to meet the requirements of high-performance, air-cooled two-cycle engines.

Fuel Mixture

The fuel:oil ratio is 50 parts gasoline to 1 part oil or 50:1.



Note: Never use a mixing ratio less than 50:1 regardless of the oil package mixing instructions. Ratios less the 50:1, (for example, 60:1, 80:1, 100:1), reduce the amount of lubrication to the internal moving parts of the engine and can cause damage.

Fuel Mixture Chart

Gasoline	50:1 2-cycle oil
1 gallon	2.6 oz.
2 gallons	5.2 oz.
5 gallons	12.8 oz.

Mixing Instructions

IMPORTANT: Never mix gasoline and oil directly in the String Trimmer fuel tank.

1. Always mix fuel and oil in a clean container approved for gasoline.
2. Mark the container to identify it as fuel mix for the String Trimmer.
3. Use regular unleaded gasoline and fill the container with half the required amount of gasoline.
4. Pour the correct amount of oil into the container then add the remaining amount of gasoline.
5. Close the container tightly and shake it momentarily to evenly mix the oil and the gasoline before filling the fuel tank on the String Trimmer.
6. When refilling the String Trimmer fuel tank, clean around the fuel tank cap to prevent dirt and debris from entering the tank during cap removal.
7. Always shake the premix fuel container momentarily before filling the fuel tank
8. Always use a spout or funnel when fueling to reduce fuel spillage.
9. Fill the tank only to within 1/4–1/2 inch (6mm–13mm) from the top of the tank. Avoid filling to the top of the tank filler neck.

Starting And Stopping


Before Starting The Engine

1. Fill the fuel tank as instructed in the Before Operation section of this manual.
2. Rest the String Trimmer on the ground.
3. Make sure the trimmer head is clear of any broken glass, nails, wire, rocks or other debris.
4. Keep all bystanders, children and animals away from the working area.

Cold Starting Procedure

The carburetors on Toro engines contain a choke system. To start a “cold” engine properly, perform the following procedure:

1. Pump the primer bulb at the bottom of the carburetor until fuel can be seen flowing through the fuel return line to the fuel tank (Figs. 7 and 8). (Flowing fuel should be almost clear, not foamy or full of bubbles.)



Model 53002 & 53003 m–2978

Figure 7

1. Primer Bulb
2. Fuel Return Line




Figure 8

1. Primer Bulb
2. Fuel Return Line

2. Move the choke lever to the closed ( ) position and move the stop switch to the “ON” position (Figs. 9).




Figure 9

1. Starter Handle
2. Choke Lever (typical)

3. Lock the throttle trigger in the fast-idle start position, then pull the starter handle (Figs. 10).




Figure 10

1. Stop Switch
2. Fast-idle Lock
3. Throttle Trigger (in fast-idle start position)
4. Throttle Trigger (in idle position)

4. After the engine starts, move the choke lever to the open ( ) position, then squeeze and release the throttle trigger to allow it to return to the idle position (Figs. 10).

If the engine stops running before you move the choke lever to the open ( ) position:

A. Go ahead and open the choke (Fig. 9).

B. Make sure the throttle trigger is set to the fast-idle start position (Fig. 10).

C. Pull the starter handle until the engine starts (Fig. 9).

Hot Restart

To start an engine that is already warmed up (hot restart), or if the ambient temperature exceeds 68°F (20°C):

1. Pump the primer bulb at the bottom of the carburetor until fuel can be seen flowing through the fuel return line to the fuel tank (Figs. 7 and 8).

2. Move the choke lever to the open ( ) position and move the stop switch to the “ON” position (Figs. 9 and 10).

3. Leave the throttle trigger in the idle position and pull the starter handle (Figs. 9 and 10).

4. If the engine fails to start after three to four pulls, follow the instructions in the Cold Starting Procedure section above.

   If the engine fails to start after you follow the above procedures, contact an authorized Toro dealer.

To Stop The Engine:

1. Release the throttle trigger (Fig. 10).

2. Slide the stop switch to the “STOP” position (Fig. 10).

Operation

⚠ CAUTION

- **Read the Safety instructions on page 3 concerning proper use of the String Trimmer.**

Operating Position

Before using the Trimmer, check the following (Fig. 11):




Figure 11

1. Hearing Protection
2. Eye Protection
3. Right Arm Slightly Bent
4. Left Arm Fully Extended, Hand Holding Loop Handle
5. Hand Holding Throttle Grip, Fingers on Throttle Trigger
6. Trimmer Head Near and Parallel to Ground

1. The Trimmer should be on the operator’s right side.

2. The operator’s right hand should be holding the shaft grip, with his or her fingers on the throttle trigger. The right arm should be slightly bent.

3. The left hand should be holding the loop handle with the fingers and thumb fully enclosed around the grip. The left arm should be extended. Reposition the loop handle up or down the driveshaft if necessary for a comfortable position.

4. The Trimmer weight should be evenly distributed between the arms. The trimmer head should be near and parallel to the ground.

5. Accelerate and hold the engine at cutting speed before entering the material to be cut.

6. Always release the throttle trigger and allow the engine to return to idle speed when not cutting.

7. Stop the Trimmer engine when moving between work sites.


⚠ CAUTION

- **Always wear gloves and protective clothing when operating the String Trimmer.**

- If the trimmer head becomes jammed, stop the engine immediately.
- Make certain all moving parts have stopped and disconnect the spark plug before inspecting the equipment for damage.
- Never use a String Trimmer that has chipped, cracked or broken trimmer head.

Cutting with Nylon Trimmer Line

- The tip of the line does the cutting. The line should stay extended while cutting (Fig. 12).




m−2979

CORRECT

Figure 12

1. Three inches (7.6 cm) Above Ground

- Do not force the line into the material. Forcing the line will cause it to slap against the material, increasing line usage and causing poor cutting results (Fig. 13).




m−2980

INCORRECT

Figure 13

Trimming

Hold the bottom of the trimmer head about 3 in. (7.6 cm) above the ground and at an angle. Allow only the tip of the line to make contact (Figs. 14).




m−2981

Figure 14

1. Three inches (7.6 cm) Above Ground

Scaling

To remove unwanted vegetation, hold the trimmer head about 3 in. (7.6 cm) above the ground and at an angle. Allow the tip of the line to strike the ground cutting the vegetation off at the surface (Fig. 15).



m−2982

Figure 15

Mowing

Keep the line parallel to the ground and use a gentle side-to-side motion (Fig. 16).




Figure 16

Rewinding the Trimmer Spool

⚠ WARNING

POTENTIAL HAZARD
- **Use of improper line could cause line to break and be thrown in operator's or bystander's direction.**

WHAT CAN HAPPEN
- **Use of improper line could result in serious personal injury.**

HOW TO AVOID THE HAZARD
- **Use only good quality, commercial grade, weld resistant trimmer line with a diameter of .095 inches (2.413 mm).**
- **Do not use any type of wire or other string-like substance. Do not use metal-reinforced line.**

1. Push in on one side of the head where it says to "push open" then pull on bottom (Figs. 17).




Figure 17

1. Push here

2. Remove the empty spool from the head (Fig. 18).




Figure 18

1. Spool

3. Clean the dirt from the inside of the spool parts if required.

4. Cut two (2) new lines (10'–15') of equal length.

5. Place ends of line in holes on inside of spool (Figs. 19).

6. Place the two (2) lines through the slits and wind the line in even, tight layers onto the spool in the direction indicated on the spool (Figs. 19).




Figure 19

1. Holes
2. Slits
3. Wind direction arrow

7. Snap the two (2) ends in the grooves as indicated, leaving 3-4 inches of line to be placed through eyelets (Figs. 20).




Figure 20

1. Groves

8. Thread the two ends of the line through the eyelets, place spool into head and pull line to release from grooves (Figs. 21).




Figure 21

1. Eyelets

9. Align the eyelet projections andsnap the cover and head together (Figs. 22).




Figure 22

Maintenance

NOTICE:Maintenance, replacement or repair of the emission control devices and systems may be performed by any non-road engine repair establishment or individual. However, to obtain no charge repairs under the terms and provisions of the Toro warranty statement, any service or emission control part repair or replacement must be performed by an Authorized Toro Service Dealer.

Air Filter

Maintenance Interval

- The air filter should be cleaned **daily**, or more often when working in extremely dusty conditions.
- Replace after every 100 hours of operation.

Air Filter Cleaning

Model 53010 & 53011

1. Unsnap the air filter cover (Fig. 23).
2. Remove the foam filter (Fig. 23).
3. Clean the filter with warm, soapy water. Let the filter completely dry.
4. Apply a light coat of SAE 30 motor oil to the foam filter and squeeze out all excess oil.
5. Reassemble the filter and filter cover (Fig. 23).




Figure 23

1. Air Filter Cover
2. Foam Filter

Model 53002 & 53003

1. Loosen the knob and remove the air filter cover (Fig. 24).
2. Remove the foam ring and filter screen from the air filter cover (Fig. 24).
3. Clean the foam ring and filter screen with warm, soapy water. Let the screen and ring dry completely.
4. Apply a light coat of SAE 30 motor oil to the foam ring and squeeze out all excess oil.
5. Reassemble the filter screen and foam ring to the air filter cover (Fig. 24).




Figure 24

1. Air Filter Cover
2. FIlter Screen
3. Foam Ring

IMPORTANT: The air filter screen is designed to fit into the air filter cover ONE WAY ONLY. Make sure the cutouts in the screen fit onto the matching plastic posts in the air filter cover. The fit should be snug (Fig. 25).




Figure 25

1. Filter Screen
2. Cutout (typical)
3. Air Filter Cover
4. Plastic Post (typical)

6. Reinstall the air filter cover and tighten the knob (Fig. 24).

Fuel Filter

Maintenance Interval

The fuel filter should be replaced after every 100 hours of operation.

Fuel Filter Replacement

The fuel filter is attached to the end of the fuel pick-up hose inside the fuel tank (Fig. 26).

To replace the fuel filter:

1. Make sure the fuel tank is empty.

2. Remove the fuel cap.

3. Using a wire hook, gently pull the fuel filter out through the fuel filler opening (Fig. 26).

4. Grasp the fuel hose next to the fuel filter fitting and remove the filter, but do not release the hose.

5. While still holding on to the fuel hose, attach the new fuel filter.

6. Drop the new fuel filter back into the fuel tank.

7. Make sure that the fuel filter is not stuck in a corner of the tank, and that the fuel hose is not doubled over (kinked) before refueling.




Figure 26

1. Wire
2. Fuel Pick-up Hose
3. Fuel Filter

Idle Speed Adjustment

This String Trimmer is equipped with non-adjustable fuel mixture carburetor. The engine idle speed is the only adjustment for the operator.

⚠ WARNING

POTENTIAL HAZARD
- **Engine must be running to make some carburetor adjustments.**
- **When engine is running, trimmer head is rotating and other parts are moving.**

WHAT CAN HAPPEN
- **Contact with rotating trimmer head or other moving parts could cause serious personal injury or death.**

HOW TO AVOID THE HAZARD
- **Keep hands, feet and clothing away from trimmer head and other moving parts.**
- **Keep all bystanders and pets away from unit while making carburetor adjustments.**

The trimmer head may be rotating during idle speed adjustment. Wear the recommended personal protective equipment and observe all safety instructions. Keep hands and body away from the trimmer head.

When the throttle trigger is released, the engine should return to an idle speed between 2400 and 2800 RPM, or just below the clutch engagement speed. The trimmer head must not rotate and the engine should not stall (stop running) at engine idle speed (Fig. 27).




Figure 27

1. Throttle Trigger in Idle Position
2. No Trimmer Head Rotation

To adjust the engine idle speed, rotate the idle speed adjustment screw on the carburetor (Fig. 28).

- Turn the idle speed screw in (clockwise) to increase the engine idle speed.
- Turn the screw out (counterclockwise) to decrease the engine idle speed.

If idle speed adjustment is necessary, and after adjustment the trimmer head rotates or the engine stalls, stop using the String Trimmer immediately!

Contact your local authorized Toro Dealer for assistance and servicing.




Figure 28

1. Idle Speed Adjustment Screw

Spark Plug

Maintenance Interval

- The spark plug should be removed from the engine and checked after each 25 hours of operation.
- Replace the spark plug (NGK BPM6Y) after every 100 hours of operation.

Spark Plug Maintenance

Model 53010 & 53011

1. With the engine at ambient (room) temperature, remove the socket head screw holding the muffler cover, then remove the muffler cover (Fig. 30).

2. Loosen the cylinder cover screw and lift off the cylinder cover (Fig. 29).




Figure 29

1. Screw
2. Cylinder Cover

3. Twist the high tension lead boot on the spark plug back and forth a couple of times to loosen the boot, then pull the boot off of the spark plug.

4. Remove the spark plug.

5. Clean the electrodes with a stiff brush (Fig. 32).

6. Adjust the electrode air gap to .024–.028 in. (0.6–0.7mm) (Fig. 32).

7. Replace the spark plug if it is oil-fouled, damaged, or if the electrodes are worn down.

8. Do not overtighten the spark plug when installing. The tightening torque is 95–148 in. lbs. (10.7–16.6 N•m).

9. Reinstall the cylinder and muffler covers (Figs. 29 and 30).




Figure 30

1. Muffler Cover
2. Socket Head Screw

Model 53002 & 53003

1. With the engine at ambient (room) temperature, loosen the knob and remove the air cleaner cover (Fig. 31).

2. Loosen the knob and lift off the cylinder cover (Fig. 31).




Figure 31

1. Air Filter Cover
2. FIlter Screen
3. Foam Ring

3. Twist the high tension lead boot on the spark plug back and forth a couple of times to loosen the boot, then pull the boot off of the spark plug.

4. Remove the spark plug.

5. Clean the electrodes with a stiff brush (Fig. 32).

6. Adjust the electrode air gap to .024–.028 in. (0.6–0.7mm) (Fig. 32).

7. Replace the spark plug if it is oil-fouled, damaged, or if the electrodes are worn down.

8. Do not overtighten the spark plug when installing. The tightening torque is 95–148 in. lbs. (10.7–16.6 N•m).

9. Reinstall the cylinder and air cleaner covers (Fig. 31).




Figure 32

1. .024”–.028” (0.6–0.7 mm)

Cylinder Cooling Fins

Maintenance Interval

The cylinder cooling fins should be cleaned after every 25 hours of operation, or once a week, whichever comes first.

Air must flow freely around and through the cylinder cooling fins to prevent engine overheating. Leaves, grass, dirt and debris buildup on the fins will increase the operating temperature of the engine, which can reduce engine performance and shorten engine life.

Cooling Fin Cleaning

Model 53010 & 53011

1. With the engine cool (ambient or room temperature), remove the socket head screw holding the muffler cover, then remove the muffler cover (Fig. 30).

2. Loosen the cylinder cover screw and remove the cylinder cover (Fig. 29).

3. Clean all dirt and debris from the cooling fins and from around the cylinder base.

4. Reinstall the cylinder cover and the muffler cover (Figs 30 and 29).

Model 53002 & 53003

1. With the engine at ambient (room) temperature, loosen the knob and remove the air cleaner cover (Fig. 33).

2. Loosen the knob and lift off the cylinder cover (Fig. 33).

3. Clean all dirt and debris from the cooling fins and from around the cylinder base.

4. Reinstall the cylinder and air cleaner covers (Fig. 33).




Figure 33

1. Air Filter Cover
2. FIlter Screen
3. Foam Ring

Spark Arrester

⚠ WARNING

POTENTIAL HAZARD
- **Muffler surface becomes hot when Trimmer is in operation and remains hot for some time after the engine is shut off.**

WHAT CAN HAPPEN
- **Contact with hot muffler surfaces could cause a burn.**

HOW TO AVOID THE HAZARD
- **Make sure the muffler is cool before inspecting and cleaning the spark arrester.**

Maintenance Interval

- The spark arrester should be inspected and cleaned after every 25 hours of use.
- Replace the screen if it cannot be thoroughly cleaned, or if it is damaged.

Spark Arrester Maintenance

Model 53010 & 53011

1. With the engine at ambient (room) temperature, remove the socket head screw holding the muffler cover, then remove the muffler cover (Fig. 30).
2. Remove the four socket head screws holding the spark arrester assembly to the muffler (Fig. 34).
3. Remove and clean the tail, screen, gasket and plate with a safety solvent and a stiff brush. If any part cannot be thoroughly cleaned, it must be replaced.
4. Reinstall the plate, gasket, screen and tail onto the muffler, then reinstall and tighten the four socket head screws (Fig. 34).




Figure 34

1. Socket Head Screw (4)
2. Tail
3. Screen
4. Gasket
5. Plate
6. Muffler

5. Reinstall the muffler cover (Fig. 30).

Model 53002 & 53003

1. With the engine at ambient (room) temperature, loosen the knob and remove the air cleaner cover (Fig. 33).
2. Loosen the knob and lift off the cylinder cover (Fig. 33).
3. Remove the two socket head screws holding the spark arrester assembly to the muffler (Fig. 35).
4. Remove and clean the tail, gasket and spark arrester with a safety solvent and a stiff brush. If any part cannot be thoroughly cleaned, it must be replaced.
5. Reinstall the spark arrester, gasket and tail onto the muffler, then reinstall and tighten the two socket head screws (Fig. 35).




Figure 35

1. Socket Head Screw (2)
2. Tail
3. Gasket
4. Spark Arrester
5. Muffler

6. Reinstall the cylinder and air cleaner covers (Fig. 33).

Gearcase Maintenance

The gearcase is a sealed unit which has been greased at the factory. No gearcase maintenance or lubrication is required or recommended.

General Cleaning and Tightening

⚠ WARNING

POTENTIAL HAZARD
- **When engine is running, cutting head is rotating and other parts are moving.**

WHAT CAN HAPPEN
- **Contact with rotating cutting head or other moving parts could cause serious personal injury or death.**

HOW TO AVOID THE HAZARD
- **Always turn off your Trimmer before you clean or perform any maintenance on it.**

The Toro String Trimmer will provide maximum performance for many, many hours if it is maintained properly. Good maintenance includes regular checking of all fasteners for correct tightness, and cleaning the entire machine.

Storage

For long-term storage of the String Trimmer:

1. Empty the fuel tank into a suitable fuel storage container.
2. Pump the primer bulb on the carburetor until all fuel is discharged through the clear fuel return hose.
3. Run the engine to remove any fuel that may remain in the carburetor.
4. Perform all regular maintenance procedures and any needed repairs.
5. Remove the spark plug and squirt a very small amount of oil into the cylinder (Fig. 36).




Figure 36

⚠ CAUTION

POTENTIAL HAZARD
- **Oil may squirt out of the spark plug opening when you pull the starter handle.**

WHAT CAN HAPPEN
- **Oil can cause eye injuries.**

HOW TO AVOID THE HAZARD
- **Protect your eyes and keep your face away from the spark plug opening.**

6. Pull the starter handle once.
7. Slowly pull the starter handle to bring the piston to the top of the cylinder (TDC).
8. Reinstall the spark plug.
9. Store the String Trimmer in a dry place away from excessive heat, sparks or open flame.

Accessories

The following accessories may be purchased at your local authorized TORO Service Dealer.

1. **Single Strap Harness, Model No. 46–2951** and **Deluxe Strap Harness, Model No. 46–2961**—safety release straps made out of durable nylon webbing (Fig. 37).




Figure 37

1. Red Band
2. Strap
3. Ring

⚠ WARNING

POTENTIAL HAZARD

- **Without the Brushcutter blade shield installed on the String Trimmer, the Brushcutter blade can throw foreign objects.**
- **Without the correct blade shield, handles and strap installed on the String Trimmer, the Brushcutter can produce side thrust which can expose the operator and bystanders to blade contact.**

WHAT CAN HAPPEN

- **Contact with the Brushcutter blade or thrown objects can cause severe personal injury.**

HOW TO AVOID THE HAZARD

- **Never install only a Brushcutter blade onto a String Trimmer.**
- **To convert a String Trimmer to a Brushcutter, you must purchase and install the entire Brushcutter Accessory Kit.**

2. **Brushcutter Accessory Kit, Model No. 53050**—allows you to convert the String Trimmer to a Brushcutter; available for Industrial Models (53002 and 53003) only.

Troubleshooting

Problem	Cause	Action
Engine Will Not Start	STOP switch set to off position	Move switch to on position
	Empty fuel tank	Fill fuel tank
	Primer bulb wasn't pushed enough	Press primer bulb until fuel flows through fuel return line
	Engine flooded	Use warm engine starting procedure
Engine Will Not Idle	Idle speed set incorrectly	Set idle speed
Engine Lacks Power or Stalls When Cutting	Throttle wire has come loose	Tighten throttle wire
	Dirty air filter	Clean or replace air filter

If further assistance is required, contact your local authorized Toro service dealer.

Specifications

Note: All models are CARB approved.

53010/Commercial

Engine Displacement	23cc
Shaft	Straight (59”/150 cm) steel with 5 ball bearings, 5 bushings
Anti Vibration	Dual Isolation – grip and engine mount
Carburetor	Walbro – Choke Type
Ignition System	Solid State
Fuel Tank Capacity	0.63 qts. (0.6 liter)
Gas to Oil Ratio	50:1
Cutting Head	4” Semiautomatic
Weight	12.6 lbs. (5.7 kg)
Spark Plug	NGK BPM6Y
Spark Plug Gap	.024–.028 in (0.6–0.7mm)

53002/Industrial

Engine Displacement	26cc
Shaft	Straight (59”/150 cm) steel with 6 ball bearings, 5 bushings
Anti Vibration	Dual Isolation – grip and engine mount
Carburetor	Walbro – Choke Type
Ignition System	Solid State
Fuel Tank Capacity	0.85 qts. (0.8 liter)
Gas to Oil Ratio	50:1
Cutting Head	5” Semiautomatic
Weight	14.8 lbs. (6.7 kg)
Spark Plug	NGK BPM6Y
Spark Plug Gap	.024–.028 in (0.6–0.7mm)

53011/Commercial

Engine Displacement	26cc
Shaft	Straight (59”/150 cm) steel with 6 ball bearings, 5 bushings
Anti Vibration	Dual Isolation – grip and engine mount
Carburetor	Walbro – Choke Type
Ignition System	Solid State
Fuel Tank Capacity	0.74 qts. (0.7 liter)
Gas to Oil Ratio	50:1
Cutting Head	4” Semiautomatic
Weight	13.3 lbs. (6 kg)
Spark Plug	NGK BPM6Y
Spark Plug Gap	.024–.028 in (0.6–0.7mm)

53003/Industrial

Engine Displacement	32cc
Shaft	Straight (59”/150 cm) steel with 6 ball bearings, 5 bushings
Anti Vibration	Dual Isolation – grip and engine mount
Carburetor	Walbro – Choke Type
Ignition System	Solid State
Fuel Tank Capacity	1.05 qts. (1 liter)
Gas to Oil Ratio	50:1
Cutting Head	5” Semiautomatic
Weight	15.3 lbs. (6.9 kg)
Spark Plug	NGK BPM6Y
Spark Plug Gap	.024–.028 in (0.6–0.7mm)

Federal and California Emission Control Warranty Statement

A Two Year Limited Warranty

Your Warranty Rights and Obligations

The U.S. Environmental Protection Agency (EPA), the California Air Resources Board (CARB) and Toro are pleased to explain the emission control system warranty on your 1995 and later utility/lawn/garden equipment engine. In California, new utility/lawn/garden equipment engines must be designed, built and equipped to meet the State's stringent anti–smog standards. In other states, new 1997 and later model year utility/lawn/garden equipment engines must be designed, built and equipped, at the time of sale, to meet the U.S. EPA regulations for small nonroad engines. The equipment engine must be free from defects in materials and workmanship which cause it to fail to conform with U.S. EPA standards for the first two years of engine use from the date of sale to the ultimate purchaser. Toro must warrant the emission control system on your utility/lawn/garden equipment engine for the period of time listed above provided there has been no abuse, neglect or improper maintenance of your utility/lawn/garden equipment engine.

Your emission control system may include parts such as the carburetor or fuel injection system, the ignition system, and catalytic converter. Also included may be hoses, belts, and connectors and other emission related assemblies.

Where a warrantable condition exists, Toro will repair your engine at no cost to you including diagnosis, parts and labor.

Manufacturer's Warranty Coverage:

Utility/Lawn/Garden equipment engines are warranted for two years from the date of delivery. If any emission–related part on your engine is defective in materials or workmanship, the part will be repaired or replaced by Toro free of charge.

Owner's Warranty Responsibilities:

- As the engine owner, you are responsible for the performance of the required maintenance listed in your owner's manual. Toro recommends that you retain all receipts covering maintenance on your equipment, but Toro cannot deny warranty solely for the lack of receipts or for your failure to ensure the performance of all scheduled maintenance.
- Any replacement part or service that is equivalent in performance and durability may be used in non–warranty maintenance or repairs, and shall not reduce the warranty obligations of the engine manufacturer.
- As the engine owner, you should, however, be aware that Toro may deny you warranty coverage if your engine or a part has failed due to abuse, neglect, improper maintenance or unapproved modifications or parts.
- You are responsible for presenting your equipment engine to a TORO Service Dealer as soon as a problem exists. The warranty repairs should be completed in a reasonable amount of time, not to exceed 30 days.
- If you have any questions regarding your warranty rights and responsibilities or if you need a referral to a TORO Service Dealer, please feel free to contact us at the following address:

  Toro Customer Service Department
  8111 Lyndale Avenue South
  Bloomington, MN 55420–1196
  612–888–8801
  800–348–2424

Warranted Parts:

The warranty period begins on the date the engine or equipment is delivered to a retail purchaser. The manufacturer warrants to the initial owner and each subsequent purchaser that the engine is free from defects in materials and workmanship which cause the engine to fail to conform with applicable regulations for a period of two years.

Failures caused by abuse, neglect, or improper maintenance are not covered. The use of add–on or modified parts can be grounds for disallowing a warranty claim. The manufacturer is not liable to cover failures of warranted parts caused by the use of add–on or modified parts. Toro is liable for damages to other engine components caused by the failure of a warranted part still under warranty. The owner is responsible for the performance of the required maintenance, as defined by the manufacturer in the written instructions.

Any warranted part which is not scheduled for replacement as required maintenance, or which is scheduled only for regular inspection to the effect of ”repair or replace as necessary” shall be warranted for the warranty period. Any warranted part which is scheduled for replacement as required maintenance shall be warranted for the period of time up to the first scheduled replacement point for that part. Coverage under this warranty extends only to the parts listed below (the emissions system parts) to the extent that these parts were present on the engine when purchased.

– Fuel Metering System
  - Cold start enrichment system including the choke mechanism or priming system
  - Fuel pump
  - Air fuel ratio feed back system
  - Carburetor and internal parts
  - Fuel injection system

– Air Induction System
  - Air cleaner
  - Reed intake system
  - Intake manifold
  - Controlled hot air intake system

– Ignition System
  - Spark plug(s)
  - Ignition coils and electronics
  - Advance/retard mechanisms

– Catalytic Converter/Thermal Reactor System
  - Catalytic converter
  - Thermal reactor
  - Exhaust manifold

– Air Injection System
  - Air injection system or pulse valve
  - Valves affecting distribution of air

– Exhaust Gas Recirculation (EGR) System
  - EGR valve body and piping system connecting to the intake side of the engine
  - EGR control system

– Particulate Controls
  - Traps filters, precipators and any other device used to capture particulate emissions

– Miscellaneous Items Used in the Above Systems
  - Vacuum, temperature, and time sensitive valves and switches
  - Electronic controls
  - Hoses, connectors, and assemblies of same

How to Get Warranty Service:

Should you feel your TORO Product requires warranty service, contact the dealer who sold you the product or any Authorized TORO Service Dealer or TORO Master Service Dealer. The Yellow Pages of your telephone directory is a good reference source. The dealer will either arrange service at his/her dealership or recommend another Authorized Service Dealer who may be more convenient. You may need proof of purchase (copy of registration card, sales receipt, etc.) for warranty validation. The owner shall not be charged for diagnostic labor which leads to the determination that a warranted part is defective, if the diagnostic work is performed at a warranty station.

The Toro Company is not liable for indirect, incidental or consequential damages in connection with the use of the TORO Products covered by this warranty, except for damages to other engine components caused by the failure of a warranted part still under warranty. Some states do not allow exclusions of incidental or consequential damages, so the above exclusion may not apply to you.

This warranty gives you specific legal rights, and you may also have other rights which vary from state to state.

LCG

THE TORO TOTAL COVERAGE GUARANTEE

A One-Year Limited Warranty
(A Two-Year Full Warranty for Residential Use)

What Is Covered By This Express Warranty?

The Toro Company promises to repair any TORO Product used for commercial, institutional, or rental purposes if defective in materials or workmanship for a period of one year from the date of purchase. The cost of parts and labor are included, but the customer pays the transportation cost. Transportation within a 15-mile radius of a TORO ProLine Service Dealer is covered under this warranty for Riding Products, Mid-size Mowers and Turf Maintenance Equipment.

What Products Are Covered By This Warranty?

The following products and their attachments are covered by this warranty:

- Z-Master Zero Radius Tractors
- ProLine Mid-size Mowers
- Groundsmaster Riding Mowers
- ProLine Hand-held Gas Products
- Backpack Blowers
- Commercial WPM
- Turf Maintenance Equipment
- Debris Management Equipment

How About Residential Use?

TORO Products used for residential use are covered by a full two-year warranty.

How Do You Get Warranty Service?

Should you feel your TORO Product contains a defect in materials or workmanship, contact the dealer who sold you the product or any TORO ProLine Service Dealer. The Yellow Pages of your telephone directory is a good reference source; look under TORO Commercial Service Dealers. The Service Dealer will either arrange service at his/her dealership or recommend another authorized Service Dealer who may be more convenient. You may need proof of purchase (copy of registration card, sales receipt, etc.) for warranty validation.

If for any reason you are dissatisfied with a Service Dealer's analysis of the defect in materials or workmanship or if you need a referral to a TORO ProLine Service Dealer, please feel free to contact us at the following address:

Toro Customer Service Department
8111 Lyndale Avenue South
Bloomington, MN 55420–1196
612–888–8801 or 800–348–2424

What Must You Do To Keep The Warranty In Effect?

You must maintain your TORO Product by following the maintenance procedures described in the operator's manual. Such routine maintenance, whether performed by a dealer or by you, is at your expense.

What Does This Warranty Not Cover? and How Does Your State Law Relate To This Warranty?

There is no other express warranty except for special emission system coverage on some products and as described above. This express warranty does not cover:

- Cost of regular maintenance service or parts, such as filters, fuel, lubricants, tune-up parts, blade sharpening, brake and clutch adjustments.
- Any product or part which has been altered or misused or required replacement or repair due to normal wear, accidents, or lack of proper maintenance.
- Repairs necessary due to improper fuel, contaminants in the fuel system, or failure to properly prepare the fuel system prior to any period of non-use over three months.
- Pickup and delivery charges for distances beyond a 15-mile radius from a TORO ProLine Service Dealer.

All repairs covered by this warranty must be performed by a TORO Service Dealer using Toro approved replacement parts.

The Toro Company is not liable for indirect or consequential damages in connection with the use of the TORO Products covered by this warranty, including any cost or expense of providing substitute equipment or service during reasonable periods of malfunction or non-use pending completion of repairs under this warranty. Some states do not allow exclusions of incidental or consequential damages, so the above exclusion may not apply to you.

This warranty gives you specific legal rights, and you may also have other rights which vary from state to state.

COUNTRIES OTHER THAN THE UNITED STATES OR CANADA

Customers who have purchased TORO products exported from the United States or Canada should contact their TORO Distributor (Dealer) to obtain guarantee policies for your country, province, or state. If for any reason you are dissatisfied with your Distributor's service or have difficulty obtaining guarantee information, contact the TORO importer. If all other remedies fail, you may contact us at The Toro Company.

Rev 6/18/97