Form No. 3439-771 Rev C

TORO®

Count on it.

Parts Catalog

# SnowMaster 724 QXE

## Snowthrower

**Model No. 36002—Serial No. 406500000 and Up**

Register at www.Toro.com.
Original Instructions (EN)

*3439-771* C

# Ordering Replacement Parts

To order replacement parts, please supply the part number, the quantity, and the description of each part desired.

### Understanding Reference Numbers

Each identified part in an illustration has a reference number. The reference number for a part also appears in the parts list, along with other information about the part.

This catalog uses two special reference number formats, one to indicate parts in a service assembly and another to indicate the quantity of a given part in an illustration.

### Service Assembly Reference Numbers

Parts in service assemblies have reference numbers in the form a:b. The a represents the reference number of the entire service assembly and the b represents a sequential number unique to each part within the service assembly.

For example, a wheel assembly might be identified by reference number 6, the tire by 6:1, the valve by 6:2, and the wheel by 6:3. When you order the assembly identified by reference number 6, you receive all parts identified by reference numbers 6:1,6:2, and 6:3. However, you may also order any part individually. Reference numbers of this type appear in illustration and in parts lists.

### Reference Numbers Indicating Quantity

In an illustration, if a reference number indicates more than one part, the reference number has the form nX y. The n represents the quantity of the part, the X is the multiplication symbol, and the y represents the reference number.

For example, in an illustration, the reference number 2X 37 means that two of the parts identified by reference number 37 are indicated.

# Contents

Main Frame Assembly . . . . . 4
Rotor Assembly . . . . . 6
Rotor Drive Assembly . . . . . 8
Transmission, Drive and Tire Assembly . . . . . 10
Engine Assembly . . . . . 12
Fuel System and Carburetor Assembly . . . . . 14
Intake and Exhaust Assembly . . . . . 16
Ignition and Electrical Assembly . . . . . 18
Crankcase Assembly . . . . . 20
Governor Assembly . . . . . 22
Piston and Head Assembly . . . . . 24
Blower Housing and Shrouds Assembly . . . . . 26
Engine Decal Assembly . . . . . 28
Chute Assembly . . . . . 30
Chute Control Lever Assembly . . . . . 32
Handle and Control Assembly . . . . . 34
Attachments and Accessories . . . . . 36

**© 2021—The Toro® Company**
**8111 Lyndale Avenue South**
**Bloomington, MN 55420**



**Contact us at www.Toro.com.**
**Printed in the USA.**
**All Rights Reserved**

# Main Frame Assembly

# Main Frame Assembly (continued)

| Ref. | Part Number | Qty. | Description |
|---|---|---|---|
| 1 | 130-9550-01 | 1 | Frame |
| 2 | 130-9581-01 | 1 | Cover-Belt |
| 3 | 49-2040 | 3 | Screw-HWHTF |
| 6 | 130-9628 | 1 | Scraper ASM |
| 7 | 104-0858 | 6 | Bolt-Shoulder |
| 8 | 3296-42 | 6 | Nut-Lock, NI |
| 9 | 130-9619 | 2 | Skid ASM |
| 10 | 3230-16 | 4 | Screw-CARR |
| 11 | 52-2861 | 4 | Washer |
| 12 | 104-8300 | 4 | Nut-HF, NI |
| 13 | 131-1793-03 | 1 | Bracket-Cable |
| 14 | 32144-4 | 4 | Screw-HWH |
| 15 | 95-7949 | 1 | Cable-Pulley |
| 16 | 115-5103 | 1 | Screw-HHF |
| 17 | 55-9370 | 1 | Spacer-Blade, Rotor |
| 18 | 104-7201 | 1 | Nut-HF |

| Ref. | Part Number | Qty. | Description |
|---|---|---|---|
| 28 | 136-7172 | 1 | Plate-Stud, Front |
| 29 | 923786 | 1 | Rivet |
| 35 | 131-1763 | 1 | Cover-Belt, Lower |
| 36 | 131-1764 | 1 | Cover-Belt, Upper |
| 37 | 46-8091 | 2 | Screw-HWH |
| 38 | 3296-47 | 1 | Nut-Lock, NI |
| 40 | 107-1013 | 2 | Nut-Speed |
| 41 | 131-1797-01 | 1 | Support-Frame, Lower |
| 42 | 107069 | 2 | Clip |
| 43 | 3256-2 | 2 | Washer-Flat |
| 44 | 136-7177 | 1 | Plate-Stud, Rear |
| 45 | 131-5944-01 | 1 | Plate-Spacer |
| 46 | 131-5945 | 2 | Isolator-Engine |
| 47 | 109-5667 | 2 | Nut-Push |
| 48 | 133-8061 | 1 | Decal-Warning |

# Rotor Assembly

# Rotor Assembly (continued)

| Ref. | Part Number | Qty. | Description |
|---|---|---|---|
| 1 | 130-9571-03 | 1 | Rotor ASM |
| 2 | 130-9568-03 | 2 | Support-Center, Rotor |
| 3 | 130-9569 | 2 | Paddle-Center |
| 4 | 3229-2 | 6 | Screw-CARR |
| 5 | 3296-42 | 6 | Nut-Lock, NI |
| 7 | 32144-4 | 6 | Screw-HWH |
| 8 | 136-7134 | 1 | Flange-Bearing |
| 9 | 38-7820 | 2 | Bearing-Ball |
| 10 | 52-7280 | 2 | Washer-Thrust |
| 11 | 136-7169 | 1 | Flange-Bearing |
| 12 | 130-9558-01 | 1 | Cap-Bearing |
| 13 | 131-5905 | 1 | Washer-Rubber |
| 14 | 110-9380 | 1 | Screw-HWH |

# Rotor Drive Assembly

# Rotor Drive Assembly (continued)

| Ref. | Part Number | Qty. | Description |
|---|---|---|---|
| 1 | 130-9574 | 1 | Pulley-Rotor |
| 2 | 3290-456 | 2 | Washer-Belleville |
| 4 | 136-7179 | 1 | Arm-Engagement, Rotor |
| 5 | 117-7711 | 1 | Bushing-Idler |
| 6 | 3234-29 | 1 | Screw-HHF |
| 7 | 104-8300 | 1 | Nut-HF, NI |
| 8 | 108-4925 | 1 | Washer |
| 9 | 131-5988 | 1 | Pulley-Idler, Flat |
| 10 | 323-29 | 1 | Screw-HH |
| 11 | 3296-59 | 1 | Nut-Lock, NI |
| 12 | 130-9577 | 1 | Pulley-Jackshaft, Rotor |
| 13 | 131-5967 | 1 | Belt-Poly V |
| 14 | 130-9572 | 1 | Spring-Extension |
| 15 | 136-7133 | 1 | Clip-Spring |
| 17 | 9080046 | 2 | Screw-HH |
| 18 | 136-7134 | 1 | Flange-Bearing |
| 19 | 52-7280 | 1 | Washer-Thrust |
| 20 | 38-7820 | 1 | Bearing-Ball |
| 21 | 32144-4 | 3 | Screw-HWH |

# Transmission, Drive and Tire Assembly

# Transmission, Drive and Tire Assembly (continued)

| Ref. | Part Number | Qty. | Description |
|---|---|---|---|
| 1 | 130-9642 | 1 | Transmission |
| 1:1 | 131-5973 | 1 | Pulley Repair Kit |
| 1:2 | 131-5984 | 1 | Plug-Oil |
| 2 | 130-9643 | 2 | Bearing-Axle |
| 3 | | 1 | RH Wheel And Tire ASM ● |
| 3:1 | 130-9559 | 1 | Tire |
| 3:2 | 130-9560 | 1 | Wheel |
| 3:3 | 232-27 | 1 | Stem-Valve |
| 4 | | 1 | LH Wheel And Tire ASM ● |
| 4:1 | 130-9559 | 1 | Tire |
| 4:2 | 130-9560 | 1 | Wheel |
| 4:3 | 232-27 | 1 | Stem-Valve |
| 6 | 321-9 | 2 | Screw-HH |
| 7 | 3296-42 | 2 | Nut-Lock, NI |
| 10 | 130-9586-03 | 1 | Plate-Support, Jackshaft |
| 11 | 131-1794 | 1 | Support-Bearing |
| 12 | 49-2040 | 7 | Screw-HWHTF |
| 13 | 131-1795 | 1 | Idler-Traction |
| 14 | 108-4925 | 2 | Washer |
| 16 | 104-8300 | 1 | Nut-HF, NI |
| 17 | 136-7192 | 1 | Bolt-Shoulder, HHF |
| 18 | 130-9645 | 1 | Spring-Extension |
| 19 | 130-9583 | 1 | Pulley-Jackshaft |
| 20 | 3290-456 | 1 | Washer-Belleville |
| 21 | 9080046 | 1 | Screw-HH |
| 22 | 38-7820 | 1 | Bearing-Ball |
| 23 | 136-7171 | 1 | Retainer-Bearing |
| 24 | 32144-4 | 2 | Screw-HWH |
| 25 | 52-7280 | 1 | Washer-Thrust |
| 26 | 131-5988 | 1 | Pulley-Idler, Flat |
| 27 | 323-29 | 1 | Screw-HH |
| 28 | 3296-59 | 1 | Nut-Lock, NI |
| 29 | 131-5968 | 1 | Belt-Poly V |
| 31 | 131-5904 | 2 | Washer-Rubber |
| 32 | 131-5910 | 1 | Spacer-Axle |
| 33 | 130-9585 | 1 | Jackshaft |

● Not serviced separately

# Engine Assembly

# Engine Assembly (continued)

| Ref. | Part Number | Qty. | Description |
|---|---|---|---|
| 1 | 127-9171 | 1 | Engine-G210Fds-2 |
| 2 | 131-5908 | 1 | Pulley-Engine |
| 3 | 131-5919 | 1 | Screw-HH, Patch |
| 4 | 3290-456 | 1 | Washer-Belleville |
| 5 | 32128-20 | 4 | Nut-HF |

# Fuel System and Carburetor Assembly

# Fuel System and Carburetor Assembly (continued)

| Ref. | Part Number | Qty. | Description |
|---|---|---|---|
| 1 | 133-9823 | 1 | Cap-Fuel |
| 2 | 127-9497 | 1 | Fuel Tank And Filter ASM |
| 2:2 | 127-9065 | 1 | Filter-Fuel |
| 3 | 121-0294 | 1 | Screw-HHF |
| 5 | 127-9120 | 1 | Clamp-Hose |
| 6 | 127-9403 | 1 | Hose-Fuel |
| 7 | 121-0087 | 1 | Clamp-Hose |
| 8 | 121-0076 | 1 | Gasket-Carburetor |
| 9 | 121-0077 | 1 | Insulator-Carburetor |
| 10 | 121-0078 | 1 | Gasket-Carburetor |
| 11 | 127-9111 | 1 | Carburetor ASM |
| 12 | 121-0080 | 1 | Gasket-Carburetor |
| 13 | 127-9079 | 1 | Primer Kit |
| 14 | 127-9394 | 1 | Internal Carb Service Kit |
| 99 | 127-9301 | 1 | High Altitude Kit - G210 ● |

● Not illustrated

# Intake and Exhaust Assembly

# Intake and Exhaust Assembly (continued)

| Ref. | Part Number | Qty. | Description |
|---|---|---|---|
| 1 | 121-0294 | 6 | Screw-HHF |
| 2 | 136-7778 | 1 | Guard-Muffler |
| 3 | 121-0199 | 2 | Nut-HH |
| 4 | 133-9846 | 1 | Muffler ASM |
| 5 | 121-0167 | 1 | Gasket-Exhaust |
| 6 | 121-0464 | 2 | Stud-Exhaust |
| 7 | 121-4112 | 2 | Stud-Intake |
| 8 | 127-9112 | 1 | Box-Heater |
| 9 | 121-0308 | 2 | Nut-Flange |

# Ignition and Electrical Assembly

# Ignition and Electrical Assembly (continued)

| Ref. | Part Number | Qty. | Description |
|---|---|---|---|
| 1 | 121-0326 | 1 | Clip |
| 2 | 121-0283 | 1 | Switch-Key |
| 3 | 117-7728 | 1 | Key |
| 4 | 136-7769 | 1 | Ignition Coil ASM |
| 5 | 121-0097 | 2 | Screw-HHF |
| 6 | 121-0047 | 1 | Nut-Flange |
| 7 | 127-9106 | 1 | Cup-Starter |
| 8 | 127-9002 | 1 | Fan |
| 9 | 127-9005 | 1 | Flywheel |
| 10 | 121-0306 | 2 | Screw-Bhp |
| 11 | 121-0312 | 2 | Washer-Plain |
| 12 | 136-7776 | 1 | Motor-Starter |
| 13 | 133-1546 | 2 | Screw-Flange |
| 14 | 121-0055 | 2 | Pin-Dowel |
| 15 | 127-9407 | 1 | Bracket-Box, Switch |
| 16 | 127-9123 | 2 | Screw-HHF |
| 17 | 121-0017 | 1 | Clip-Harness, Wire |

# Crankcase Assembly

# Crankcase Assembly (continued)

| Ref. | Part Number | Qty. | Description |
|---|---|---|---|
| 1 | 127-9409 | 1 | Dipstick-Oil |
| 2 | 127-9492 | 1 | Gasket-Dipstick, Rubber |
| 3 | 121-4114 | 6 | Screw-HHF |
| 5 | 121-0209 | 1 | Seal-Oil |
| 6 | 133-9843 | 1 | Crankcase Cover ASM |
| 7 | 121-0105 | 1 | Gasket-Cover, Crankcase |
| 8 | 121-0054 | 2 | Pin-Dowel |
| 9 | 139-0733 | 1 | Camshaft |

| Ref. | Part Number | Qty. | Description |
|---|---|---|---|
| 10 | 127-9399 | 1 | Crankshaft |
| 11 | 121-0056 | 1 | Bearing-Ball |
| 13 | 121-0030 | 2 | Screw-HHF |
| 14 | 121-0048 | 3 | Washer-Plain |
| 15 | 127-9104 | 1 | Tube-Drain, Oil |
| 16 | 121-0208 | 1 | Seal-Oil |
| 17 | 120-4320 | 1 | Key-Woodruff |
| 18 | 133-9805 | 1 | Plug-Drain |

# Governor Assembly

# Governor Assembly (continued)

| Ref. | Part Number | Qty. | Description |
|---|---|---|---|
| 1 | 120-4236 | 1 | Nut-Flange |
| 2 | 120-4238 | 1 | Bolt-Arm, Governor |
| 3 | 121-0155 | 1 | Arm-Governor |
| 4 | 120-4256 | 1 | Pin-Hair |
| 5 | 136-7763 | 1 | Shaft-Governor |
| 6 | 121-0498 | 1 | Washer-Plain |
| 7 | 133-9994 | 1 | Governor Gear ASM |
| 8 | 127-9398 | 1 | Spring-Governor |
| 9 | 121-0153 | 1 | Spring-Return, Throttle |
| 10 | 121-0148 | 1 | Rod-Governor |

# Piston and Head Assembly

# Piston and Head Assembly (continued)

| Ref. | Part Number | Qty. | Description |
|---|---|---|---|
| 1 | 120-4454 | 4 | Screw-HHF |
| 2 | 127-9094 | 1 | Cover-Valve |
| 3 | 127-9408 | 1 | Clamp-Hose |
| 4 | 139-0631 | 1 | Tube-Breather |
| 5 | 121-0109 | 1 | Gasket-Cover, Valve |
| 6 | 121-4110 | 4 | Screw-HHF |
| 7 | 81-3250 | 1 | Spark Plug |
| 8 | 127-9013 | 1 | Head-Cylinder |
| 9 | 127-9000 | 1 | Gasket-Head, Cylinder |
| 10 | 121-0053 | 2 | Pin-Dowel |
| 11 | 120-4475 | 2 | Rocker Arm ASM |
| 12 | 121-4120 | 1 | Plate-Guide, Push Rod |
| 13 | 121-4121 | 2 | Rod-Push |
| 14 | 127-9015 | 2 | Tappet-Valve |
| 15 | 121-4116 | 2 | Rotator-Valve |
| 16 | 121-4117 | 2 | Retainer-Spring, Valve |
| 17 | 127-9014 | 2 | Spring-Valve |
| 18 | 121-4202 | 1 | Seal-Stem, Valve |
| 19 | 127-9016 | 1 | Valve Set |
| 20 | 121-4295 | 1 | Ring Set, Piston |
| 21 | 121-4293 | 1 | Piston |
| 22 | 121-0313 | 2 | Clip-Pin, Piston |
| 23 | 121-4128 | 1 | Pin-Piston |
| 24 | 127-9017 | 1 | Connecting Rod ASM |
| 25 | 133-9839 | 1 | Complete Head ASM |

# Blower Housing and Shrouds Assembly

# Blower Housing and Shrouds Assembly (continued)

| Ref. | Part Number | Qty. | Description |
|---|---|---|---|
| 1 | 121-0118 | 4 | Screw-HHF |
| 2 | 127-9396 | 1 | Speed Control ASM |
| 3 | 127-9383 | 2 | Nut-Acorn |
| 4 | 127-9406 | 1 | Panel-Front |
| 5 | 127-9110 | 2 | Stud-Mount |
| 7 | 127-9096 | 1 | Shroud-Lower |
| 8 | 120-4454 | 1 | Screw-HHF |
| 9 | 127-9121 | 1 | Shield-Flywheel |
| 10 | 127-9401 | 1 | Shroud-Blower |
| 11 | 121-0294 | 2 | Screw-HHF |
| 12 | 127-9402 | 1 | Recoil Starter ASM |
| 12:1 | 121-0287 | 1 | Handle-Recoil |
| 13 | 127-9380 | 4 | Washer-Plain |
| 14 | 127-9031 | 4 | Screw-HHF |

# Engine Decal Assembly

# Engine Decal Assembly (continued)

| Ref. | Part Number | Qty. | Description |
|---|---|---|---|
| 1 | 120-9805 | 1 | Decal-Control, Engine |
| 2 | 120-9806 | 1 | Decal-Engine, Series G210 |
| 3 | 120-9809 | 1 | Decal-Recoil, G210 |

# Chute Assembly

# Chute Assembly (continued)

| Ref. | Part Number | Qty. | Description |
|---|---|---|---|
| 1 | 130-9587 | 1 | Chute-Lower |
| 2 | 130-9588 | 1 | Guide-Chute |
| 3 | 130-9589-03 | 1 | Bracket-Post, Support (Chute) |
| 4 | 130-9590 | 1 | Retainer- Post, Chute |
| 5 | 130-9603-03 | 1 | Post-Chute |
| 6 | 130-9605 | 1 | Gear-Chute |
| 7 | 136-7170 | 1 | Bracket-Cable |
| 8 | 133-5591 | 1 | Chute-Discharge |
| 9 | 130-9596 | 1 | Ring-Chute |
| 10 | 130-9607 | 1 | Latch-Chute |
| 11 | 130-9608 | 1 | Mount-Gear, Chute |
| 12 | 106-4471 | 1 | Gear-Face |
| 13 | 131-5915 | 1 | Deflector-Chute |
| 14 | 136-7145 | 1 | Rod-Deflector |
| 15 | 130-9609 | 1 | Guide-Cable |
| 16 | 130-9611 | 1 | Cover-Gear, Chute |
| 17 | 120-9299 | 1 | Chute-Cover |
| 18 | 136-7191 | 1 | Clamp-Cable |
| 19 | 136-7199 | 1 | Bolt-Shoulder |
| 20 | 63-2650 | 1 | Screw-Shoulder |
| 21 | 130-9616 | 1 | Spring-Torsion, Latch (Chute) |
| 22 | 131-5927 | 1 | Screw-HHF |
| 24 | 46-8091 | 17 | Screw-HWH |
| 25 | 98-1375 | 5 | Screw-HWH |
| 26 | 32144-10 | 1 | Screw-HWH |
| 27 | 104-8300 | 2 | Nut-HF, NI |
| 28 | 108-0988 | 2 | Screw-CARR |
| 29 | 114-3778 | 3 | Nut-HF |
| 31 | 136-7143 | 1 | Spring-Torsion |
| 32 | 94-4496 | 3 | Screw-PPH |
| 33 | 131-1754 | 1 | Shroud-Upper, LH |
| 34 | 131-1765 | 1 | Shroud-Lower, RH |
| 35 | 32144-85 | 2 | Screw-HWH |
| 37 | 131-1768 | 1 | Kicker-Housing |
| 38 | 130-6658 | 2 | Screw-Flange, Plastic |
| 40 | 133-5592 | 1 | Decal |

# Chute Control Lever Assembly

# Chute Control Lever Assembly (continued)

| Ref. | Part Number | Qty. | Description |
|---|---|---|---|
| 1 | 94-4496 | 8 | Screw-PPH |
| 3 | 105-9982 | 1 | Spring-Torsion |
| 4 | 137-6238 | 1 | Trigger-Latch |
| 5 | 138-0688 | 1 | Link-Latch |
| 6 | 136-6678 | 1 | Globe-Quickstick, LH |
| 7 | 105-9988 | 1 | Lever-Cable, Deflector |
| 8 | 130-9614 | 1 | Cable-Release, Chute |
| 9 | 130-9613 | 1 | Cable-Control, Deflector |
| 10 | 138-0659 | 1 | Screw-Shoulder, HWH |
| 11 | 138-0662 | 1 | Rod-Control, Chute |
| 12 | 137-6239 | 1 | Cap-Lever |
| 13 | 137-6235 | 1 | Lever-Control, Chute (RH) |
| 13 | 137-6236 | 1 | Lever-Control, Chute (LH) |
| 15 | 136-6677 | 1 | Globe-Quickstick, RH |
| 16 | 136-6632 | 1 | Plate-Stiffner |
| 17 | 106-7310 | 1 | Pawl-Latch |
| 18 | 138-0744 | 1 | Washer-Friction, Composite |
| 20 | 137-3087 | 1 | Nut-Hex |
| 22 | 144-1236 | 1 | Rod-Chute |
| 23 | 137-3056 | 3 | Bolt-CARR |
| 24 | 137-3094 | 3 | Nut-Hex |
| 25 | 32144-85 | 1 | Screw-HWH |

# Handle and Control Assembly

# Handle and Control Assembly (continued)

| Ref. | Part Number | Qty. | Description |
|---|---|---|---|
| 1 | 120-2333-03 | 1 | Handle-Upper |
| 2 | 120-2334-03 | 1 | Handle-Lower |
| 3 | 131-5921 | 1 | Handle |
| 4 | 120-2336 | 1 | Handle-Bottom, LH |
| 5 | 131-1770 | 1 | Handle-Bottom, RH |
| 6 | 120-2343 | 2 | Sleeve Handle |
| 9 | 136-7130 | 2 | Lock-Handle |
| 10 | 106-4161 | 2 | Knob-Handle |
| 11 | 136-7150 | 1 | Bar-Control, Traction |
| 12 | 136-7166 | 1 | Spring-Torsion |
| 13 | 131-5917 | 1 | Lever-Traction |
| 14 | 131-5924 | 1 | Cable-Transmission |
| 15 | 120-2338 | 1 | Cable-Rotor, Upper |
| 16 | 131-1753 | 1 | Cable-Rotor, Lower |
| 17 | 120-2349 | 12 | Screw |
| 18 | 131-1771 | 2 | Pin-Dowel |
| 19 | 95-4453 | 1 | Screw |
| 20 | 92-2269 | 1 | Screw-Handle |
| 21 | 3296-73 | 3 | Nut-Lock, NI |
| 22 | 107-3844 | 7 | Washer |
| 23 | 3296-73 | 4 | Nut-Lock, NI |
| 27 | 120-2342-03 | 1 | Bracket-Chute, Control |
| 30 | 139-3507 | 1 | Cover-Top |
| 32 | 105-9987 | 2 | Support-Rod |
| 34 | 131-1787 | 1 | Decal-Display |
| 35 | 131-1785 | 1 | Decal-Control, Panel |
| 36 | 3234-29 | 4 | Screw-HHF |
| 37 | 104-8300 | 4 | Nut-HF, NI |
| 38 | 136-7147 | 1 | Guide-Rope |
| 40 | 92-7729 | 1 | Anchor-Cable, Upper |
| 41 | 131-5903 | 1 | Cable-Guide |
| 42 | 131-5901 | 1 | Bail-Mount |
| 43 | 32144-4 | 2 | Screw-HWH |
| 44 | 117-7737 | 4 | Screw-Handle |
| 46 | 130-2343 | 1 | Spacer |
| 47 | 3256-1 | 2 | Washer-Flat |
| 48 | 131-5943 | 1 | Bail ASM |
| 48:1 | | 1 | Bail-Auger ● |
| 48:2 | 131-5902 | 1 | Cover-Bail |

● Not serviced separately

# Attachments and Accessories

## For 36002 SnowMaster 724 QXE Snowthrower

| Product Name | Model/Part |
|---|---|
| Center Paddle Replacement Kit | 130-9569P |
| Skid Replacement Kit | 130-9619P |
| Scraper Kit | 130-9628P |
| Rotor Belt | 131-5967P |
| Engine Maintenance Kit | 138-0699 |
| Case of 24 20-Ounce Bottles 5W30 Winter Oil | 38908 |
| Toro Snow Oil 0W30 Synthetic 20-Ounce Bottle | 38913 |
| Toro 2-Stage Cover | 490-7466 |

**Notes:**

**Notes:**

**Notes:**

TORO®

Count on it.