Form Number 3351-422

Fifth Wheel Hitch Kit

Heavy-Duty Workman® Vehicles

Model No. 44230 - 200000001 and up.

Parts Catalog

Ordering Replacement Parts

To order replacement parts, please supply the part number, the quantity, and the description of each part desired.

Understanding Reference Numbers

Each Identified part in an illustration has a reference number. The reference number for a part also appears in the parts list, along with other information about the part.

This catalog uses two special reference number formats, one to indicate parts in a service assembly and another to indicate the quantity of a given part in an illustration.

Service Assembly Reference Numbers

Parts in service assemblies have reference numbers in the form a:b. The a represents the reference number of the entire service assembly and the b represents a sequential number unique to each part within the service assembly.

For example, a wheel assembly might be identified by reference number 6, the tire by 6:1, the valve by 6:2, and the wheel by 6:3. When you order the assembly identified by reference number 6, you receive all parts identified by reference numbers 6:1, 6:2, and 6:3. However, you may also order any part individually. Reference numbers of this type appear in illustrations and in part lists.

Reference Numbers Indicating Quantity

In an illustration, if a reference number indicates more than one part, the reference number has the form nX y. The n represents the quantity of the part, the X is the multiplication symbol, and the y represents the reference number.

For example, in an illustration, the reference number 2X 37 means that two of the parts identified by reference number 37 are indicated.

©The Toro Company - 2004
All Rights Reserved

Part Description Abbreviations

Part descriptions in this catalog may include the following abbreviations.

AR. . . . . as required
ASM. . . . . assembly
CARR. . . . . carriage
DEG. . . . . degrees
FH. . . . . flat head
GA. . . . . gauge
HF. . . . . hex flange
HH. . . . . hex head
HHF. . . . . hex head flange
HHFTF. . . . . hex head flange thread forming
HJ. . . . . hex jam
HLH. . . . . hex lag head
HOC. . . . . height-of-cut
HS. . . . . hex
HSBH. . . . . hex socket button head
HSFH. . . . . hex socket flat head
HSH. . . . . hex socket head
HWH. . . . . hex washer head
HWHTF. . . . . hex washer head thread forming
HYD. . . . . hydraulic
INC. . . . . incorporated
LH. . . . . left hand
NI. . . . . nylon insert
PPH. . . . . phillips pan head
PTH. . . . . phillips truss head
PTO. . . . . power take off
RH. . . . . right hand
SFH. . . . . slotted fillister head
SHH. . . . . slotted hex head
SHWH. . . . . slotted hex washer head
SPH. . . . . slotted pan head
SQH. . . . . square head
SRH. . . . . slotted round head
STD. . . . . standard
TAP. . . . . self tapping
TTH. . . . . torx truss head
WH. . . . . wing head

Footnotes

❶ Not illustrated

Contents

Description	Page
Fifth Wheel Hitch Assembly	 3



Fifth Wheel Hitch Assembly

Ref	Part No.	Qty.	Description
1	100-9382	1	Access Lid ASM
1:2	75-5190	1	Decal- No Riders
1:3	54-0890	1	Decal-Rotating
1:4	92-4527	1	U - Channel Lid
2	3296-59	2	Nut-Lock, NI
3	3256-4	4	Washer-Flat
4	92-4528	2	Spacer - Lid
5	100-9383	1	Frame ASM
5:2	01-506-1300	1	Decal-Danger
6	325-5	2	Screw-HH
7	3256-26	4	Washer-Flat
8	92-2667-03	2	Bracket-Attachment, Mount
9	3296-25	2	Nut-Lock, NI
12	2412-133	2	R-Clamp
13	74-0720	1	Tube-Manual
14	321-4	2	Screw-HH
15	3253-3	2	Washer-Lock
16	3256-2	2	Washer-Flat
17	3296-51	1	Nut-Lock, NI
18	92-4508-03	1	Washer-Rebound
19	01-286-0740	1	Isolator-Rubber
20	324-6	3	Screw-HH
21	92-4523	1	Spacer - Rebound
22	92-4550	1	Hitch Ball ASM

Ref	Part No.	Qty.	Description
23	324-7	1	Screw-HH
24	3296-48	4	Nut-Lock, NI
25	92-4544	1	Bracket - Wire
26	3217-7	4	Nut-Hex
27	3253-5	4	Washer-Lock
28	323-6	4	Screw-HH
29	92-4509-03	1	Anti-Tip Bar
30	92-1233	2	Pin-Clevis
31	92-1298	4	Pin-Lynch
32	3296-52	4	Nut-Lock NI
33	107-8001	1	Wiring Harness
34	92-4524-03	1	Bracket-Brake Plug
35	92-4541	1	Cap - Wire Plug
36	3290-93	4	Screw-Head, Pan
37	3256-25	1	Washer-Flat
38	3296-2	2	Nut-Lock
39	92-4526-03	1	Spacer-Brake
40	02-266-0910	1	Electric Brake W/plug
41	32105-13	2	Screw-SHH
❶43	218-594	1	Fuse-20 Amp
45	106-7969	1	Coupler-Quick, Male
46	106-7968	1	Coupler-Quick, Female
47	106-1381	2	Fitting-Straight
47:1	237-42	1	O-Ring



ONLY FOR USE ON WORKMAN PRIOR TO SERIAL # 240000001



Fifth Wheel Hitch Assembly (continued)

Ref	Part No.	Qty.	Description
48	92-2672	2	Coupling-HYD

NOTES

NOTES

NOTES


TORO®