
FORM NO. 3316–623

TORO®

MODEL NO. 20439–4900001 & UP

PARTS CATALOG

21" RECYCLER®
Mower




C–1417

HOUSING ASSEMBLY

Ref. No.	Part No.	Description	No. Used
1	71–0561	Spring Arm Ass'y R.H.	1
2	25–7740	Knob – Arm	2
3	92–1720	Plate – Kicker Right Front	1
4	92–1730	Plate – Kicker Left Front	1
5	32144–111	Screw – Plastite	6
6	43–8480	Decal – Danger	1
7		Deflector – Recycler	1
8	46–6810	Screw & Washer Assembly	1
9	14–4069	Recycler Cover Assembly (Incl. Ref. #7 & 39)	1
10	46–6811	Screw & Washer Assembly	3
11	82–8450	Decal – Danger	1
12	92–1750	Plate – Kicker Left Rear	1
13	37–7262	Screw – Hex Hd. Tapping	1
14	2412–87	Clamp – Cable	1
15	3–5792	Washer	1

Ref. No.	Part No.	Description	No. Used
16	32144–112	Screw – Self Tapping	1
17	2412–83	R–Clamp	1
18	32144–70	Screw – Thread Forming Hex Washer Hd.	2
19	82–5680	Bracket – Traction Adj.	1
20	46–7030	Retainer – Cable	1
21	82–9910	Cover – Belt	1
22	62–3720	Clamp – Cable	1
23	33–3208	Rod – Shield	1
24	44–0580	Shield – Trailing	1
25	46–7370	Decal – Step Pad	1
27	66–0560	Screw – Shoulder	2
28	27–6250	Bushing – Wheel	4
29	27–6232	Bolt – Wheel	2
30	14–9989	Wheel & Tire Assembly (Incl Ref. #28)	2

© The TORO Company – 1993
All Rights Reserved




C–1417

HOUSING ASSEMBLY (CONTINUED)

Ref. No.	Part No.	Description	No. Used
31	40–1940	Washer – Wheel Bolt	4
32	66–0580–03	Arm – Pivot	2
33	3296–6	Nut – Lock	4
34	71–0571	Spring Arm Assembly L.H.	1
35	32144–85	Screw – Thread Forming	2
36	92–2281	Decal – Deck	1
37	16–1589	Housing Assembly (Incl. Ref. #3–6, 8, 11, 12, & 42, Pg. 1) (Incl . Ref. #5–6, Pg. 3)	1


Ref. No.	Part No.	Description	No. Used
39		Screw – Plastite	5
40	37–7260	Screw – Special	1
41	91–2253	Cover – Wheel	1
42	92–2279	Decal – H.O.C.	4



C–1332

ENGINE ASSEMBLY

Ref. No.	Part No.	Description	No. Used
1	2210–249	Clamp – Throttle	1
2	2210–313	Screw – Clamp	1
3	77–8991	Engine (Incl. Ref. #4 & 8)	1
4	92–3147	Decal – Recoil	1
5	66–0570	Guide – Belt	1
6	46–6811	Screw – Hex Washer Hd.	2
7	32144–102	Screw – Thread Forming	3
8	92–2289	Plate – Toro	1
9	55–3570	Gas Cap Assembly	1




C–1336

BLADE BRAKE CLUTCH ASSEMBLY

Ref. No.	Part No.	Description	No. Used
1	49–2810	Link – Control	1
2	32104–107	Screw – Self Tap Hex Hd.	1
3	3256–23	Washer – Plain	2
4	49–7960	Bell Crank	1
5	49–7950	Sleeve – Bell Crank	1
6	3257–17	Key – Woodruff	1
7	56–6160	Flywheel	1
8	56–6170	Drum – Brake	1
9	46–5690	Shield	1
10	46–6811	Screw – Thread Forming Hex Washer Hd.	3
11	62–4280	Spacer – Blade	1
12	54–9190	Locknut	2
13	80–2770	Cup – Anti–Scalp	1
14	91–2255	Stiffener – Blade	1
15	3296–33	Locknut	1
16	42–6890	Hub Assembly	1
17	52–3480	Dampener – Vibration	2

Ref. No.	Part No.	Description	No. Used
18	42–3190	Bolt – Blade	2
19	62–7560	Pulley Driver	1
20		Pad – Brake	1
21	3295–23	Rivet – Semi Tubular	2
22	46–5650	Pulley Idler	1
23	14–9419	Blade – 21"	1
24	322–16	Hex Hd. Capscrew	1
25	49–7920	Brake Plate (Incl. Ref. # 20 & 21)	1
26	46–5670	Spring – Torsion Lower	1
27	46–5630	Hub – Idler Pulley	1
28	42–0884	V–Belt	1
29	3296–47	Locknut	1
30	68–9780	Bearing	2
31	70–1160	Washer – P.M.	1
32	49–7970	Spring – Torsion Upper	1
33	32104–96	Screw – Self Tap Hex Hd.	1
34	49–2820	Lever	1




GEAR CASE ASSEMBLY

Ref. No.	Part No.	Description	No. Used
1	65–4750	Pinion	2
2	63–8701–03	Pivot Arm Assembly (Incl. Ref # 19, 20, & 21)	2
3	25–7740	Knob – Arm	2
4	63–8721	Spring Arm Assembly	2
5	42–3520	End Cap	2
7	62–4320	Bracket – Belt Guide	1
8	49–2040	Screw – Self Tapping	8
9	62–6660	Spacer	1
10	60–8840	Pulley – Half	2
11	3296–5	Locknut	1
12	3256–24	Washer – Flat	1
13	62–3900	V–Belt	1
14	3272–10	Pin – Cotter	1
15	82–8780	Cable – Retainer	1
16	32144–70	Screw – Thread Forming	1
17	60–8821	Lever – Shift	1
18	65–4770	Shaft – Output	1
19	70–9760	Bushing	2
20	302–56	Fitting – Grease	2
21	48–2060	Needle Bearing	2
22	65–4730	Thrust Washer	2
23	65–4740	Thrust Washer	4
24	65–2720	Ring – Retaining	4
25	65–4710	Ring – Friction	2

Ref. No.	Part No.	Description	No. Used
26	65–4760	Washer – Clutch	2
27	66–6050	Key – Rocker L.H.	1
*	66–6040	Key – Rocker R.H.	1
28	65–4720	Spring	2
29	74–1660	Cover – Wheel	2
30	16–0029	Wheel – Tire & Gear Ass'y (Incl. Ref. # 31)	2
31	27–6250	Bushing – Wheel	4
32	27–6232	Wheel Bolt	2
33	74–1670	Spacer – Wheel Cover	2
34	3296–6	Locknut	2
35	32144–85	Screw	2
36	60–8870	Yoke – Shift	1
37	29–9570	Bushing – Yoke	1
38	60–8810	Retainer – Shift Fork	1
39	76–0780	Sleeve – Shift Key	1
40	76–0760	Key – Shift	2
41	76–0770	Collar – Shift	1
42	36–4780	Washer – Thrust	1
43	60–8770	Bushing – Output Shaft	1
44	60–8730	Cover – Gear Case	1
45	60–8750	Bushing – Int. Shaft	2
46	36–4791	Washer – Thrust	2
47	55–3760	Gear – Pinion 15 Tooth	1
48	55–3780	Gear – Pinion 20 Tooth	1

*Not Illustrated

3316–623




GEAR CASE ASSEMBLY (CONTINUED)

Ref. No.	Part No.	Description	No. Used
49	55–3800	Gear – Pinion	1
50	60–8800	Shaft – Intermediate	1
51	60–8850	Bushing – Output Shaft	1
52	32121–120	Pin – Coil	1
53	60–8790	Sleeve – Gear	1
54	55–3810	Gear – 39 Tooth 3rd Gear	1
55	55–3790	Gear – 44 Tooth 2nd Gear	1

Ref. No.	Part No.	Description	No. Used
56	55–3770	Gear – 49 Tooth 1st Gear	1
57	60–8890	Pinion – Bevel	1
58	38–7820	Bearing – Ball	1
59	60–8710	Gear Case – Upper	1
60	237–153	O–Ring	2
61	65–5250	Clip – Spring	1
*	62–6673	Gear Case Assembly	1

*Not Illustrated




HANDLE ASSEMBLY

Ref. No.	Part No.	Description	No. Used
1	82–5531	Handle – Lower	1
2	76–2712	Control – Ground Speed	
3	92–2277	Handle – Upper	1
4	63–9060	Decal – Danger	1
5	92–8657	Decal – Instructions	1
6	16–1659	Panel – Control (Incl. Ref. #4, 5, & 31)	1
7	46–5780	Switch – Starter	1
8	63–8360	Key – Ignition	1
9	218–461	Nut – Hex	1
10	3254–5	Washer – Lock	1
11	71–8391	Control – Throttle (Bend Type #5) (Sheath Lg. 62 3/4") (Wire Lg. 2 1/16")	1
12	2412–50	Clip – Convoluted Tubing	3
13	46–6440	Cover – Control Cables	1
14	3290–378	Tie – Cable	5

Ref. No.	Part No.	Description	No. Used
15	92–1743	Charger – Battery	1
16	84–8361	Latch – Handle L.H.	1
17	27–7211	Screw – Shoulder	2
18	27–7210	Screw – Shoulder	2
19	3–3287	Spacer – Handle Latch	2
20	3296–72	Nut – Lock	3
21	3296–47	Nut – Lock	3
†22	49–2750	Pin – Handle	2
23	55–7520	Battery Assembly	1
25	55–8180	Retainer – Battery	1
26	80–4790	Harness – Wire	1
27	32144–115	Screw – Self Tap Slotted	4
28	92–2260	Screw – Handle	2
29	19–4050	Knob – Handle Release	2
30	84–8401	Latch – Handle R.H.	1
31	92–3146	Decal – Front Panel	1
32	92–4086	Grip – Foam	1
33	92–1709	Decal – Charger	1

†Service Replacement Part




C–1429

TRACTION CONTROL ASSEMBLY

Ref. No.	Part No.	Description	No. Used
1	46–7040	Screw – Thread Forming Hex Washer Hd.	3
2	12–3429	Housing – Control R.H. (Incl Ref. # 4 & 5)	1
3	52–7430	Control Bar Assembly	1
4	52–7410	Spring – Leaf	1
5	57–6290	Pin – Insert	1
6	46–5530	Hook – Control	1
7	46–5510	Spring – Torsion	1
8	46–5550	Bushing – P.M.	1
9	32121–9	Pin – Coil	1
10	46–5460	Housing – Control L.H.	1
11	92–2261	Screw – Handle	1

Ref. No.	Part No.	Description	No. Used
12	92–2267	Screw – Handle	1
13	46–5590	Spacer	1
14	46–5520	Lever – Traction	1
15	66–0180	Rocker	1
16	46–5480	Cable – Traction	1
17	83–6600	Cable – Clutch	1
18	46–5540	Lever – Cable	1
19	66–0170	Washer – Nylon	1
20	66–0190	Spring – Detent	1
21	3296–75	Locknut	1
22	3296–74	Locknut	2
23	49–1630	Support – Spacer	1
24	92–2260	Screw – Handle	1




Assemblies include all parts shown in frames.

ENGINE GTS–150

Ref. No.	Part No.	Description	No. Used
3	77–9060	Seal – Oil	1
7	77–7740	Gasket – Cylinder Head	1
9	77–7440	Gasket – Valve Cover	1
9A	77–7410	Gasket – Breather	1
12	77–7550	Gasket – Engine Base	1
20	77–7570	Seal – Oil	1
116A	77–7660	Seal – O Ring	1
163	77–7960	Gasket – Air Cleaner	1
358	77–8900	Gasket Set	1

Ref. No.	Part No.	Description	No. Used
524	77–7270	Seal – Intake Elbow	1
842	77–7300	Seal – O Ring	1
868	77–7890	Seal Assy. – Valve	1
868A	77–7900	Gasket – Valve	1
883	77–7760	Gasket – Exhaust	1
1022	77–7320	Gasket – Rocker Cover	1
1041	77–8590	Seal – Foam	1
		GTS150 Key/BBC Engine	1
	77–9000	High Altitude Jet	1

ENGINE GTS–150




ENGINE GTS–150

Ref. No.	Part No.	Description	No. Used
1	77–7590	Cylinder Assy.	1
*3	77–9060	Seal – Oil	1
5	77–7730	Head – Cylinder	1
*7	77–7740	Gasket – Cylinder Head	1
8	77–7430	Breather Valve	1
*9	77–7440	Gasket – Valve Cover	1
*9A	77–7410	Gasket – Breather	1
10	77–7360	Screw – Hex. Head (valve cover)	4
11	77–7350	Tube – Breather	1
*12	77–7550	Gasket – Engine Base	1
13	77–7630	Screw – Cylinder Head	4
15	77–7580	Plug – Oil Drain	1
16	77–7510	Crankshaft Note: Order Part No. 77–7540 For Timing Gear Key	1
18	77–7560	Base – Engine	1
*20	77–7570	Seal – Oil	1
22	77–9070	Screw – Engine Base Note: Order Part No. 77–9080 For Hole Nearest Breather	1
25	77–7690	Piston Assy. (Std.)	1
26	77–7700	Ring Set (Std.)	1
27	77–7710	Lock – Piston Pin	2
28	77–7720	Pin – Piston (STD)	1
29	77–7670	Rod – Connecting	1
32	77–7680	Screw – Connecting Rod	2
33	77–7860	Valve – Exhaust	1
34	77–7880	Valve – Intake	1
35	77–7810	Spring – Valve	2
40	77–7870	Retainer – Spring	2
45	77–7610	Tappet – Valve	2
46	77–7490	Gear – Cam	1
*116A	77–7660	Seal – O Ring	1
†122	77–7820	Adapter Assy.	1
166	77–7780	Stud – Rocker Arm	2
188	77–7450	Screw – Sem (Breather Mounting, pump cover)	5

Ref. No.	Part No.	Description	No. Used
192	77–7910	Nut – Hex Special	2
192A	77–9090	Screw – Set	1
219	77–7500	Gear – Governor	1
227	77–7370	Lever – Governor	1
230	77–7470	Washer – Thrust	1
238	77–7800	Cap – Valve	2
305	77–8310	Screw – Hex. Head	2
307	77–7420	Screw – Sem (Breather Cover)	4
337	77–7330	Plug – Spark	1
523	77–7260	Dipstick – Oil	1
*524	77–7270	Seal – Intake Elbow	1
525	77–7290	Tube – Oil Filler	1
562	77–7380	Bolt – Governor Lever	1
572	77–7400	Baffle – Cylinder	1
592	77–7390	Nut – Hex.	1
615	77–7480	Fastener	1
616	77–7460	Crank – Governor	1
635	77–7340	Elbow – Spark Plug	1
718	77–7600	Dowel – Sleeve	2
741	77–7530	Gear – Timing	1
*842	77–7300	Seal – O Ring	1
*868	77–7890	Seal Assy. – Valve	1
*868A	77–7900	Gasket – Valve	1
*883	77–7760	Gasket – Exhaust	1
979	77–7650	Cover – Oil Pump	1
*1022	77–7320	Gasket – Rocker Cover	1
1023	77–7060	Cover – Valve	1
1024	77–7640	Pump – Oil	1
1026	77–7620	Rod – Push	2
1029	77–7790	Arm – VLV Rocker	2
1034	77–7770	Guide – Push Rod	1
	77–9280	Short Block (Incl. Ref. #1, 7, 9, 9A,, 16,18, 25, 28, 29, 45, 46, 122, 219, 230, 615, 616, 883, 979, 1022, & 1024 pg. 10) (Incl. Ref. #163 pg.12)	1

*Included in Gasket Set
†Included in Carburetor Overhaul Kit

ENGINE GTS–150



Assemblies include all parts shown in frames.


ENGINE GTS–150

Ref. No.	Part No.	Description	No. Used
95	77–8090	Screw – Round Head	1
98	77–8240	Screw – Idle Adj.	1
98A	77–8020	Screw Assy – Speed Adj.	1
†104	77–8180	Pin – Float Hinge	1
108	77–8070	Valve – Choke	1
†116	77–8210	Washer – Fuel Bowl	1
†117	77–8060	Jet – Needle Valve	1
†118	77–8230	Valve & Kit – Needle	1
†122	77–7820	Adapter Assy.	1
124	77–7970	Screw – Hex Head (Carburetor Mounting)	2
125	77–8050	Carburetor Assy.	1
†127	77–8100	Plug – Welch	1
130	77–8080	Valve – Throttle	1
131	77–8160	Shaft – Throttle	1
133	77–8170	Float – Carburetor	1
†134	77–8110	Valve – Float (Includes Seat)	1
136	77–7240	Bowl – Fuel	1
†137	77–8200	Gasket – Fuel Bowl	1
141	77–8130	Shaft – Choke	1
147	77–8120	Adapter – Jet Note: For High Altitude Jet, Order Part No. 77–9000	1

Ref. No.	Part No.	Description	No. Used
*163	77–7960	Gasket – Air Cleaner	1
188	77–7450	Screw – Hex. Head (connecting bracket)	2
201	77–7980	Link – Governor	1
209	77–7990	Spring – Governor	1
529	77–8030	Tube – Breather	1
535	77–7950	Element – Filter Note: 77–9010 – Element Paper (Optional)	1
618	77–8140	Spring – Return	1
620	77–8000	Bracket – Carburetor	1
621	77–8010	Switch – Stop	1
†634	77–8150	Washer – Seal	2
955	77–8220	Screw – Hex. Head	1
966	77–7940	Base Air Cleaner	1
968	77–7040	Cover – Air Cover	1
969	77–7920	Screw – Air Cleaner	1
971	77–7930	Screw – Air Cleaner	3
975	77–8190	Bowl Assy. – Carburetor	1
1011	77–8040	Tube – Vent	1
†1039	77–7250	Limiter – Float	1

*Included in Gasket Set
†Included in Carburetor Overhaul Kit

ENGINE GTS–150




Assemblies include all parts shown in frames.

ENGINE GTS–150

Ref. No.	Part No.	Description	No. Used
23	77–8320	Flywheel – Magneto	1
24	77–8340	Key – Flywheel	1
55	77–8460	Housing – Rewind Starter	1
56	77–8560	Pulley – Rewind Starter	1
58	77–8480	Spool – Starter Rope (Cut To Suit)	1
59	77–7210	Insert – Starter Grip	1
60	77–8510	Grip – Starter Rope	1
65	77–8300	Screw – Hex. Head	4
188	77–7450	Screw – Hex. Head (Blower bracket)	2
265	77–8280	Clamp – Casing	1
267	77–8290	Screw – Hex Head	1
304	77–8250	Housing – Blower	1
305	77–8310	Screw – Hex. Head (Blower Housing)	4
305A	77–8390	Stud – Mtg.	2

Ref. No.	Part No.	Description	No. Used
332	77–8360	Nut – Hexagon	1
333	77–8420	Armature – Magneto	1
334	77–8440	Screw – Sem	2
356	77–8400	Wire – Ground	1
455	77–8350	Cup – Starter	1
456	77–8470	Retainer – Spring	1
459	77–8530	Pawl & spring – Ratchet	2
461	77–8490	Screw – Rewind Starter	1
474	77–8370	Alternator	1
482	77–8380	Screw – Sem	2
515	77–8500	Spring – Retainer	1
608	77–8450	Starter Assy. – Rewind	1
718A	77–8550	Dowel – Sleeve	1
851	77–8430	Terminal – Spark Plug	1
980	77–7140	Bracket – Blower Housing	1
1002	77–7180	Grommet	1
1016	77–8570	Cover – Pulley	1

ENGINE GTS–150





Assemblies include all parts shown in frames.

ENGINE GTS–150

Ref. No.	Part No.	Description	No. Used
22A	77–8720	Screw – Carb. Mtg.	2
74	77–8800	Screw – Sem	3
180	77–8580	Tank Assy. – Fuel	1
182	77–7170	Bracket – Fuel Tank	1
187	77–8620	Hose – Fuel (Cut To Suit)	1
188	77–7450	Screw – Hex. Head (Muffler guard, muffler manifold to head, connecting bracket, Tk bracket)	7
300	77–8640	Muffler – Exhaust	1
309	77–8670	Motor Starter	1
310	77–8710	Bolt – Thru	2
346	77–8650	Screw – Self Tap (Muffler Guard)	2
346A	77–9050	Screw – Arrester Mtg.	1
510	77–8910	Drive – Starter	1
513	77–8770	Clutch – Starter	1
544	77–8730	Armature Starter	1
548	77–8740	Washer – Starter	1
601	77–8630	Clamp – CL Pipe	2
670	77–9030	Spacer – Fuel Tank (Incl. 2)	1
674	77–8600	Screw – Tank Mtg.	2
782	77–8810	Gear – Starter	1
783	77–8760	Gear – Pinion	1
784	77–8780	Cover – Gear	1
785	77–8790	Gasket – Gear Cover	1
801	77–8680	Cap – Drive	1
802	77–8690	Cap – End	1
803	77–8700	Housing – Starter	1
832	77–8660	Guard – Muffler	1
*883	77–7760	Gasket – Exhaust	1
925	77–7200	Cover – Starter	1
937	77–8820	Drive – Starter	1
938	77–8830	Retainer – Lock	1
994	77–9040	Arrester – Spark	1
*1041	77–8590	Seal – Foam	1

*Included in Gasket Set





Assemblies include all parts shown in frames.

ENGINE GTS–150

Ref. No.	Part No.	Description	No. Used
104	77–8180	Pin – Float Hinge	1
116	77–8210	Washer – Fuel Bowl	1
117	77–8060	Jet – Needle Valve	1
118	77–8230	Valve & Kit – Needle	1
121	77–8920	Overhaul Kit – Carburetor	1
122	77–7820	Adapter Assy.	1
127	77–8100	Plug – Welch	1

Ref. No.	Part No.	Description	No. Used
134	77–8110	Valve – Float (Includes Seat)	1
137	77–8200	Gasket – Fuel Bowl	1
634	77–8150	Washer – Seal	2
977	77–8930	Gasket Set – Carburetor	1
1039	77–7250	Limiter – Float	1

TORO PART NUMBER INDEX

3–3287	Spacer – Handle Latch	7	19	2
3–5792	Washer	1	15	1
12–3429	Housing – Control R.H.	8	2	1
14–4069	Recycler Cover Assembly	1	9	1
14–9419	Blade – 21	4	23	1
14–9989	Wheel & Tire Assembly	1	30	2
16–0029	Wheel – Tire & Gear Ass'y	5	30	2
16–1589	Housing Assembly	2	37	1
16–1659	Panel – Control	7	6	1
19–4050	Knob – Handle Release	7	29	2
25–7740	Knob – Arm	1	2	2
25–7740	Knob – Arm	5	3	2
27–6232	Bolt – Wheel	1	29	2
27–6232	Wheel Bolt	5	32	2
27–6250	Bushing – Wheel	1	28	4
27–6250	Bushing – Wheel	5	31	4
27–7210	Screw – Shoulder	7	18	2
27–7211	Screw – Shoulder	7	17	2
29–9570	Bushing – Yoke	5	37	1
33–3208	Rod – Shield	1	23	1
36–4780	Washer – Thrust	5	42	1
36–4791	Washer – Thrust	5	46	2
37–7260	Screw – Special	2	40	1
37–7262	Screw – Hex Hd. Tapping	1	13	1
38–7820	Bearing – Ball	6	58	1
40–1940	Washer – Wheel Bolt	2	31	4
42–0884	V–Belt	4	28	1
42–3190	Bolt – Blade	4	18	2
42–3520	End Cap	5	5	2
42–6890	Hub Assembly	4	16	1
43–8480	Decal – Danger	1	6	1
44–0580	Shield – Trailing	1	24	1
46–5460	Housing – Control L.H.	8	10	1
46–5480	Cable – Traction	8	16	1
46–5510	Spring – Torsion	8	7	1
46–5520	Lever – Traction	8	14	1
46–5530	Hook – Control	8	6	1
46–5540	Lever – Cable	8	18	1
46–5550	Bushing – P.M.	8	8	1
46–5590	Spacer	8	13	1
46–5630	Hub – Idler Pulley	4	27	1
46–5650	Pulley Idler	4	22	1
46–5670	Spring – Torsion Lower	4	26	1
46–5690	Shield	4	9	1
46–5780	Switch – Starter	7	7	1
46–6440	Cover – Control Cables	7	13	1
46–6810	Screw & Washer Assembly	1	8	1
46–6811	Screw & Washer Assembly	1	10	3
46–6811	Screw – Hex Washer Hd.	3	6	2
46–6811	Screw – Thread Forming	4	10	3
46–7030	Retainer – Cable	1	20	1
46–7040	Screw – Thread Forming	8	1	3
46–7370	Decal – Step Pad	1	25	1
48–2060	Needle Bearing	5	21	2
49–1630	Support – Spacer	8	23	1
49–2040	Screw – Self Tapping	5	8	8
49–2750	Pin – Handle	7	22	2
49–2810	Link – Control	4	1	1
49–2820	Lever	4	34	1
49–7920	Brake Plate	4	25	1
49–7950	Sleeve – Bell Crank	4	5	1
49–7960	Bell Crank	4	4	1
49–7970	Spring – Torsion Upper	4	32	1
52–3480	Dampener – Vibration	4	17	2
52–7410	Spring – Leaf	8	4	1
52–7430	Control Bar Assembly	8	3	1
54–9190	Locknut	4	12	2
55–3570	Gas Cap Assembly	3	9	1
55–3760	Gear – Pinion 15 Tooth	5	47	1
55–3770	Gear – 49 Tooth 1st Gear	6	56	1
55–3780	Gear – Pinion 20 Tooth	5	48	1
55–3790	Gear – 44 Tooth 2nd Gear	6	55	1
55–3800	Gear – Pinion	6	49	1
55–3810	Gear – 39 Tooth 3rd Gear	6	54	1
55–7520	Battery Assembly	7	23	1
55–8180	Retainer – Battery	7	25	1
56–6160	Flywheel	4	7	1
56–6170	Drum – Brake	4	8	1
57–6290	Pin – Insert	8	5	1
60–8710	Gear Case – Upper	6	59	1
60–8730	Cover – Gear Case	5	44	1
60–8750	Bushing – Int. Shaft	5	45	2
60–8770	Bushing – Output Shaft	5	43	1
60–8790	Sleeve – Gear	6	53	1
60–8800	Shaft – Intermediate	6	50	1
60–8810	Retainer – Shift Fork	5	38	1
60–8821	Lever – Shift	5	17	1
60–8840	Pulley – Half	5	10	2
60–8850	Bushing – Output Shaft	6	51	1
60–8870	Yoke – Shift	5	36	1
60–8890	Pinion – Bevel	6	57	1
62–3720	Clamp – Cable	1	22	1
62–3900	V–Belt	5	13	1
62–4280	Spacer – Blade	4	11	1
62–4320	Bracket – Belt Guide	5	7	1
62–6660	Spacer	5	9	1
62–6673	Gear Case Assembly	6	*	1
62–7560	Pulley Driver	4	19	1
63–8360	Key – Ignition	7	8	1
63–8701	Pivot Arm Assembly	5	2	2
63–8721	Spring Arm Assembly	5	4	2
63–9060	Decal – Danger	7	4	1
65–2720	Ring – Retaining	5	24	4
65–4710	Ring – Friction	5	25	2
65–4720	Spring	5	28	2
65–4730	Thrust Washer	5	22	2
65–4740	Thrust Washer	5	23	4
65–4750	Pinion	5	1	2
65–4760	Washer – Clutch	5	26	2
65–4770	Shaft – Output	5	18	1
65–5250	Clip – Spring	6	61	1
66–0170	Washer – Nylon	8	19	1
66–0180	Rocker	8	15	1
66–0190	Spring – Detent	8	20	1
66–0560	Screw – Shoulder	1	27	2
66–0570	Guide – Belt	3	5	1
66–0580–03	Arm – Pivot	2	32	2
66–6040	Key – Rocker R.H.	5	*	1
66–6050	Key – Rocker L.H.	5	27	1
68–9780	Bearing	4	30	2
70–1160	Washer – P.M.	4	31	1
70–9760	Bushing	5	19	2
71–0561	Spring Arm Ass'y R.H.	1	1	1
71–0571	Spring Arm Assembly L.H.	2	34	1
71–8391	Control – Throttle	7	11	1
74–1660	Cover – Wheel	5	29	2
74–1670	Spacer – Wheel Cover	5	33	2
76–0760	Key – Shift	5	40	2
76–0770	Collar – Shift	5	41	1
76–0780	Sleeve – Shift Key	5	39	1
76–2712	Control – Ground Speed	7	2	
77–7040	Cover – Air Cover	13	968	1
77–7060	Cover – Valve	11	1023	1
77–7140	Bracket – Blower Housing	15	980	1
77–7170	Bracket – Fuel Tank	17	182	1
77–7180	Grommet	15	1002	1
77–7200	Cover – Starter	17	925	1
77–7210	Insert – Starter Grip	15	59	1
77–7240	Bowl – Fuel	13	136	1
77–7250	Limiter – Float	13	1039	1
77–7250	Limiter – Float	18	1039	1
77–7260	Dipstick – Oil	11	523	1
77–7270	Seal – Intake Elbow	9	524	1
77–7270	Seal – Intake Elbow	11	*524	1

*Not Illustrated

TORO PART NUMBER INDEX (Cont.)

Part No.	Description	Pg. No.	Ref. No.	Qty.
77–7290	Tube – Oil Filler	11	525	1
77–7300	Seal – O Ring	11	*842	1
77–7300	Seal – O Ring	9	842	1
77–7320	Gasket – Rocker Cover	11	*1022	1
77–7320	Gasket – Rocker Cover	9	1022	1
77–7330	Plug – Spark	11	337	1
77–7340	Elbow – Spark Plug	11	635	1
77–7350	Tube – Breather	11	11	1
77–7360	Screw – Hex. Head	11	10	4
77–7370	Lever – Governor	11	227	1
77–7380	Bolt – Governor Lever	11	562	1
77–7390	Nut – Hex.	11	592	1
77–7400	Baffle – Cylinder	11	572	1
77–7410	Gasket – Breather	11	*9A	1
77–7410	Gasket – Breather	9	9A	1
77–7420	Screw – Sem	11	307	4
77–7430	Breather Valve	11	8	1
77–7440	Gasket – Valve Cover	11	*9	1
77–7440	Gasket – Valve Cover	9	9	1
77–7450	Screw – Hex. Head	13	188	2
77–7450	Screw – Hex. Head	15	188	2
77–7450	Screw – Hex. Head	17	188	7
77–7450	Screw – Sem	11	188	5
77–7460	Crank – Governor	11	616	1
77–7470	Washer – Thrust	11	230	1
77–7480	Fastener	11	615	1
77–7490	Gear – Cam	11	46	1
77–7500	Gear – Governor	11	219	1
77–7510	Crankshaft	11	16	1
77–7530	Gear – Timing	11	741	1
77–7550	Gasket – Engine Base	11	*12	1
77–7550	Gasket – Engine Base	9	12	1
77–7560	Base – Engine	11	18	1
77–7570	Seal – Oil	11	*20	1
77–7570	Seal – Oil	9	20	1
77–7580	Plug – Oil Drain	11	15	1
77–7590	Cylinder Assy.	11	1	1
77–7600	Dowel – Sleeve	11	718	2
77–7610	Tappet – Valve	11	45	2
77–7620	Rod – Push	11	1026	2
77–7630	Screw – Cylinder Head	11	13	4
77–7640	Pump – Oil	11	1024	1
77–7650	Cover – Oil Pump	11	979	1
77–7660	Seal – O Ring	9	116A	1
77–7660	Seal – O Ring	11	*116A	1
77–7670	Rod – Connecting	11	29	1
77–7680	Screw – Connecting Rod	11	32	2
77–7690	Piston Assy. (Std.)	11	25	1
77–7700	Ring Set (Std.)	11	26	1
77–7710	Lock – Piston Pin	11	27	2
77–7720	Pin – Piston (STD)	11	28	1
77–7730	Head – Cylinder	11	5	1
77–7740	Gasket – Cylinder Head	11	*7	1
77–7740	Gasket – Cylinder Head	9	7	1
77–7760	Gasket – Exhaust	11	*883	1
77–7760	Gasket – Exhaust	17	*883	1
77–7760	Gasket – Exhaust	9	883	1
77–7770	Guide – Push Rod	11	1034	1
77–7780	Stud – Rocker Arm	11	166	2
77–7790	Arm – VLV Rocker	11	1029	2
77–7800	Cap – Valve	11	238	2
77–7810	Spring – Valve	11	35	2
77–7820	Adapter Assy.	11	122	1
77–7820	Adapter Assy.	13	122	1
77–7820	Adapter Assy	18	122	1
77–7860	Valve – Exhaust	11	33	1
77–7870	Retainer – Spring	11	40	2
77–7880	Valve – Intake	11	34	1
77–7890	Seal Assy. – Valve	11	*868	1
77–7890	Seal Assy. – Valve	9	868	1
77–7900	Gasket – Valve	11	*868A	1
77–7900	Gasket – Valve	9	868A	1
77–7910	Nut – Hex Special	11	192	2
77–7920	Screw – Air Cleaner	13	969	1
77–7930	Screw – Air Cleaner	13	971	3
77–7940	Base Air Cleaner	13	966	1
77–7950	Element – Filter	13	535	1
77–7960	Gasket – Air Cleaner	13	*163	1
77–7960	Gasket – Air Cleaner	9	163	1
77–7970	Screw – Hex Head	13	124	2
77–7980	Link – Governor	13	201	1
77–7990	Spring – Governor	13	209	1
77–8000	Bracket – Carburetor	13	620	1
77–8010	Switch – Stop	13	621	1
77–8020	Screw Assy – Speed Adj.	13	98A	1
77–8030	Tube – Breather	13	529	1
77–8040	Tube – Vent	13	1011	1
77–8050	Carburetor Assy.	13	125	1
77–8060	Jet – Needle Valve	13	117	1
77–8060	Jet – Needle Valve	18	117	1
77–8070	Valve – Choke	13	108	1
77–8080	Valve – Throttle	13	130	1
77–8090	Screw – Round Head	13	95	1
77–8100	Plug – Welch	13	127	1
77–8100	Plug – Welch	18	127	1
77–8110	Valve – Float	13	134	1
77–8110	Valve – Float	18	134	1
77–8120	Adapter – Jet	13	147	1
77–8130	Shaft – Choke	13	141	1
77–8140	Spring – Return	13	618	1
77–8150	Washer – Seal	13	634	2
77–8150	Washer – Seal	18	634	2
77–8160	Shaft – Throttle	13	131	1
77–8170	Float – Carburetor	13	133	1
77–8180	Pin – Float Hinge	13	104	1
77–8180	Pin – Float Hinge	18	104	1
77–8190	Bowl Assy. – Carburetor	13	975	1
77–8200	Gasket – Fuel Bowl	13	137	1
77–8210	Washer – Fuel Bowl	13	116	1
77–8210	Washer – Fuel Bowl	18	116	1
77–8220	Screw – Hex. Head	13	955	1
77–8230	Valve & Kit – Needle	13	118	1
77–8230	Valve & Kit – Needle	18	118	1
77–8240	Screw – Idle Adj.	13	98	1
77–8250	Housing – Blower	15	304	1
77–8280	Clamp – Casing	15	265	1
77–8290	Screw – Hex Head	15	267	1
77–8300	Screw – Hex. Head	15	65	4
77–8310	Screw – Hex. Head	11	305	2
77–8310	Screw – Hex. Head	15	305	4
77–8320	Flywheel – Magneto	15	23	1
77–8340	Key – Flywheel	15	24	1
77–8350	Cup – Starter	15	455	1
77–8360	Nut – Hexagon	15	332	1
77–8370	Alternator	15	474	1
77–8380	Screw – Sem	15	482	2
77–8390	Stud – Mtg.	15	305A	2
77–8400	Wire – Ground	15	356	1
77–8420	Armature – Magneto	15	333	1
77–8430	Terminal – Spark Plug	15	851	1
77–8440	Screw – Sem	15	334	2
77–8450	Starter Assy. – Rewind	15	608	1
77–8460	Housing – Rewind Starter	15	55	1
77–8470	Retainer – Spring	15	456	1
77–8480	Spool – Starter Rope	15	58	1
77–8490	Screw – Rewind Starter	15	461	1
77–8500	Spring – Retainer	15	515	1
77–8510	Grip – Starter Rope	15	60	1
77–8530	Pawl & spring – Ratchet	15	459	2
77–8550	Dowel – Sleeve	15	718A	1
77–8560	Pulley – Rewind Starter	15	56	1
77–8570	Cover – Pulley	15	1016	1
77–8580	Tank Assy. – Fuel	17	180	1
77–8590	Seal – Foam	17	*1041	1

*Not Illustrated

TORO PART NUMBER INDEX (Cont.)

Part No.	Description	Pg. No.	Ref. No.	Qty.
77–8600	Screw – Tank Mtg.	17	674	2
77–8620	Hose – Fuel	17	187	1
77–8630	Clamp – CL Pipe	17	601	2
77–8640	Muffler – Exhaust	17	300	1
77–8650	Screw – Self Tap	17	346	2
77–8660	Guard – Muffler	17	832	1
77–8670	Motor Starter	17	309	1
77–8680	Cap – Drive	17	801	1
77–8690	Cap – End	17	802	1
77–8700	Housing – Starter	17	803	1
77–8710	Bolt – Thru	17	310	2
77–8720	Screw – Carb. Mtg.	17	22A	2
77–8730	Armature Starter	17	544	1
77–8740	Washer – Starter	17	548	1
77–8760	Gear – Pinion	17	783	1
77–8770	Clutch – Starter	17	513	1
77–8780	Cover – Gear	17	784	1
77–8790	Gasket – Gear Cover	17	785	1
77–8800	Screw – Sem	17	74	3
77–8810	Gear – Starter	17	782	1
77–8820	Drive – Starter	17	937	1
77–8830	Retainer – Lock	17	938	1
77–8900	Gasket Set	9	358	1
77–8910	Drive – Starter	17	510	1
77–8920	Overhaul Kit – Carburetor	18	121	1
77–8930	Gasket Set – Carburetor	18	977	1
77–8991	Engine	3	3	1
77–9000	High Altitude Jet	9		1
77–9030	Spacer – Fuel Tank	17	670	1
77–9040	Arrester – Spark	17	994	1
77–9050	Screw – Arrester Mtg.	17	346A	1
77–9060	Seal – Oil	11	*3	1
77–9060	Seal – Oil	9	3	1
77–9070	Screw – Engine Base	11	22	1
77–9090	Screw – Set	11	192A	1
77–9290	Short Block	11		1
80–2770	Cup – Anti–Scalp	4	13	1
80–4790	Harness – Wire	7	26	1
82–5531–05	Handle – Lower	7	1	1
82–5680	Bracket – Traction Adj.	1	19	1
82–8450	Decal – Danger	1	11	1
82–8780	Cable – Retainer	5	15	1
82–9910	Cover – Belt	1	21	1
83–6600	Cable – Clutch	8	17	1
84–8361	Latch – Handle L.H.	7	16	1
84–8401	Latch – Handle R.H.	7	30	1
91–2253	Cover – Wheel	2	41	1
91–2255	Stiffener – Blade	4	14	1
92–1709	Decal – Charger	7	33	1
92–1720	Plate – Kicker Right Front	1	3	1
92–1730	Plate – Kicker Left Front	1	4	1
92–1743	Charger – Battery	7	15	1
92–1750	Plate – Kicker Left Rear	1	12	1
92–2260	Screw – Handle	8	24	1
92–2260	Screw – Handle	7	28	2
92–2260	Screw – Handle	8	24	1
92–2261	Screw – Handle	8	11	1

Part No.	Description	Pg. No.	Ref. No.	Qty.
92–2267	Screw – Handle	8	12	1
92–2277	Handle – Upper	7	3	1
92–2279	Decal – H.O.C.	2	42	4
92–2281	Decal – Deck	2	36	1
92–2289	Plate – Toro	3	8	1
92–3146	Decal – Front Panel	7	31	1
92–3147	Decal – Recoil	3	4	1
92–4086	Grip – Foam	7	32	1
92–8657	Decal – Instructions	7	5	1
218–461	Nut – Hex	7	9	1
2210–249	Clamp – Throttle	3	1	1
2210–313	Screw – Clamp	3	2	1
237–153	O–Ring	6	60	2
2412–50	Clip – Convoluted Tubing	7	12	3
2412–83	R–Clamp	1	17	1
2412–87	Clamp – Cable	1	14	1
302–56	Fitting – Grease	5	20	2
322–16	Hex Hd. Capscrew	4	24	1
3254–5	Washer – Lock	7	10	1
3256–23	Washer – Plain	4	3	2
3256–24	Washer – Flat	5	12	1
3257–17	Key – Woodruff	4	6	1
3272–10	Pin – Cotter	5	14	1
3290–378	Tie – Cable	7	14	5
3295–23	Rivet – Semi Tubular	4	21	2
3296–5	Locknut	5	11	1
3296–6	Locknut	5	34	2
3296–6	Nut – Lock	2	33	4
3296–33	Locknut	4	15	1
3296–47	Locknut	4	29	1
3296–47	Nut – Lock	7	21	3
3296–72	Nut – Lock	7	20	3
3296–75	Locknut	8	21	1
3296–74	Locknut	8	22	2
32104–96	Screw – Self Tap Hex Hd.	4	33	1
32104–107	Screw – Self Tap Hex Hd.	4	2	1
32121–9	Pin – Coil	8	9	1
32121–120	Pin – Coil	6	52	1
32144–70	Screw – Thread Forming	5	16	1
32144–70	Screw – Thread Forming	1	18	2
32144–85	Screw	5	35	2
32144–85	Screw – Thread Forming	2	35	2
32144–102	Screw – Thread Forming	3	7	3
32144–111	Screw – Plastite	1	5	6
32144–112	Screw – Self Tapping	1	16	1
32144–115	Screw – Self Tap Slotted	7	27	4

OPTIONAL EQUIPMENT

Recycler Side Discharge Kit .... Model No. 59189
Wear Plate Kit ..... Part No. 49–4080
Recycler Bagging Kit ..... Model No. 59174
Dethatcher Kit ..... Model No. 59131

*Not Illustrated

PRODUCT CHANGES

In an effort to make improvements available to TORO owners as quickly as possible, minor changes are incorporated into Toro's products from time to time that do not become immediately shown in the Parts Catalog. If such a change has been made in your unit, which is not reflected in your manual, see your TORO Distributor or his Authorized TORO Service Dealer for information and part numbers.

COUNTRIES OTHER THAN THE UNITED STATES OR CANADA

Customers who have purchased TORO products exported from the United States or Canada should contact their Toro Distributor (Dealer) to obtain guarantee policies for your country, province or state. If for any reason you are dissatisfied with your Distributor's service or have difficulty obtaining guarantee information, contact the TORO importer. If all other remedies fail, you may contact us at The Toro Company.

MAINTENANCE RECORD

Date								

Compliance with Radio Interference Regulations Certified.
Certifie Conforme au Reglement sur le Brouillage Radioelectrique.

Litho in U.S.A.

MAINTENANCE RECORD

Date								

MAINTENANCE RECORD

Date								