



Count on it.

## OSMAC® RDR Door Lock Kit, 102-3218 Installation Instructions

1. Insert key and turn the lock tumbler clockwise 90° to the open position as shown. The flat portion of the threaded barrel is aligned with the catch plate and the key cannot be removed when the lock is in the open position.

**Note:** The 7/8" lock nut can only be removed and installed when the lock is in the open position.

**The catch plate retaining nut, lock washer and catch plate should not be removed.**

2. Remove the 7/8" lock nut and insert the lock assembly (in the open position) into the cabinet door. Reinstall and tighten the lock nut.
3. Close and lock the cabinet door.

