



PART NO. 56-2250

INSTALLATION  
INSTRUCTIONSELECTRICAL UPDATE KIT  
(for 8 & 11 hp Commercial Walk Mowers)

1. Disconnect throttle cable from engine.
2. Cut (2) wire ties securing throttle control cable and wire harness to upper handle.
3. Remove screws mounting plastic electrical box to frame.
4. Disconnect wire connections at alternator, clutch, and grounds.
5. Remove (2) screws securing control panel to upper handle. Remove wire harness, plastic electrical box and control panel.
6. Remove engine blower housing.
7. Remove rewind starter clutch assembly from end of crank shaft.
8. Remove flywheel, using (19165) Flywheel Puller.
9. Remove alternator (4 screws, 1 wire tab and screw).
10. Install new alternator (4 screws, 1 tab and wire).
11. Install flywheel and starter clutch assembly.
12. Install engine blower shroud.
13. Apply decal to new control panel.
14. Install throttle control to control panel, routing cable thru upper hole in front of panel.
15. Install clutch switch to control panel.
16. Align control panel with (2) existing holes in left side of upper handle. Using control panel as a template, mark and drill (2) 7/32" dia. holes thru right side of upper handle.
17. Install wire harness interlock module, throttle control and control panel to upper handle, using left front screw. Secure control panel with remaining mounting screws.
18. Attach and adjust throttle control cable to engine. Throttle cable must be routed under transmission shaft.
19. Connect wire harness to clutch and clutch switch. Attach ground wires to engine screw and ignition wire to throttle assembly. Wire harness must be routed over transmission output shaft.
20. Secure wire harness and throttle cable to upper handle with (2) wire ties.
21. Install bottom panel to control panel with (4) self tapping screws.