



Customer Service Bulletin Commercial Business Group

Topdresser 2300®

<u>Model/Serial Range:</u>	<u>Model Number:</u>	<u>Serial Numbers:</u>
	44501	00000-99999
	Olathe 23	00000-99999

Subject: Sand metering control improvement.

Sand Seal Kit (95-0110) is now available to improve the metering control over sand when the particle size of the sand is very small. A copy of the Installation Instructions and Parts List is included with this bulletin for reference purposes.

NOTE: The Sand Seal may limit the ability to apply heavier rates of material. In those cases the seal will require removal.



PART NO. 95-0110

INSTALLATION INSTRUCTIONS

SAND SEAL KIT (2300 TOPDRESSER)

1. Remove bolts "A" and "B" from each side of the hopper assembly.
2. Loosen bolts "C" on the hopper assembly until sides of the hopper can move freely in the slots. Repeat on other side.
3. Position the Sand Seal (95-0112) in the hopper and secure bottom with bolts "A".
4. Install bolt "B" but do not tighten. Push the side of the hopper in against the edge of the Sand Seal until there is no gap. Secure bolts "B" and "C". Repeat on the other side.
5. Drill (2) holes through the hopper back with a 9/32 inch drill bit. Use the punched holes in the Sand Seal as a guide.
6. Install and secure bolts "D" through the top two center holes of the Sand Seal as shown.
7. Position the Brace - Seal (95-0111) underneath and behind the Sand Seal. Line up the holes in the brace with the slots in the Sand Seal and loosely assemble both parts. Push the brace downward until it rests against the inside flange of the Sand Seal and tighten the bolts.

