



Canopy for Four-Post Roll-Over Protection System Kit

Workman HD/HDX/HDX-D Utility Vehicle

Model No. 119-9457

Form No. 3365-329 Rev A

Installation Instructions

Installation

Important: Before the canopy can be installed, the Four Post Roll Over Protection System, Model 07378 must be installed on the Workman Utility Vehicle.

Note: Determine the left and right sides of the machine from the normal operating position.

1. Stop the engine, set the parking brake and remove the key from the ignition.
2. Remove the two flange head bolts and flange nuts securing the right ROPS post to the roll bar (Figure 1).




Figure 1

1. Right ROPS post

3. Using the bolts and nuts removed, loosely mount the right rear canopy bracket to the right ROPS post (Figure 2).

Note: When tightened, at least two bolt threads must extend out of the nuts. If the existing bolts are too short, use the 1/2 x 3-1/2 inch bolts included with the kit.




Figure 2

1. Right rear canopy bracket
2. Left rear canopy bracket
3. Right front canopy bracket
4. Left front canopy bracket
5. Front center canopy bracket

4. Repeat the procedure to install the left rear canopy bracket.
5. Remove the two flange head bolts, washers and flange nuts securing the right end of the crossbar to the right ROPS post (Figure 3).




Figure 3

1. Crossbar

6. Loosely mount the right front canopy bracket to the right ROPS post and crossbar with new 3/8 x 3-3/4 inch bolts and washers and the existing nuts (Figure 2).
7. Repeat the procedure to install the left front canopy bracket.

8. Loosely mount the front canopy bracket to the center of the crossbar with the U-bolt and 5/16 inch nuts (Figure 2).
9. Position the canopy onto the ROPS aligning it's mounting holes with the holes in the brackets (Figure 4).




Figure 4

- | | |
|-----------|--------------------|
| 1. Canopy | 4. Rubber bushings |
| 2. Bolt | 5. Nut |
| 3. Washer | |
-
10. Loosely mount the canopy to the brackets with (5) 1/4 x 1-1/4 inch bolts, 7/8 inch washers and 1/4 inch nuts. Also, make sure a rubber bushing is positioned on the top side and under side of the canopy when installing each bolt (Figure 4).
 11. Tighten the nuts securing the mounting brackets to the ROPS then tighten the nuts securing the canopy to the brackets.