# INSTRUCTIONS FOR INSTALLING CRUMBER AND RESTRAINT BAR KITS ON 660, 760, 860, AND 960 TRENCHERS

#### **PARTS LIST - COMMON PARTS FOR CRUMBER**

REF.	PART NO.	DESCRIPTION	QTY.	REF.	PART NO.	DESCRIPTION	QTY.							
2. 3. 4.	195-545 H673072 H672721 H673071 132-312	WASHER - flat, 3/4 LINK - short LINK - long ARM - blade PIN - cotter, 3/16	2 2 1	7. 8. 9.	111-538 H274894 131-1153 H309450 H438910	BOLT - 1/2 NC x 4	2 2 1							
PARTS LIST - KIT H939129, 1.2 m (4 Foot) Boom														
REF.	PART NO.	DESCRIPTION	QTY.	REF.	PART NO.	DESCRIPTION	QTY.							
11.	H672169	BOOM - crumber	1	12.	H438909	DECAL	2							
	PARTS LIST - KIT H939130, 1.5 m (5 Foot) Boom													
REF.	PART NO.	DESCRIPTION	QTY.	REF.	PART NO.	DESCRIPTION	QTY.							
13.	H672170	BOOM - crumber	1	14.	H438909	DECAL	2							
		PARTS LIST - I	KIT H939131.	1.8 r	n (6 Foot) Bo	om								
REF.	PART NO.	DESCRIPTION	QTY.		PART NO.		QTY.							
15.	H672171	BOOM - crumber	1	16.	H438909	DECAL	2							
PARTS LIST - KIT H939132, 2.1 m (7 Foot) Boom														
REF.	PART NO.	DESCRIPTION	QTY.		PART NO.		QTY.							
17.	H672172	BOOM - crumber	1	18.	H438909	DECAL	2							
PARTS LIST - KIT 443778A1, 1.2 m (4 Foot) Boom														
REF.	PART NO.	DESCRIPTION	QTY.		PART NO.		QTY.							
19.	H672169	BOOM - crumber	1	20.	428652A1	DECAL	2							
PARTS LIST - KIT 443779A1, 1.5 m (5 Foot) Boom														
REF	PART NO.	DESCRIPTION	QTY.		PART NO.		QTY.							
21.	H672170	BOOM - crumber			428652A1	DECAL								
	··•				···		···· <b>-</b>							



PARTS LIST - KIT 443780A1, 1.8 m (6 Foot) Boom													
REF.	PART NO.	DESCRIPTION	QTY.	REF.	PART NO.	DESCRIPTION	QTY.						
23.	H672171	BOOM - crumber	1	24.	428652A1	DECAL	2						
PARTS LIST - KIT 443781A1, 2.1 m (7 Foot) Boom													
REF.	PART NO.	DESCRIPTION	QTY.	•	PART NO.		QTY.						
25.	H672172	BOOM - crumber	1	26.	H428652A1	DECAL	2						
PARTS LIST - COMMON PARTS FOR RESTRAINT BAR													
REF.	PART NO.	DESCRIPTION	QTY.	REF.	PART NO.	DESCRIPTION	QTY.						
27.	428652A1	DECAL	2	28.	H438910	DECAL	1						
	PARTS LIST - KIT 443782A1, 1.2 m (4 Foot) Boom												
REF.	PART NO.	DESCRIPTION	QTY.										
29.	H434220	BAR - restraint	1										
PARTS LIST - KIT 443783A1, 1.5 m (5 Foot) Boom													
REF.	PART NO.	DESCRIPTION	QTY.										
30.	H434221	BAR - restraint	1										
PARTS LIST - KIT 443784A1, 1.8 m (6 Foot) Boom													
REF.	PART NO.	DESCRIPTION	QTY.										
31.	H434222	BAR - restraint	1										
PARTS LIST - KIT 443785A1, 2.1 m (7 Foot) Boom													
REF.	PART NO.	DESCRIPTION	QTY.										
32.	H434223	BAR - restraint	1										

## **GENERAL INFORMATION**

The illustration for this instruction sheet is on the last page. Separate the pages so that you can see the illustration as you read the instructions.

The reference numbers and the letters on the illustration are the same as the reference numbers and letters in the instructions.

Special torque specifications are included in the instructions. If torque specifications are not included in the instructions, use standard torque specifications. See your Service Manual or Case Dealer if you need standard torque specifications.

**NOTE:** Kits H939129, H939130, and H939131 are for the 660, 760, and 860 Trenchers. Kit H939132 is for the 760 and 860 Trenchers. Kits 443778A1, 443779A1, 443780A1, 443781A1, 443782A1, 443783A1, 443784A1, and 443785A1 are for 960 Trenchers.

Bur 8-75222 Issued 4-02 Printed in U.S.A

## **PREPARATION**

- 1. Loosen the nuts (A) and bolts (B) that hold the existing guard (not shown) in between the mounting brackets (C).
- 2. Remove the existing guard (not shown) from the mounting brackets (C).

## **BOOM/BAR INSTALLATION**

- 1. Install the boom (11, 13, 15, 17, 19, 21, 23, or 25) or restraint bar (29, 30, 31, or 32) in between the mounting brackets (C).
- Tighten the nuts (A) on the bolts (B) that hold the boom or bar in between the mounting brackets (C).

### **CRUMBER INSTALLATION**

- 1. Install a flat washer (1) on the pin of both a short link (2) and a long link (3).
- 2. Install the pins of the links (2 and 3) through the holes in the blade arm (4).
- 3. Install a flat washer (1) on the pin of each of the links (2 and 3) that are installed in the blade arm (4).
- 4. Install the pins on the other links (2 and 3) in the boom (11, 13, 15, 17, 19, 21, 23, or 25) as shown.
- 5. Install the blade arm (4) and links (2 and 3) on the boom (11, 13, 15, 17, 19, 21, 23, or 25) and the links (2 and 3) already installed in the boom.
- 6. Install the cotter pins (5) in the link pins.

#### CRUMBER BLADE INSTALLATION

**NOTE:** The crumber blade (D) is not included in these kits.

- 1. Put the crumber blade (D) and plate (9) in position on the blade arm (4) as shown.
- 2. Install the bolts (6), flat washers (7), and lock nuts (8) as shown.


#### DECAL INSTALLATION

- 1. Clean each side and top of the boom (11, 13, 15, 17, 19, 21, 23, or 25) and restraint bar (29, 30, 31, or 32) of all dirt, grease, and oil.
- Install the decal (10) on the top of the boom (11, 13, 15, 17, 19, 21, 23, or 25) and restraint bar (29, 30, 31, or 32) as shown.
- 3. Cut both decals (12, 14, 16, 18, 20, 22, 24, 26, or 28) in half.
- 4. Install a complete decal (12, 14, 16, 18, 20, 22, 24, 26, or 28) on each side of the boom (11, 13, 15, 17, 19, 21, 23, or 25).

## **ADJUSTMENT**

- 1. Lower the crumber are into position.
- 2. Loosen the nuts (A) and bolts (B).
- 3. Move the boom (11, 13, 15, 17, 19, 21, 23, or 25) until the crumber blade is 75 to 100 mm (3 to 4 inches) from the teeth on the digging chain.
- 4. Tighten the nuts (A).

Bur 8-75222 Issued 4-02 Printed in U.S.A



BS02D004

A. Nut B. Bolt C. Mounting Bracket

D. Crumber Blade (Not Included)

Bur 8-75222 Issued 4-02 Printed in U.S.A