



Walk Greensmower Light Switch Part Information

Product: Flex and GR Series Greensmower Light Kits

September 28, 2007

Affected Units:

Models:

Serial Numbers:

Greensmaster Light Kit

04058

N/A

Greensmaster 1000 & 1600 Light Kit

04059


N/A

Situation:

Due to an oversight, the part number information for the replacement light switch was not provided in the parts documentation included with the above indicated Toro Walk Greensmower Light Kits.

Instructions:

To replace the light switch in the Lamp w/Switch ASM (94-9023), order Switch/Nut ASM (110-6269) from your local Toro Commercial Products Parts department.



Light Kit Assembly

Ref	Part No.	Qty.	Description	Ref	Part No.	Qty.	Description
1	94-9024	2	Standard Lamp ASM	20	112-9474	1	Switch Plate ASM
1:1	95-0909	1	Lamp-12 Volt				
1:2	3230-28	1	Screw-CARR				
1:3	3253-33	1	Washer-Lock				
1:4	3217-6	1	Nut-Hex				
2	112-7612	2	Bracket-Light, Wide				
3	107-3024	2	Clamp-Light				
4	3296-42	5	Nut-Lock, NI				
5	3290-378	4	Tie-Cable				
6	110-3462	1	Wire Harness				
7	112-9418	1	Voltage-Regulator, Ac				
8	104-0507	1	Strap-Regulator, Voltage				
9	321-10	1	Screw-HH				
12	2412-81	1	Clamp-R				
13	3218-1	1	Nut-Jam				
14	3256-22	2	Washer-Flat				
15	33114-016	1	Screw-HH				
16	3255-9	1	Washer-Lock				
17	69-9740	1	Switch				
17:1	218-498	2	Locknut				
17:2	218-588	3	Screw				
17:3	218-589	1	Washer				
17:4	3253-19	3	Washer-Lock				
19	110-7321	1	Template-Light Kit				