



Form No. 3401-744 Rev A

**Count on it.**

# Parts Catalog

## **TITAN® ZX 4800 Zero-Turn-Radius Riding Mower**

Model No. 74855—Serial No. 316000001 and Up



# Ordering Replacement Parts

To order replacement parts, please supply the part number, the quantity, and the description of each part desired.

## Understanding Reference Numbers

Each identified part in an illustration has a reference number. The reference number for a part also appears in the parts list, along with other information about the part.

This catalog uses two special reference number formats, one to indicate parts in a service assembly and another to indicate the quantity of a given part in an illustration.

## Service Assembly Reference Numbers

Parts in service assemblies have reference numbers in the form a:b. The a represents the reference number of the entire service assembly and the b represents a sequential number unique to each part within the service assembly.

For example, a wheel assembly might be identified by reference number 6, the tire by 6:1, the valve by 6:2, and the wheel by 6:3. When you order the assembly identified by reference number 6, you receive all parts identified by reference numbers 6:1, 6:2, and 6:3. However, you may also order any part individually. Reference numbers of this type appear in illustration and in parts lists.

## Reference Numbers Indicating Quantity

In an illustration, if a reference number indicates more than one part, the reference number has the form nX y. The n represents the quantity of the part, the X is the multiplication symbol, and the y represents the reference number.

For example, in an illustration, the reference number 2X 37 means that two of the parts identified by reference number 37 are indicated.

# List of Abbreviations

**AR:** as required

**ASM:** assembly

**BBC:** blade brake control

**BHTF:** button head thread forming

**CARR:** carriage

**CCW:** counter clockwise

**CW:** clockwise

**DEG:** degrees

**DPA:** Dual Point Adjustment

**ECM:** electronic control module

**EXT:** external

**FH:** flat head

**GA:** gauge

**HD:** heavy-duty

**HF:** hex flange

**HH:** hex head

**HHF:** hex head flange

**HHFTF:** hex head flange thread forming

**HJ:** hex jam

**HLH:** hex lag head

**HOC:** height-of-cut

**HP:** high pressure

**HSBH:** hex socket button head

**HSFH:** hex socket flat head

**HSH:** hex socket head

**HWH:** hex washer head

**HWHTF:** hex washer head thread forming

**HYD:** hydraulic

**LH:** left hand

**LP:** low pressure

**LPG:** Liquefied Petroleum Gas

**NI:** nylon insert

**NPTF:** national pipe thread fine

**PFH:** phillips flat head

**PPH:** phillips pan head

**PPHTF:** phillips pan head thread forming

**PRH:** phillips round head

**PTH:** phillips truss head

**PTO:** power-take-off

**RH:** right hand

**ROPS:** roll-over protection system

**RRB:** rear roller brush

**SFH:** slotted fillister head

**SHH:** slotted hex head

**SHWH:** slotted hex washer head

**SPH:** slotted pan head

**SQH:** square head

**SRH:** slotted round head

**STD:** standard

**TAP:** self tapping

**TTH:** torx truss head

# Contents

Frame, Front Axle and Caster Wheel Assembly ..... 4

Control Panel and Body Styling Pod Assembly ..... 6

Deck Lift Assembly..... 8

Seat Mounting Assembly ..... 10

Seat Assembly No. 131-4147 ..... 12

Traction Drive Assembly ..... 14

Motion Control Assembly ..... 16

Brake Link Assembly ..... 18

Engine, Muffler and Clutch Assembly ..... 20

Fuel Delivery Assembly..... 22

Multi Layer Fuel Tank Assembly No. 117-7352 ..... 24

Roll-Over Protection System Assembly ..... 26

Electrical Assembly ..... 28


48 Inch Deck Assembly..... 30

48 Inch Deck and Decal Assembly No. 131-4142..... 32

Deck, Belt and Mulch Blade Assembly ..... 34

Attachments and Accessories ..... 36


# Frame, Front Axle and Caster Wheel Assembly



## Frame, Front Axle and Caster Wheel Assembly (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>  | <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i> |
|-------------|--------------------|-------------|---------------------|-------------|--------------------|-------------|--------------------|
| 1           | 131-4039-01        | 1           | Frame ASM           | 17          | 120-2248-03        | 1           | Guard-Rear         |
| 2           | 127-3423-01        | 1           | Pan-Floor           | 18          | 67-1300            | 1           | Decal              |
| 3           | 32144-70           | 6           | Screw-HWHTF         | 19          | 105-8278           | 1           | Decal              |
| 4           | 132-0871           | 1           | Decal-Danger        | 20          | 121-0704-01        | 1           | Tube-Guard         |
| 5           | 127-3447           | 2           | Tire And Wheel ASM  | 21          | 322-10             | 2           | Screw-HH           |
| 5:1         | 120-2252           | 1           | Tire-13 Inch Smooth | 22          | 121-2980           | 2           | Cap                |
| 5:3         | 114-1640           | 2           | Bushing-Flange      | 23          | 117-1241           | 1           | Cover-Fan, RH      |
| 5:4         | 232-27             | 1           | Stem-Valve          | 24          | 117-1242           | 1           | Cover-Fan, LH      |
| 5:5         | 302-5              | 1           | Fitting-Grease      | 25          | 46-8560            | 2           | Screw-HHFTF        |
| 5:99        | 232-46             | 1           | Tube                | 28          | 127-3330-01        | 2           | Spacer-Caster      |
| 6           | 119-3475           | 2           | Spanner             | 30          | 116-4348           | 2           | Cap-Grease         |
| 7           | 325-37             | 2           | Screw-HH            | 32          | 131-4137-03        | 1           | Shield-Heat        |
| 8           | 3296-45            | 2           | Nut-Lock, NI        | 33          | 322-23             | 2           | Screw-HH           |
| 9           | 127-3309-01        | 2           | Fork-Caster         | 34          | 3256-23            | 4           | Washer-Flat        |
| 10          | 10-8110            | 2           | Washer-Thrust       | 36          | 116-1297           | 2           | Screw-Shoulder     |
| 11          | 109-3678           | 4           | Bearing-Ball        | 37          | 1-513658           | 3           | Bumper             |
| 12          | 3256-68            | 2           | Washer-Flat         | 38          | 112-9771           | 1           | Washer-Teflon      |
| 13          | 3234-47            | 2           | Screw-HHF           | 39          | 130-0733           | 3           | Pad-Rubber         |
| 14          | 121-2953-03        | 1           | Support-Seat        | 40          | 117-1232-03        | 1           | Bracket-Hitch      |
| 15          | 322-12             | 4           | Screw-HH            | 42          | 131-4036           | 1           | Decal              |
| 16          | 104-8300           | 10          | Nut-Flange, NI      |             |                    |             |                    |

# Control Panel and Body Styling Pod Assembly




## Control Panel and Body Styling Pod Assembly (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>   |
|-------------|--------------------|-------------|----------------------|
| 1           | 120-5488           | 1           | Pod-RH               |
| 2           | 120-5489           | 1           | Pod-LH               |
| 3           | 115-9632           | 1           | Decal-Panel, Control |
| 4           | 121-0770           | 1           | Cable-Throttle       |
| 5           | 3258-166           | 4           | Screw-PRH            |
| 6           | 107069             | 4           | Clip                 |

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i> |
|-------------|--------------------|-------------|--------------------|
| 7           | 115-2591-03        | 1           | Panel-Control      |
| 8           | 120-7950           | 6           | Screw-Shoulder     |
| 9           | 120-2291           | 1           | Cable-Choke        |
| 10          | 3253-21            | 1           | Washer-Lock        |
| 11          | 3220-3             | 1           | Nut-HJ             |
| 12          | 105-1853           | 2           | Clamp-Hose         |


Deck Lift Assembly



## Deck Lift Assembly (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>  | <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>  |
|-------------|--------------------|-------------|---------------------|-------------|--------------------|-------------|---------------------|
| 1           | 131-4058-03        | 1           | Pivot-Front         | 14          | 116-4313           | 4           | Spacer-Step, Double |
| 2           | 131-4059-03        | 1           | Pivot-Rear          | 15          | 104-8301           | 10          | Nut-Flange, NI      |
| 3           | 116-2887           | 4           | Gusset-Lift, Deck   | 16          | 43-0940            | 4           | Spacer              |
| 4           | 115-5065           | 4           | Bushing-Flange      | 17          | 130-0742           | 8           | Bolt-Shoulder       |
| 5           | 322-6              | 8           | Screw-HH            | 18          | 130-0785           | 1           | Decal               |
| 6           | 104-8300           | 8           | Nut-Flange, NI      | 19          | 127-3329-01        | 1           | Pan-Deck, Pivot     |
| 7           | 127-3389-03        | 2           | Plate-Deck, Lift    | 20          | 127-3399           | 1           | Rod-Deck, Pivot     |
| 8           | 127-3391           | 1           | Lock-Transport, HOC | 21          | 3256-26            | 2           | Washer-Flat         |
| 9           | 116-4312           | 1           | Grip-Bar, Flat      | 22          | 1-806005           | 2           | Pin-Cotter          |
| 10          | 127-3390-03        | 1           | Link-HOC            | 23          | 115-9652           | 1           | Spring-Extension    |
| 11          | 116-5584           | 1           | Pin-HOC             | 24          | 130-0668           | 4           | Chain-Decklift      |
| 12          | 130-0654           | 1           | Decal-HOC           | 25          | 130-0734           | 2           | Pad-Rubber          |
| 13          | 114-4681           | 4           | Screw-HHF           |             |                    |             |                     |


# Seat Mounting Assembly



## Seat Mounting Assembly (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i> | <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>  |
|-------------|--------------------|-------------|--------------------|-------------|--------------------|-------------|---------------------|
| 1           | 131-3944-03        | 1           | Pan-Seat           | 8           | 3290-250           | 2           | Pin-Cotter          |
| 2           | 131-4147           | 1           | Seat ASM           | 9           | 130-6996           | 1           | Decal-Maintenance   |
| 3           | 701178             | 3           | Cap-Protector      | 10          | 107069             | 1           | Clip                |
| 4           | 3234-47            | 3           | Screw-HHF          | 11          | 99-6810            | 1           | Screw-HHF           |
| 5           | 92-7054            | 3           | Spring-Compression | 12          | 131-1038           | 1           | Bracket-Stop, Seat  |
| 6           | 104-8300           | 3           | Nut-Flange, NI     | 13          | 131-4008-03        | 1           | Bracket-Latch, Seat |
| 7           | 115-4966           | 1           | Rod-Stop           | 15          | 32144-70           | 2           | Screw-HWHTF         |

# Seat Assembly No. 131-4147




## Seat Assembly No. 131-4147 (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>   |
|-------------|--------------------|-------------|----------------------|
| 2           | 131-4149           | 1           | Cushion-Seat, Back   |
| 3           | 131-4151           | 1           | Cushion-Seat, Bottom |
| 4           | 131-4153           | 1           | Track ASM            |
| 5           | 131-4154           | 1           | Bushing ASM          |

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i> |
|-------------|--------------------|-------------|--------------------|
| 6           | 131-4155           | 1           | Armrest Kit        |
| 7           | 131-4156           | 1           | Shell              |
| 8           | 82-2190            | 1           | Switch-Bail        |
| 9           | 110-4163           | 2           | Cushion-Rest, Arm  |


# Traction Drive Assembly



## Traction Drive Assembly (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>           | <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i> |
|-------------|--------------------|-------------|------------------------------|-------------|--------------------|-------------|--------------------|
| 1           | 127-3381           | 1           | LH Hydro Transmission<br>ASM | 20          | 1-806003           | 2           | Pin-Cotter         |
| 2           | 127-3382           | 1           | RH Hydro Transmission<br>ASM | 21          | 125-8950           | 2           | Rod-Bypass         |
| 3           | 110-9981           | 1           | Washer-Plain                 | 22          | 119-8952           | 2           | Washer             |
| 4           | 115-4986           | 1           | Spacer                       | 23          | 127-3449           | 2           | Tire And Wheel ASM |
| 5           | 114-0463           | 2           | Washer-Friction, Composite   | 23:2        | 125-1821           | 1           | Tire               |
| 6           | 117-5350           | 1           | Arm-Idler                    | 23:3        | 232-27             | 1           | Stem-Valve         |
| 7           | 104-8301           | 3           | Nut-Flange, NI               | 23:99       | 105-4070           | 1           | Tube-Inner         |
| 9           | 109-3397           | 2           | Pulley-Idler, Flat           | 24          | 242-50             | 8           | Nut-Lug            |
| 10          | 1-603402           | 1           | Spring-Extension             | 25          | 115-9613           | 1           | V-Belt             |
| 11          | 3231-26            | 2           | Screw-CARR                   | 26          | 115-9618           | 1           | HYD Reservoir ASM  |
| 12          | 323-12             | 1           | Screw-HH                     | 26:2        | 109-3320           | 1           | Cap-Reservoir, HYD |
| 13          | 109-3652           | 2           | Spacer-Hydro                 | 27          | 115-4969           | 2           | Hose-Overflow      |
| 14          | 115-2559           | 1           | Shaft-Cross, Hydro           | 28          | 117-1193           | 4           | Clamp-Hose         |
| 15          | 322-13             | 4           | Screw-HH                     | 29          | 46-8560            | 2           | Screw-HHFTF        |
| 16          | 104-8300           | 8           | Nut-Flange, NI               | 30          | 130-6922           | 2           | Decal-Bypass       |
| 17          | 322-38             | 2           | Screw-HH                     | 31          | 3256-23            | 8           | Washer-Flat        |
| 18          | 322-11             | 2           | Screw-HH                     | 32          | 117-5351           | 1           | Spacer             |
| 19          | 323-10             | 2           | Screw-HH                     | 33          | 117-7248-03        | 2           | Plate-Spring       |
|             |                    |             |                              | 34          | 110769             | 2           | Spring-Extension   |


# Motion Control Assembly



## Motion Control Assembly (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i> | <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>     |
|-------------|--------------------|-------------|--------------------|-------------|--------------------|-------------|------------------------|
| 1           | 127-3282-03        | 1           | Box-Control        | 23          | 110-6751           | 2           | Bracket-Return         |
| 2           | 120-7950           | 2           | Screw-Shoulder     | 24          | 110-6750           | 2           | Plate-Return           |
| 3           | 110-6828           | 2           | Activator Arm ASM  | 25          | 110-6752           | 2           | Spring-Compression     |
| 3:2         | 105-3455           | 2           | Bushing            | 26          | 110-6894           | 6           | Washer-Pivot           |
| 4           | 106-2214           | 2           | Bolt-Shoulder      | 27          | 323-4              | 2           | Screw-HH               |
| 5           | 131-0964           | 2           | Damper             | 28          | 110-6784           | 2           | Bolt-Shoulder          |
| 6           | 3296-42            | 4           | Nut-Lock, NI       | 29          | 37-8771            | 2           | Bolt-Shoulder          |
| 7           | 46-8560            | 4           | Screw-HHFTF        | 30          | 104-8300           | 4           | Nut-Flange, NI         |
| 8           | 3296-48            | 2           | Nut-Lock, NI       | 31          | 112-9771           | 2           | Washer-Teflon          |
| 9           | 119-8952           | 2           | Washer             | 32          | 130-0655           | 1           | Decal-Fill, Fuel       |
| 10          | 32128-23           | 2           | Nut-HF             | 33          | 117-1255-03        | 1           | Cover-Control, RH      |
| 11          | 3256-5             | 2           | Washer-Flat        | 34          | 1-603807           | 2           | Spring-Return, Neutral |
| 12          | 117-7422           | 2           | Rod-Control        | 35          | 115-2561-03        | 1           | Cover-Control, LH      |
| 13          | 117-7423           | 2           | Bracket-Control    | 36          | 115-9625           | 1           | Decal-Brake, Parking   |
| 14          | 1-808280           | 2           | Pin-Clevis         | 37          | 99-8936            | 2           | Decal-Control, Motion  |
| 15          | 1-806003           | 2           | Pin-Cotter         | 38          | 127-3383           | 1           | Decal                  |
| 16          | 3256-23            | 2           | Washer-Flat        | 39          | 3256-24            | 4           | Washer-Flat            |
| 17          | 132-9344-05        | 2           | Arm-Actuator       | 40          | 323-6              | 4           | Screw-HH               |
| 19          | 115-5023           | 2           | Tab-Stop           | 41          | 121-0731           | 1           | Handle-Control, RH     |
| 20          | 110-6873           | 2           | Eccentric          | 41:1        | 121-0726           | 1           | Grip                   |
| 21          | 110-6874           | 2           | Screw-Eccentric    | 42          | 121-0730           | 1           | Handle-Control, LH     |
| 22          | 110-6875           | 2           | Bolt-Shoulder      | 42:1        | 121-0726           | 1           | Grip                   |


# Brake Link Assembly



## Brake Link Assembly (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>  | <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>       |
|-------------|--------------------|-------------|---------------------|-------------|--------------------|-------------|--------------------------|
| 1           | 131-4057           | 1           | Brake Handle ASM    | 12          | 3256-23            | 6           | Washer-Flat              |
| 2           | 63-2650            | 1           | Screw-Shoulder      | 13          | 1-603807           | 2           | Spring-Return, Neutral   |
| 3           | 131-4056-03        | 1           | Brake Bellcrank ASM | 14          | 3272-11            | 2           | Pin-Cotter               |
| 4           | 115-5074           | 1           | Link-Brake          | 15          | 3256-27            | 2           | Washer-Flat              |
| 5           | 117-7322           | 1           | Rod-Brake, LH       | 16          | 40-1940            | 2           | Washer                   |
| 6           | 117-7323           | 1           | Rod-Brake, RH       | 17          | 32144-70           | 4           | Screw-HWHTF              |
| 7           | 115-9681           | 2           | Fitting-Rod         | 18          | 322-10             | 2           | Screw-HH                 |
| 8           | 1-633268           | 1           | Grip-Lever          | 19          | 106-9758           | 2           | Screw-CARR               |
| 9           | 104-8300           | 5           | Nut-Flange, NI      | 20          | 127-3435-01        | 1           | Plate-Support, Floor Pan |
| 10          | 256-292            | 2           | Bushing-Flange, NI  | 21          | 119-0718           | 2           | Spacer                   |
| 11          | 1-806003           | 8           | Pin-Cotter          |             |                    |             |                          |

# Engine, Muffler and Clutch Assembly



## Engine, Muffler and Clutch Assembly (continued)


| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>                  |
|-------------|--------------------|-------------|-------------------------------------|
| 1           |                    | 1           | Engine-Kawasaki,<br>Fr651V-S12-R ●■ |
| 1:1         | 1-653313           | 2           | Gasket-Exhaust                      |
| 1:2         | 114-3549           | 4           | Nut                                 |
| 1:3         | 114-3550           | 4           | Washer-Lock                         |
| 3           | 125-5576           | 1           | Pulley-Engine                       |
| 4           | 125-1760           | 1           | Muffler                             |
| 5           | 117-7344-03        | 1           | Bracket-Stop, PTO                   |
| 6           | 127-3410           | 1           | Clutch-PTO                          |

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i> |
|-------------|--------------------|-------------|--------------------|
| 8           | 3212-13            | 1           | Screw-HH           |
| 9           | 323-50             | 4           | Bolt-HH            |
| 10          | 117-7335-03        | 1           | Tube-Stiffener     |
| 11          | 104-8300           | 1           | Nut-Flange, NI     |
| 12          | 104-8301           | 3           | Nut-Flange, NI     |
| 14          | 110-9981           | 1           | Washer-Plain       |
| 15          | 3234-47            | 1           | Screw-HHF          |
| 16          | 106-7022           | 1           | Tube-Drain, Oil    |
| 17          | 323-6              | 3           | Screw-HH           |

● Not serviced separately

■ Obtain parts from [www.kawpowerepc.com](http://www.kawpowerepc.com)


# Fuel Delivery Assembly



## Fuel Delivery Assembly (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>       | <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>      |
|-------------|--------------------|-------------|--------------------------|-------------|--------------------|-------------|-------------------------|
| 1           | 117-7352           | 1           | Fuel Tank ASM            | 15          | 46-8560            | 3           | Screw-HHFTF             |
| 2           | 117-1221           | 1           | Canister-Carbon, 800Cc   | 16          | 125-1847           | 1           | Cap-Fuel                |
| 3           | 114-0292           | 1           | Bracket-Canister, Carbon | 17          | 3334-945           | 1           | Tie-Cable               |
| 4           | 110-4103           | 1           | Hose-Fuel                | 18          | 614249             | 4           | Tie-Cable               |
| 5           | 110-7502           | 1           | Hose-Fuel                | 19          | 107-0589           | 1           | Hose-Fuel               |
| 7           | 51-3215            | 1           | Hose-Fuel                | 20          | 115-2620           | 1           | Rod-Tank, Gas           |
| 8           | 109-0293           | 1           | Hose-Fuel                | 21          | 117-1298           | 1           | Seal-Tank               |
| 9           | 115-7854           | 1           | Filter-Fuel, Inline      | 22          | 32144-70           | 1           | Screw-HWHTF             |
| 10          | 116-2232           | 1           | Valve-Control, Vacuum    | 23          | 2412-98            | 2           | Clamp-Hose              |
| 11          | 119-8501           | 1           | Hose-Vent, Formed        | 24          | 116-2469           | 1           | Strap-Velcro, Cable Tie |
| 12          | 119-8502           | 1           | Hose-Vent, Formed        | 26          | 322-12             | 1           | Screw-HH                |
| 13          | 121-0743           | 1           | Adapter-Orifice          | 27          | 104-8300           | 1           | Nut-Flange, NI          |
| 14          | 130-7011-03        | 1           | Bracket-Canister         |             |                    |             |                         |


Multi Layer Fuel Tank Assembly No. 117-7352



## Multi Layer Fuel Tank Assembly No. 117-7352 (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>      |
|-------------|--------------------|-------------|-------------------------|
| 1           | 121-0793           | 1           | Connector-Elbow, 90 DEG |
| 2           | 46-6560            | 2           | Bushing                 |
| 4           | 117-7400           | 1           | Fitting-Plastic         |


# Roll-Over Protection System Assembly



## Roll-Over Protection System Assembly (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>  | <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>  |
|-------------|--------------------|-------------|---------------------|-------------|--------------------|-------------|---------------------|
| 1           | 121-2986-03        | 2           | Tube-ROPS, Lower    | 11:2        | 130-6927           | 1           | Decal-ROPS, Warning |
| 2           | 115-4962-03        | 2           | Tube-Support, ROPS  | 13          | 3256-26            | 8           | Washer-Flat         |
| 3           | 115-4963-03        | 2           | Bracket-Reinforcing | 16          | 119-8969           | 2           | Nut-Hex             |
| 4           | 84-1560            | 4           | Washer-Thrust       | 18          | 99-5107            | 12          | Nut-Lock            |
| 5           | 325-18             | 2           | Screw-HH            | 19          | 1-513658           | 2           | Bumper              |
| 6           | 325-14             | 10          | Screw-HH            | 20          | 115-5038-03        | 1           | Bracket-Belt, Seat  |
| 7           | 325-5              | 2           | Screw-HH            | 21          | 115-5060-03        | 1           | Bracket-Belt, Seat  |
| 9           | 127-3326-03        | 4           | Plate-ROPS          | 22          | 3234-38            | 2           | Screw-HHF           |
| 11          | 130-6929           | 1           | Upper ROPS ASM      | 23          | 109-9805           | 1           | Seat Belt Kit       |


# Electrical Assembly



## Electrical Assembly (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>      | <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i> |
|-------------|--------------------|-------------|-------------------------|-------------|--------------------|-------------|--------------------|
| 1           | 105-1692           | 1           | Battery-Dry             | 13          | 3256-22            | 2           | Washer-Flat        |
| 2           | 117-2221           | 1           | Switch-Ignition         | 14          | 32144-1            | 3           | Screw-Taptite      |
| 3           | 63-8360            | 1           | Key-Ignition            | 15          | 92-6989            | 1           | Wire-21 Inch       |
| 4           | 103-5221           | 1           | Switch-PTO              | 16          | 32128-33           | 3           | Nut-HF             |
| 5           | 110-6765           | 2           | Switch                  | 17          | 98-7249            | 1           | Relay              |
| 7           | 117-1197           | 1           | Solenoid                | 18          | 46-8560            | 2           | Screw-HHFTF        |
| 8           | 117-5342           | 1           | Cable-Battery, Positive | 19          | 3220-2             | 2           | Nut-Jam            |
| 9           | 117-7240           | 1           | Cable-Battery, Negative | 22          | 120-2244           | 1           | Hourmeter          |
| 10          | 117-7313-01        | 1           | Strap-Battery           | 23          | 99-7408            | 1           | Switch-Reverse     |
| 11          | 321-4              | 2           | Screw-HH                | 24          | 117-1283-03        | 1           | Tray-Battery       |
| 12          | 130-0651           | 1           | Harness-Wire            | 25          | 1-633651           | 1           | Bolt-Holddown      |
| 12:5        | 109103             | 1           | Fuse-Blade, 30 Amp      | 26          | 1-543792           | 1           | Wingnut            |
| 12:6        | 109102             | 1           | Fuse-Blade, 25 Amp      | 27          | 33104-016          | 1           | Screw-HHF          |
| 12:9        | 100-4918           | 1           | Diode-Over Molded       |             |                    |             |                    |


# 48 Inch Deck Assembly



## 48 Inch Deck Assembly (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>       | <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i> |
|-------------|--------------------|-------------|--------------------------|-------------|--------------------|-------------|--------------------|
| 1           | 131-4142           | 1           | 48 Inch Deck ASM         | 18          | 117-1270           | 1           | Deflector          |
| 2           | 117-7396-05        | 1           | Cover-Belt               | 19          | 115-5048-03        | 1           | Plate-Deflector    |
| 3           | 117-7397-05        | 1           | Cover-Belt               | 20          | 117-7418-03        | 1           | Baffle-Cutoff      |
| 4           | 32144-70           | 2           | Screw-HWHTF              | 21          | 3230-3             | 4           | Screw-CARR         |
| 9           | 104-8301           | 3           | Nut-Flange, NI           | 22          | 3230-22            | 4           | Screw-CARR         |
| 10          | 1-603299           | 3           | Roller-Scalp, Anti       | 23          | 104-8300           | 8           | Nut-Flange, NI     |
| 11          | 130-0762           | 1           | Pivot-Deflector          | 24          | 109-8854           | 1           | Pin-Chute          |
| 11:2        | 130-0731           | 1           | Decal-Danger             | 25          | 121-2983           | 1           | Spring-Torsion     |
| 12          | 323-23             | 3           | Screw-HH                 | 26          | 95-2747            | 2           | Fitting-Washout    |
| 13          | 104-0892           | 3           | Spacer-Axle, Rear        | 27          | 46-6290            | 2           | O-Ring             |
| 14          | 98-7912            | 3           | Tube-Spanner             | 28          | 46-8560            | 4           | Screw-HHFTF        |
| 16          | 3256-68            | 2           | Washer-Flat              | 29          | 95-3270            | 1           | Connector-Hose     |
| 17          | 114-1648-05        | 1           | Bracket-Deflector, Upper | 30          | 119-3382           | 1           | Decal-Deck         |

# 48 Inch Deck and Decal Assembly No. 131-4142




## 48 Inch Deck and Decal Assembly No. 131-4142 (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i> |
|-------------|--------------------|-------------|--------------------|
| 3           | 130-0731           | 1           | Decal-Danger       |
| 4           | 132-0873           | 2           | Decal-Danger, Deck |

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>  |
|-------------|--------------------|-------------|---------------------|
| 5           | 130-0765           | 1           | Decal-Scalp, Anti   |
| 6           | 117-1194           | 1           | Decal-Routing, Belt |

# Deck, Belt and Mulch Blade Assembly



## Deck, Belt and Mulch Blade Assembly (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>       | <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>         |
|-------------|--------------------|-------------|--------------------------|-------------|--------------------|-------------|----------------------------|
| 1           | 7-4150             | 3           | Washer                   | 12          | 110-9981           | 3           | Washer-Plain               |
| 2           | 120-5477           | 3           | Spindle ASM              | 13          | 114-0463           | 2           | Washer-Friction, Composite |
| 2:2         | 116-0720           | 2           | Bearing-Ball             | 14          | 1-413088           | 1           | Bushing-Lever, Lift        |
| 2:3         | 115-2641           | 1           | Spacer-Bearing           | 15          | 115-5054           | 1           | Arm-Idler                  |
| 3           | 32144-41           | 18          | Screw-Taptite            | 16          | 323-10             | 1           | Screw-HH                   |
| 4           | 117-7210           | 3           | Shield-Bearing           | 17          | 104-8301           | 3           | Nut-Flange, NI             |
| 5           | 115-2642           | 3           | Shaft-Spindle            | 18          | 115-2577           | 3           | Bushing-Idler              |
| 6           | 117-7326           | 3           | Pulley                   | 19          | 116-3626           | 3           | Pulley-Idler               |
| 7           | 1-603401           | 1           | Spacer-Fender            | 20          | 3231-31            | 1           | Screw-CARR                 |
| 8           | 117-7277-03        | 3           | Blade-Hi Flo, 16.50 Inch | 21          | 80-6990            | 3           | Washer-Hardened            |
| 9           | 125-1736           | 3           | Washer-Belleville        | 22          | 323-9              | 3           | Screw-HH                   |
| 10          | 51-4060            | 3           | Screw-Blade              | 23          | 108-4056           | 1           | Spring-Extension           |
| 11          | 3219-7             | 3           | Nut-Hex                  | 24          | 133-1166           | 1           | V-Belt                     |

# Attachments and Accessories

## For 74855 TITAN ZX 4800 Zero-Turn-Radius Riding Mower

| Product Name                                             | Model/Part |
|----------------------------------------------------------|------------|
| 48in Recycler Kit.....                                   | 119-3320   |
| Light Kit.....                                           | 117-5317   |
| 48in Striping Kit.....                                   | 119-3380   |
| Leaf Bagging Enhancement Kit .....                       | 119-3381   |
| Transport Seat Hold Down Kit.....                        | 117-7251   |
| Cargo Carrier .....                                      | 79032      |
| Front Weight Kit .....                                   | 79033      |
| Seat Kit .....                                           | 130-0788   |
| ROPS Conversion Kit .....                                | 130-6850   |
| MVP Filter .....                                         | 127-1628   |
| Bagger Kit.....                                          | 79328      |
| 48in Bagger Finishing Kit (Used with 79328 Bagger) ..... | 121-5662   |
| E-Z Vac Twin Bagger .....                                | 79330      |

**Notes:**

**Notes:**

**Notes:**



**Count on it.**