

EU Declaration of Conformity

The Toro Company®, 8111 Lyndale Ave. South, Bloomington, MN, USA, declares that the following unit(s):

Model No.	Serial No.	Product Description	Invoice Description
03820	316000001 and Up	Reelmaster 3555 Traction Unit	REELMASTER 3555
03821	316000001 and Up	Reelmaster 3575 Traction Unit	REELMASTER 3575

Conform(s) to the following directives:

2000/14/EC (Noise), 2006/42/EC (Machinery Safety), 2004/108/EC (EMC, effective until 20 April 2016), 2014/30/EU (EMC, effective 20 April 2016)

Further, the following accessories/attachments conform to the directives indicated below when installed according to instructions on the models listed above:

Model	Description	Directive
Accessories/Attachments for Model 03820		
03487	22in HD 8-blade DPA Cutting Unit	2006/42/EC
03488	22in HD 11-blade DPA Cutting Unit	2006/42/EC

Model	Description	Directive
Accessories/Attachments for Model 03821		
03638	7in 8-Blade DPA CU (R)	2006/42/EC
03639	7in 8-Blade DPA CU (FSR)	2006/42/EC
03641	7in 11-Blade DPA CU (FSR)	2006/42/EC

Data for Noise Directive (2000/14/EC):

Model	Classification	Cutting Width (cm)	Measured Sound Power (dBA)	Guaranteed Sound Power (dBA)	Engine Speed (rpm)*
03820	Lawn Mower	254	101	102	3320
03821	Lawn Mower	254	101	102	3320

* Maximum engine operating speed

Conformity Assessment: Annex VIII

Notified Body: SNCH 11, Route De Luxembourg, L-5230 Sandweiler

This declaration has been issued under the sole responsibility of the manufacturer.

The object of the declaration is in conformity with relevant Union harmonization legislation.

Certified:



David Klis
Sr. Engineering Manager
8111 Lyndale Ave. South
Bloomington, MN 55420, USA
January 19, 2016

EU Technical Contact:

Marcel Dutrieux
Manager European Product Integrity
Toro Europe NV
Nijverheidsstraat 5
2260 Oevel
Belgium

Tel. +32 16 386 659



EU Specifications

Machine Power, Mass, and Vibration Data

Model	Nominal Power (kW)	Machine Mass [‡] (kg)	Hand/Arm Vibration (m/s ²)*		Whole Body Vibration (m/s ²)*	
			Level	Uncertainty	Level	Uncertainty
03820	18.5	1034	0.3	0.2	0.4	0.2
03821	18.5	1157	0.3	0.2	0.4	0.2

[‡] With empty tanks in the normal operating configuration

* Determined in accordance with ISO 5395–1:2013, Annex G

Machine Sound Data

Model	Sound Pressure (dBA)*	
	Level	Uncertainty
03820	84	1
03821	84	1

* A-weighted levels determined in accordance with ISO 5395–1:2013, Annex F.



BG: За да получите копие от този документ на вашия език, отидете на www.toro.com/en-us/pages/manuals/default.aspx.

CS: Kopii tohoto dokumentu ve svém jazyce získáte na adrese www.toro.com/en-us/pages/manuals/default.aspx.

DA: For at indhente en kopi af dette dokument på dit sprog skal du besøge www.toro.com/en-us/pages/manuals/default.aspx.

DE: Ein Exemplar dieses Dokuments in Ihrer Sprache erhalten Sie unter www.toro.com/en-us/pages/manuals/default.aspx.

EL: Για να λάβετε αντίγραφο του εγγράφου αυτού στη γλώσσα σας μεταβείτε στη διεύθυνση www.toro.com/en-us/pages/manuals/default.aspx.

EN: To obtain a copy of this document in your language, go to www.toro.com/en-us/pages/manuals/default.aspx.

ES: Puede obtener una copia de este documento en su idioma en www.toro.com/en-us/pages/manuals/default.aspx.

ET: Dokumendist enda keeles koopia saamiseks külastage veebilehte www.toro.com/en-us/pages/manuals/default.aspx.

FI: Tästä asiakirjasta saa omakielisen version osoitteesta www.toro.com/en-us/pages/manuals/default.aspx.

FR: Pour vous procurer une copie de ce document dans votre langue, rendez-vous sur www.toro.com/en-us/pages/manuals/default.aspx.

HU: Ha szüksége van a dokumentum egy példányára a saját nyelvén, letöltheti azt a www.toro.com/en-us/pages/manuals/default.aspx oldalról.

IT: La copia del presente documento nella vostra lingua è disponibile su www.toro.com/en-us/pages/manuals/default.aspx.

LT: Norėdami gauti šio dokumento kopiją savo kalba, apsilankykite www.toro.com/en-us/pages/manuals/default.aspx.

LV: Lai iegūtu šī dokumenta kopiju savā valodā, lūdzu, dodieties uz www.toro.com/en-us/pages/manuals/default.aspx.

NL: Voor een exemplaar van dit document in uw eigen taal, gaat u naar: www.toro.com/en-us/pages/manuals/default.aspx.

NO: For å få en kopi av dette dokumentet på ditt språk, gå til www.toro.com/en-us/pages/manuals/default.aspx.

PL: Aby uzyskać kopię dokumentu dla swojego języka, należy przejść na stronę www.toro.com/en-us/pages/manuals/default.aspx.

PT: Para obter uma cópia deste documento no seu idioma, vá a www.toro.com/en-us/pages/manuals/default.aspx.

RO: Pentru a obține un exemplar al prezentului document în limba dumneavoastră, vizitați www.toro.com/en-us/pages/manuals/default.aspx.

SK: Ak chcete získať kópiu tohto dokumentu vo svojom jazyku, prejdite na adresu www.toro.com/en-us/pages/manuals/default.aspx.

SL: Za izvod tega dokumenta v vašem jeziku obiščite spletno stran www.toro.com/en-us/pages/manuals/default.aspx.

SV: Gå in på www.toro.com/en-us/pages/manuals/default.aspx om du vill ha ett exemplar av det här dokumentet på ditt språk.