



Form No. 3403-977 Rev A

Count on it.

Parts Catalog

Road Light Kit including Brake Lights

LT-F3000 Series Traction Unit

Model No. 02918—Serial No. 316000001 and Up



Ordering Replacement Parts

To order replacement parts, please supply the part number, the quantity, and the description of each part desired.

Understanding Reference Numbers

Each identified part in an illustration has a reference number. The reference number for a part also appears in the parts list, along with other information about the part.

This catalog uses two special reference number formats, one to indicate parts in a service assembly and another to indicate the quantity of a given part in an illustration.

Service Assembly Reference Numbers

Parts in service assemblies have reference numbers in the form a:b. The a represents the reference number of the entire service assembly and the b represents a sequential number unique to each part within the service assembly.

For example, a wheel assembly might be identified by reference number 6, the tire by 6:1, the valve by 6:2, and the wheel by 6:3. When you order the assembly identified by reference number 6, you receive all parts identified by reference numbers 6:1, 6:2, and 6:3. However, you may also order any part individually. Reference numbers of this type appear in illustration and in parts lists.

Reference Numbers Indicating Quantity

In an illustration, if a reference number indicates more than one part, the reference number has the form nX y. The n represents the quantity of the part, the X is the multiplication symbol, and the y represents the reference number.

For example, in an illustration, the reference number 2X 37 means that two of the parts identified by reference number 37 are indicated.

List of Abbreviations

AR: as required

ASM: assembly

BBC: blade brake control

BHTF: button head thread forming

CARR: carriage

CCW: counter clockwise

CW: clockwise

DEG: degrees

DPA: Dual Point Adjustment

ECM: electronic control module

EXT: external

FH: flat head

GA: gauge

HD: heavy-duty

HF: hex flange

HH: hex head

HHF: hex head flange

HHFTF: hex head flange thread forming

HJ: hex jam

HLH: hex lag head

HOC: height-of-cut

HP: high pressure

HSBH: hex socket button head

HSFH: hex socket flat head

HSH: hex socket head

HWH: hex washer head

HWHTF: hex washer head thread forming

HYD: hydraulic

LH: left hand

LP: low pressure

LPG: Liquefied Petroleum Gas

NI: nylon insert

NPTF: national pipe thread fine

PFH: phillips flat head

PPH: phillips pan head

PPHTF: phillips pan head thread forming

PRH: phillips round head

PTH: phillips truss head

PTO: power-take-off

RH: right hand

ROPS: roll-over protection system

RRB: rear roller brush

SFH: slotted fillister head

SHH: slotted hex head

SHWH: slotted hex washer head

SPH: slotted pan head

SQH: square head

SRH: slotted round head

STD: standard

TAP: self tapping

TTH: torx truss head

Contents


Road Light Kit Assembly 4

Front Light Assembly 6

Left Rear Light Assembly 8

Right Rear Light Assembly 10

Road Light Kit Assembly




Road Light Kit Assembly (continued)

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>	<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
4	111-9512-03	1	Bracket-Support, Right	22	111-6178	1	Plate-Number
5	111-9513-03	1	Bracket-Support, Left	22:4	111-6086	1	Housing ●
6	111-8034	2	Cable-Headlamp	23	111-3764	2	Setscrew
7	111-6174	2	Harness-Light, Front	24	HY09697	2	Washer-Plain
8	111-3893	1	Lead-Connector	25	HY09698	2	Nut-Nyloc
9	111-6181	2	Connector-Lights, Rear	26	ZBH1P110U	2	Bolt
10	111-2223	1	Switch-Warning, Hazard	27	09456	2	Nut
11	111-2252	1	Switch-Lights	28	ZDH1L035U	4	Screw-HH
12	111-2244	1	Switch-Indicator	29	ZNN1L000U	4	Nut-Nyloc
13	111-3766	1	Relay-Flasher	30	ZWP1L000U	8	Washer-Plain
14	111-5020	2	Reflector-Adhesive	31	03162	4	Screw-HH
15	70-09-026	1	Fuse-10A	32	09267	6	Washer
16	70-09-151	1	Fuse-15A	33	09441	4	Nut-Hex, NI
17	09472	4	Washer-Plain	34	ZWP1H000U	4	Washer-Plain
18	111-3759	1	Switch-Pressure	35	09363	2	Screw-HH
19	09438	2	Nut-Nyloc	36	ZDH1F030U	2	Screw-Set
20	111-3921	1	Connector-Switch, Pressure	37	924633	2	Headlamp-Dip/Main ●
21	111-9633-03	1	Bracket-Plate, Number	37:1	924632	1	Headlamp-Bulb ●

● Not illustrated


Front Light Assembly



Front Light Assembly (continued)

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>	<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
1	111-9514-03	1	Bracket-Light, Front	4	09470	24	Washer
2	111-6177	2	Indicator-Light, Front	5	ZDH1E020U	12	Screw-HH
3	111-6176	2	Marker-Light, Front	6	09430	12	Nut-Nyloc


Left Rear Light Assembly



Left Rear Light Assembly (continued)

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>	<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
1	111-9511-03	1	Bracket-Light, Rear	7	ZDH1E020U	6	Screw-HH
2	111-3710-03	1	Guard-Light	8	09430	6	Nut-Nyloc
3	111-6180	1	Light-Indicator, Rear	9	ZCS1F025U	1	Screw
4	111-6179	1	Light-Stop/Tail	10	09472	1	Washer-Plain
5	111-3760	1	Reflector-Red	11	09438	1	Nut-Nyloc
6	09470	12	Washer				

Right Rear Light Assembly



Right Rear Light Assembly (continued)

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>	<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
1	111-9510-03	1	Bracket-Light, Rear	7	ZDH1E020U	6	Screw-HH
2	111-3710-03	1	Guard-Light	8	09430	6	Nut-Nyloc
3	111-6180	1	Light-Indicator, Rear	9	ZCS1F025U	1	Screw
4	111-6179	1	Light-Stop/Tail	10	09472	1	Washer-Plain
5	111-3760	1	Reflector-Red	11	09438	1	Nut-Nyloc
6	09470	12	Washer				



Count on it.