Form No. 3387-831 Rev C

TORO®

Count on it.

Parts Catalog

TimeMaster 76cm

Lawn Mower

Model No. 20977—Serial No. 315000001 and Up

Register at www.Toro.com.
Original Instructions (EN)

CE

3387-831 C

Ordering Replacement Parts

To order replacement parts, please supply the part number, the quantity, and the description of each part desired.

Understanding Reference Numbers

Each identified part in an illustration has a reference number. The reference number for a part also appears in the parts list, along with other information about the part.

This catalog uses two special reference number formats, one to indicate parts in a service assembly and another to indicate the quantity of a given part in an illustration.

Service Assembly Reference Numbers

Parts in service assemblies have reference numbers in the form a:b. The a represents the reference number of the entire service assembly and the b represents a sequential number unique to each part within the service assembly.

For example, a wheel assembly might be identified by reference number 6, the tire by 6:1, the valve by 6:2, and the wheel by 6:3. When you order the assembly identified by reference number 6, you receive all parts identified by reference numbers 6:1,6:2, and 6:3. However, you may also order any part individually. Reference numbers of this type appear in illustration and in parts lists.

Reference Numbers Indicating Quantity

In an illustration, if a reference number indicates more than one part, the reference number has the form nX y. The n represents the quantity of the part, the X is the multiplication symbol, and the y represents the reference number.

For example, in an illustration, the reference number 2X 37 means that two of the parts identified by reference number 37 are indicated.

List of Abbreviations

AR: as required

ASM: assembly

BBC: blade brake control

BHTF: button head thread forming

CARR: carriage

CCW: counter clockwise

CW: clockwise

DEG: degrees

DPA: Dual Point Adjustment

ECM: electronic control module

EXT: external

FH: flat head

GA: gauge

HD: heavy-duty

HF: hex flange

HH: hex head

HHF: hex head flange

HHFTF: hex head flange thread forming

HJ: hex jam

HLH: hex lag head

HOC: height-of-cut

HP: high pressure

HSBH: hex socket button head

HSFH: hex socket flat head

HSH: hex socket head

HWH: hex washer head

HWHTF: hex washer head thread forming

HYD: hydraulic

LH: left hand

LP: low pressure

LPG: Liquefied Petroleum Gas

NI: nylon insert

NPTF: national pipe thread fine

PFH: phillips flat head

PPH: phillips pan head

PPHTF: phillips pan head thread forming

PRH: phillips round head

PTH: phillips truss head

PTO: power-take-off

RH: right hand

ROPS: roll-over protection system

RRB: rear roller brush

SFH: slotted fillister head

SHH: slotted hex head

SHWH: slotted hex washer head

SPH: slotted pan head

SQH: square head

SRH: slotted round head

STD: standard

TAP: self tapping

TTH: torx truss head


Contents

Deck and Frame Assembly 4
Belt, Spindle and Blade Assembly 6
Side Discharge Chute Assembly 8
Bag Assembly 10
Engine and Pulley Assembly 12
Front Wheel and Axle Assembly 14
Transmission, Rear Wheel and Height-of-Cut Assembly 16
Handle Assembly 18
Attachments and Accessories 20

© 2016—The Toro® Company
8111 Lyndale Avenue South
Bloomington, MN 55420

Contact us at www.Toro.com.
Printed in the USA.
All Rights Reserved


Deck and Frame Assembly



Deck and Frame Assembly (continued)

Ref.	Part Number	Qty.	Description
1	125-2534	1	Housing ASM
3	121-9198-01	1	Frame
4	120-3336	1	Chute
5	3230-5	2	Screw-CARR
6	120-3344	1	Rod-Release, Handle
7	120-7018	1	Grip-Lever
8	121-9114	1	Bracket-Door, LH
9	121-9115	1	Bracket-Door, RH
11	120-7048	1	Rear Deflector ASM
12	115-2859	1	Spring-Torsion
13	114-7924	1	Spring-Torsion
14	46-8091	2	Screw-HWH
15	107-7497	1	Bracket-Cable, Traction
16	120-5225	1	Plug-Mulch
17	120-6241	1	Shield-Trailing
18	49-2040	9	Screw-HWHTF
21	117-1092	2	Screw-PTH
24	3296-29	4	Nut-Lock, NI
25	121-5810	1	Cover-Belt
26	121-5793-03	1	Door-Access
27	121-5840	2	Fastener
28	125-2507	1	Decal-Access Panel
29	130-2352-01	1	Baffle-Control
30	125-5081-01	1	Plate-Deck
31	120-7085-03	1	Skid-LH
32	120-9488-03	1	Skid-RH
33	3274-55	2	Screw-HSBH
99	125-5072	1	Frame Plate Kit (Service)
99:1	125-2542	1	Plate Frame ASM
99:2	3229-3	3	Screw-CARR
99:3	3296-42	3	Nut-Lock, NI


Belt, Spindle and Blade Assembly



Belt, Spindle and Blade Assembly (continued)

Ref.	Part Number	Qty.	Description
1	121-9107	2	Spindle
2	32144-57	10	Screw
3	120-5234	1	Shaft-Spindle
4	120-5235	1	Shaft-Spindle
5	121-9100	2	Sprocket
6	130-6664	1	Pulley-Brake, Spindle
7	109-9505	2	Washer-Spring
8	3296-19	2	Nut-Hex
9	63-7400	1	Washer-Rebound
10	120-6242	1	Arm-Brake
11	121-2305	2	Washer-Friction, Composite
12	120-9490	1	Spacer
13	9114524	1	Bolt-TAP, HH
14	3256-3	4	Washer-Flat
15	322-7	1	Screw-HH
16	3296-29	2	Nut-Lock, NI
17	131-4509	2	Kit-Pulley
18	120-3348	1	Bracket-Idler
19	120-7024	2	Screw-Shoulder, HHF
20	120-3335	1	Belt-Synchronous
21	120-5245-03	1	Guide-Belt, Spindle
22	120-5236	2	Adapter-Blade
23	121-5808	1	Spring-Extension, Brake
24	125-2466	2	Bolt-Blade
25	49-2040	2	Screw-HWHTF
26	120-7082	1	Pulley-Idler
27	322-6	1	Screw-HH
28	3296-47	1	Nut-Lock, NI
29	120-9500-03	2	Blade-Atomic, 15.4In
30	121-2336	1	Spring-Flat


Side Discharge Chute Assembly



Side Discharge Chute Assembly (continued)

Ref.	Part Number	Qty.	Description
1	112-8760	1	Decal-Danger
2	112-6416	1	Bracket-Cover
3	99-8445	2	Screw-HWH
4	99-5291	1	Rod-Cover
5	127-0721	1	Spring-Torsion, Cover
6	125-5091	1	Deflector-Side
7	127-6874	1	Side Discharge Chute ASM
8	95-2747	1	Fitting-Washout
9	46-8560	2	Screw-HHFTF
10	46-6290	1	O-Ring
11	95-3270	1	Connector-Hose
12	120-9570	1	Decal-Warning


Bag Assembly



Bag Assembly (continued)

Ref.	*Part Number*	*Qty.*	*Description*
1	121-5766-03	1	Frame-Bag
2	121-5770	1	Bag-Grass

Engine and Pulley Assembly




Engine and Pulley Assembly (continued)

Ref.	Part Number	Qty.	Description
1		1	Engine-Briggs, 121S070006F1 ●■
2	120-3333	1	Pulley-Engine
3	121-5765	1	V-Belt
4	120-9470	1	V-Belt, Traction
5	120-7077	1	Guide-Belt
6	95-1727	3	Screw-Taptite
7	3290-465	1	Washer-Belleville
8	26-0671	1	Screw-HH
11	32144-1	1	Screw-Taptite
12	131-0889-03	1	Guard-Engine
13	126-2713	2	Screw-HHF

● Not serviced separately

■ Obtain parts from www.briggsandstratton.com


Front Wheel and Axle Assembly



Front Wheel and Axle Assembly (continued)

Ref.	Part Number	Qty.	Description
1	46-8091	7	Screw-HWH
2	120-9535	1	Grip-Lever
3	104-8301	2	Nut-Flange, NI
4	125-2495	2	Bushing-Pivot, Front
5	131-0814	1	Axle-Front
6	120-7037-03	1	Plate-HOC, LH
7	120-7038-03	1	Plate-HOC, RH
8	120-7043	1	Arm-Spring
9	125-2510	2	8 Inch Wheel ASM
10	125-5027	1	Front Cover ASM
11	700057	1	Screw-HWH
12	3274-55	6	Screw-HSBH
13	3296-29	6	Nut-Lock, NI

Transmission, Rear Wheel and Height-of-Cut Assembly




Transmission, Rear Wheel and Height-of-Cut Assembly (continued)

Ref.	Part Number	Qty.	Description
1	1-633295	1	Grip-Lever, Lift
2	121-5799	1	Conduit-Convoluted
3	49-2040	2	Screw-HWHTF
4	104-8301	2	Nut-Flange, NI
5	104-8699	1	Bearing-Ball
7	106-5681	1	Pin-Stop
8	109-8020	2	Bearing-Ball
9	110-7191	2	Washer-Thrust
10	110-9417	2	Gear-Pinion, 15T
12	120-3342-03	1	Plate-HOC, LH
13	120-3343-03	1	Plate-HOC, RH
14	120-5208	1	Arm-Spring, Rear
15	120-5209	1	Key-Springarm
16	120-5210	2	Retainer-Bearing
17	130-6670	1	Transmission Kit
17:1		1	Transmission-Mv502●
17:1:1	130-2370	1	Transmission Pulley Kit
18	120-6233	2	Cover-Gear
19	131-0815	1	Axle-Rear
19	131-0815	1	Axle-Rear
20	125-2509	2	10 Inch Wheel Gear ASM
21	120-7008	1	Mount-Bearing
22	120-7026	1	Spring-Extension
23	120-7027	1	Spring-Extension
24	121-5800	2	Conduit-Convoluted
25	701243	8	Screw-HWHTF
26	32144-4	1	Screw-HWH
27	32151-61	1	Ring-Retaining
28	36-4780	2	Washer-Plain
29	121-5821	1	Bracket-Stop
30	3296-47	1	Nut-Lock, NI
31	125-2497	1	Decal-HOC, Rear
32	130-2369	2	Pin-Snap

● Not serviced separately

Handle Assembly



Handle Assembly (continued)

Ref.	Part Number	Qty.	Description
1	120-5204-05	1	Handle-Lower
2	121-5783-05	1	Handle-Upper
3	105-6842	1	Guide-LH
4	105-6841	1	Guide-RH
5	104-8678	1	Handle-Control
6	99-1588	1	Bar-Control, Traction
7	127-6842	1	Lever-Traction
8	120-7025	2	Bolt-Shoulder, HHF
9	32144-1	1	Screw-Taptite
10	120-6243	1	Cable-Brake, BBC
12	127-6867	1	Cable-Traction, Rwd
14	104-7953	1	Decal
15	3256-1	1	Washer-Flat
16	3296-73	1	Nut-Lock, NI
17	121-9118	1	Spring-Torsion
18	120-3911	1	Decal-Handle
19	108-3788-03	1	Bail-Brake
20	106-9169	1	Screw-HWH
21	107-7462	1	Spring-Torsion
22	107-7463	1	Spacer
23	106-6802	1	Lever
24	32128-17	1	Nut-Lock, Flange
25	112-8884	1	Knob-BBC
26	3290-337	1	Nut-Speed
27	3296-29	2	Nut-Lock, NI
28	92-2260	2	Screw-Handle
29	117-5976	2	Knob-Handle
30	114-7988	1	Guide-Cable
31	130-2343	1	Spacer
32	104-9368	3	Plug-Dome
33	120-7087	1	Handle-Assist, Traction
34	130-2356	2	Screw-Handle, Lock
35	130-2341	2	Nut-Acorn
36	106-8397	1	Battery-Wet
37	108-3795	1	Housing-Switch, Key
38	321-50	1	Screw-HH
39	92-7729	1	Anchor-Cable, Upper
40	23-0660	1	Switch-Starter
40:1	218-461	1	Nut-HH
40:2	3254-5	1	Washer-Tooth, Internal
41	108-3796	1	Cover-Swtch
42	32144-111	2	Screw-PPH
43	700918	1	Key
44	120-3947	1	Charger-Ce
45	108-9751	1	Decal-Switch, Ignition
46	117-0070	1	Harness-Wire
46:4	99-6124	1	Fuse-40 Amp
47	108-0987	1	Foam-Battery
49	120-3329	1	Cover-Battery
53	3256-23	2	Washer-Flat
55	131-0894	1	Decal-Traction, Adjust
56	131-0897	1	Knob-Handle, Locking
99	614249	2	Tie-Cable

Attachments and Accessories

For 20977 TimeMaster 76cm Lawn Mower

Product Name	Model/Part
Replacement Blade Kit	20120P
Lawn Striping Kit with 30in Roller	20602
Mower Cover	490-7461

Notes:

Notes:

Notes:



Count on it.