



Count on it.

Form No. 3410-514 Rev A

Parts Catalog

Electric Lift Kit

TM5490/TM7490 Trailed Mowers

Model No. 02861—Serial No. 400000000 and Up



Ordering Replacement Parts

To order replacement parts, please supply the part number, the quantity, and the description of each part desired.

Understanding Reference Numbers

Each identified part in an illustration has a reference number. The reference number for a part also appears in the parts list, along with other information about the part.

This catalog uses two special reference number formats, one to indicate parts in a service assembly and another to indicate the quantity of a given part in an illustration.

Service Assembly Reference Numbers

Parts in service assemblies have reference numbers in the form a:b. The a represents the reference number of the entire service assembly and the b represents a sequential number unique to each part within the service assembly.

For example, a wheel assembly might be identified by reference number 6, the tire by 6:1, the valve by 6:2, and the wheel by 6:3. When you order the assembly identified by reference number 6, you receive all parts identified by reference numbers 6:1, 6:2, and 6:3. However, you may also order any part individually. Reference numbers of this type appear in illustration and in parts lists.

Reference Numbers Indicating Quantity

In an illustration, if a reference number indicates more than one part, the reference number has the form nX y. The n represents the quantity of the part, the X is the multiplication symbol, and the y represents the reference number.

For example, in an illustration, the reference number 2X 37 means that two of the parts identified by reference number 37 are indicated.


Contents

Electric Lift Kit Assembly 4

Remote Control Assembly No. 111-1794 6

Electrical Control Box Assembly No. 111-1795 8

Electric Lift Kit Assembly




Electric Lift Kit Assembly (continued)

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>	<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
1	10-06-030	5	Seal-Dowty	35:3	HY768701	7	Solenoid-12V
2	111-2050	2	Bracket ●	35:4	953726	3	Valve-Check
3	111-1791	1	Electric Control Kit ●	35:4:1	953727	1	Seal Kit
3:1	111-1794	1	Remote Control ASM ●	35:5	768610	1	Valve-Override, Manual
3:2	111-1795	1	Electrical Control Box ASM	35:5:1	950704	1	Seal Kit
3:3	111-1790	1	Cable-Umbilical	36	HY768601	1	Tee ●
4	10-06-031	10	Seal-Dowty	37	HY768602	1	Hose
5	10-06-085	2	Adaptor	38	768605	1	Adaptor ●
6	60-06-011	1	Tee-BSP ●	39	768607	1	Hose ●
9	ZNH1H000U	4	Nut-Hex ●	40	HY768701	2	Solenoid-12V
10	03162	6	Screw-HH	41	950619	2	Line-Body
11	09-06-218	1	Coupling	42	953606	1	Adaptor-BSP ●
13	09364	2	Screw-HH ●	44	ZBH1H065U	1	Bolt
15	09438	2	Nut-Nyloc ●	45	ZBH1H075U	2	Bolt
16	09442	9	Nut	47	09546	4	Screw-Taptite
18	09472	4	Washer-Plain ●	49	111-5169	1	Sensor-Ferrious, Proximity ●
19	09475	18	Washer	50	111-3676	1	Spacer-Switch, Proximity ●
20	09479	1	Washer-Plain ●	51	111-5170-03	1	Sensor-Bracket, Proximity ●
22	10-06-033	1	Seal-Dowty ●	52	111-5171-03	1	Bracket-Actuator ●
23	30-06-200	1	Plug-HYD	53	ZDH1E020U	2	Screw-HH ●
25	50-06-207	2	Plug	54	09430	2	Nut-Nyloc ●
26	20-06-203	1	Adaptor-Tee	55	09470	4	Washer ●
27	65-05-121	1	Pin-Spring ●	56	65-07-053	1	Bushing ●
28	65-06-019	1	Adaptor ●	70	10-06-085	1	Adaptor
29	70-06-096	2	Valve-Solenoid (Closed)	71	66-06-004	1	Elbow-90 DEG
29:1	910642	1	Seal Kit ●	72	65-06-013	1	Cross
30	70-11-005	1	Pin-Split ●	73	50-06-009	2	Adaptor-BSP
31	65-06-303	1	Valve-Check	74	10-06-042	3	Adaptor-BSPP
33	767605	1	Valve-Cylinder ●	75	20-06-204	1	Elbow-90 DEG
33:1	65-06-341	1	Seal Kit(Rotary Valves) ●	76	767606	1	Adaptor-BSPP ●
34	768101W	1	Control Box-Bracket	77	65-07-049	2	Spring ●
35	768600	1	Manifold-Lift	78	66-06-111	1	Hose
35:1	70-06-096	6	Valve-Solenoid (Closed)	99	50-07-033	1	Tie-Cable ●
35:1:1	910642	1	Seal Kit	99	74-07-020	2	Tie-Cable ●
35:2	70-06-097	1	Valve-Solenoid (Open)	99	HY3966	8	Tie-Cable ●
35:2:1	910642	1	Seal Kit				

● Not illustrated

Remote Control Assembly No. 111-1794




Remote Control Assembly No. 111-1794 (continued)

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
1	111-1778	1	Enclosure ASM
3	111-1777	1	Decal
4	111-1779	1	Switch-Stop
5	70-09-001	5	Switch-Toggle
6	111-0336	1	Relay-30A

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
7	111-0348	6	Diode
8	111-1780	1	Green-LED
9	111-1849	1	Socket-Mount, Chassis
10	111-1895	4	Screw

Electrical Control Box Assembly No. 111-1795



Electrical Control Box Assembly No. 111-1795 (continued)

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
1	111-1899	1	Box-Drilled
2	111-1890	10	Cable
3	111-1883-03	1	Plate-Component, Mounting
4	111-0360	10	Base-Relay
5	111-0336	10	Relay-30A
6	995713	1	Relay-Neutral, Start
7	111-1884	1	Block-Terminal
8	111-1885	3	Block-Terminal
9	111-0348	13	Diode
10	111-1886	9	Screw

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
11	111-1887	2	Screw
12	111-1888	9	Screw
13	111-1895	6	Screw
14	09658	9	Washer
15	111-1911	1	Plug-Panel
16	111-1849	1	Socket-Mount, Chassis
17	HY3966	12	Tie-Cable ●
18	910850	1	Digital-Hourmeter
19	111-1882-03	1	Meter-Bracket, Hour
20	111-1780	1	Green-LED

● Not illustrated

Notes:

Notes:



Count on it.