



**Count on it.**

# Parts Catalog

**TRX-26**

**Trencher**

Model No. 22974—Serial No. 316000001 and Up



# Ordering Replacement Parts

To order replacement parts, please supply the part number, the quantity, and the description of each part desired.

## Understanding Reference Numbers

Each identified part in an illustration has a reference number. The reference number for a part also appears in the parts list, along with other information about the part.

This catalog uses two special reference number formats, one to indicate parts in a service assembly and another to indicate the quantity of a given part in an illustration.

## Service Assembly Reference Numbers

Parts in service assemblies have reference numbers in the form a:b. The a represents the reference number of the entire service assembly and the b represents a sequential number unique to each part within the service assembly.

For example, a wheel assembly might be identified by reference number 6, the tire by 6:1, the valve by 6:2, and the wheel by 6:3. When you order the assembly identified by reference number 6, you receive all parts identified by reference numbers 6:1, 6:2, and 6:3. However, you may also order any part individually. Reference numbers of this type appear in illustration and in parts lists.

## Reference Numbers Indicating Quantity


In an illustration, if a reference number indicates more than one part, the reference number has the form nX y. The n represents the quantity of the part, the X is the multiplication symbol, and the y represents the reference number.

For example, in an illustration, the reference number 2X 37 means that two of the parts identified by reference number 37 are indicated.

# Contents

|                                                       |    |
|-------------------------------------------------------|----|
| Main Frame Assembly . . . . .                         | 4  |
| Tower, Control Panel and Fuel Tank Assembly . . . . . | 6  |
| Track Drive Assembly . . . . .                        | 8  |
| Hydraulic Pump Assembly No. 117-6409 . . . . .        | 10 |
| Hydraulic Pump Assembly No. 117-6410 . . . . .        | 12 |
| Hydraulic Motor Assembly No. 104-8470 . . . . .       | 14 |
| Parking Brake Assembly . . . . .                      | 16 |
| Engine, Muffler and Fuel Line Assembly. . . . .       | 18 |
| Gear Pump and Mount Assembly . . . . .                | 20 |
| Gear Pump Assembly No. 117-6307. . . . .              | 22 |
| 2-Spool Valve and Hydraulic Motor Assembly . . . . .  | 24 |
| 2-Spool Valve Assembly No. 115-4062 . . . . .         | 26 |
| Oil Cooler Assembly . . . . .                         | 28 |
| Trencher Head and Auger Assembly . . . . .            | 30 |
| Traction Control Assembly . . . . .                   | 32 |
| Battery and Wire Harness Assembly. . . . .            | 34 |
| Cylinder and Crankcase Assembly . . . . .             | 36 |
| Piston and Crankshaft Assembly . . . . .              | 37 |
| Valve and Camshaft Assembly. . . . .                  | 38 |
| Lubrication Equipment Assembly . . . . .              | 39 |
| Cooling Equipment Assembly . . . . .                  | 40 |
| Electric Equipment Assembly. . . . .                  | 41 |
| Carburetor Assembly . . . . .                         | 42 |
| Control Equipment Assembly . . . . .                  | 44 |
| Air Filter and Muffler Assembly. . . . .              | 45 |
| Fuel Tank and Valve Assembly. . . . .                 | 46 |
| Starter Assembly . . . . .                            | 47 |
| Label Set . . . . .                                   | 48 |
| Attachments and Accessories . . . . .                 | 49 |


# Main Frame Assembly



## Main Frame Assembly (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>  | <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i> |
|-------------|--------------------|-------------|---------------------|-------------|--------------------|-------------|--------------------|
| 1           | 127-9602           | 1           | Main Frame ASM      | 20          | 119-4566-03        | 1           | Plate-Cover, Front |
| 1:2         | 100-4650           | 1           | Decal-Warning       | 21          | 3234-18            | 3           | Screw-HHF          |
| 1:3         | 93-7814            | 2           | Decal-Danger        | 22          | 107-3154           | 5           | Nut-Push           |
| 1:4         | 93-6686            | 1           | Decal-Oil, HYD      | 23          | 100-4860           | 1           | Bracket-Clamp      |
| 2           | 114-3075           | 1           | Sight Glass ASM     | 24          | 93-5023            | 1           | Spacer             |
| 2:1         | 237-79             | 1           | O-Ring              | 25          | 322-10             | 1           | Screw-HH           |
| 3           | 354-120            | 1           | Fitting-HYD, 90 DEG | 26          | 32128-20           | 1           | Nut-HF             |
| 3:1         | 237-79             | 1           | O-Ring              | 27          | 323-12             | 1           | Screw-HH           |
| 9           | 114-3039           | 1           | In-Tank Filter ASM  | 28          | 32128-40           | 2           | Nut-Flange         |
| 10          | 114-3042           | 1           | Hose-Breather       | 29          | 115-6503-01        | 1           | Cover-Rear         |
| 11          | 68-6150            | 1           | Breather            | 30          | 3234-11            | 2           | Screw-HHF          |
| 12          | 2412-36            | 2           | Clamp-Hose          | 31          | 117-6407-01        | 1           | Bracket-Fuel Tank  |
| 15          | 93-9084            | 2           | Decal-Point, Lift   | 32          | 117-6417           | 1           | Pad-Foam           |
| 17          | 1-523420           | 1           | Bumper              | 34          | 3296-42            | 2           | Nut-Lock, NI       |
| 18          | 32128-33           | 1           | Nut-HF              | 35          | 321-6              | 2           | Screw-HH           |
| 19          | 105-4886           | 5           | Nut-Tinnerman       |             |                    |             |                    |


# Tower, Control Panel and Fuel Tank Assembly



## Tower, Control Panel and Fuel Tank Assembly (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>     | <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>    |
|-------------|--------------------|-------------|------------------------|-------------|--------------------|-------------|-----------------------|
| 1           | 117-6419-01        | 1           | Tower                  | 24          | 3229-1             | 2           | Bolt-CARR             |
| 2           | 3234-11            | 8           | Screw-HHF              | 25          | 3256-22            | 4           | Washer-Flat           |
| 3           | 32128-40           | 8           | Nut-Flange             | 26          | 32149-2            | 2           | Nut-Keps              |
| 4           | 100-1268           | 1           | Switch-Plunger         | 27          | 114-3012-03        | 1           | Plate-Reverse         |
| 5           | 120-7358           | 1           | Tank-Fuel              | 28          | 114-1337           | 2           | Spacer-Spring         |
| 5:1         | 103-2605           | 1           | Fitting-Fuel, Bulkhead | 29          | 98-8425            | 1           | Spring-Torsion, LH    |
| 6           | 114-0284           | 1           | Grommet                | 30          | 98-8424            | 1           | Spring-Torsion, RH    |
| 7           | 114-0285           | 1           | Valve-Rollover         | 31          | 323-11             | 2           | Screw-HH              |
| 8           | 120-5461           | 1           | Cap-Fuel, Ratcheting   | 32          | 256-257            | 2           | Bushing-Nyliner       |
| 9           | 114-3065-01        | 1           | Bracket-Cover, Tank    | 33          | 3256-24            | 2           | Washer-Flat           |
| 10          | 107-7507           | 1           | Pad-Foam               | 34          | 3296-39            | 2           | Nut-Lock, NI          |
| 11          | 2412-120           | 2           | Clamp-R                | 35          | 117-6389           | 1           | Panel-Control         |
| 12          | 104-7050           | 1           | Tube-Manual            | 35:2        | 115-1231           | 1           | Decal-Console, RH     |
| 13          | 104-7048           | 1           | Cap-Housing            | 35:3        | 115-1230           | 1           | Decal-Console, LH     |
| 14          | 3269-17            | 2           | Rivet-Pop              | 36          | 106-7715           | 1           | Bar-Reference         |
| 15          | 322-5              | 2           | Screw-HH               | 37          | 95-1726            | 4           | Screw-Taptite         |
| 16          | 3296-29            | 2           | Nut-Lock, NI           | 40          | 105-1217           | 1           | Decal                 |
| 17          | 3210-7             | 1           | Screw-HH               | 43          | 117-6415           | 1           | Decal-Side, LH        |
| 18          | 3220-2             | 1           | Nut-Jam                | 44          | 120-7533           | 1           | Decal-Info            |
| 19          | 100-1263           | 1           | Plate-Switch           | 45          | 114-8727           | 1           | Rod-Interlock         |
| 20          | 100-1270           | 1           | Switch-Proximity       | 46          | 85-6750            | 1           | Spring-Control        |
| 21          | 3229-20            | 2           | Screw-CARR             | 47          | 88-7200            | 1           | Washer-Flat           |
| 22          | 3256-51            | 2           | Washer-Flat            | 48          | 3290-307           | 1           | Pin-Cotter            |
| 23          | 32149-7            | 2           | Nut-Keps               | 50          | 117-2718           | 1           | Decal-Arrester, Spark |


# Track Drive Assembly



## Track Drive Assembly (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>     | <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>    |
|-------------|--------------------|-------------|------------------------|-------------|--------------------|-------------|-----------------------|
| 1           | 115-1289-03        | 2           | Bracket-Mount, Pump    | 22          | 106-7557           | 12          | Cap-Wheel, Bearing    |
| 2           | 117-6409           | 1           | RH HYD Pump ASM        | 23          | 106-7595           | 12          | Ring-Snap, Internal   |
| 3           | 340-4              | 4           | Fitting-HYD, Straight  | 24          | 114-3077-03        | 2           | Tensioner-Track       |
| 3:1         | 237-30             | 1           | O-Ring                 | 25          | 3256-26            | 4           | Washer-Flat           |
| 3:2         | 237-79             | 1           | O-Ring                 | 26          | 325-8              | 4           | Screw-HH              |
| 4           | 340-77             | 2           | Fitting-HYD, 90 DEG    | 27          | 3296-45            | 4           | Nut-Lock, NI          |
| 4:1         | 237-22             | 1           | O-Ring                 | 28          | 112-4874           | 2           | Screw-HH, TAP         |
| 4:2         | 237-42             | 1           | O-Ring                 | 29          | 3217-11            | 2           | Nut-Hex               |
| 5           | 100-4887           | 1           | Fitting-Barbed, 90 DEG | 30          | 104-8470           | 2           | HYD Wheel Motor ASM   |
| 5:1         | 237-42             | 1           | O-Ring                 | 31          | 340-6              | 4           | Fitting-HYD, Straight |
| 6           | 117-6410           | 1           | LH HYD Pump ASM        | 31:1        | 237-30             | 1           | O-Ring                |
| 7           | 340-86             | 1           | Fitting-Tee            | 31:2        | 237-80             | 1           | O-Ring                |
| 7:1         | 237-22             | 2           | O-Ring                 | 32          | 3234-27            | 8           | Screw-HHF             |
| 7:2         | 237-42             | 1           | O-Ring                 | 33          | 114-2992-03        | 1           | Frame-Track, LH       |
| 8           | 324-5              | 4           | Screw-HH               | 34          | 3234-6             | 10          | Screw-HHF             |
| 9           | 32128-42           | 4           | Nut-HF                 | 35          | 114-3091           | 2           | Bar-Thread            |
| 10          | 80-6090            | 2           | Key-Pump               | 36          | 117-6426-03        | 2           | Wheel-Drive           |
| 11          | 115-4002           | 2           | Spacer                 | 37          | 106-8159           | 2           | Nut-Lock              |
| 12          | 115-1298           | 2           | Sheave                 | 38          | 340-3              | 1           | Adapter               |
| 13          | 108-4211           | 2           | Bushing                | 38:1        | 237-22             | 1           | O-Ring                |
| 14          | 73-3580            | 2           | Washer                 | 38:2        | 237-79             | 1           | O-Ring                |
| 15          | 33103-016          | 2           | Screw-HHF              | 39          | 115-1285           | 1           | Tube-HYD              |
| 16          | 325-4              | 4           | Screw-HH               | 40          | 115-1286           | 1           | Tube-HYD              |
| 17          | 32128-49           | 8           | Nut-HHF                | 41          | 115-1287           | 1           | Tube-HYD              |
| 18          | 114-2993-03        | 1           | Frame-Track, RH        | 42          | 115-1288           | 1           | Tube-HYD              |
| 19          | 112-4817           | 12          | Wheel-Tensioner        | 43          | 115-1297           | 1           | Hose-HYD              |
| 19:1        | 114-3014-03        | 1           | Wheel-Track            | 44          | 117-1305           | 1           | Tube-HYD              |
| 19:2        | 120-5378           | 1           | Bearing-Ball           | 45          | 115-4083           | 1           | Hose                  |
| 20          | 106-7585           | 12          | Gasket-Bogie           | 46          | 2412-36            | 2           | Clamp-Hose            |
| 21          | 327-4              | 12          | Screw-HH               | 47          | 112-4816           | 2           | Track-Rubber          |

# Hydraulic Pump Assembly No. 117-6409




# Hydraulic Pump Assembly No. 117-6409 (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>     | <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>              |
|-------------|--------------------|-------------|------------------------|-------------|--------------------|-------------|---------------------------------|
| 1           | 115-4464           | 1           | Housing Kit            | 29          | 94-1936            | 1           | Spring-Block                    |
| 3           | 106-8753           | 2           | Pin-Headless, Straight | 30          | 94-1937            | 1           | Washer-Thrust                   |
| 4           | 106-8754           | 4           | Bolt-HF                | 31          | 105-6185           | 1           | Plate-Valve                     |
| 5           | 106-8755           | 1           | O-Ring                 | 32          | 94-1907            | 1           | Swashplate-Variable             |
| 6           | 106-8756           | 1           | Charge Pump Kit        | 34          | 94-6922            | 1           | Bearing-Thrust                  |
| 7           | 104-2122           | 1           | Gerotor ASM            | 37          | 115-4458           | 1           | Arm-Trunnion, Tapered<br>Square |
| 8           | 106-8757           | 1           | O-Ring                 | 38          | 94-1910            | 1           | Guide-Slot                      |
| 10          | 104-2111           | 2           | Capscrew               | 42          | 98-3252            | 2           | Valve-Check (W/Poppet)          |
| 15          | 106-8759           | 1           | Bypass Valve Kit       | 44          | 106-8760           | 1           | Charge Relief Valve Kit         |
| 18          | 103-2664           | 1           | Input Shaft Kit        | 49          | 114-8155           | 1           | Trunnion Seal Kit               |
| 19          | 104-5311           | 1           | Bearing-Ball           | 56          | 106-8762           | 1           | Plug-HSH                        |
| 20          | 104-5310           | 1           | Seal-Lip               | 66          | 106-8763           | 1           | Plug-HSH                        |
| 21          | 104-5308           | 1           | Spacer                 | 99          | 105-6184           | 1           | Seal Overhaul Kit ●             |
| 22          | 104-5309           | 1           | Ring-Retaining         |             |                    |             |                                 |
| 25          | 103-2666           | 1           | Cylinder Block Kit     |             |                    |             |                                 |

● Not illustrated

# Hydraulic Pump Assembly No. 117-6410




# Hydraulic Pump Assembly No. 117-6410 (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>     |
|-------------|--------------------|-------------|------------------------|
| 1           | 115-4464           | 1           | Housing Kit            |
| 3           | 106-8753           | 2           | Pin-Headless, Straight |
| 4           | 106-8754           | 4           | Bolt-HF                |
| 5           | 106-8755           | 1           | O-Ring                 |
| 6           | 106-8756           | 1           | Charge Pump Kit        |
| 7           | 104-2122           | 1           | Gerotor ASM            |
| 8           | 106-8757           | 1           | O-Ring                 |
| 10          | 104-2111           | 2           | Capscrew               |
| 15          | 106-8759           | 1           | Bypass Valve Kit       |
| 18          | 103-2664           | 1           | Input Shaft Kit        |
| 19          | 104-5311           | 1           | Bearing-Ball           |
| 20          | 104-5310           | 1           | Seal-Lip               |
| 21          | 104-5308           | 1           | Spacer                 |
| 22          | 104-5309           | 1           | Ring-Retaining         |
| 25          | 103-2666           | 1           | Cylinder Block Kit     |

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>           |
|-------------|--------------------|-------------|------------------------------|
| 29          | 94-1936            | 1           | Spring-Block                 |
| 30          | 94-1937            | 1           | Washer-Thrust                |
| 31          | 105-6185           | 1           | Plate-Valve                  |
| 32          | 94-1907            | 1           | Swashplate-Variable          |
| 34          | 94-6922            | 1           | Bearing-Thrust               |
| 37          | 115-4458           | 1           | Arm-Trunnion, Tapered Square |
| 38          | 94-1910            | 1           | Guide-Slot                   |
| 42          | 98-3252            | 2           | Valve-Check (W/Poppet)       |
| 44          | 106-8760           | 1           | Charge Relief Valve Kit      |
| 49          | 114-8155           | 1           | Trunnion Seal Kit            |
| 56          | 106-8762           | 1           | Plug-HSH                     |
| 66          | 106-8763           | 1           | Plug-HSH                     |
| 99          | 105-6184           | 1           | Seal Overhaul Kit ●          |

● Not illustrated

# Hydraulic Motor Assembly No. 104-8470




## Hydraulic Motor Assembly No. 104-8470 (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i> |
|-------------|--------------------|-------------|--------------------|
| 1           | 115-4061           | 1           | Seal Kit           |
| 2           | 3257-42            | 1           | Key-Woodruff       |

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i> |
|-------------|--------------------|-------------|--------------------|
| 3           | 99-3090            | 1           | Shaft-Coupling     |
| 4           | 120-5395           | 1           | Motor Housing ASM  |


# Parking Brake Assembly



## Parking Brake Assembly (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>    | <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>  |
|-------------|--------------------|-------------|-----------------------|-------------|--------------------|-------------|---------------------|
| 1           | 117-6421-03        | 1           | Handle-Brake          | 6           | 114-2975           | 1           | Link-Mounting       |
| 2           | 7-0030             | 1           | Screw-Shoulder, HH    | 7           | 114-2972-03        | 1           | Bar-Brake           |
| 3           | 32128-20           | 1           | Nut-HF                | 8           | 114-8629           | 1           | Bolt-Shoulder       |
| 4           | 103-4335           | 1           | Brake Rod ASM         | 9           | 3296-47            | 2           | Nut-Lock, NI        |
| 4:1         | 1-633131           | 2           | Yoke-Linkage, Brake   | 10          | 27-7211            | 1           | Screw-Shoulder      |
| 4:2         | 103-3907           | 1           | Linkage-Handle, Brake | 11          | 67-1450            | 1           | Spring-Idler        |
| 4:3         | 3219-3             | 2           | Nut-Hex               | 12          | 62-9130            | 1           | Grip-Handle         |
| 5           | 103-2399           | 1           | Pin-Spring, Clevis    | 13          | 107-8495           | 1           | Decal-Parking Brake |


# Engine, Muffler and Fuel Line Assembly



## Engine, Muffler and Fuel Line Assembly (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>      | <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i> |
|-------------|--------------------|-------------|-------------------------|-------------|--------------------|-------------|--------------------|
| 1           | 117-6305           | 1           | Engine-Kawasaki, Fx730V | 20          | 92-6877            | 1           | Valve-Drain, Oil   |
| 2           | 1-653313           | 2           | Gasket-Exhaust          | 21          | 106-5709           | 1           | Hose-Vent          |
| 3           | 120-7535           | 1           | Manifold, Muffler       | 22          | 2412-36            | 1           | Clamp-Hose         |
| 4           | 115-9227           | 1           | Plate-Shield, Heat      | 23          | 2412-81            | 1           | Clamp-R            |
| 5           | 115-6496           | 4           | Washer-Spring           | 24          | 322-4              | 1           | Screw-HH           |
| 6           | 115-6611           | 4           | Nut-Hex                 | 25          | 32128-20           | 1           | Nut-HF             |
| 7           | 115-6488           | 1           | Clamp                   | 26          | 323-8              | 2           | Screw-HH           |
| 8           | 115-6494           | 1           | Screw-Pan               | 27          | 109-0306           | 1           | Hose-Fuel          |
| 9           | 115-6495           | 1           | Nut-Hex                 | 28          | 1-603770           | 1           | Valve-Fuel         |
| 10          | 115-9233-03        | 1           | Bracket-Mount, Muffler  | 29          | 2412-98            | 4           | Clamp-Hose         |
| 11          | 33114-016          | 2           | Screw-HH                | 30          | 109-0295           | 1           | Hose-Fuel          |
| 12          | 120-7536           | 1           | Muffler                 | 31          | 117-6396           | 1           | Hose-Vent, Tank    |
| 13          | 131-0602-03        | 1           | Guard-Muffler           | 32          | 110-5547           | 1           | Lever-Control      |
| 14          | 131-0604           | 1           | Foil-Guard              | 33          | 3256-21            | 4           | Washer-Flat        |
| 15          | 33103-016          | 1           | Screw-HHF               | 34          | 3290-134           | 4           | Screw              |
| 16          | 33114-020          | 3           | Screw-HH                | 35          | 3296-2             | 4           | Nut-Lock, NI       |
| 17          | 112-2844           | 3           | Nut-HF                  | 36          | 115-1211           | 2           | Cable-Control      |
| 18          | 2112-11            | 1           | Clamp-Muffler           | 37          | 108-9730           | 1           | Lever-Control      |
| 19          | 103-1966           | 1           | Adapter                 | 38          | 233-42             | 2           | Knob               |


# Gear Pump and Mount Assembly



## Gear Pump and Mount Assembly (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i> | <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>         |
|-------------|--------------------|-------------|--------------------|-------------|--------------------|-------------|----------------------------|
| 1           | 115-1480-03        | 1           | Mount-Pump         | 20          | 125-0251           | 1           | Spacer-Idler               |
| 2           | 117-6307           | 1           | Gear Pump ASM      | 21          | 114-0463           | 2           | Washer-Friction, Composite |
| 3           | 99-3017            | 2           | Fitting            | 22          | 1-413088           | 1           | Bushing-Lever, Lift        |
| 3:1         | 237-81             | 1           | O-Ring             | 23          | 125-0252           | 1           | Arm-Idler                  |
| 4           | 340-22             | 1           | Fitting-HYD, Tee   | 24          | 104-8426           | 1           | Spacer                     |
| 4:1         | 237-65             | 2           | O-Ring             | 25          | 121-4523           | 1           | Spring-Extension           |
| 4:2         | 237-80             | 1           | O-Ring             | 26          | 614672             | 1           | Bolt-Shoulder              |
| 6           | 86-5860            | 1           | Nipple             | 27          | 3296-59            | 1           | Nut-Lock, NI               |
| 7           | 354-79             | 1           | Cap-Dust           | 28          | 95-8802            | 1           | Pulley-Idler               |
| 8           | 324-6              | 2           | Screw-HH           | 29          | 3256-24            | 1           | Washer-Flat                |
| 9           | 121-4517           | 1           | Washer-Wave        | 30          | 3234-11            | 1           | Screw-HHF                  |
| 10          | 115-7210           | 1           | Washer-Thrust      | 31          | 110-9981           | 1           | Washer-Plain               |
| 11          | 27-8590            | 1           | Key-Square         | 32          | 323-14             | 1           | Screw-HH                   |
| 12          | 114-2933           | 1           | Coupler-Flex       | 33          | 104-8301           | 1           | Nut-Flange, NI             |
| 12:1        | 100-7594           | 1           | Screw-Set          | 34          | 323-9              | 1           | Screw-HH                   |
| 13          | 93-8827            | 1           | Coupler-Spider     | 35          | 3290-357           | 2           | Nut-HHF, Whiz              |
| 14          | 114-8559-03        | 1           | Pulley-Engine      | 36          | 114-2991           | 1           | Belt-V                     |
| 15          | 608006             | 1           | Key-Square         | 37          | 114-2917           | 1           | Hose-Suction               |
| 16          | 3246-6             | 2           | Screw-Set, HSH     | 38          | 2412-111           | 2           | Clamp                      |
| 17          | 323-8              | 2           | Screw-HH           | 39          | AU112950           | 2           | Protector-Hose, 4 Inch     |
| 18          | 322-5              | 2           | Screw-HH           | 40          | 3290-378           | 3           | Tie-Cable                  |
| 19          | 32128-20           | 2           | Nut-HF             |             |                    |             |                            |


**Gear Pump Assembly No. 117-6307**



## Gear Pump Assembly No. 117-6307 (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i> |
|-------------|--------------------|-------------|--------------------|
| 1           | 115-1265           | 1           | Seal Kit           |


# 2-Spool Valve and Hydraulic Motor Assembly



## 2-Spool Valve and Hydraulic Motor Assembly (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>      | <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>    |
|-------------|--------------------|-------------|-------------------------|-------------|--------------------|-------------|-----------------------|
| 1           | 115-4062           | 1           | HYD Valve ASM           | 24          | 3256-26            | 2           | Washer-Flat           |
| 2           | 340-133            | 2           | Adapter ASM             | 25          | 33114-060          | 1           | Screw-HH              |
| 2:1         | 237-79             | 1           | O-Ring                  | 26          | 3234-14            | 1           | Screw-HHF             |
| 2:2         | 237-21             | 1           | O-Ring                  | 27          | 3290-467           | 2           | Pin-Hair              |
| 3           | 340-4              | 2           | Fitting-HYD, Straight   | 28          | 233-21             | 1           | Knob                  |
| 3:1         | 237-30             | 1           | O-Ring                  | 29          | 120-7352           | 1           | Pin-Pivot             |
| 3:2         | 237-79             | 1           | O-Ring                  | 30          | 321-18             | 1           | Screw-HH              |
| 4           | 340-155            | 1           | Fitting-HYD, Straight   | 32          | 302-5              | 1           | Fitting-Grease        |
| 4:1         | 237-79             | 1           | O-Ring                  | 33          | 121-1955           | 1           | HYD Cylinder ASM      |
| 4:2         | 237-151            | 1           | O-Ring                  | 34          | 340-82             | 1           | Fitting-HYD, 90       |
| 5           | 353-954            | 1           | Adapter                 | 34:1        | 237-42             | 1           | O-Ring                |
| 5:1         | 237-79             | 1           | O-Ring                  | 34:2        | 237-21             | 1           | O-Ring                |
| 6           | 340-3              | 1           | Adapter                 | 35          | 115-4081           | 1           | Valve-Check           |
| 6:1         | 237-22             | 1           | O-Ring                  | 35:1        | 237-42             | 1           | O-Ring                |
| 6:2         | 237-79             | 1           | O-Ring                  | 35:2        | 237-22             | 1           | O-Ring                |
| 7           | 237-42             | 1           | O-Ring                  | 36          | 340-159            | 1           | Fitting-HYD, 90 DEG   |
| 8           | 72-4310            | 1           | Switch-Ball             | 36:1        | 237-22             | 2           | O-Ring                |
| 9           | 322-12             | 3           | Screw-HH                | 37          | 114-3043           | 1           | Hose-HYD              |
| 10          | 3296-29            | 7           | Nut-Lock, NI            | 38          | 114-3044           | 1           | Hose-HYD              |
| 11          | 104-2827           | 1           | Spacer-Hiflo            | 39          | 114-3045           | 1           | Hose-HYD              |
| 12          | 33114-035          | 1           | Screw-HH                | 40          | 114-3046           | 1           | Hose-HYD              |
| 13          | 112-2738           | 1           | Spring-Torsion          | 41          | 114-3085           | 1           | Hose-HYD              |
| 14          | 112-2739           | 1           | Lever-Auxiliary         | 42          | 117-4038           | 1           | Hose-HYD              |
| 15          | 3256-16            | 1           | Washer-Flat             | 43          | 99-5648            | 2           | Sleeve-Protective     |
| 16          | 3296-42            | 2           | Nut-Lock, NI            | 44          | 115-4064           | 1           | Sleeve-Protective     |
| 17          | 112-2605           | 1           | Grip-Rubber             | 45          | 3334-945           | 8           | Tie-Cable             |
| 18          | 20-1620            | 2           | Bearing-Wheel, Friction | 46          | 117-6306           | 1           | Hydraulic Motor ASM   |
| 19          | 322-3              | 4           | Screw-HH                | 47          | 325-6              | 2           | Screw-HH              |
| 20          | 103-0384           | 1           | Spacer                  | 48          | 340-6              | 2           | Fitting-HYD, Straight |
| 21          | 115-1273           | 1           | Bearing-Rod End         | 48:1        | 237-30             | 1           | O-Ring                |
| 22          | 112-7210           | 1           | Bracket-Control         | 48:2        | 237-80             | 1           | O-Ring                |
| 23          | 114-8598           | 1           | Rod-Lever, Cylinder     | 49          | 3253-7             | 2           | Washer-Lock           |

# 2-Spool Valve Assembly No. 115-4062




## 2-Spool Valve Assembly No. 115-4062 (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i> |
|-------------|--------------------|-------------|--------------------|
| 1           | 106-7719           | 4           | Seal-Valve         |
| 3           | 100-8805           | 1           | Valve-Relief       |
| 4           | 115-4084           | 1           | Spool-Valve        |
| 5           | 106-7572           | 1           | Spool              |
| 6           | 100-7229           | 2           | Lever Kit          |
| 7           | 115-4092           | 1           | Spring Return Kit  |

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>       |
|-------------|--------------------|-------------|--------------------------|
| 8           | 115-4093           | 1           | Switch Spring Return Kit |
| 9           | 115-4097           | 1           | Seal-Return              |
| 10          | 115-4094           | 1           | Spacer-Square            |
| 11          | 115-4089           | 1           | Spacer-Spring Return     |
| 12          | 115-4088           | 1           | Gasket-Return            |


# Oil Cooler Assembly



## Oil Cooler Assembly (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i> | <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>   |
|-------------|--------------------|-------------|--------------------|-------------|--------------------|-------------|----------------------|
| 1           | 115-9240-01        | 1           | Mount-Cooler       | 9           | 3296-29            | 4           | Nut-Lock, NI         |
| 2           | 120-7390           | 2           | Fan                | 11          | 115-1207           | 1           | Hose-Return          |
| 3           | 321-3              | 12          | Screw-HH           | 12          | 117-3966           | 1           | Hose-Cooler          |
| 4           | 104-7201           | 16          | Nut-Flange, NI     | 13          | 2412-129           | 4           | Clamp-Hose           |
| 5           | 105-5723           | 4           | Spacer-Tube        | 14          | 3334-945           | 3           | Tie-Cable            |
| 6           | 131-0733           | 8           | Clamp              | 15          | 119-4633-01        | 1           | Cover-Cooler         |
| 7           | 117-6320           | 1           | Cooler-Oil         | 16          | 32104-95           | 4           | Screw-HWH            |
| 8           | 322-11             | 4           | Screw-HH           | 17          | 131-0642           | 4           | Plate-Support, Clamp |


# Trencher Head and Auger Assembly



## Trencher Head and Auger Assembly (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i> | <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>  |
|-------------|--------------------|-------------|--------------------|-------------|--------------------|-------------|---------------------|
| 1           | 117-6423           | 1           | Trencher Head ASM  | 17          | 115-4001-03        | 1           | Plate-Strap, Shield |
| 1:2         | 99-9952            | 2           | Decal-Danger       | 18          | 117-6316-03        | 1           | Bar-Clamp           |
| 2           | 120-7352           | 1           | Pin-Pivot          | 19          | 115-4049           | 2           | Screw-HSH           |
| 3           | 321-18             | 1           | Screw-HH           | 20          | 106-8871           | 1           | Bearing-Ball        |
| 4           | 3296-42            | 1           | Nut-Lock, NI       | 21          | 114-2955           | 1           | Seal-Grease         |
| 5           | 302-5              | 3           | Fitting-Grease     | 22          | 117-6308           | 1           | Shaft-Trencher      |
| 6           | 121-4571           | 1           | Spacer-Pivot       | 23          | 112-4979           | 1           | Spacer              |
| 7           | 104-9216           | 2           | Washer-Hardened    | 24          | 111199             | 1           | Bearing-Ball        |
| 8           | 117-6327           | 1           | Bolt-HH            | 25          | 114-2956           | 1           | Lockwasher-Bearing  |
| 9           | 3296-53            | 1           | Nut-Lock, NI       | 26          | 88-1450            | 1           | Locknut-Bearing     |
| 10          | 302-34             | 1           | Fitting-Lube       | 27          | 117-6315           | 1           | Collar-Splined      |
| 11          | 115-1279-03        | 1           | Bracket-Shield     | 28          | 104-1964           | 1           | Sprocket-Trencher   |
| 12          | 322-5              | 8           | Screw-HH           | 29          | 3274-4             | 6           | Screw-HSH           |
| 13          | 3296-29            | 11          | Nut-Lock, NI       | 30          | 117-8852-03        | 1           | Auger-Trencher      |
| 14          | 322-23             | 1           | Screw-HH           | 31          | 325-13             | 1           | Screw-HH            |
| 15          | 3256-3             | 4           | Washer-Flat        | 32          | 117-3479           | 2           | Washer-Saddle       |
| 16          | 117-6317           | 1           | Shield-Dirt        | 33          | 3296-23            | 1           | Nut-Lock, NI        |


# Traction Control Assembly



## Traction Control Assembly (continued)


| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>  | <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>         |
|-------------|--------------------|-------------|---------------------|-------------|--------------------|-------------|----------------------------|
| 1           | 27-2320            | 2           | Bearing             | 28          | 108-0634           | 4           | Spacer-Plate, Retaining    |
| 2           | 106-5737           | 1           | Control Support ASM | 29          | 103-1167           | 2           | Joint-Ball End, LH         |
| 2:2         | 256-252            | 2           | Bearing-Flange      | 30          | 3274-2             | 2           | Screw-HSH                  |
| 3           | 95-3703            | 2           | Washer-Spring, Wave | 31          | AU107344           | 2           | Screw-Jack, Control        |
| 4           | 3256-39            | 2           | Washer-Flat         | 32          | 3220-3             | 2           | Nut-HJ                     |
| 5           | 322-3              | 4           | Screw-HH            | 33          | 115-6549           | 1           | Plate-Base, LH             |
| 6           | 3296-29            | 6           | Nut-Lock, NI        | 34          | 256-116            | 8           | Bushing-Flange             |
| 7           | 117-6335           | 1           | Rod-Drive           | 35          | 115-6637           | 1           | Pivot-LH                   |
| 8           | 257-8              | 1           | Washer-Thrust       | 36          | 114-8629           | 4           | Bolt-Shoulder              |
| 9           | 112-2783           | 1           | Lever-Pivot         | 37          | 3296-47            | 10          | Nut-Lock, NI               |
| 10          | 115-1204           | 1           | Plate-Neutral       | 38          | 115-6628           | 1           | Plate-Arm, Return, LH      |
| 11          | 321-4              | 1           | Screw-HH            | 39          | 322-5              | 2           | Screw-HH                   |
| 12          | 3296-42            | 1           | Nut-Lock, NI        | 40          | 3253-4             | 2           | Washer-Lock                |
| 13          | 108-9743           | 3           | Washer-Plain        | 41          | 251-259            | 2           | Bearing-Ball               |
| 14          | 98-8407            | 1           | Lever-Return, RH    | 42          | 115-1290           | 2           | Plate-Adapter, Control, RH |
| 15          | 98-8408            | 1           | Lever-Return, LH    | 43          | 322-4              | 4           | Screw-HH                   |
| 16          | 32151-91           | 1           | Ring-Retaining      | 44          | 117-6429           | 2           | Lock-Trunion               |
| 17          | 63-2650            | 2           | Screw-Shoulder      | 45          | 3256-3             | 2           | Washer-Flat                |
| 18          | 108-4724           | 1           | Spring-Extension    | 46          | 94-3559            | 2           | Screw-HSH                  |
| 19          | 323-8              | 1           | Screw-HH            | 47          | 121-4409           | 2           | Spring-Extension           |
| 20          | 3296-39            | 3           | Nut-Lock, NI        | 48          | 115-6535           | 1           | Plate-Base, RH             |
| 21          | 120-5380-03        | 1           | Handle-Control      | 49          | 115-6636           | 1           | Pivot-RH                   |
| 22          | 3247-6             | 2           | Screw-Set           | 50          | 115-6536           | 1           | Plate-Arm, Return          |
| 23          | 3218-3             | 2           | Nut-Jam             | 51          | 3290-456           | 2           | Washer-Belleville          |
| 24          | 115-4020           | 1           | Decal-Traction      | 52          | 3273-14            | 2           | Screw-HSH                  |
| 25          | 98-1459            | 1           | Decal               | 53          | 131-0668           | 1           | Link-Steering, LH          |
| 26          | 3234-18            | 1           | Screw-HHF           | 54          | 131-0669           | 1           | Link-Steering, RH          |
| 27          | 32128-43           | 1           | Nut-Flange          | 55          | AU129-289          | 2           | Nut-Jam, LH                |

# Battery and Wire Harness Assembly



## Battery and Wire Harness Assembly (continued)


| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>     | <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>       |
|-------------|--------------------|-------------|------------------------|-------------|--------------------|-------------|--------------------------|
| 1           | 117-6338           | 1           | Harness-Wire           | 13          | 3234-6             | 2           | Screw-HHF                |
| 1:1         | 109103             | 1           | Fuse-Blade, 30 Amp     | 14          | 32128-49           | 2           | Nut-HHF                  |
| 1:2         | 109102             | 1           | Fuse-Blade, 25 Amp     | 15          | 62-4300            | 1           | Pad-Skid, Anti           |
| 1:3         | 109101             | 1           | Fuse-Blade, 20 Amp     | 16          | 104-8162           | 1           | Battery-Dry              |
| 1:4         | 116-0053           | 1           | Cap-Plug               | 17          | 106-8945           | 1           | Cable-Battery, Positive  |
| 2           | 98-7249            | 2           | Relay                  | 18          | 117-6422           | 1           | Cable-Battery, Black     |
| 3           | 88-9830            | 1           | Key Switch ASM         | 19          | 322-3              | 2           | Screw-HH                 |
| 3:1         | 3254-5             | 1           | Washer-Tooth, Internal | 20          | 3256-2             | 2           | Washer-Flat              |
| 3:2         | 218-461            | 1           | Nut-HH                 | 21          | 32149-1            | 2           | Nut-Keps                 |
| 4           | 120-2244           | 1           | Hourmeter              | 22          | 115-6621-03        | 1           | Plate-Hold Down, Battery |
| 5           | 104-4234           | 1           | Clip-Mounting          | 23          | 104-8567           | 2           | Holdown-Battery          |
| 6           | 63-8360            | 1           | Key-Ignition           | 24          | 3296-42            | 2           | Nut-Lock, NI             |
| 7           | 32105-23           | 1           | Screw                  | 30          | 3255-8             | 1           | Washer-Lock              |
| 8           | 3296-2             | 2           | Nut-Lock, NI           | 31          | 33114-016          | 1           | Screw-HH                 |
| 9           | 32105-13           | 1           | Screw-HWH              | 34          | 33004-00           | 1           | Nut-HF                   |
| 12          | 105-3150-01        | 1           | Tray-Battery           |             |                    |             |                          |



## Cylinder and Crankcase Assembly


| Ref.   | Part Number | Qty. | Description          |
|--------|-------------|------|----------------------|
| 130    | 93-8548     | 10   | Bolt-Flanged (6X25)  |
| 130A   | 119-5822    | 4    | Bolt-Flanged (10X50) |
| 130B   | 119-5823    | 6    | Bolt-Flanged (10X65) |
| 172    | 114-8658    | 4    | Bolt-Stud (8X18)     |
| 214    | 115-6422    | 1    | Screw-Pan (4X8)      |
| 670    | 95-9771     | 2    | O-Ring (11Mm)        |
| 11004  | 119-5800    | 2    | Gasket-Head          |
| 11008  | 119-5801    | 1    | Head-Cylinder (No.1) |
| 11008A | 119-5802    | 1    | Head-Cylinder (No.2) |
| 11022  | 119-5803    | 1    | Case-Rocker (No.1)   |
| 11022A | 119-5804    | 1    | Case-Rocker (No.2)   |
| 11061  | 119-5805    | 2    | Gasket-Case, Rocker  |
| 11061A | 119-5806    | 1    | Gasket-Breather      |
| 13272  | 119-5808    | 1    | Plate-Breather       |
| 14091  | 119-5809    | 1    | Cover-Breather       |
| 16126  | 119-5810    | 1    | Valve-Breather       |

| Ref.   | Part Number | Qty. | Description                 |
|--------|-------------|------|-----------------------------|
| 32154  | 119-5811    | 3    | Pipe                        |
| 32155  | 119-5812    | 1    | Pipe-Breather               |
| 49015  | 119-5813    | 1    | Cover-Crankcase             |
| 49120  | 119-5814    | 1    | Crankcase ASM               |
| 59071  | 95-9715     | 1    | Joint                       |
| 92043  | KW10694     | 6    | Pin                         |
| 92049  | 114-8650    | 4    | Seal-Oil, Rv C2 (6X11X10.2) |
| 92049A | 119-5816    | 1    | Seal-Oil, So (8X14X5) Hs    |
| 92049B | 119-5817    | 1    | Seal-Oil, Sd (35X48X8) R Hs |
| 92049C | 119-5818    | 1    | Seal-Oil (38X62X8) Mtclv    |
| 92066  | 119-5819    | 1    | Plug                        |
| 92066A | 119-5820    | 2    | Plug                        |
| 92104  | 119-5821    | 1    | Gasket-Liquid (Tb1217H)     |
| 92153  | 114-8655    | 6    | Bolt (6X12)                 |
| 92153A | 114-8656    | 10   | Bolt (8X50)                 |



## Piston and Crankshaft Assembly


| Ref.  | Part Number | Qty. | Description              |
|-------|-------------|------|--------------------------|
| 13001 | 119-5824    | 2    | Piston-Engine            |
| 13002 | 119-5825    | 2    | Pin-Piston               |
| 13008 | 119-5826    | 2    | Piston Ring Set          |
| 13025 | 119-5827    | 1    | Piston Ring Set, L (0.5) |
| 13029 | 119-5828    | 1    | Piston-Engine, L (0.5)   |
| 13031 | 119-5829    | 1    | Crankshaft ASM           |
| 13251 | 119-5830    | 2    | Connecting Rod ASM       |
| 92033 | 119-5831    | 4    | Ring-Snap                |
| 92151 | 115-6565    | 4    | Bolt (6X35)              |



## Valve and Camshaft Assembly


| Ref.  | Part Number | Qty. | Description            |
|-------|-------------|------|------------------------|
| 130   | 119-5845    | 4    | Bolt-Flanged (8X14)    |
| 312   | 119-5846    | 4    | Nut-Hex (6Mm)          |
| 11055 | 119-5832    | 4    | Bracket                |
| 12004 | 119-5833    | 2    | Valve-Intake           |
| 12005 | 119-5834    | 2    | Valve-Exhaust          |
| 12009 | 108-2525    | 4    | Retainer-Spring, Valve |
| 12011 | 95-9744     | 8    | Collet                 |
| 12016 | 119-5835    | 4    | Arm-Rocker             |
| 12032 | 108-2527    | 4    | Tappet                 |
| 13070 | 119-5836    | 1    | Guide-Governor         |
| 13116 | 119-5837    | 4    | Rod-Push               |
| 13271 | 114-8671    | 1    | Plate                  |

| Ref.   | Part Number | Qty. | Description               |
|--------|-------------|------|---------------------------|
| 13271A | 114-8672    | 1    | Plate-Governor            |
| 42036  | 114-8673    | 1    | Sleeve                    |
| 49078  | 119-5838    | 4    | Spring-Valve, Engine (In) |
| 49118  | 119-5839    | 1    | Camshaft ASM              |
| 92033  | 114-8675    | 3    | Ring-Snap                 |
| 92140  | 114-8676    | 6    | Ball                      |
| 92145  | 114-8677    | 1    | Spring                    |
| 92152  | 119-5840    | 4    | Collar                    |
| 92153  | 119-5841    | 4    | Bolt (6X29.5)             |
| 92200  | 119-5842    | 4    | Washer (8.1X18X0.5)       |
| 92200A | 119-5843    | 1    | Washer (16X42X0.91)       |
| 92200B | 119-5844    | 1    | Washer (16.3X30X2.28)     |




## Lubrication Equipment Assembly

| Ref.   | Part Number | Qty. | Description       |
|--------|-------------|------|-------------------|
| 555    | 119-5859    | 1    | Pin-Spring (4X20) |
| 670    | 1-413506    | 2    | Discontinued      |
| 13272  | 119-5847    | 1    | Plate-Rotor       |
| 14075  | 119-5848    | 1    | Oil Gauge Cap ASM |
| 16154  | 119-5849    | 1    | Rotor-Pump, Outer |
| 16154A | 119-5850    | 1    | Rotor-Pump, Inner |
| 49065  | 119-5851    | 1    | Filter-Oil        |
| 49065A | 119-5852    | 1    | Filter-Oil        |
| 59231  | 119-5853    | 1    | Tube-Filler, Oil  |
| 92066  | 119-5854    | 1    | Plug              |
| 92066A | 119-5855    | 1    | Plug              |
| 92140  | 119-5856    | 1    | Ball              |
| 92145  | 119-5857    | 1    | Spring            |
| 92153  | 119-5858    | 1    | Bolt              |
| 92153A | 115-6419    | 3    | Bolt (6X12)       |



## Cooling Equipment Assembly

| Ref.   | Part Number | Qty. | Description   |
|--------|-------------|------|---------------|
| 13272  | 119-5860    | 1    | Plate-Fan     |
| 49089  | 119-5862    | 1    | Shroud-Engine |
| 49089A | 119-5863    | 1    | Shroud-Engine |
| 49089B | 119-5864    | 1    | Shroud-Engine |
| 55020  | 119-5865    | 1    | Guard         |
| 59041  | 119-5867    | 1    | Fan           |
| 59066  | 119-5868    | 1    | Housing-Fan   |
| 92153  | 114-8655    | 18   | Bolt (6X12)   |




## Electric Equipment Assembly

| Ref.   | Part Number | Qty. | Description         |
|--------|-------------|------|---------------------|
| 130    | 95-9893     | 4    | Bolt-Flanged (6X20) |
| 510    | KW10163     | 1    | Key-Woodruff        |
| 13272  | 119-5870    | 1    | Plate               |
| 21066  | 120-7356    | 1    | Regulator-Voltage   |
| 21171  | 119-5872    | 2    | Ignition Coil ASM   |
| 21193  | 119-5874    | 1    | Flywheel ASM        |
| 26031  | 119-5876    | 1    | Harness             |
| 26031A | 119-5877    | 1    | Harness             |
| 59031  | 120-7355    | 1    | Coil-Charging       |


| Ref.   | Part Number | Qty. | Description        |
|--------|-------------|------|--------------------|
| 92009  | 119-5879    | 2    | Screw              |
| 92009A | 95-9716     | 1    | Screw              |
| 92066  | 119-5820    | 1    | Plug               |
| 92070  | 92-2153     | 2    | Spark Plug         |
| 92072  | 115-6585    | 1    | Band               |
| 92151  | 115-6408    | 1    | Bolt (12X30)       |
| 92171  | 115-8665    | 2    | Clamp              |
| 92172  | 115-4030    | 4    | Screw (5X20)       |
| 92200  | 115-4031    | 1    | Washer (12.2X46X3) |

# Carburetor Assembly



## Carburetor Assembly (continued)


| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>               | <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>     |
|-------------|--------------------|-------------|----------------------------------|-------------|--------------------|-------------|------------------------|
| 130         | 119-5940           | 4           | Bolt-Flanged (6X30)              | 92009A      | 119-5917           | 1           | Screw-Drain            |
| 172         | 119-5941           | 2           | Bolt-Stud (6X115)                | 92026       | 119-5918           | 1           | Spacer                 |
| 11009       | 119-5895           | 1           | Gasket                           | 92043       | 119-5919           | 1           | Pin-Float              |
| 11061       | 119-5896           | 1           | Gasket                           | 92055       | 119-5920           | 1           | O-Ring                 |
| 11061A      | 119-5897           | 1           | Gasket                           | 92055A      | 119-5921           | 2           | O-Ring                 |
| 11061B      | 119-5898           | 2           | Gasket-Carburetor/Manifold       | 92055B      | 119-5921           | 1           | O-Ring                 |
| 11061C      | 119-5899           | 2           | Gasket-Manifold                  | 92055C      | 119-5923           | 2           | O-Ring                 |
| 13280       | 119-5901           | 2           | Holder                           | 92055D      | 119-5924           | 1           | O-Ring                 |
| 13280A      | 119-5902           | 1           | Holder                           | 92063       | 119-5926           | 1           | Jet-Main (No. 108)     |
| 14092       | 119-5903           | 1           | Cover                            | 92063A      | 119-5927           | 1           | Jet-Main (No. 104)     |
| 15004       | 119-5904           | 1           | Carburetor ASM                   | 92063B      | 119-5928           | 1           | Jet-Main (No. 114)     |
| 16025       | 119-5905           | 2           | Valve-Throttle                   | 92063C      | 119-5929           | 1           | Jet-Main (No. 110)     |
| 16030       | 119-5906           | 1           | Valve-Float                      | 92063D      | 119-5930           | 1           | Jet-Main (No. 107)     |
| 16031       | 119-5907           | 1           | Float                            | 92063E      | 119-5931           | 1           | Jet-Main (No. 111)     |
| 16041       | 119-5908           | 1           | Carburetor Throttle Shaft<br>ASM | 92066       | 119-5932           | 2           | Plug-Expansion         |
| 16041A      | 119-5909           | 1           | Shaft-Choke, Carburetor          | 92093       | 119-5933           | 2           | Seal (6.9)             |
| 16073       | 119-5910           | 1           | Insulator                        | 92145       | 119-5934           | 1           | Spring                 |
| 16126       | 119-5911           | 1           | Valve                            | 92152       | 119-5935           | 1           | Collar                 |
| 16184       | 119-5912           | 1           | Float Chamber ASM                | 92152A      | 119-5936           | 1           | Collar                 |
| 16187       | 119-5913           | 2           | Needle-Jet                       | 92172       | 119-5937           | 2           | Screw (M5)             |
| 21188       | 119-5914           | 1           | Solenoid                         | 92172A      | 119-5938           | 1           | Screw (M4)             |
| 59076       | 119-5915           | 1           | Manifold-Intake                  | 92172B      | 119-5939           | 1           | Screw-Adjust, Throttle |
| 92009       | 119-5916           | 6           | Screw                            |             |                    |             |                        |



## Control Equipment Assembly

| Ref.   | Part Number | Qty. | Description        |
|--------|-------------|------|--------------------|
| 214    | 115-6422    | 2    | Screw-Pan (4X8)    |
| 311    | 114-8698    | 1    | Nut-Hex (6Mm)      |
| 312    | 119-5894    | 2    | Nut-Hex (5Mm)      |
| 411    | 115-6423    | 1    | Washer-Plain (6Mm) |
| 13107  | 119-5882    | 1    | Shaft-Governor     |
| 13271  | 119-5883    | 1    | Plate              |
| 16171  | 119-5884    | 1    | Link               |
| 39129  | 119-5885    | 1    | Spring-Governor    |
| 49103  | 119-5886    | 1    | Arm-Governor       |
| 49103A | 119-5887    | 1    | Arm-Governor       |


| Ref.   | Part Number | Qty. | Description       |
|--------|-------------|------|-------------------|
| 49113  | 119-5888    | 1    | Control Panel ASM |
| 92145  | 119-5889    | 1    | Spring            |
| 92145A | 119-5890    | 1    | Spring            |
| 92150  | 95-9853     | 2    | Bolt (5X18)       |
| 92151  | 119-5891    | 2    | Bolt (5X30)       |
| 92153  | 119-5892    | 1    | Bolt (6X12)       |
| 92153A | 115-6420    | 1    | Bolt (6X35)       |
| 92153B | 119-5892    | 1    | Bolt (6X12)       |
| 92170  | 115-6421    | 2    | Clamp             |



## Air Filter and Muffler Assembly


| Ref.   | Part Number | Qty. | Description                 |
|--------|-------------|------|-----------------------------|
| 130    | 119-5960    | 2    | Bolt-Flanged (6X110)        |
| 130A   | 119-5961    | 6    | Bolt-Flanged (6X16)         |
| 461    | 119-5962    | 4    | Washer-Spring (8Mm)         |
| 11010  | 119-5942    | 1    | Air Filter ASM              |
| 11011  | 119-5943    | 1    | Case-Filter, Air            |
| 11013  | 119-5944    | 1    | Element-Filter, Air (Outer) |
| 11013A | 119-5945    | 1    | Element-Filter, Air (Inner) |
| 11055  | 119-5946    | 1    | Bracket                     |
| 11055A | 119-5947    | 1    | Bracket                     |
| 11060  | 119-5948    | 2    | Gasket-Muffler              |
| 11061  | 119-5949    | 1    | Gasket                      |

| Ref.   | Part Number | Qty. | Description          |
|--------|-------------|------|----------------------|
| 11065  | 119-5950    | 1    | Cap                  |
| 11065A | 119-5951    | 1    | Cap                  |
| 11065B | 119-5952    | 1    | Cap                  |
| 16060  | 119-5953    | 1    | Pipe-Intake          |
| 92015  | 119-5954    | 2    | Nut                  |
| 92171  | 119-5955    | 3    | Clamp                |
| 92173  | 119-5956    | 2    | Clamp                |
| 92192  | 119-5957    | 1    | Tube (12.6X18.6X118) |
| 92192A | 119-5958    | 1    | Tube                 |
| 92210  | 119-5959    | 4    | Nut (M8)             |



## Fuel Tank and Valve Assembly

| Ref.   | Part Number | Qty. | Description          |
|--------|-------------|------|----------------------|
| 42036  | 119-5963    | 2    | Sleeve               |
| 49019  | 121-4570    | 1    | Filter-Fuel          |
| 49040  | 119-5965    | 1    | Pump-Fuel            |
| 92009  | 119-5879    | 2    | Screw                |
| 92170  | 119-5967    | 6    | Clamp                |
| 92171  | 119-5968    | 1    | Clamp                |
| 92192  | 119-5969    | 1    | Tube (6.35X12.7X185) |
| 92192A | 119-5970    | 1    | Tube (6.4X12.7X150)  |
| 92192B | 119-5971    | 1    | Tube (6.35X12.7X390) |




## Starter Assembly


| Ref.   | Part Number | Qty. | Description         |
|--------|-------------|------|---------------------|
| 130    | 119-5991    | 2    | Bolt-Flanged (8X40) |
| 13081  | 119-5972    | 1    | Clutch ASM          |
| 13091  | 119-5973    | 1    | Holder-Brush        |
| 13168  | 119-5974    | 1    | Lever-Shift         |
| 16073  | 119-5975    | 1    | Insulator           |
| 16146  | 119-5976    | 1    | Cover ASM           |
| 16146A | 119-5977    | 1    | Cover ASM           |
| 21039  | 119-5978    | 4    | Brush               |
| 21040  | 119-5979    | 4    | Spring-Brush        |
| 21080  | 119-5980    | 1    | Armature            |

| Ref.   | Part Number | Qty. | Description      |
|--------|-------------|------|------------------|
| 21163  | 119-5981    | 1    | Starter-Electric |
| 27010  | 119-5982    | 1    | Switch           |
| 27012  | 119-5983    | 1    | Hook             |
| 32085  | 119-5985    | 1    | Stopper          |
| 92002  | 119-5986    | 2    | Bolt             |
| 92015  | 119-5987    | 2    | Nut              |
| 92015A | 119-5988    | 1    | Nut              |
| 92033  | 119-5989    | 1    | Ring-Snap        |
| 92210  | 119-5990    | 1    | Nut              |

56014



56070



## Label Set

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i> |
|-------------|--------------------|-------------|--------------------|
| 56014       | 119-5992           | 1           | Emblem             |
| 56070       | 115-6469           | 1           | Label-Warning      |

# Attachments and Accessories

## For 22974 TRX-26 Trencher

| Product Name                                       | Model/Part |
|----------------------------------------------------|------------|
| 8in Chain Conversion Kit for 36in Soil Chain ..... | 117-3480   |
| Crumber Kit .....                                  | 22477      |
| 24in X 4in Soil Chain .....                        | 22480      |
| 24in X 4in Combination Chain .....                 | 22481      |
| 24in X 4in Rock Tooth Chain .....                  | 22482      |
| 24in X 6in Soil Chain .....                        | 22483      |
| 24in X 6in Combination Chain .....                 | 22484      |
| 24in X 6in Rock Tooth Chain .....                  | 22485      |
| 36in X 4in Soil Chain .....                        | 22486      |
| 36in X 4in Combination Chain .....                 | 22487      |
| 36in X 4in Rock Tooth Chain .....                  | 22488      |
| 36in X 6in Rock Tooth Chain .....                  | 22489      |
| 36in X 6in Soil Chain .....                        | 22490      |
| 36in X 6in Combination Chain .....                 | 22491      |
| 48in x 4in Soil Chain .....                        | 22492      |
| 48in x 4in Combination Chain .....                 | 22493      |
| 48in x 6in Soil Chain .....                        | 22494      |
| 48in x 6in Combination Chain .....                 | 22495      |
| 24in X 4in Bullet Chain .....                      | 22496      |
| 24in X 6in Bullet Chain .....                      | 22497      |
| 36in X 4in Bullet Chain .....                      | 22498      |
| 36in X 6in Bullet Chain .....                      | 22499      |
| 24in Trencher Boom .....                           | 22975      |
| 36in Trencher Boom .....                           | 22976      |
| 48in Trencher Boom .....                           | 22977      |
| Bore Drive Attachment .....                        | 22978      |
| Backfill Blade .....                               | 22980      |
| Spark Arrestor Screen .....                        | 94-8157    |

**Notes:**

**Notes:**



**Count on it.**