Form No. 3412-337 Rev A

TORO®

Count on it.

Parts Catalog

Light Kit


T4240 Mower


Model No. 02844


Register at www.Toro.com.
Original Instructions (EN)

3412-337 A

Light Kit Assembly







Light Kit Assembly (continued)

Ref.	Part Number	Qty.	Description
1	70-07-115	2	Reflector-Reflex, Red
2	70-09-112	2	Lamp-Front
3	70-09-113	2	Lamp-Indicator, Rear
3:1	09473	2	Washer-Shakeproof
3:2	09437	2	Nut
4	952116	1	Plate Lamp ASM
4:10	952117	2	Rear Bulb Light Assembly ●
6	03469	4	Washer-Spring
7	09365	4	Screw-Taptite
8	09368	4	Screw-HH
9	09430	5	Nut-Nyloc
12	09470	10	Washer
13	09475	4	Washer
17	924633	2	Headlamp-Dip/Main
17:1	924632	1	Bulb-Headlamp ●
19	924138W	1	Bracket-Plate, Number
20	ZDH1E016U	4	Screw-HH
21	63-01-836	2	Stop-Bump
23	111-0722-03	1	Plate-Bracket, Rear Light (RH)
24	111-0772-03	1	Plate-Bracket, Rear Light (LH)
35	70-09-117	4	Bulb-Indicator
36	70-09-118	2	Bulb
37	70-09-119	2	Bulb
99	111-6284	2	Cable-Headlamp ●
99	111-6285	1	Cable-Number, Plate ●
99	111-6287	2	Cable-Side, Light ●
99	111-6288	1	Harness-Wiring, Lights ●
99	70-09-026	1	Fuse-10A ●
99	70-09-151	1	Fuse-15A ●
99	74-07-020	4	Tie-Cable ●
99	924604	1	Switch-Dip/Main ●
99	924607	1	Switch ●
99	924610	1	Switch-Indicators ●
99	924611	1	Switch-Hazard, Warning ●
99	924612	1	Lens-Main, Light ●
99	924613	1	Lens-Beam, High ●
99	924615	1	Lens-Hazard, Warning ●
99	952151	1	Lens-Switch, Indicator ●
99	952152	2	Light-Side, Wire ●
99:1	111-6286	1	Cable-Side, Light ●
99:2	111-6167	1	3 Way Connector Kit ●
99:3	111-6120	1	Instruction Sheet Connector Kit ●
99	HY3966	10	Tie-Cable ●
99	ZDH1E012U	1	Screw-HH ●

● Not illustrated



Count on it.