



**Count on it.**

Form No. 3413-131 Rev A

# Parts Catalog

## Double Detent Valve Kit TX 1000 Compact Tool Carrier

Model No. 23171



# Ordering Replacement Parts

To order replacement parts, please supply the part number, the quantity, and the description of each part desired.

## Understanding Reference Numbers

Each identified part in an illustration has a reference number. The reference number for a part also appears in the parts list, along with other information about the part.

This catalog uses two special reference number formats, one to indicate parts in a service assembly and another to indicate the quantity of a given part in an illustration.

## Service Assembly Reference Numbers

Parts in service assemblies have reference numbers in the form a:b. The a represents the reference number of the entire service assembly and the b represents a sequential number unique to each part within the service assembly.

For example, a wheel assembly might be identified by reference number 6, the tire by 6:1, the valve by 6:2, and the wheel by 6:3. When you order the assembly identified by reference number 6, you receive all parts identified by reference numbers 6:1, 6:2, and 6:3. However, you may also order any part individually. Reference numbers of this type appear in illustration and in parts lists.

## Reference Numbers Indicating Quantity

In an illustration, if a reference number indicates more than one part, the reference number has the form nX y. The n represents the quantity of the part, the X is the multiplication symbol, and the y represents the reference number.


For example, in an illustration, the reference number 2X 37 means that two of the parts identified by reference number 37 are indicated.

# Contents

Double Detent Valve Kit. . . . . 4

Double Detent Valve Assembly No. 136-4538. . . . . 6

# Double Detent Valve Kit




## Double Detent Valve Kit (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>      |
|-------------|--------------------|-------------|-------------------------|
| 1           | 136-4538           | 1           | Double Detent Valve ASM |
| 2           | 136-4552           | 1           | Hose-Radiator           |
| 3           | 104-4804           | 1           | Outlet-Water            |

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i> |
|-------------|--------------------|-------------|--------------------|
| 4           | 105-3748           | 1           | Gasket-Thermostat  |
| 5           | 136-5813           | 1           | Harness-Wire       |

Double Detent Valve Assembly No. 136-4538



## Double Detent Valve Assembly No. 136-4538 (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>      |
|-------------|--------------------|-------------|-------------------------|
| 1           | 132-6038           | 1           | Lever Kit (With Screws) |
| 2           | 114-8624           | 1           | Valve-Spool             |
| 3           | 132-6039           | 1           | Valve-Relief            |
| 4           | 106-7719           | 2           | Seal-Valve              |

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>    |
|-------------|--------------------|-------------|-----------------------|
| 5           | 136-5810           | 1           | Spring/Coil Valve Kit |
| 6           | 136-5811           | 1           | Coil-Valve            |
| 7           | 136-5812           | 1           | Valve-Tube, Pull      |



**Count on it.**