



Form No. 3413-928 Rev A

Count on it.

Parts Catalog

Chemical Pre-Mix Kit

2015 and After Multi-Pro 5800 Turf Sprayer

Model No. 41622—Serial No. 400000000 and Up



Ordering Replacement Parts

To order replacement parts, please supply the part number, the quantity, and the description of each part desired.

Understanding Reference Numbers

Each identified part in an illustration has a reference number. The reference number for a part also appears in the parts list, along with other information about the part.

This catalog uses two special reference number formats, one to indicate parts in a service assembly and another to indicate the quantity of a given part in an illustration.

Service Assembly Reference Numbers

Parts in service assemblies have reference numbers in the form a:b. The a represents the reference number of the entire service assembly and the b represents a sequential number unique to each part within the service assembly.

For example, a wheel assembly might be identified by reference number 6, the tire by 6:1, the valve by 6:2, and the wheel by 6:3. When you order the assembly identified by reference number 6, you receive all parts identified by reference numbers 6:1, 6:2, and 6:3. However, you may also order any part individually. Reference numbers of this type appear in illustration and in parts lists.

Reference Numbers Indicating Quantity

In an illustration, if a reference number indicates more than one part, the reference number has the form nX y. The n represents the quantity of the part, the X is the multiplication symbol, and the y represents the reference number.

For example, in an illustration, the reference number 2X 37 means that two of the parts identified by reference number 37 are indicated.

Contents


Mounting Assembly 4

Eductor Mounting Assembly 5

Eductor Valve Assembly No. 130-7324 7

Eductor Assembly No. 127-2949..... 8


Hose Assembly..... 9



Mounting Assembly


Ref.	Part Number	Qty.	Description
1	120-8643-03	1	Eductor-Mount
2	100-8541	2	Bushing-A Arm
3	119-4951	2	Tab-Spring
4	119-4962	1	Plate-Strike
5	119-4907-03	1	Arm-Pivot, LH
6	119-4908-03	1	Arm-Pivot, RH
7	256-257	2	Bushing-Nyliner
8	120-0718	2	Pivot-Pin
9	3234-24	2	Screw-HHF
10	3218-3	2	Nut-Jam
11	99-7981	2	Knob-Grip, Soft

Ref.	Part Number	Qty.	Description
14	120-0722	2	Spring-Extension
15	3290-467	2	Pin-Hair
16	106-9888	2	Washer-Flat
17	104-8300	1	Nut-HF, NI
18	1-807533	13	Bolt-CARR
19	3296-12	13	Nut-Lock, NI
20	93-6674	2	Decal-Warning
23	125-5891	1	Plate-Guide
24	3245-41	2	Screw-HSH
25	120-8640	1	Latch-Rod




Eductor Mounting Assembly

Ref.	Part Number	Qty.	Description	Ref.	Part Number	Qty.	Description
1	130-7324	1	Eductor Valve ASM	16:1	125-5894	1	Fitting-Hose Barb
2	117-7851	1	Bulkhead ASM	16:3	2412-34	2	Clamp-Hose
2:2	100-8646	1	Gasket-Bulkhead	16:4	131-3727	1	Fitting-Valve, Eductor
2:3	100-8647	1	Nut-Bulkhead	16:4:1	131-0231	2	O-Ring
3	119-4912-03	1	Plate-Pivot	17	119-6897	2	Nut-Flange, Hex
4	119-4928	1	Bracket-Latch	18	2412-96	1	Clamp-R
5	119-4963	2	Pad-Wear	19	3234-11	4	Screw-HHF
6	127-2949	1	Eductor ASM	20	32128-43	4	Nut-Flange
7	119-4937	1	Clip-Spring	21	104-8300	5	Nut-HF, NI
9	131-3725-03	1	Mount-Valve, Eductor	22	131-0235	2	Fork-Fitting, Eductor Valve
10	3234-47	4	Screw-HHF	23	3250-12	2	Screw-PPH
11	127-5005	2	Clamp-Worm Screw	24	3296-2	2	Nut-Lock, NI
12	127-5004	2	Gasket	25	1-807533	6	Bolt-CARR
13	125-5892-03	1	Tab-Extension	26	3296-12	8	Nut-Lock, NI
14	117-7996	1	Fork	28	119-4988	1	Decal-Lock
15	130-8278	1	Eductor Hose ASM	29	3234-4	2	Screw-HHF
15:1	117-7870	1	Hosebarb ASM	30	32128-33	2	Nut-HF
15:1:2	100-6989	1	O-Ring	31	115-8215	1	Draw Latch ASM
15:3	41327	2	Clamp-Hose	32	115-9830	5	Screw-HSBH
15:4	125-5895	1	Fitting-Hose Barb	33	3230-2	1	Bolt-CARR
16	131-5823	1	Supply Hose ASM	34	127-5000-03	1	Handle-Eductor



Eductor Mounting Assembly (continued)

Ref.	Part Number	Qty.	Description
35	136-2291-03	1	Mount-Valve, Eductor
36	3256-23	2	Washer-Plain




Eductor Valve Assembly No. 130-7324

Ref.	Part Number	Qty.	Description
1	131-0215	1	Stem-Valve, Eductor
1:1	131-0217	2	Oring-Stem, Valve
2	131-0218	1	Oring-Seat, Valve
3	131-0219	1	Seat-Valve, Eductor
4	131-0220	1	Ball-3Way, Eductor Valve
5	131-0221	1	Seat-Stem, Eductor Valve
6	131-0222	1	Cap-End, Eductor Valve
6:1	131-0218	1	Oring-Seat, Valve
6:2	131-0224	1	Oring-End Cap, Eductor
6:3	131-0219	1	Seat-Valve, Eductor
7	131-0225	1	Oring-Fitting
8	131-0226	1	Fork-Handle Plate
9	131-0232	1	Plate-Face, Eductor Valve

Ref.	Part Number	Qty.	Description
10	131-0233	1	Handle-Valve, Eductor
11	131-0234	1	Bolt-Faceplate, Eductor
12	127-1144	1	Fitting-Adapter
13	104-9089	1	Clamp-Screw, Worm
14	131-3799	4	Stud
99	131-3798	1	Repair Kit ●
99:2	131-0217	2	Oring-Stem, Valve
99:3	131-0225	1	Oring-Fitting
99:4	131-0221	1	Seat-Stem, Eductor Valve
99:5	131-0219	2	Seat-Valve, Eductor
99:6	131-0218	2	Oring-Seat, Valve
99:7	131-0224	1	Oring-End Cap, Eductor Valve


● Not illustrated



Eductor Assembly No. 127-2949

Ref.	Part Number	Qty.	Description
1	127-5027	1	Eductor
2	127-5042	1	Container-Rinse
3	127-5048	1	Nozzle-Rinse Container
4	127-6934	1	Valve-Tank
5	127-6923	1	Valve-Drain
6	127-6916	1	Lid
7	127-6939	1	Strainer
8	127-6900	1	Grommet
9	127-6904	1	Elbow-Fitting
10	127-6903	2	Elbow-Fitting
11	127-6905	1	Valve-Two Way

Ref.	Part Number	Qty.	Description
12	127-5049	2	Fitting
13	127-6906	1	Fitting-Tee
14	127-5030	1	Ring-Mounting
15	127-6922	2	Screw-HH
16	127-5031	2	Screw-HH
17	127-5029	1	Bracket
18	127-6938	4	Washer
19	127-6932	1	Gasket
20	127-5005	1	Clamp-Worm Screw
21	127-6941	1	Fitting-Tee



Hose Assembly

Ref.	Part Number	Qty.	Description
1	131-9647	1	Hose ASM
1:2	106-4933	2	Hosebarb ASM
1:2:1	100-8637	1	O-Ring
1:3	2412-34	2	Clamp-Hose
2	131-9648	1	Supply Hose ASM
2:2	106-4933	1	Hosebarb ASM
2:2:1	100-8637	1	O-Ring
2:3	131-0229	1	Fitting-Valve, Eductor
2:3:1	131-0231	2	O-Ring
2:4	2412-34	2	Clamp-Hose
3	131-9649	1	Bypass Hose ASM
3:2	106-4933	1	Hosebarb ASM
3:2:1	100-8637	1	O-Ring
3:3	127-1142	1	Fitting-Barb
3:4	2412-34	2	Clamp-Hose

Notes:

Notes:



Count on it.