




MODEL NO. 20803-8900001 & UP


**PARTS
CATALOG**
48cm RECYCLER[®]
REAR BAGGER MOWER


C-2627

ENGINE ASSEMBLY

Ref. No.	Part No.	Description	No. Used
1	32144-73	Screw	3
2	3290-378	Tie - Cable	1
3	2210-249	Clamp - Casting	1
4	93-8470	Screw - Clamp	1
5	32144-102	Screw	3
6	82-8550	Shield - Muffler	1

Ref. No.	Part No.	Description	No. Used
7	93-4354	Decal - Engine	1
8		Engine	1
9	2210-316	Rope - Stop	1
10	93-0243	Shroud	1
11	32144-121	Screw	2
12	92-2289	Plate - Logo	1



HANDLE ASSEMBLY


Ref. No.	Part No.	Description	No. Used
1	3290-378	Tie - Cable	1
2	3296-73	Nut - Lock Insert	3
3	19-4050	Knob	2
4	71-8100	Mount - Handle RH	1
5	71-8090	Mount - Handle LH	1
6	93-1116	Cable - Brake	1
7	92-7729	Anchor - Cable	1

Ref. No.	Part No.	Description	No. Used
8	95-4453	Screw - Handle	1
9	3256-1	Washer - Flat	1
10	95-4457	Rope - Guide	1
11	94-4375	Handle	1
12	95-5924	Bail - Brake	1
13	93-1118	Control - Throttle	1
14	321-48	Screw - Hex Head	1

C-2630

Ref. No.	Part No.	Description	No. Used
1	27-6230	Bolt - Wheel	2
2	32112-13	Nut - Push	1
3	63-8590	Screw	2
4	71-8080	Saddle - Height of Cut	1
5	71-8060	Spring - Trigger	2
6	32144-31	Screw	1
7	3296-5	Nut - Lock (Nylon)	2
8	71-7800	Arm - Pivot	1
9	71-7840	Rod - Trigger	1
10	71-7770	Plate - Securing	2
11	32144-4	Screw - Hex Head Tap	4

Ref. No.	Part No.	Description	No. Used
12	71-7980	Indicator - Height of Cut	1
13	71-7970	Rod - Link	1
14	71-8450	Cover - Spring	1
15	32151-93	Ring - Grip	1
16	71-7740	Spring - Counterbalance	1
17	14-9949	Rear Wheel & Tire Assembly (Incl. Ref. # 19)	2
18	40-1940	Washer	2
19	27-6250	Bushing	2
20	92-7663	Cover - Wheel	1




C-2626

BAG AND COMPONENTS ASSEMBLY

Ref. No.	Part No.	Description	No. Used
1	32144-111	Screw - Phillips Pan Head	5
2	71-9480	Handle Door	1
3	71-9470	Door - Bag	1

Ref. No.	Part No.	Description	No. Used
4	71-9900	Frame	1
5	71-9460	Bag - Grass	1

* Not Illustrated




C-2629

DECK ASSEMBLY

Ref. No.	Part No.	Description	No. Used
1	32144-4	Screw - Hex Head Tap	8
2	71-8830	Retainer Shaft Assembly	2
3	32112-11	Nut - Push	1
4	71-7990	Ramp - Discharge	1
5	95-6134	Housing Assembly (Incl. Ref.# 6-8,10,21,25 & 32-34)	1
6	95-2747	Fitting - Washout	1
7	46-6290	O-Ring	1
8	32144-111	Screw - Phillips Pan Head	8
9	71-8580	Spacer - Door	2
10	71-8920	Kicker - Front Right	1
11	71-9840	Spring - Door	2
12	71-7900	Cap - Bolt LH	1
13	322-29	Screw - Hex Head	2
14	32144-97	Screw - Phillips Pan Head	2
15	71-7860	Grip - Upper	1
16	65-5210	Screw - Thread Forming	2
17	71-7910	Cap - Bolt RH	1
18	71-7930	Trigger - Height of Cut	1

Ref. No.	Part No.	Description	No. Used
19	3284-5	Pin - Groove	1
20	71-7870	Grip - Lower	1
21	71-9230	Kicker - Rear Right	1
22	32144-70	Screw - Tap	1
24	71-7920	Cover - Belt	1
25	92-7863	Decal - Deck	1
26	27-6230	Bolt - Wheel	2
27	46-1113	Wheel & Tire Assembly 7" (Incl. Ref.# 36)	2
28	40-1940	Washer	2
29	3296-5	Nut - Lock (Nylon)	2
30	71-7820	Pivot - Front	1
31	17-1569	Door - Discharge (Incl. Ref.# 35)	1
32	46-6811	Screw - Hex Washer Head	2
33	71-9250	Kicker - Rear Left	1
34	71-9440	Kicker - Front Left	1
35	93-4105	Decal - Danger	1
36	27-6250	Bushing	2
37	71-9990	Plug - Recycler	1




C-2628

BLADE ASSEMBLY

Ref. No.	Part No.	Description	No. Used
1	71-7940	Retainer - Blade	1
2	26-0672	Bolt - Blade	1
3	3253-22	Washer - Lock	1

Ref. No.	Part No.	Description	No. Used
4	71-9260	Blade	1
5	80-0510	Stiffener - Blade	1




ENGINE BRIGGS & STRATTON MODEL 12F802-1767-E1

Ref. No.	Part No.	Description	No. Used	Ref. No.	Part No.	Description	No. Used
1	493260	Cylinder Assembly	1	337	802592	Plug – Spark	1
2	293708	Bushing	1	383	89838	Wrench – Spark Plug	1
★3	299819	Seal – Oil	1	523	495264	Dipstick	1
5	214626	Head – Cylinder	1	525	495265	Tube – Oil Filler	1
†★7	272916	Gasket – Cylinder Head	1	562	94582	Screw – Hex.	1
8	495786	Breather Assy.	1	584	224328	Baffle – Cylinder	1
†★9	272481	Gasket – Breather	1	★585	272238	Gasket – Breather	1
10	94650	Screw – Hex.	1	592	231082	Nut – Hex.	1
11	231933	Tube – Breather	1	615	94474	Fastener	1
13	94547	Screw – Hex.	1	616	263175	Crank – Governor	1
★51	272199	Gasket – Intake Elbow	1	625	497465	Tube – Fuel Intake	1
54	94526	Screw – Hex	1	635	66538	Elbow – Spark Plug	1
★116	280393	Seal – O Ring	1	847	495263	Dipstick/Tube Assy.	1
★116A	280966	Seal – O Ring	1	869	213512	Seat – Valve (Intake)	1
227	492349	Lever Assembly – Gov.	1	870	213513	Seat – Valve (Exhaust)	1
230	67072	Washer – Gov. Crank	1	871	262001	Bushing – Guide (Exhaust)	1
284	94511	Screw – Hex.	1			Note: 63709 Bushing – Guide (Intake)	1
306	224324	Shield – Cylinder	1				
307	94515	Screw – Hex.	1				

★ Included in Gasket Set—Part No. 497316.

† Included in Valve Overhaul Gasket Set—Part No. 498528.

Obtain Parts From Briggs & Stratton



Assemblies include all parts shown in frames.


ENGINE BRIGGS & STRATTON MODEL 12F802-1767-E1

Ref. No.	Part No.	Description	No. Used
4	493279	Sump – Engine	1
★12	272198	Gasket – Crankcase	1
15	94880	Plug – Oil Drain	1
16	498573	Crankshaft	1
★20	399781	Seal – Oil	1
22	94220	Screw – Hex.	1
		Note: 94612 Screw – Hex. (One (1) Used in Hole Nearest Breather.)	1
24	222698	Key – Flywheel	1
25	499429	Piston Assy. (Standard)	1
	499430	Piston Assy. (0.010" O.S.)	1
	499431	Piston Assy. (0.020" O.S.)	1
	499432	Piston Assy. (0.030" O.S.)	1

Ref. No.	Part No.	Description	No. Used
26	499425	Ring Set (Standard)	1
	499426	Ring Set (0.010" O.S.)	1
	499427	Ring Set (0.020" O.S.)	1
	499428	Ring Set (0.030" O.S.)	1
27	263190	Lock – Piston Pin	1
28	499423	Pin – Piston (Standard)	1
29	499424	Rod Assembly – Connecting	1
32	94699	Screw – Connecting Rod	1
33	262651	Valve – Exhaust	1
34	262652	Valve – Intake	1
35	262224	Spring – Valve	1
40	93312	Retainer – Valve Spring	1
45	262204	Tappet – Valve	1
46	498275	Gear – Cam	1
47	493737	Slinger – Oil	1
146	94388	Key – Timing	1
741	262598	Gear – Timing	1

★ Included in Gasket Set–Part No. 497316.

Obtain Parts From Briggs & Stratton



Assemblies include all parts shown in frames.

ENGINE BRIGGS & STRATTON MODEL 12F802-1767-E1


Ref. No.	Part No.	Description	No. Used	Ref. No.	Part No.	Description	No. Used
95	94098	Screw – Slotted	1	130	224908	Valve – Throttle	1
●104	231371	Pin – Float Hinge	1	131	493267	Shaft – Throttle	1
◆110		Washer – Bowl (Sold in Kit Only).	1	133	398187	Float – Carburetor	1
117	494870	Jet – Main (Std.)		●134	398188	Kit – Needle/Seat	1
		Note: 497315 Jet – Main (High Altitude)	1	◆137		Gasket – Bowl (Sold in Kit Only).	1
124	94840	Screw – Hex	1	◆◆★163	272653	Gasket – Air Cleaner	1
125	498170	Carburetor	1	◆◆617	270344	Seal – Intake Manifold	1
●127		Plug – Welch (Sold in Kit Only).	1	◆◆634		Washer – Foam (Sold in Kit Only).	1
				975	493640	Bowl – Float	1

★ Included in Gasket Set – Part No. 497316.

Obtain Parts From Briggs & Stratton

● Included in Carburetor Kit – Part No. 498260.

◆ Included in Carburetor Gasket Set – Part No. 498261.



Assemblies include all parts shown in frames.

ENGINE BRIGGS & STRATTON MODEL 12F802-1767-E1

Ref. No.	Part No.	Description	No. Used
161	496116	Base – Air Cleaner	1
◆★163	272653	Gasket – Air Cleaner	1
529	281299	Grommet	1
967	491588	Filter – Air	1
968	281340	Cover – Air Cleaner	1


Ref. No.	Part No.	Description	No. Used
969	94872	Screw – Slotted Hex.	1
971	94873	Screw – Hex.	1
971A	94749	Screw – Hex.	1
976	496115	Primer – Carburetor	1
1115	224815	Bracket – Support	1

★ Included in Gasket Set–Part No. 497316.

Obtain Parts From Briggs & Stratton

◆ Included in Carburetor Kit–Part No. 498260.

◆ Included in Carburetor Gasket Set–Part No. 498261.




Assemblies include all parts shown in frames.

ENGINE BRIGGS & STRATTON MODEL 12F802-1767-E1

Ref. No.	Part No.	Description	No. Used	Ref. No.	Part No.	Description	No. Used
188	94644	Screw – Hex.	1	620A	225152	Bracket – Control	1
188A	94874	Screw – Hex.	1	621	396847	Switch – Stop	1
202	262579	Link – Governor	1	★670	493823	Spacer – Bracket	2
209	263046	Spring – Governor	1	922	262640	Spring – Brake	1
258	94512	Screw – Hex.	1	923	493442	Brake Assembly	1
620	497203	Bracket – Carburetor	1				

★ Included in Gasket Set—Part No. 497316.
Obtain Parts From Briggs & Stratton




Assemblies include all parts shown in frames.

ENGINE BRIGGS & STRATTON MODEL 12F802-1767-E1

Ref. No.	Part No.	Description	No. Used	Ref. No.	Part No.	Description	No. Used
81	223664	Lock – Muffler Screw	1	601	95162	Clamp – Hose	1
187	298049	Line – Fuel	1	613	94231	Screw – Shoulder	1
		(Cut to Required Length)	1	670A	280512	Spacer – Fuel Tank	1
188B	398540	Screw – Shoulder	1	676	493871	Deflector – Muffler	1
284	94511	Screw – Shoulder	1	957	397974	Cap – Fuel Tank	1
300	496106	Muffler – Exhaust	1	972	495224	Tank – Fuel	1
346	94896	Screw – Hex.	1				

Obtain Parts From Briggs & Stratton




Assemblies include all parts shown in frames.

ENGINE BRIGGS & STRATTON MODEL 12F802-1767-E1

Ref. No.	Part No.	Description	No. Used	Ref. No.	Part No.	Description	No. Used
23	492177	Flywheel	1	334	94731	Screw - Hex.	1
37	224511	Guard - Flywheel	1	356	497833	Wire - Stop	1
304	493293	Housing - Blower	1	363	19069	Puller - Flywheel	1
305	94744	Screw - Hex.	1	455	225121	Cup - Flywheel	1
332	94877	Nut - Flywheel	1	851	493880	Terminal - Cable	1
333	802574	Armature - Magneto	1	1036	499341	Label Kit - Emission	1

Obtain Parts From Briggs & Stratton







Assemblies include all parts shown in frames.

ENGINE BRIGGS & STRATTON MODEL 12F802-1767-E1

Ref. No.	Part No.	Description	No. Used	Ref. No.	Part No.	Description	No. Used
55	497440	Housing—Rewind Starter	1	373	94908	Nut – Hex.	1
56	498144	Pulley – Starter	1	456	281503	Retainer – Spring	1
58	280399	Rope – Starter	1	459	281505	Pawl – Ratchet	1
59	224467	Insert – Starter Grip	1	461	94943	Screw – Shoulder	1
60	493926	Grip – Starter Rope	1	515	263073	Spring – Friction	1
65	94904	Screw – Hex.	1	608	497680	Starter – Rewind	1

Obtain Parts From Briggs & Stratton



Assemblies include all parts shown in frames.

ENGINE BRIGGS & STRATTON MODEL 12F802-1767-E1

Ref. No.	Part No.	Description	No. Used	Ref. No.	Part No.	Description	No. Used
★3	299819	Seal – Oil	1	●134	398188	Kit – Needle/Seat	1
†★7	272916	Gasket – Cylinder Head	1	●◆137		Gasket – Bowl (Sold in Kit Only).	1
†★9	272481	Gasket – Breather	1	●◆★163	272653	Gasket – Air Cleaner	1
★12	272198	Gasket – Crankcase	1	358	497316	Gasket Set	1
★20	399781	Seal – Oil	1	★585	272238	Gasket – Breather	1
★51	272199	Gasket – Intake	1	●◆617	270344	Seal – Intake Manifold	1
●104	231371	Pin – Float Hinge	1	●◆634		Washer – Foam (Sold in Kit Only).	1
●◆110		Washer – Bowl (Sold in Kit Only).	1	★670	493823	Spacer – Bracket	2
★116	280393	Seal – O Ring	1	977	498261	Gasket Set – Carburetor	1
★116A	280966	Seal – O Ring	1	1095	498528	Gasket Set – Valve Overhaul	1
121	498260	Carburetor Kit	1				
●127		Plug – Welch (Sold in Kit Only).	1				

● Included in Carburetor Kit—Part No. 498260.

◆ Included in Carburetor Gasket Set—Part No. 498261.

Obtain Parts From Briggs & Stratton

★ Included in Gasket Set—Part No. 497316.

† Included in Valve Overhaul Gasket Set—Part No. 498528.

TORO PART NUMBER INDEX

Part No.	Description	Pg. No.	Ref. No.	Qty.	Part No.	Description	Pg. No.	Ref. No.	Qty.
14-9949	Rear Wheel & Tire Assembly 8"	3	17	2	71-9900	Frame	4	4	1
17-1569	Door - Discharge	5	31	1	71-9990	Plug - Recycler	5	37	1
19-4050	Knob	2	3	2	80-0510	Stiffener - Blade	6	5	1
26-0672	Bolt - Blade	6	2	1	82-8550	Shield - Muffler	1	6	1
27-6230	Bolt - Wheel	3	1	2	92-2289	Plate - Logo	1	12	1
27-6230	Bolt - Wheel	5	26	2	92-7663	Cover - Wheel	3	20	1
27-6250	Bushing	3	19	2	92-7729	Anchor - Cable	2	7	1
27-6250	Bushing	5	36	2	92-7863	Decal - Deck	5	25	1
40-1940	Washer	3	18	2	93-0243	Shroud	1	10	1
40-1940	Washer	5	28	2	93-1116	Cable - Brake	2	6	1
46-1113	Wheel & Tire Assembly 7"	5	27	2	93-1118	Control - Throttle	2	13	1
46-6290	O-Ring	5	7	1	93-4105	Decal - Danger	5	35	1
46-6811	Screw - Hex Washer Head	5	32	2	93-4354	Decal - Engine	1	7	1
63-8590	Screw	3	3	2	93-8470	Screw - Clamp	1	4	1
65-5210	Screw - Thread Forming	5	16	2	94-4375	Handle	2	11	1
71-7740	Spring - Counterbalance	3	16	1	95-2747	Fitting - Washout	5	6	1
71-7770	Plate - Securing	3	10	2	95-4453	Screw - Handle	2	8	1
71-7800	Arm - Pivot	3	8	1	95-4457	Rope - Guide	2	10	1
71-7820	Pivot - Front	5	30	1	95-5924	Bail - Brake	2	12	1
71-7840	Rod - Trigger	3	9	1	95-6134	Housing Assembly	5	5	1
71-7860	Grip - Upper	5	15	1	2210-249	Clamp - Casting	1	3	1
71-7870	Grip - Lower	5	20	1	2210-316	Rope - Stop	1	9	1
71-7900	Cap - Bolt LH	5	12	1	321-48	Screw - Hex Head	2	14	1
71-7910	Cap - Bolt RH	5	17	1	322-29	Screw - Hex Head	5	13	2
71-7920	Cover - Belt	5	24	1	3253-22	Washer - Lock	6	3	1
71-7930	Trigger - Height of Cut	5	18	1	3256-1	Washer - Flat	2	9	1
71-7940	Retainer - Blade	6	1	1	3284-5	Pin - Groove	5	19	1
71-7970	Rod - Link	3	13	1	3290-378	Tie - Cable	2	1	1
71-7980	Indicator - Height of Cut	3	12	1	3290-378	Tie - Cable	1	2	1
71-7990	Ramp - Discharge	5	4	1	3296-5	Nut - Lock (Nylon)	3	7	2
71-8060	Spring - Trigger	3	5	2	3296-5	Nut - Lock (Nylon)	5	29	2
71-8080	Saddle - Height of Cut	3	4	1	3296-73	Nut - Lock Insert	2	2	3
71-8090	Mount - Handle LH	2	5	1	32112-11	Nut - Push	5	3	1
71-8100	Mount - Handle RH	2	4	1	32112-13	Nut - Push	3	2	1
71-8450	Cover - Spring	3	14	1	32144-4	Screw - Hex Head Tap	5	1	8
71-8580	Spacer - Door	5	9	2	32144-4	Screw - Hex Head Tap	3	11	4
71-8830	Retainer Shaft Assembly	5	2	2	32144-31	Screw	3	6	1
71-8920	Kicker - Front Right	5	10	1	32144-70	Screw - Tap	5	22	1
71-9230	Kicker - Rear Right	5	21	1	32144-73	Screw	1	1	3
71-9250	Kicker - Rear Left	5	33	1	32144-97	Screw - Phillips Pan Head	5	14	2
71-9260	Blade	6	4	1	32144-102	Screw	1	5	3
71-9440	Kicker - Front Left	5	34	1	32144-111	Screw - Phillips Pan Head	4	1	5
71-9460	Bag - Grass	4	5	1	32144-111	Screw - Phillips Pan Head	5	8	8
71-9470	Door - Bag	4	3	1	32144-121	Screw	1	11	2
71-9480	Handle Door	4	2	1	32151-93	Ring - Grip	3	15	1
71-9840	Spring - Door	5	11	2					

*Not Illustrated