

# **LAWN-BOY®**

## **21" Silver Series Walk-Behind Mower**

**Model No. 10313 – 8900001 & Up**

---

## **Parts Catalog**

## ORDERING REPLACEMENT PARTS

To order replacement parts, please supply: the part number, the quantity, and the description of each part desired.

## Contents

| Description                 | Page | Description                                    | Page  |
|-----------------------------|------|------------------------------------------------|-------|
| Housing Assembly .....      | 1    | Engine LEV120-361003A .....                    | 8-10  |
| Rear Axle Assembly .....    | 2    | Recoil Starter Assembly 590702 .....           | 11    |
| Engine Assembly .....       | 3    | Recoil Starter Assembly 590739 (Optional) .... | 12    |
| Handle Assembly .....       | 4    | Lawn-Boy Part Number Index .....               | 13-14 |
| Gear Case Assembly .....    | 5    | Maintenance .....                              | 15-17 |
| Rear Catcher Assembly ..... | 6    |                                                |       |
| Carburetor No. 640119 ..... | 7    |                                                |       |

**Note:**

## Accessories

| Description             | Model / Parts No. | Description                | Model / Parts No. |
|-------------------------|-------------------|----------------------------|-------------------|
| Side Bagging Kit .....  | Model No. 89814   | Leaf Bag Kit w/Chute ..... | Model No. 89811   |
| Leaf Bag .....          | Model No. 89804   | Mow & Feed .....           |                   |
| Leaf Shredder Kit ..... | Model No. 89860   | Fertilizer Spreader .....  | Model No. 50270   |

## Part Description Abbreviations

Part descriptions in this catalog may include the following abbreviations.

| Abbreviation | Meaning                | Abbreviation | Meaning                 |
|--------------|------------------------|--------------|-------------------------|
| AR .....     | as required            | HWHTF .....  | hex washer head         |
| ASM .....    | assembly               |              | thread forming          |
| CARR .....   | carriage               | INC .....    | incorporated            |
| DEG .....    | degrees                | LH .....     | left hand               |
| FH .....     | flat head              | PH .....     | pan head                |
| GA .....     | gauge                  | PPH .....    | Phillips pan head       |
| HF .....     | hex flange             | PTO .....    | power take off          |
| HFW .....    | hex flange washer      | RH .....     | right hand              |
| HH .....     | hex head               | SFH .....    | slotted fillister head  |
| HHF .....    | hex head flange        | SH .....     | square head             |
| HHST .....   | hex head self tapping  | SHWH .....   | slotted hex washer head |
| HJ .....     | hex jam                | SPH .....    | slotted pan head        |
| HOC .....    | height-of-cut          | STD .....    | standard                |
| HS .....     | hex socket             | TAP .....    | self tapping            |
| HSBH .....   | hex socket button head | TH .....     | truss head              |
| HSFH .....   | hex socket flat head   | TTH .....    | Torx truss head         |
| HSB .....    | hex socket head        | WH .....     | wing head               |
| HWH .....    | hex washer head        |              |                         |

## Important Format Explanations

This catalog uses special formats to convey information in illustrations and parts lists. Specifically, one format is used in conjunction with service assemblies and another with quantities associated with reference numbers.

## Service Assemblies

Parts within service assemblies have reference numbers in the form  $X:Y$ .  $X$  is the reference number of the service assembly and  $Y$  is a sequential number unique to each part within the service assembly.


For example, a wheel assembly might be identified by reference number 6, the tire by 6:1, the valve by 6:2, and the wheel by 6:3. When you order the assembly identified by reference number 6, you receive all parts identified by reference numbers 6:1, 6:2, and 6:3. However, you may also order any part individually.

Reference numbers of this type appear in part lists and as callouts in illustrations.

## Reference Numbers with Quantities

Illustrations may have a quantity in parentheses next to a reference number, in the form  $X (Y)$ .  $X$  is the reference number.  $Y$  in parentheses is the quantity of the part identified by the reference number.

For example, the illustration callout 4 (2) indicates that two parts are used in that instance.




Sheet No.:2

## Housing Assembly

| Ref. No. | Part No. | Qty. | Description              |
|----------|----------|------|--------------------------|
| 1        | 92-2915  | 1    | Decal-HOC                |
| 2        | 92-2914  | 1    | Decal-HOC                |
| 3        | 92-7724  | 1    | ASM-Handle Bracket       |
| 4        | 92-7735  | 1    | ASM-Gear Case            |
| 5        | 605120   | 1    | Grommet                  |
| 6        | 92-7728  | 1    | Guide-Transmission       |
| 7        | 98-8332  | 1    | Knob-Cover Plate         |
| 8        | 92-8630  | 1    | Mulch Plate-21"          |
| 9        | 614677   | 2    | Screw-Sems               |
| 10       | 94-1610  | 2    | Grommet-Plastic          |
| 11       | 613765   | 1    | Nut-Cage                 |
| 14       | 92-4881  | 2    | Plate-Height Adjust      |
| 15       | 92-4890  | 2    | Washer                   |
| 16       | 92-7731  | 2    | Plate-Baffle             |
| 17       | 95-7403  | 2    | Bracket-Wheel Height Adj |
| 18       | 40-1940  | 2    | Washer                   |
| 19       | 684776   | 2    | ASM-Wheel & Tire 6"      |
| 20       | 92-1099  | 2    | Bolt-Shoulder            |
| 21       | 614672   | 2    | Bolt-Shoulder            |
| 22       | 614687   | 2    | Spring Arm-Front         |
| 23       | 92-1008  | 4    | Knob-Height Adjust       |
| 24       | 49-2040  | 2    | Screw-HH                 |
| 26       | 92-9665  | 1    | Screw-Phil               |
| 27       | 95-7068  | 1    | Cover-Drive              |
| 28       | 93-7250  | 1    | Decal-Warning            |

| Ref. No. | Part No. | Qty. | Description          |
|----------|----------|------|----------------------|
| 30       | 92-7723  | 1    | ASM-Handle Bracket   |
| *31      | 614249   | 4    | Tie Strap            |
| *32      | 607560   | 1    | Plate-Cover          |
| 33       | 39-5770  | 1    | Decal-Danger         |
| 34       | 92-1097  | 1    | Decal-Discharge      |
| 35       | 98-4477  | 1    | ASM-Housing & Baffle |
| 37       | 3296-29  | 6    | Nut-Lock             |
| 38       | 92-8647  | 1    | Shield-Trailing      |
| 39       | 322-3    | 6    | Screw-HH             |
| 40       | 98-1567  | 1    | Decal-Deck           |


\* Not illustrated



## Rear Axle Assembly

| Ref. No. | Part No. | Qty. | Description        |
|----------|----------|------|--------------------|
| 1        | 92-1057  | 2    | Bolt-Shoulder      |
| 2        | 92-1042  | 2    | ASM-Whl            |
| 3        | 65-2720  | 4    | Ring-Retaining     |
| 4        | 65-4740  | 4    | Washer-Thrust      |
| 5        | 66-6050  | 1    | Key-Rocking LH     |
| 6        | 66-6040  | 1    | Key-Locking RH     |
| 7        | 65-4710  | 2    | Ring-Friction      |
| 8        | 92-7746  | 2    | ASM-Hgt Adj Arm    |
| 8:2      | 70-9760  | 2    | Bushing            |
| 8:3      | 47-2900  | 2    | Bushing            |
| 8:4      | 302-56   | 2    | Fitting-Grease     |
| 9        | 614447   | 2    | Spacer-Axle Shaft  |
| 10       | 93-7381  | 1    | V-Belt             |
| 11       | 32144-85 | 2    | Screw-HH           |
| 12       | 92-1004  | 2    | ASM-Spring Arm     |
| 13       | 610358   | 2    | Nut-Lock           |
| 14       | 65-4730  | 2    | Washer-Thrust      |
| 15       | 65-4760  | 2    | Washer             |
| 16       | 65-4750  | 2    | Gear-Pinion        |
| 17       | 65-4720  | 2    | Spring-Compression |
| 18       | 94-1609  | 2    | Cover-Wheel        |
| 19       | 614426   | 2    | Washer-Stepped     |


| Ref. No. | Part No. | Qty. | Description |
|----------|----------|------|-------------|
|          |          |      |             |



Sheet No.:4

Engine Assembly


| Ref. No. | Part No. | Qty. | Description           | Ref. No. | Part No. | Qty. | Description |
|----------|----------|------|-----------------------|----------|----------|------|-------------|
| 1        | 677525   | 1    | ASM-Plate & Collar    |          |          |      |             |
| 2        | 92-9575  | 1    | Pulley-Engine         |          |          |      |             |
| 3        | 95-1726  | 3    | Screw-Engine Mount    |          |          |      |             |
| 4        | 92-1024  | 1    | Guide-Belt            |          |          |      |             |
| 5        | 92-4851  | 1    | Decal-Oil Instruction |          |          |      |             |
| 6        |          | 1    | ASM-Engine            |          |          |      |             |
| 7        | 92-1701  | 1    | Rope-Stop             |          |          |      |             |
| 8        | 603164   | 1    | Nut-Blade             |          |          |      |             |
| 9        | 95-7449  | 1    | Decal-Shroud          |          |          |      |             |
| 10       | 92-4852  | 4    | Screw-Recoil Cover    |          |          |      |             |
| 11       | 92-4854  | 1    | Cover-Starter         |          |          |      |             |
| 12       | 94-6088  | 1    | Shroud-Engine         |          |          |      |             |
| 13       | 32144-85 | 1    | Screw-HH              |          |          |      |             |
| 14       | 65-2690  | 1    | Decal-Hot Surface     |          |          |      |             |
| 15       | 94-6066  | 1    | Guard-Muffler         |          |          |      |             |
| 16       | 613227   | 1    | Screw-Set             |          |          |      |             |
| 17       | 612543   | 1    | Blade-21" Whirl       |          |          |      |             |
| 18       | 92-1630  | 1    | Fan-Mulching          |          |          |      |             |
| 19       | 93-4196  | 1    | Shield-Grass          |          |          |      |             |
| 20       | 94-8083  | 1    | Decal-Primer          |          |          |      |             |



Sheet No.:5

## Handle Assembly

| Ref. No. | Part No. | Qty. | Description          |
|----------|----------|------|----------------------|
| 1        | 93-7380  | 1    | Anchor-Cable         |
| 2        | 614697   | 2    | Screw-Handle         |
| 3        | 98-7134  | 2    | Knob                 |
| 4        | 3296-73  | 2    | Nut-Lock             |
| 5        | 92-2266  | 1    | Screw-Handle         |
| 6        | 92-7729  | 1    | Anchor-Cable         |
| 7        | 92-7726  | 1    | Cable-Traction       |
| 8        | 92-5412  | 2    | Stop-Pivot           |
| 9        | 92-1001  | 1    | Bail-Sp Control      |
| 10       | 92-5424  | 1    | Staple-Handle        |
| 12       | 93-4184  | 1    | Bail-Flywheel Brake  |
| 13       | 95-1713  | 1    | Handle Section-Upper |
| 14       | 92-4853  | 1    | Handle-Starter       |
| 15       | 321-50   | 1    | Screw                |
| 16       | 93-7383  | 1    | Guide-Rope           |
| 18       | 98-1560  | 1    | ASM-Brake Cable      |
| 19       | 614643   | 1    | Handle Section-Lower |
| 38       | 93-3653  | 1    | Handle-Guard         |
| 41       | 3256-1   | 1    | Washer-Flat          |




Sheet No.:100

## Gear Case Assembly

| Ref. No. | Part No. | Qty. | Description        |
|----------|----------|------|--------------------|
| 1        | 614668   | 1    | Cover—Gear Case    |
| 2        | 92-7727  | 1    | Gearcase—Upper Ss  |
| 3        | 60-8850  | 2    | Bushing—Output     |
| 4        | 3285-19  | 2    | Pin—Spirol         |
| 5        | 614596   | 1    | Gear—34t           |
| 6        | 36-4780  | 2    | Washer—Thrust      |
| 7        | 93-0239  | 1    | Shaft—Output       |
| 8        | 614696   | 1    | Shaft—Intermediate |
| 9        | 32144-4  | 4    | Screw—TAP          |
| 10       | 55-3760  | 1    | 15 T Pinion        |
| 11       | 36-4791  | 2    | Washer—Thrust      |
| 12       | 60-8750  | 2    | Bushing            |
| 13       | 38-7820  | 1    | Bearing—Ball       |
| 14       | 3256-24  | 1    | Washer—Flat        |
| 15       | 60-8890  | 1    | Gear—Pinnion       |
| 16       | 3296-5   | 1    | Nut—Lock           |
| 17       | 614669   | 2    | Pulley—Half        |
| 18       | 62-6660  | 1    | Spacer—Pulley      |


| Ref. No. | Part No. | Qty. | Description |
|----------|----------|------|-------------|
|          |          |      |             |



Sheet No.:200

## Rear Catcher Assembly


| Ref. No. | Part No. | Qty. | Description         |
|----------|----------|------|---------------------|
| 1        | 684729   | 1    | ASM-Chute & Support |
| 2        | 614589   | 1    | Nut-Cap             |
| 3        | 614591   | 1    | Support-Chute       |
| 4        | 684727   | 1    | ASM-Adaptor         |
| 5        | 614700   | 1    | Tie Strap           |
| 6        |          | 1    | ASM-Bag & Adapter   |
| 7        | 613462   | 2    | Hanger-Clamp        |
| 8        | 613455   | 1    | Hanger-Wire         |
| 9        | 92-2919  | 1    | Decal-Danger        |



## CARBURETOR No. 640119

| Ref. No. | Part No. | Description                               | No. Used | Ref. No. | Part No. | Description                           | No. Used |
|----------|----------|-------------------------------------------|----------|----------|----------|---------------------------------------|----------|
| 1        | 631615   | Throttle Shaft & Lever Assembly           | 1        | 27       | 631024   | Float Shaft                           | 1        |
| 2        | 631767   | Throttle Return Spring                    | 1        | 28       | 632019   | Float                                 | 1        |
| 4        | 631184   | Dust Seal Washer                          | 1        | 29       | 631028   | Float Bowl "O" Ring                   | 1        |
| 5        | 631183   | Dust Seal (Throttle)                      | 1        | 30       | 631021   | Inlet Needle, Seat, & Clip (Incl. 31) | 1        |
| 6        | 640070   | Throttle Shutter                          | 1        | 31       | 631022   | Spring Clip                           | 1        |
| 7        | 650506   | Shutter Screw                             | 1        | 35       | 36045A   | Primer Bulb/Retainer Ring             | 1        |
| 16       | 631807   | Fuel Fitting                              | 1        | 36       | 632735   | Main Nozzle Tube                      | 1        |
| 17       | 651025   | Throttle Crack Screw/<br>Idle Speed Screw | 1        | 37       | 632547   | O-Ring, Main Nozzle Tube              | 2        |
| 18       | 630766   | Tension Spring                            | 1        | 40       | 632736   | High Speed Bowl Nut                   | 1        |
| 20       | 640016   | Idle Restrictor Screw                     | 1        | 44       | 27110    | Bowl Nut Washer                       | 1        |
| 20A      | 640053   | Idle Restrictor Screw Cap                 | 1        | 47       | 630748   | Welch Plug, Idle Mixture Well         | 1        |
| 25       | 631867   | Float Bowl                                | 1        | 48       | 631027   | Welch Plug, Atmospheric Vent          | 1        |

# ENGINE LEV120-361003A



**ENGINE LEV120-361003A**


| Ref. No. | Part No. | Description                                  | No. Used |
|----------|----------|----------------------------------------------|----------|
| 1        | 36774    | Cylinder<br>(Incl. 2 & 20))                  | 1        |
| 2        | 26727    | Dowel Pin                                    | 2        |
| 6        | 33734    | Breather Element                             | 1        |
| 7        | 36557    | Breather Body Ass'y.<br>(Incl. 6 & 12A)      | 1        |
| 12       | 36775    | Breather Tube                                | 1        |
| 12A      | 36558    | Breather Cover & Tube<br>(Incl. 12B)         | 1        |
| 12B      | 36694    | Breather Tube Elbow                          | 1        |
| 14       | 28277    | Washer                                       | 1        |
| 15       | 30589    | Governor Rod (Incl. 14)                      | 1        |
| 16       | 34839A   | Governor Lever                               | 1        |
| 17       | 31335    | Governor Lever Clamp                         | 1        |
| 18       | 651018   | Screw                                        | 1        |
| 19       | 36281    | Extension Spring                             | 1        |
| 20       | 32600    | Oil Seal                                     | 1        |
| 30       | 36597    | Crankshaft                                   | 1        |
| 40       | 40027    | Piston, Pin & Ring Set (Std.)                | 1        |
| 40       | 40028    | Piston, Pin & Ring Set<br>(.010" OS)         | 1        |
| 41       | 40025    | Piston & Pin Ass'y. (Std.)<br>(Incl. 43)     | 1        |
| 41       | 40026    | Piston & Pin Ass'y.<br>(.010" OS) (Incl. 43) | 1        |
| 42       | 40006    | Ring Set (Std.)                              | 1        |
| 42       | 40007    | Ring Set (.010" OS)                          | 1        |
| 43       | 20381    | Piston Pin Retaining Ring                    | 2        |
| 45       | 36777    | Connecting Rod Ass'y.<br>(Incl. 46)          | 1        |
| 46       | 32610A   | Connecting Rod Bolt                          | 2        |
| 48       | 27241    | Valve Lifter                                 | 2        |
| 50       | 36778    | Camshaft (MCR)                               | 1        |
| 52       | 29914    | Oil Pump Ass'y.                              | 1        |
| 69       | 35261    | Mounting Flange Gasket                       | 1        |
| 70       | 36995    | Mounting Flange<br>(Incl. 72 thru 83)        | 1        |
| 72       | 36083    | Oil Drain Plug                               | 1        |
| 75       | 27897    | Oil Seal                                     | 1        |
| 80       | 30574A   | Governor Shaft                               | 1        |
| 81       | 30590A   | Washer                                       | 1        |
| 82       | 30591    | Governor Gear Ass'y.<br>(Incl. 81)           | 1        |
| 83       | 30588A   | Governor Spool                               | 1        |
| 86       | 650488   | Screw                                        | 6        |
| 89       | 611004   | Flywheel Key                                 | 1        |
| 90       | 611112   | Flywheel                                     | 1        |
| 92       | 650815   | Belleville Washer                            | 1        |
| 93       | 650816   | Flywheel Nut                                 | 1        |
| 100      | 34443B   | Solid State Ignition                         | 1        |
| 101      | 610118   | Spark Plug Cover                             | 1        |
| 103      | 651007   | Screw, Torx T-15,                            | 2        |
| 110      | 37047    | Ground Wire                                  | 1        |
| 119      | 36787    | Cylinder Head Gasket                         | 1        |
| 120      | 36825    | Cylinder Head                                | 1        |
| 125      | 36779    | Exhaust Valve (Std.)<br>(Incl. 151)          | 1        |

| Ref. No. | Part No. | Description                             | No. Used |
|----------|----------|-----------------------------------------|----------|
| 125      | 36780    | Exhaust Valve (1/32" OS)<br>(Incl. 151) | 1        |
| 126      | 36781    | Intake Valve (Std.)<br>(Incl. 151)      | 1        |
| 126      | 36782    | Intake Valve (1/32" OS)<br>(Incl. 151)  | 1        |
| 130      | 6021A    | Screw                                   | 8        |
| 135      | 35395    | Resistor Spark Plug<br>(RJ19LM)         | 1        |
| 150      | 35991    | Valve Spring                            | 2        |
| 151      | 31673    | Valve Spring Cap                        | 2        |
| 151A     | 40017    | Intake Valve Seal                       | 1        |
| 169      | 36783    | Valve Cover Gasket                      | 1        |
| 172      | 36784    | Valve Cover                             | 1        |
| 174      | 30200    | Screw                                   | 2        |
| 178      | 29752    | Nut & Lock Washer                       | 2        |
| 182      | 6201     | Screw                                   | 2        |
| 184      | 26756    | Carburetor To Intake Pipe<br>Gasket     | 1        |
| 185      | 36785    | Intake Pipe                             | 1        |
| 186      | 32653    | Governor Link                           | 1        |
| 189      | 650839   | Screw                                   | 2        |
| 191      | 36559    | S.E. Brake Bracket<br>(Incl. 195)       | 1        |
| 195      | 610973   | Terminal                                | 1        |
| 207      | 34336    | Throttle Link                           | 1        |
| 216      | 33086    | R.P.M. Adjusting Lever                  | 1        |
| 223      | 650451   | Screw                                   | 2        |
| 224      | 36786    | Intake Pipe Gasket                      | 1        |
| 238      | 650932   | Screw                                   | 2        |
| 239      | 34338    | Air Cleaner Gasket                      | 1        |
| 241      | 35797    | Air Cleaner Collar                      | 1        |
| 245      | 35066    | Air Cleaner Filter                      | 1        |
| 250      | 35986    | Air Cleaner Cover                       | 1        |
| 260      | 36999    | Blower Housing                          | 1        |
| 261      | 30200    | Screw                                   | 2        |
| 262      | 650831   | Screw                                   | 2        |
| 275      | 36790    | Muffler                                 | 1        |
| 277      | 650988   | Screw                                   | 2        |
| 285      | 35000A   | Starter Cup                             | 1        |
| 287      | 650926   | Screw                                   | 2        |
| 290      | 34357    | Fuel Line                               | 1        |
| 292      | 26460    | Fuel Line Clamp                         | 2        |
| 300      | 35586    | Fuel Tank<br>(Incl. 292 & 301)          | 1        |
| 301      | 36246    | Fuel Cap                                | 1        |
| 305      | 35819A   | Oil Fill Tube                           | 1        |
| 306      | 36996    | "O" - Ring                              | 1        |
| 307      | 35499    | "O" - Ring                              | 1        |
| 309      | 651014   | Screw                                   | 1        |
| 310      | 36259    | Dipstick                                | 1        |
| 313      | 34080    | Spacer                                  | 1        |
| 370A     | 36261    | Lubrication Decal                       | 1        |
| 380      | 640119   | Carburetor<br>(Incl. 184)               | 1        |

**ENGINE LEV120 – 361003A**


| Ref. No. | Part No. | Description                                                                                                                                              | No. Used |
|----------|----------|----------------------------------------------------------------------------------------------------------------------------------------------------------|----------|
| 390      | 590702   | Rewind Starter<br>(NOTE: This engine could have been built with 590739 starter.                                                                          | 1        |
| 400      | 36792A   | Gasket Set<br>(Incl. Items Marked PK in Notes)<br>(Incl. part #'s 26756 (1), 28833 (1), 34388 (1) 35261 (1), 36786 (1) 36787 (1), 36832 (1) & 36996 (1). | 1        |
| 416      | 36085    | Spark Arrestor Kit<br>(Incl. 417) (Optional)                                                                                                             | 1        |
| 417      | 650760   | Screw (Optional)                                                                                                                                         | 1        |

| Ref. No. | Part No. | Description                          | No. Used |
|----------|----------|--------------------------------------|----------|
| 420      | 730225   | SAE 30 4–Cycle Engine Oil<br>(Quart) | 1        |



**RECOIL STARTER ASSEMBLY 590702**

| Ref. No. | Part No. | Description          | No. Used | Ref. No. | Part No. | Description                               | No. Used |
|----------|----------|----------------------|----------|----------|----------|-------------------------------------------|----------|
| 0        | 590702   | Recoil Starter       | 1        | 8        | 590700   | Pulley & Rewind Spring Ass'y.             | 1        |
| 1        | 590599A  | Spring Pin (Incl. 4) | 1        | 11       | 590703   | Starter Housing Ass'y (40 degree grommet) | 1        |
| 2        | 590600   | Washer               | 1        | 12       | 590535   | Starter Rope (98" X 9/64" dia.)           | 1        |
| 3        | 590696   | Retainer             | 1        | 13       | 590701   | Starter Handle                            | 1        |
| 4        | 590601   | Washer               | 2        |          |          |                                           |          |
| 5        | 590697   | Brake Spring         | 1        |          |          |                                           |          |
| 6        | 590698   | Starter Dog          | 2        |          |          |                                           |          |
| 7        | 590699   | Dog Spring           | 2        |          |          |                                           |          |



**RECOIL STARTER ASSEMBLY 590739 (Optional)**

| Ref. No. | Part No. | Description                  | No. Used | Ref. No. | Part No. | Description                               | No. Used |
|----------|----------|------------------------------|----------|----------|----------|-------------------------------------------|----------|
| 0        | 590739   | Rewind Starter               | 1        | 11       | 590638   | Starter Housing Ass'y (40 degree grommet) | 1        |
| 3        | 590740   | Retainer                     | 1        | 12       | 590535   | Starter Rope (Length 98" x 9/64" dia.)    | 1        |
| 6        | 590616   | Starter Dog                  | 2        | 13       | 590701   | Starter Handle                            | 1        |
| 7        | 590617   | Dog Spring                   | 2        | 14       | 590741   | Locking Tab                               | 1        |
| 8        | 590618A  | Pulley & Rewind Spring Ass'y | 1        |          |          |                                           |          |

# Lawn—Boy Part Number Index

| Part No. | Page No. | Ref. No. | Qty. | Description          |
|----------|----------|----------|------|----------------------|
| 603164   | 3        | 8        | 1    | Nut—Blade            |
| 605120   | 1        | 5        | 1    | Grommet              |
| 607560   | 1        | 32       | 1    | Plate—Cover          |
| 610358   | 2        | 13       | 2    | Nut—Lock             |
| 612543   | 3        | 17       | 1    | Blade—21" Whirl      |
| 613227   | 3        | 16       | 1    | Screw—Set            |
| 613455   | 6        | 8        | 1    | Hanger—Wire          |
| 613462   | 6        | 7        | 2    | Hanger—Clamp         |
| 613765   | 1        | 11       | 1    | Nut—Cage             |
| 614249   | 1        | 31       | 4    | Tie Strap            |
| 614426   | 2        | 19       | 2    | Washer—Stepped       |
| 614447   | 2        | 9        | 2    | Spacer—Axle Shaft    |
| 614589   | 6        | 2        | 1    | Nut—Cap              |
| 614591   | 6        | 3        | 1    | Support—Chute        |
| 614596   | 5        | 5        | 1    | Gear—34t             |
| 614643   | 4        | 19       | 1    | Handle Section—Lower |
| 614668   | 5        | 1        | 1    | Cover—Gear Case      |
| 614669   | 5        | 17       | 2    | Pulley—Half          |
| 614672   | 1        | 21       | 2    | Bolt—Shoulder        |
| 614677   | 1        | 9        | 2    | Screw—Sems           |
| 614687   | 1        | 22       | 2    | Spring Arm—Front     |
| 614696   | 5        | 8        | 1    | Shaft—Intermediate   |
| 614697   | 4        | 2        | 2    | Screw—Handle         |
| 614700   | 6        | 5        | 1    | Tie Strap            |
| 677525   | 3        | 1        | 1    | ASM—Plate & Collar   |
| 684727   | 6        | 4        | 1    | ASM—Adaptor          |
| 684729   | 6        | 1        | 1    | ASM—Chute & Support  |
| 684776   | 1        | 19       | 2    | ASM—Wheel & Tire 6"  |
| 36-4780  | 5        | 6        | 2    | Washer—Thrust        |
| 36-4791  | 5        | 11       | 2    | Washer—Thrust        |
| 38-7820  | 5        | 13       | 1    | Bearing—Ball         |
| 39-5770  | 1        | 33       | 1    | Decal—Danger         |
| 40-1940  | 1        | 18       | 2    | Washer               |
| 47-2900  | 2        | 8:3      | 2    | Bushing              |
| 49-2040  | 1        | 24       | 2    | Screw—HH             |
| 55-3760  | 5        | 10       | 1    | 15 T Pinion          |
| 60-8750  | 5        | 12       | 2    | Bushing              |
| 60-8850  | 5        | 3        | 2    | Bushing—Output       |
| 60-8890  | 5        | 15       | 1    | Gear—Pinnion         |
| 62-6660  | 5        | 18       | 1    | Spacer—Pulley        |
| 65-2690  | 3        | 14       | 1    | Decal—Hot Surface    |
| 65-2720  | 2        | 3        | 4    | Ring—Retaining       |
| 65-4710  | 2        | 7        | 2    | Ring—Friction        |
| 65-4720  | 2        | 17       | 2    | Spring—Compression   |
| 65-4730  | 2        | 14       | 2    | Washer—Thrust        |
| 65-4740  | 2        | 4        | 4    | Washer—Thrust        |
| 65-4750  | 2        | 16       | 2    | Gear—Pinion          |
| 65-4760  | 2        | 15       | 2    | Washer               |
| 66-6040  | 2        | 6        | 1    | Key—Locking RH       |
| 66-6050  | 2        | 5        | 1    | Key—Rocking LH       |
| 70-9760  | 2        | 8:2      | 2    | Bushing              |
| 92-1001  | 4        | 9        | 1    | Bail—Sp Control      |
| 92-1004  | 2        | 12       | 2    | ASM—Spring Arm       |
| 92-1008  | 1        | 23       | 4    | Knob—Height Adjust   |
| 92-1024  | 3        | 4        | 1    | Guide—Belt           |
| 92-1042  | 2        | 2        | 2    | ASM—Whl              |
| 92-1057  | 2        | 1        | 2    | Bolt—Shoulder        |
| 92-1097  | 1        | 34       | 1    | Decal—Discharge      |
| 92-1099  | 1        | 20       | 2    | Bolt—Shoulder        |
| 92-1630  | 3        | 18       | 1    | Fan—Mulching         |
| 92-1701  | 3        | 7        | 1    | Rope—Stop            |
| 92-2266  | 4        | 5        | 1    | Screw—Handle         |

\*Not Illustrated

# Lawn-Boy Part Number Index (cont.)

| Part No. | Page No. | Ref. No. | Qty. | Description              |
|----------|----------|----------|------|--------------------------|
| 92-2914  | 1        | 2        | 1    | Decal-HOC                |
| 92-2915  | 1        | 1        | 1    | Decal-HOC                |
| 92-2919  | 6        | 9        | 1    | Decal-Danger             |
| 92-4851  | 3        | 5        | 1    | Decal-Oil Instruction    |
| 92-4852  | 3        | 10       | 4    | Screw-Recoil Cover       |
| 92-4853  | 4        | 14       | 1    | Handle-Starter           |
| 92-4854  | 3        | 11       | 1    | Cover-Starter            |
| 92-4881  | 1        | 14       | 2    | Plate-Height Adjust      |
| 92-4890  | 1        | 15       | 2    | Washer                   |
| 92-5412  | 4        | 8        | 2    | Stop-Pivot               |
| 92-5424  | 4        | 10       | 1    | Staple-Handle            |
| 92-7723  | 1        | 30       | 1    | ASM-Handle Bracket       |
| 92-7724  | 1        | 3        | 1    | ASM-Handle Bracket       |
| 92-7726  | 4        | 7        | 1    | Cable-Traction           |
| 92-7727  | 5        | 2        | 1    | Gearcase-Upper Ss        |
| 92-7728  | 1        | 6        | 1    | Guide-Transmission       |
| 92-7729  | 4        | 6        | 1    | Anchor-Cable             |
| 92-7731  | 1        | 16       | 2    | Plate-Baffle             |
| 92-7735  | 1        | 4        | 1    | ASM-Gear Case            |
| 92-7746  | 2        | 8        | 2    | ASM-Hgt Adj Arm          |
| 92-8630  | 1        | 8        | 1    | Mulch Plate-21"          |
| 92-8647  | 1        | 38       | 1    | Shield-Trailing          |
| 92-9575  | 3        | 2        | 1    | Pulley-Engine            |
| 92-9665  | 1        | 26       | 1    | Screw-Phil               |
| 93-0239  | 5        | 7        | 1    | Shaft-Output             |
| 93-3653  | 4        | 38       | 1    | Handle-Guard             |
| 93-4184  | 4        | 12       | 1    | Bail-Flywheel Brake      |
| 93-4196  | 3        | 19       | 1    | Shield-Grass             |
| 93-7250  | 1        | 28       | 1    | Decal-Warning            |
| 93-7380  | 4        | 1        | 1    | Anchor-Cable             |
| 93-7381  | 2        | 10       | 1    | V-Belt                   |
| 93-7383  | 4        | 16       | 1    | Guide-Rope               |
| 94-1609  | 2        | 18       | 2    | Cover-Wheel              |
| 94-1610  | 1        | 10       | 2    | Grommet-Plastic          |
| 94-6066  | 3        | 15       | 1    | Guard-Muffler            |
| 94-6088  | 3        | 12       | 1    | Shroud-Engine            |
| 94-8083  | 3        | 20       | 1    | Decal-Primer             |
| 95-1713  | 4        | 13       | 1    | Handle Section-Upper     |
| 95-1726  | 3        | 3        | 3    | Screw-Engine Mount       |
| 95-7068  | 1        | 27       | 1    | Cover-Drive              |
| 95-7403  | 1        | 17       | 2    | Bracket-Wheel Height Adj |
| 95-7449  | 3        | 9        | 1    | Decal-Shroud             |
| 98-1560  | 4        | 18       | 1    | ASM-Brake Cable          |
| 98-1567  | 1        | 40       | 1    | Decal-Deck               |
| 98-4477  | 1        | 35       | 1    | ASM-Housing & Baffle     |
| 98-7134  | 4        | 3        | 2    | Knob                     |
| 98-8332  | 1        | 7        | 1    | Knob-Cover Plate         |
| 302-56   | 2        | 8:4      | 2    | Fitting-Grease           |
| 321-50   | 4        | 15       | 1    | Screw                    |
| 322-3    | 1        | 39       | 6    | Screw-HH                 |
| 3256-1   | 4        | 41       | 1    | Washer-Flat              |
| 3256-24  | 5        | 14       | 1    | Washer-Flat              |
| 3285-19  | 5        | 4        | 2    | Pin-Spirol               |
| 3296-5   | 5        | 16       | 1    | Nut-Lock                 |
| 3296-29  | 1        | 37       | 6    | Nut-Lock                 |
| 3296-73  | 4        | 4        | 2    | Nut-Lock                 |
| 32144-4  | 5        | 9        | 4    | Screw-TAP                |
| 32144-85 | 2        | 11       | 2    | Screw-HH                 |
| 32144-85 | 3        | 13       | 1    | Screw-HH                 |

\*Not Illustrated

[illegible]

[illegible]

17