



**Count on it.**

# Parts Catalog

## TimeCutter® HD MyRide 48in Riding Mower

Model No. 75210—Serial No. 400000000 and Up



# Ordering Replacement Parts

To order replacement parts, please supply the part number, the quantity, and the description of each part desired.

## Understanding Reference Numbers

Each identified part in an illustration has a reference number. The reference number for a part also appears in the parts list, along with other information about the part.

This catalog uses two special reference number formats, one to indicate parts in a service assembly and another to indicate the quantity of a given part in an illustration.

## Service Assembly Reference Numbers

Parts in service assemblies have reference numbers in the form a:b. The a represents the reference number of the entire service assembly and the b represents a sequential number unique to each part within the service assembly.

For example, a wheel assembly might be identified by reference number 6, the tire by 6:1, the valve by 6:2, and the wheel by 6:3. When you order the assembly identified by reference number 6, you receive all parts identified by reference numbers 6:1, 6:2, and 6:3. However, you may also order any part individually. Reference numbers of this type appear in illustration and in parts lists.

## Reference Numbers Indicating Quantity


In an illustration, if a reference number indicates more than one part, the reference number has the form nX y. The n represents the quantity of the part, the X is the multiplication symbol, and the y represents the reference number.

For example, in an illustration, the reference number 2X 37 means that two of the parts identified by reference number 37 are indicated.

# Contents

|                                               |    |
|-----------------------------------------------|----|
| Frame Assembly . . . . .                      | 4  |
| Deck Lift Assembly . . . . .                  | 6  |
| Caster Fork Assembly . . . . .                | 8  |
| Hydro Transmission Assembly . . . . .         | 10 |
| LH Transaxle Assembly No. 133-4420 . . . . .  | 12 |
| RH Transaxle Assembly No. 133-4421 . . . . .  | 14 |
| Parking Brake Assembly . . . . .              | 16 |
| Rear Tire and Wheel Assembly . . . . .        | 18 |
| Seat Assembly . . . . .                       | 20 |
| Seat Assembly No. 137-5007 . . . . .          | 22 |
| Motion Control Assembly . . . . .             | 24 |
| Engine Assembly . . . . .                     | 26 |
| Body Styling and Fuel Tank Assembly . . . . . | 28 |
| Fuel Tank Assembly No. 133-4484 . . . . .     | 30 |
| Electrical Assembly . . . . .                 | 32 |
| Deck Assembly . . . . .                       | 34 |
| Model Specific Decal Assembly . . . . .       | 36 |
| Series Decal Assembly . . . . .               | 38 |
| Clutch Assembly . . . . .                     | 40 |
| Attachments and Accessories . . . . .         | 42 |


Frame Assembly



## Frame Assembly (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>             | <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>      |
|-------------|--------------------|-------------|--------------------------------|-------------|--------------------|-------------|-------------------------|
| 1           | 133-1192-01        | 1           | Frame ASM                      | 20          | 131-0901-01        | 1           | Mount-Hydro, Front (RH) |
| 3           | 133-7051-03        | 1           | Bracket-Pod Support, LH        | 21          | 121-2989           | 2           | Decal-Bypass            |
| 4           | 136-4185-03        | 1           | Tray-Battery                   | 23          | 133-4431-03        | 1           | Guard-Engine            |
| 5           | 133-4383-01        | 1           | Bracket-Mounting, LH           | 24          | 99-4693            | 1           | Decal                   |
| 6           | 133-4384-01        | 1           | Bracket-Mounting, RH           | 26          | 133-9345-01        | 1           | Plate-Front             |
| 7           | 133-4413-01        | 1           | Brace-Cross, Lower             | 27          | 136-7472           | 1           | Decal-Timecutter HD     |
| 8           | 133-4435-01        | 1           | Bracket-Mount Damper,<br>Lower | 29          | 133-4303-01        | 1           | Crossmember-Rear        |
| 9           | 322-5              | 4           | Screw-HH                       | 30          | 133-4429-03        | 1           | Guard-Muffler           |
| 10          | 104-8301           | 10          | Nut-HF, NI                     | 31          | 117-1232-03        | 1           | Bracket-Hitch           |
| 11          | 3234-29            | 20          | Screw-HHF                      | 32          | 3234-47            | 6           | Screw-HHF               |
| 12          | 104-8300           | 30          | Nut-HF, NI                     | 33          | 133-1201-03        | 2           | Mount-Hydro             |
| 13          | 133-4485-03        | 1           | Bracket-Mount                  | 35          | 133-4414-01        | 2           | Bracket-Stop, Bump      |
| 14          | 32144-70           | 26          | Screw-HWHTF                    | 36          | 131-8834           | 4           | Bumper                  |
| 15          | 133-4310-01        | 1           | Axle-Front                     | 38          | 3296-42            | 4           | Nut-Lock, NI            |
| 16          | 3234-42            | 10          | Screw-HHF                      | 39          | 133-7072           | 2           | Guard-Rail              |
| 17          | 109-3678           | 4           | Bearing-Ball                   | 40          | 46-8091            | 6           | Screw-HWH               |
| 18          | 116-4348           | 2           | Cap-Grease                     | 41          | 325-4              | 2           | Screw-HH                |
| 19          | 131-0902-01        | 1           | Mount-Hydro, Front (LH)        | 42          | 99-5107            | 2           | Nut-Lock                |


# Deck Lift Assembly



## Deck Lift Assembly (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>  | <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i> |
|-------------|--------------------|-------------|---------------------|-------------|--------------------|-------------|--------------------|
| 1           | 131-4059-03        | 1           | Pivot-Rear          | 14          | 116-4312           | 1           | Grip-Flat          |
| 2           | 133-4430-03        | 1           | Pivot-Front         | 15          | 116-5584           | 1           | Pin-HOC            |
| 3           | 133-4316-03        | 2           | Plate               | 16          | 115-5065           | 4           | Bushing-Flange     |
| 4           | 3234-29            | 8           | Screw-HHF           | 17          | 116-2887           | 4           | Gusset-Lift, Deck  |
| 5           | 104-8300           | 16          | Nut-HF, NI          | 18          | 322-6              | 8           | Screw-HH           |
| 6           | 130-0742           | 8           | Bolt-Shoulder       | 19          | 130-0668           | 4           | Chain-Decklift     |
| 7           | 127-3390-03        | 1           | Link-HOC            | 20          | 133-4311-01        | 1           | Pan-Pivot, Deck    |
| 8           | 104-8301           | 10          | Nut-HF, NI          | 21          | 133-7071           | 1           | Rod-Pivot, Deck    |
| 9           | 127-3389-03        | 2           | Plate-Deck, Lift    | 22          | 3256-26            | 2           | Washer-Flat        |
| 10          | 133-7049           | 1           | Plate-Lift          | 23          | 1-806005           | 2           | Pin-Cotter         |
| 11          | 116-4313           | 4           | Spacer-Step, Double | 24          | 115-9652           | 1           | Spring-Extension   |
| 12          | 114-4681           | 4           | Screw-HHF           | 25          | 43-0940            | 4           | Spacer             |
| 13          | 127-3391           | 1           | Lock-Transport, HOC | 26          | 130-0734           | 2           | Pad-Rubber         |

# Caster Fork Assembly




## Caster Fork Assembly (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i> | <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i> |
|-------------|--------------------|-------------|--------------------|-------------|--------------------|-------------|--------------------|
| 1           | 126-4312-01        | 2           | Fork-Caster        | 4           | 126-5389           | 2           | Screw-HHF          |
| 2           | 133-4428           | 2           | Tire And Wheel ASM | 5           | 99-5107            | 2           | Nut-Lock           |
| 2:2         | 125-5581           | 1           | Tire               | 6           | 133-7088           | 4           | Guard-Seal         |
| 2:3         | 232-27             | 1           | Stem-Valve         | 7           | 3256-68            | 2           | Washer-Flat        |
| 2:4         | 136-4190           | 2           | Bearing            | 8           | 3234-47            | 2           | Screw-HHF          |
| 2:99        | 232-46             | 1           | Tube-Inner ●■      | 9           | 136-5590           | 4           | Washer             |
| 3           | 133-4487           | 2           | Spanner-Wheel      |             |                    |             |                    |

● Not illustrated

■ Optional Equipment


# Hydro Transmission Assembly



## Hydro Transmission Assembly (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>           | <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>  |
|-------------|--------------------|-------------|------------------------------|-------------|--------------------|-------------|---------------------|
| 1           | 119-3353           | 2           | Spacer                       | 20          | 242-50             | 8           | Nut-Lug             |
| 2           | 106-2176           | 2           | Pulley-Idler                 | 21          | 130-0718-01        | 1           | Plate-Cross, Hydro  |
| 3           | 1-613235           | 1           | Washer                       | 22          | 323-11             | 2           | Screw-HH            |
| 4           | 110-9981           | 3           | Washer-Plain                 | 23          | 323-7              | 2           | Screw-HH            |
| 5           | 114-8549           | 1           | Bushing                      | 24          | 323-9              | 2           | Screw-HH            |
| 6           | 114-0463           | 2           | Washer-Friction, Composite   | 25          | 104-8301           | 6           | Nut-HF, NI          |
| 7           | 133-4423           | 1           | Arm-Idler                    | 26          | 133-4304           | 1           | Rod Bypass, RH      |
| 8           | 104-6415           | 1           | Spring-Return, Pedal         | 27          | 133-4305           | 1           | Rod Bypass, LH      |
| 9           | 322-9              | 1           | Screw-HH                     | 28          | 3256-22            | 2           | Washer-Flat         |
| 10          | 104-8300           | 9           | Nut-HF, NI                   | 29          | 3290-307           | 2           | Pin-Cotter          |
| 11          | 119-9784           | 1           | Screw-CARR                   | 30          | 322-14             | 2           | Screw-HH            |
| 12          | 119-8822           | 1           | Pulley-Idler                 | 31          | 133-1247           | 2           | Support-Hydro, Rear |
| 13          | 3230-6             | 1           | Screw-CARR                   | 32          | 3296-29            | 2           | Nut-Lock, NI        |
| 14          | 133-4371           | 1           | V-Belt                       | 34          | 325-6              | 4           | Screw-HH            |
| 15          | 133-4420           | 1           | LH Hydro Transmission<br>ASM | 35          | 136-4183           | 2           | Breather Kit        |
| 16          | 133-4421           | 1           | RH Hydro Transmission<br>ASM | 36          | 105-1853           | 2           | Clamp-Hose          |
| 17          | 322-11             | 2           | Screw-HH                     | 38          | 136-4182           | 2           | Hose-Hydro          |
| 18          | 3256-23            | 6           | Washer-Plain                 | 39          | 117-1193           | 4           | Clamp-Hose          |
| 19          | 322-13             | 4           | Screw-HH                     | 40          | 3256-3             | 1           | Washer-Flat         |
|             |                    |             |                              | 41          | 99-5107            | 4           | Nut-Lock            |


# LH Transaxle Assembly No. 133-4420



# LH Transaxle Assembly No. 133-4420 (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>       | <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>           |
|-------------|--------------------|-------------|--------------------------|-------------|--------------------|-------------|------------------------------|
| 1           | 117-5357           | 1           | RH Main Housing Kit      | 82          | 120-7974           | 1           | Gear-11T                     |
| 2           | 117-5358           | 1           | RH Housing Side Kit      | 83          | 104-5329           | 1           | Pin-Jackshaft                |
| 7           | 117-5359           | 16          | Screw-HHF                | 90          | 104-2169           | 1           | Ring-Retaining               |
| 11          | 135-1140           | 1           | Plug-Straight            | 91          | 114-1694           | 1           | Gear-54T                     |
| 23          | 109-3321           | 1           | Element-Oil Filter, HYD  | 92          | 120-7975           | 1           | Spacer                       |
| 30          | 106-8676           | 1           | Seal-Lip                 | 93          | 137-2004           | 1           | Bearing Kit                  |
| 31          | 106-8677           | 1           | Ring-Retaining, External | 95          | 109-8110           | 1           | Input Bearing Kit            |
| 32          | 114-1685           | 1           | Rod-Bypass               | 96          | 130-8478           | 1           | Seal-Lip                     |
| 33          | 106-8679           | 1           | Ring-Retaining, Internal | 97          | 109-5939           | 1           | Hub Kit                      |
| 34          | 112-9852           | 1           | Arm-Bypass               | 102         | 125-0021           | 1           | Handle-Brake                 |
| 35          | 106-8681           | 1           | Ring-Retaining, External | 103         | 131-0906           | 1           | Ring-Retaining, EXT          |
| 40          | 104-5304           | 1           | Swashplate-Trunnion      | 105         | 104-2120           | 3           | Screw                        |
| 41          | 104-5313           | 1           | Seal-Lip                 | 106         | 120-7981           | 1           | Guard-Filter, RH             |
| 42          | 104-2116           | 1           | Stud                     | 111         | 109-3278           | 1           | Adapter-Straight             |
| 43          | 112-9853           | 1           | Puck-Friction            | 130         | 126-3251           | 2           | Tube-Charge                  |
| 55          | 104-5308           | 1           | Spacer                   | 156         | 115-5057           | 1           | Cover-Nut, Axle              |
| 56          | 104-5310           | 1           | Seal-Lip                 | 157         | 130-8486           | 1           | Seal-Gerotor                 |
| 57          | 104-5309           | 1           | Ring-Retaining           | 164         | 121-5745           | 1           | Spacer                       |
| 60          | 112-4154           | 1           | Bearing-Thrust           | 200         | 109-3537           | 1           | Seal Kit                     |
| 64          | 114-1689           | 1           | Motor Cylinder Block Kit | 201         | 137-2005           | 1           | RH Charge Center Section Kit |
| 65          | 94-6922            | 1           | Bearing-Thrust           | 202         | 114-8464           | 1           | Charge Relief Kit            |
| 69          | 110-8561           | 1           | Pump Block ASM           | 203         | 114-8465           | 1           | Charge Kit                   |
| 70          | 104-5339           | 1           | Washer-Flat              | 207         | 137-2006           | 1           | Fan Pulley Kit               |
| 71          | 104-5340           | 1           | Ring-Retaining           | 209         | 114-8467           | 1           | Puller-Hub, 4 Bolt           |
| 72          | 131-0905           | 1           | Gear-14T                 | 210         | 117-5361           | 1           | Input Shaft Kit              |
| 73          | 114-1691           | 1           | Shaft-Motor              | 211         | 117-5362           | 1           | Control Arm Kit              |
| 74          | 104-5360           | 1           | Washer                   | 212         | 114-8470           | 1           | Axle Shaft Kit               |
| 80          | 119-5541           | 2           | Washer                   | 215         | 137-2007           | 1           | Brake Shaft Kit              |
| 81          | 114-1692           | 1           | Gear-45T                 |             |                    |             |                              |

# RH Transaxle Assembly No. 133-4421




200 = Items Included in Seal Repair Kit

## RH Transaxle Assembly No. 133-4421 (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>       | <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>           |
|-------------|--------------------|-------------|--------------------------|-------------|--------------------|-------------|------------------------------|
| 1           | 114-8471           | 1           | LH Main Housing Kit      | 82          | 120-7974           | 1           | Gear-11T                     |
| 2           | 114-8472           | 1           | LH Side Cover Kit        | 83          | 104-5329           | 1           | Pin-Jackshaft                |
| 7           | 117-5359           | 16          | Screw-HHF                | 90          | 104-2169           | 1           | Ring-Retaining               |
| 11          | 135-1140           | 1           | Plug-Straight            | 91          | 114-1694           | 1           | Gear-54T                     |
| 23          | 109-3321           | 1           | Element-Oil Filter, HYD  | 92          | 120-7975           | 1           | Spacer                       |
| 30          | 106-8676           | 1           | Seal-Lip                 | 93          | 137-2004           | 1           | Bearing Kit                  |
| 31          | 106-8677           | 1           | Ring-Retaining, External | 95          | 109-8110           | 1           | Input Bearing Kit            |
| 32          | 114-1685           | 1           | Rod-Bypass               | 96          | 130-8478           | 1           | Seal-Lip                     |
| 33          | 106-8679           | 1           | Ring-Retaining, Internal | 97          | 109-5939           | 1           | Hub Kit                      |
| 34          | 107-2490           | 1           | Arm-Bypass               | 102         | 125-0021           | 1           | Handle-Brake                 |
| 35          | 106-8681           | 1           | Ring-Retaining, External | 103         | 131-0906           | 1           | Ring-Retaining, EXT          |
| 40          | 104-5304           | 1           | Swashplate-Trunnion      | 105         | 104-2120           | 3           | Screw                        |
| 41          | 104-5313           | 1           | Seal-Lip                 | 106         | 120-7979           | 1           | Guard-Filter, LH             |
| 42          | 104-2116           | 1           | Stud                     | 111         | 109-3278           | 1           | Adapter-Straight             |
| 43          | 112-9853           | 1           | Puck-Friction            | 130         | 126-3251           | 2           | Tube-Charge                  |
| 55          | 104-5308           | 1           | Spacer                   | 156         | 115-5057           | 1           | Cover-Nut, Axle              |
| 56          | 104-5310           | 1           | Seal-Lip                 | 157         | 130-8486           | 1           | Seal-Gerotor                 |
| 57          | 104-5309           | 1           | Ring-Retaining           | 164         | 121-5745           | 1           | Spacer                       |
| 60          | 112-4154           | 1           | Bearing-Thrust           | 200         | 109-3537           | 1           | Seal Kit                     |
| 64          | 114-1689           | 1           | Motor Cylinder Block Kit | 201         | 137-2012           | 1           | LH Charge Center Section Kit |
| 65          | 94-6922            | 1           | Bearing-Thrust           | 202         | 114-8464           | 1           | Charge Relief Kit            |
| 69          | 110-8561           | 1           | Pump Block ASM           | 203         | 114-8465           | 1           | Charge Kit                   |
| 70          | 104-5339           | 1           | Washer-Flat              | 207         | 137-2006           | 1           | Fan Pulley Kit               |
| 71          | 104-5340           | 1           | Ring-Retaining           | 209         | 114-8467           | 1           | Puller-Hub, 4 Bolt           |
| 72          | 131-0905           | 1           | Gear-14T                 | 210         | 117-5361           | 1           | Input Shaft Kit              |
| 73          | 114-1691           | 1           | Shaft-Motor              | 211         | 117-5362           | 1           | Control Arm Kit              |
| 74          | 104-5360           | 1           | Washer                   | 212         | 114-8470           | 1           | Axle Shaft Kit               |
| 80          | 119-5541           | 2           | Washer                   | 215         | 137-2013           | 1           | Brake Shaft Kit              |
| 81          | 114-1692           | 1           | Gear-45T                 |             |                    |             |                              |


# Parking Brake Assembly



## Parking Brake Assembly (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>      | <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>       |
|-------------|--------------------|-------------|-------------------------|-------------|--------------------|-------------|--------------------------|
| 1           | 136-5554           | 1           | Detent-Brake            | 12          | 3256-23            | 5           | Washer-Plain             |
| 2           | 136-7476           | 1           | Lever-Brake             | 13          | 3290-307           | 8           | Pin-Cotter               |
| 3           | 136-5648           | 1           | Bushing-Flange          | 14          | 133-9341-03        | 2           | Plate-Support, Bellcrank |
| 4           | 136-5647           | 1           | Bushing-Brake, Flanged  | 15          | 136-7469           | 2           | Bearing-Spherical        |
| 5           | 126-8220           | 1           | Spring-Wave             | 16          | 3234-47            | 4           | Screw-HHF                |
| 6           | 126-7439           | 1           | Screw-Torx              | 17          | 133-9343           | 1           | Rod-Brake, RH            |
| 7           | 104-8300           | 5           | Nut-HF, NI              | 18          | 133-9344           | 1           | Rod-Brake, LH            |
| 9           | 133-9338           | 1           | Bellcrank-Brake         | 19          | 1-603807           | 2           | Spring-Return, Neutral   |
| 10          | 133-9342           | 1           | Rod-Brake, Intermediate | 20          | 110769             | 2           | Spring-Extension         |
| 11          | 115-9681           | 2           | Fitting-Rod             |             |                    |             |                          |

# Rear Tire and Wheel Assembly




## Rear Tire and Wheel Assembly (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i> |
|-------------|--------------------|-------------|--------------------|
| 1           | 127-3449           | 2           | Tire And Wheel ASM |
| 1:2         | 125-1821           | 1           | Tire               |

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i> |
|-------------|--------------------|-------------|--------------------|
| 1:3         | 232-27             | 1           | Stem-Valve         |
| 1:99        | 105-4070           | 1           | Tube-Inner ●       |

● Optional Equipment

# Seat Assembly



## Seat Assembly (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>               | <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>               |
|-------------|--------------------|-------------|----------------------------------|-------------|--------------------|-------------|----------------------------------|
| 1           | 136-9191           | 1           | Subframe-Front                   | 24          | 131-6456           | 8           | Screw-HWH                        |
| 1:2         | 132-0869           | 1           | Decal-Danger                     | 25          | 3296-2             | 8           | Nut-Lock, NI                     |
| 1:3         | 136-7470           | 1           | Decal                            | 26          | 133-4438           | 2           | Rod-Swing Arm                    |
| 3           | 133-9319-03        | 1           | Bracket-Shock Mount,<br>Upper RH | 33          | 137-5007           | 1           | Seat ASM                         |
| 4           | 133-4442-03        | 1           | Bracket-Mount, Lower             | 37          | 107069             | 1           | Clip                             |
| 5           | 133-4462-03        | 1           | Bracket-Mounting, Shock          | 38          | 131-1038           | 1           | Bracket-Stop, Seat               |
| 6           | 133-4387-03        | 2           | Bracket-Mount, Swing Arm         | 39          | 99-6810            | 1           | Screw-HHF                        |
| 7           | 133-7029-03        | 1           | Pan-Seat                         | 40          | 131-4008-03        | 1           | Bracket-Latch, Seat              |
| 8           | 32144-70           | 16          | Screw-HWHTF                      | 43          | 133-7084           | 1           | Subframe-Rear                    |
| 9           | 3231-22            | 3           | Screw-CARR                       | 44          | 133-7089-03        | 2           | Plate-Backer                     |
| 10          | 104-8301           | 11          | Nut-HF, NI                       | 45          | 323-6              | 4           | Screw-HH                         |
| 11          | 131-4651           | 1           | Shock ASM                        | 47          | 32144-109          | 4           | Screw-Taptite                    |
| 13          | 99-5107            | 6           | Nut-Lock                         | 49          | 133-9318-03        | 1           | Bracket-Shock Mount,<br>Upper LH |
| 14          | 133-5109           | 2           | Bearing-Sleeve                   | 50          | 56-6590            | 2           | Bolt-Wheel                       |
| 15          | 133-5154           | 2           | Shock/Spring ASM                 | 51          | 133-5190           | 1           | Floormat                         |
| 16          | 136-5636           | 2           | Knob-Lock, Cam                   | 52          | 117-2382           | 4           | Plug-Plastic                     |
| 17          | 131-4699           | 2           | Washer-Plastic                   | 53          | 133-5198           | 1           | Decal-Adjustment, Ride           |
| 19          | 133-5105           | 2           | Cam Lock ASM                     | 54          | 3296-45            | 2           | Nut-Lock, NI                     |
| 20          | 133-4401           | 2           | Bolt-Shoulder                    | 55          | 3-6803             | 2           | Washer-Adjusting                 |
| 22          | 133-4467-03        | 1           | Plate-Swing Arm                  | 58          | 52-7280            | 4           | Washer-Thrust                    |
| 23          | 136-5566           | 4           | Bearing-Flange                   |             |                    |             |                                  |

# Seat Assembly No. 137-5007




## Seat Assembly No. 137-5007 (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>   |
|-------------|--------------------|-------------|----------------------|
| 2           | 137-5005           | 1           | Cushion-Seat, Back   |
| 3           | 137-5006           | 1           | Custion-Seat, Bottom |
| 4           | 131-4153           | 1           | Track ASM            |
| 5           | 131-4154           | 1           | Bushing ASM          |

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i> |
|-------------|--------------------|-------------|--------------------|
| 6           | 131-4155           | 1           | Armrest Kit        |
| 7           | 131-4156           | 1           | Shell              |
| 8           | 82-2190            | 1           | Switch-Bail        |
| 9           | 110-4163           | 2           | Cushion-Rest, Arm  |


# Motion Control Assembly



## Motion Control Assembly (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i> | <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>     |
|-------------|--------------------|-------------|--------------------|-------------|--------------------|-------------|------------------------|
| 1           | 136-5614-03        | 1           | Box-Control, LH    | 20:1        | 121-0726           | 1           | Grip                   |
| 2           | 136-5613-03        | 1           | Box-Control, RH    | 21          | 3256-24            | 4           | Washer-Flat            |
| 4           | 32144-70           | 2           | Screw-HWHTF        | 22          | 323-6              | 4           | Screw-HH               |
| 5           | 3234-47            | 8           | Screw-HHF          | 23          | 117-5385           | 2           | Retainer               |
| 6           | 104-8300           | 12          | Nut-HF, NI         | 24          | 32144-1            | 4           | Screw-Taptite          |
| 7           | 119-3470           | 2           | Actuator Arm ASM   | 25          | 133-5165           | 1           | Control-Speed          |
| 7:2         | 256-156            | 2           | Bushing-Flange     | 26          | 132-9368           | 1           | Knob-RH                |
| 8           | 115-5099           | 2           | Bolt-Pivot         | 27          | 132-9369           | 1           | Knob-LH                |
| 9           | 104-8301           | 5           | Nut-HF, NI         | 28          | 94-4496            | 1           | Screw-PPH              |
| 10          | 120-2273           | 2           | Washer-Nylon       | 29          | 117-5388           | 2           | Rod-Hydro              |
| 11          | 136-5570-05        | 2           | Arm-Control        | 30          | 119-8842           | 2           | Mount-Rod, Hydro       |
| 12          | 117-1240           | 2           | Washer             | 31          | 3256-23            | 2           | Washer-Plain           |
| 13          | 117-1198           | 2           | Bolt-Pivot         | 32          | 1-603807           | 2           | Spring-Return, Neutral |
| 14          | 119-8952           | 2           | Washer             | 33          | 121-1753           | 2           | Pin-Rod, Hydro         |
| 15          | 120-7950           | 2           | Screw-Shoulder     | 34          | 93-6079            | 2           | Spacer-Nylon           |
| 16          | 131-0964           | 2           | Damper             | 35          | 321-3              | 2           | Screw-HH               |
| 17          | 110-6810           | 2           | Stud-Damper        | 36          | 3296-56            | 2           | Nut-Lock, NI           |
| 18          | 3296-42            | 4           | Nut-Lock, NI       | 37          | 119-8925           | 2           | Washer-Belleville      |
| 19          | 133-7055           | 1           | Handle-Control, LH | 38          | 119-8876           | 2           | Spring-Return          |
| 19:1        | 121-0726           | 1           | Grip               | 41          | 136-2751-03        | 1           | Gate-Control, Speed    |
| 20          | 133-7057           | 1           | Handle-Control, RH | 42          | 323-5              | 1           | Screw-HH               |

# Engine Assembly




## Engine Assembly (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>                  | <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i> |
|-------------|--------------------|-------------|-------------------------------------|-------------|--------------------|-------------|--------------------|
| 1           |                    | 1           | Engine-Kawasaki,<br>Fr651V-S12-R ●■ | 1:3         | 114-3550           | 4           | Washer-Lock        |
| 1:1         | 1-653313           | 2           | Gasket-Exhaust                      | 2           | 130-0673           | 1           | Muffler            |
| 1:2         | 114-3549           | 4           | Nut                                 | 3           | 3256-24            | 4           | Washer-Flat        |
|             |                    |             |                                     | 4           | 323-50             | 4           | Bolt-HH            |

● Not serviced separately

■ Order Parts from Kawasaki


# Body Styling and Fuel Tank Assembly



## Body Styling and Fuel Tank Assembly (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>        | <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>       |
|-------------|--------------------|-------------|---------------------------|-------------|--------------------|-------------|--------------------------|
| 1           | 133-4484           | 1           | Fuel Tank ASM             | 22          | 136-7526           | 1           | Hose, Fuel               |
| 2           | 136-4180           | 1           | Rod-Hold Down             | 23          | 119-8501           | 1           | Hose-Vent, Formed        |
| 3           | 133-9307           | 1           | Pod-RH                    | 24          | 119-8502           | 1           | Hose-Vent, Formed        |
| 4           | 133-9315           | 1           | Pod-LH                    | 25          | 114-0292           | 1           | Bracket-Canister, Carbon |
| 5           | 120-5461           | 1           | Cap-Fuel, Ratcheting      | 26          | 117-1221           | 1           | Canister-Carbon, 800Cc   |
| 7           | 107069             | 2           | Clip                      | 27          | 115-7854           | 1           | Filter-Fuel, Inline      |
| 8           | 133-9346-03        | 1           | Panel-Control             | 28          | 133-9292-03        | 1           | Carb Canister Bracket    |
| 9           | 133-9263           | 1           | Decal-Control W/Choke     | 29          | 321-4              | 2           | Screw-HH                 |
| 10          | 3258-166           | 2           | Screw-PRH                 | 30          | 3296-42            | 2           | Nut-Lock, NI             |
| 11          | 120-7950           | 4           | Screw-Shoulder            | 31          | 117-5399           | 1           | Adaptor-Orifice          |
| 12          | 136-5622           | 1           | Cable-Throttle            | 32          | 99-9415            | 1           | Hose-Fuel                |
| 13          | 112-9753           | 1           | Cable-Choke               | 33          | 116-2232           | 1           | Valve-Control, Vacuum    |
| 14          | 3253-21            | 1           | Washer-Lock               | 34          | 2412-98            | 3           | Clamp-Hose               |
| 15          | 3220-3             | 1           | Nut-HJ                    | 35          | 3334-945           | 1           | Tie-Cable                |
| 16          | 136-4243           | 1           | Decal-Lever, Control (LH) | 36          | 133-9308           | 1           | Cover-Battery            |
| 17          | 136-4244           | 1           | Decal-Lever, Control (RH) | 37          | 32144-4            | 1           | Screw-HWH                |
| 18          | 105-1853           | 2           | Clamp-Hose                | 38          | 136-4195           | 2           | Screw-Shoulder           |
| 19          | 110-5701           | 1           | Hose-Fuel                 | 39          | 121-5840           | 2           | Fastener                 |
| 20          | 136-7525           | 1           | Hose-Fuel                 | 40          | 116-2469           | 1           | Strap-Velcro, Cable Tie  |
| 21          | 109-0307           | 1           | Hose-Fuel                 | 41          | 614249             | 5           | Tie-Cable                |

# Fuel Tank Assembly No. 133-4484




## Fuel Tank Assembly No. 133-4484 (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i> |
|-------------|--------------------|-------------|--------------------|
| 2           | 46-6560            | 2           | Bushing            |
| 3           | 117-7400           | 1           | Fitting-Plastic    |
| 4           | 133-9269           | 1           | Grommet-Fuel       |

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>      |
|-------------|--------------------|-------------|-------------------------|
| 5           | 133-9270           | 1           | Gauge-Fuel              |
| 6           | 121-0793           | 1           | Connector-Elbow, 90 DEG |


# Electrical Assembly



## Electrical Assembly (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i> | <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>      |
|-------------|--------------------|-------------|--------------------|-------------|--------------------|-------------|-------------------------|
| 1           | 105-1692           | 1           | Battery            | 11          | 32128-33           | 3           | Nut-HF                  |
| 2           | 137-4100           | 1           | Switch-Ignition    | 12          | 104-2466           | 1           | Holddown-Battery        |
| 3           | 63-8360            | 1           | Key-Ignition       | 13          | 3220-2             | 2           | Nut-Jam                 |
| 4           | 117-1197           | 1           | Solenoid           | 14          | 120-2244           | 1           | Hourmeter               |
| 5           | 103-5221           | 1           | Switch-PTO         | 15          | 115-3864           | 1           | Cable-Battery, Positive |
| 6           | 110-6765           | 2           | Switch             | 16          | 136-7473           | 1           | Cable-Battery, Positive |
| 7           | 136-4191           | 1           | Harness-Wiring     | 17          | 117-7240           | 1           | Cable-Battery, Negative |
| 7:6         | 109102             | 1           | Fuse-Blade, 25 Amp | 20          | 33104-016          | 1           | Screw-HHF               |
| 7:9         | 100-4918           | 1           | Diode              | 21          | 126-6499           | 1           | Port-Power, 12V         |
| 7:16        | 109355             | 1           | Fuse-Blade, 15 Amp | 22          | 99-7408            | 1           | Switch-Reverse          |
| 8           | 32144-4            | 2           | Screw-HWH          | 23          | 98-7249            | 1           | Relay                   |
| 9           | 3256-22            | 2           | Washer-Flat        | 24          | 32144-1            | 1           | Screw-Taptite           |
| 10          | 321-3              | 2           | Screw-HH           | 25          | 614249             | 1           | Tie-Cable               |

# Deck Assembly



## Deck Assembly (continued)




| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>         | <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>  |
|-------------|--------------------|-------------|----------------------------|-------------|--------------------|-------------|---------------------|
| 1           | 133-7066           | 1           | Deck ASM                   | 23          | 3231-31            | 1           | Screw-CARR          |
| 1:2         | 130-0731           | 1           | Decal-Danger               | 24          | 115-2577           | 3           | Bushing-Idler       |
| 1:3         | 132-0872           | 2           | Decal-Danger, Deck         | 25          | 132-4718           | 3           | Pulley-Idler, Flat  |
| 1:4         | 130-0765           | 1           | Decal-Scalp, Anti          | 26          | 80-6990            | 3           | Washer-Hardened     |
| 1:5         | 117-1194           | 1           | Decal-Routing, Belt        | 27          | 323-9              | 3           | Screw-HH            |
| 1:6         | 322-2              | 1           | Screw-HH                   | 28          | 104-8301           | 6           | Nut-HF, NI          |
| 1:7         | 104-8300           | 1           | Nut-HF, NI                 | 29          | 108-4056           | 1           | Spring-Extension    |
| 6           | 133-9283           | 1           | Cover-Belt, RH             | 30          | 117-7418-03        | 1           | Baffle-Cutoff       |
| 7           | 133-9282           | 1           | Cover-Belt, LH             | 31          | 3230-22            | 2           | Screw-CARR          |
| 8           | 120-5477           | 3           | Spindle ASM                | 32          | 104-8300           | 3           | Nut-HF, NI          |
| 8:2         | 116-0720           | 2           | Bearing-Ball               | 33          | 133-9289           | 2           | Fitting-Washout     |
| 8:3         | 115-2641           | 1           | Spacer-Bearing             | 33:2        | 133-9290           | 1           | O-Ring              |
| 9           | 32144-41           | 18          | Screw-Taptite              | 36          | 95-3270            | 1           | Connector-Hose      |
| 10          | 32144-4            | 12          | Screw-HWH                  | 37          | 1-603299           | 3           | Roller-Scalp, Anti  |
| 11          | 115-2642           | 3           | Shaft-Spindle              | 38          | 98-7912            | 3           | Tube-Spanner        |
| 12          | 117-7210           | 3           | Shield-Bearing             | 39          | 104-0892           | 3           | Spacer-Axle, Rear   |
| 13          | 117-7326           | 3           | Pulley                     | 40          | 323-23             | 3           | Screw-HH            |
| 14          | 7-4150             | 3           | Washer                     | 41          | 133-7075           | 1           | V-Belt              |
| 15          | 3219-7             | 3           | Nut-Hex                    | 42          | 119-3382           | 1           | Decal-Deck          |
| 16          | 117-7277-03        | 3           | Blade-Hi Flo, 16.50 Inch   | 43          | 1-603401           | 1           | Spacer              |
| 17          | 125-1736           | 3           | Washer-Belleville          | 44          | 323-10             | 1           | Screw-HH            |
| 18          | 51-4060            | 3           | Screw-Blade                | 45          | 133-1212           | 1           | Deflector-Discharge |
| 19          | 110-9981           | 3           | Washer-Plain               | 46          | 109-8854           | 1           | Pin-Chute           |
| 20          | 1-413088           | 1           | Bushing-Lever, Lift        | 47          | 121-2983           | 1           | Spring-Torsion      |
| 21          | 114-0463           | 2           | Washer-Friction, Composite | 65          | 136-5615           | 1           | Belt Guide - Idler  |
| 22          | 115-5054           | 1           | Arm-Idler                  | 66          | 133-9313           | 1           | Tread-Step          |



## Model Specific Decal Assembly (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i> |
|-------------|--------------------|-------------|--------------------|
| 9           | 136-9186           | 1           | Decal-Bucket       |


# Series Decal Assembly



## Series Decal Assembly (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i> | <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>             |
|-------------|--------------------|-------------|--------------------|-------------|--------------------|-------------|--------------------------------|
| 1           | 136-5596           | 1           | Decal-Maintenance  | 3           | 130-0654           | 1           | Decal-HOC                      |
| 2           | 136-4245           | 1           | Decal-Smart Speed  | 4           | 121-5684           | 1           | Decal-Location, Service Dealer |

# Clutch Assembly



## Clutch Assembly (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i> | <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i> |
|-------------|--------------------|-------------|--------------------|-------------|--------------------|-------------|--------------------|
| 1           | 133-1208           | 1           | Pulley-Engine      | 5           | 112843             | 1           | Washer             |
| 2           | 119-8885           | 1           | Stop-Clutch        | 6           | 3212-19            | 1           | Screw-HH           |
| 3           | 127-3410           | 1           | Clutch-PTO         | 7           | 3234-42            | 1           | Screw-HHF          |
| 4           | 120-2217           | 1           | Isolator-Clutch    | 8           | 104-8301           | 1           | Nut-HF, NI         |

# Attachments and Accessories

## For 75210 TimeCutter HD MyRide 48in Riding Mower

| Product Name                       | Model/Part |
|------------------------------------|------------|
| 48in Striping Kit.....             | 119-3380   |
| Leaf Bagging Enhancement Kit ..... | 119-3381   |
| Jack Kit .....                     | 127-6666   |
| Deck Lift Assist Kit .....         | 132-6850   |
| 5 Gallon Bucket .....              | 133-2533   |
| 48in Recycler Kit.....             | 136-7488   |
| Mount Kit .....                    | 136-7491   |
| Weight Kit .....                   | 136-7492   |
| Light Kit.....                     | 136-7493   |
| Bucket Mount.....                  | 136-7494   |
| Rops Kit .....                     | 136-7495   |
| Jack Mount Kit .....               | 136-9200   |
| HD Shock and Spring Kit .....      | 137-2042   |
| Cargo Carrier .....                | 79040      |
| EZ Vac Complete Twin Bagger .....  | 79345      |

**Notes:**



**Count on it.**