



Form No. 3388-346 Rev B

**Count on it.**

# Parts Catalog

## 22in Recycler® Lawn Mower

Model No. 20334—Serial No. 315000001 and Up



# Ordering Replacement Parts

To order replacement parts, please supply the part number, the quantity, and the description of each part desired.

## Understanding Reference Numbers

Each identified part in an illustration has a reference number. The reference number for a part also appears in the parts list, along with other information about the part.

This catalog uses two special reference number formats, one to indicate parts in a service assembly and another to indicate the quantity of a given part in an illustration.

## Service Assembly Reference Numbers

Parts in service assemblies have reference numbers in the form a:b. The a represents the reference number of the entire service assembly and the b represents a sequential number unique to each part within the service assembly.

For example, a wheel assembly might be identified by reference number 6, the tire by 6:1, the valve by 6:2, and the wheel by 6:3. When you order the assembly identified by reference number 6, you receive all parts identified by reference numbers 6:1, 6:2, and 6:3. However, you may also order any part individually. Reference numbers of this type appear in illustration and in parts lists.

## Reference Numbers Indicating Quantity

In an illustration, if a reference number indicates more than one part, the reference number has the form nX y. The n represents the quantity of the part, the X is the multiplication symbol, and the y represents the reference number.

For example, in an illustration, the reference number 2X 37 means that two of the parts identified by reference number 37 are indicated.

# Contents

Deck, Side Chute and Rear Door Assembly ..... 4

Rear Bag Assembly ..... 6

Engine and Blade Assembly ..... 8

Front Wheel and Height-of-Cut Assembly ..... 10


Transmission and Rear Wheel Drive Assembly ..... 12

Handle Assembly ..... 14

Electical Assembly ..... 16

Attachments and Accessories ..... 18


# Deck, Side Chute and Rear Door Assembly



## Deck, Side Chute and Rear Door Assembly (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>    | <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>          |
|-------------|--------------------|-------------|-----------------------|-------------|--------------------|-------------|-----------------------------|
| 1           | 130-2389           | 1           | Housing ASM           | 16          | 114-7959           | 1           | Latch-Recycle               |
| 1:2         | 94-8072            | 1           | Decal-Danger          | 17          | 117-1031           | 1           | Spring-Compression          |
| 1:3         | 115-4676           | 1           | Decal-Recycler        | 18          | 32104-120          | 2           | Screw-PPH                   |
| 1:4         | 112-8867           | 1           | Decal-Port, Washout   | 19          | 121-5776           | 1           | Rear Door ASM               |
| 2           | 114-7963-01        | 1           | Baffle-Front          | 19:2        | 131-4514           | 1           | Decal-Warning               |
| 5           | 114-7961           | 1           | Baffle-Rear           | 20          | 115-2859           | 1           | Spring-Torsion              |
| 6           | 114-7957           | 1           | Chute-Recycle         | 21          | 114-7924           | 1           | Spring-Torsion              |
| 7           | 46-8091            | 9           | Screw-HWH             | 22          | 112-6400           | 1           | Port-Washout                |
| 8           | 112-6416           | 1           | Bracket-Cover         | 23          | 112-6401           | 1           | Coupling-Hose, Washout Port |
| 9           | 99-8445            | 2           | Screw-HWH             | 25          | 112-6438           | 1           | Washer-Seal, Washout Port   |
| 10          | 99-5291            | 1           | Rod-Cover             | 26          | 3254-5             | 1           | Washer-Tooth, Internal      |
| 11          | 99-5293            | 1           | Spring-Torsion        | 27          | 3218-6             | 1           | Nut-Jam                     |
| 12          | 115-8449           | 1           | Deflector-Side        | 29          | 114-7987           | 1           | Bumper                      |
| 13          | 115-8447           | 1           | Chute-Discharge, Side | 30          | 105-6849           | 2           | Screw-Forming, Thread       |
| 14          | 114-7960           | 1           | Deflector-Recycle     | 34          | 125-5026           | 1           | Decal                       |
| 15          | 114-7958           | 1           | Knob-Recycle          |             |                    |             |                             |


# Rear Bag Assembly



## Rear Bag Assembly (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i> |
|-------------|--------------------|-------------|--------------------|
| 1           | 114-2679-03        | 1           | Frame-Bag          |
| 2           | 115-4673           | 1           | Grass Bag ASM      |

# Engine and Blade Assembly



## Engine and Blade Assembly (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>                  |
|-------------|--------------------|-------------|-------------------------------------|
| 1           |                    | 1           | Engine-Briggs,<br>128M05-0026-F1 ●■ |
| 5           | 106-3999           | 1           | Spacer-Driver                       |
| 6           | 106-3987           | 1           | Driver-Blade                        |
| 7           | 108-9764-03        | 1           | Blade-22 Inch                       |
| 8           | 108-3766-03        | 1           | Support-Blade                       |
| 9           | 125-2466           | 1           | Bolt-Blade                          |

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>    |
|-------------|--------------------|-------------|-----------------------|
| 10          | 105-3030-03        | 1           | Guide-Belt            |
| 11          | 95-1726            | 3           | Screw-Taptite         |
| 12          | 114-7937           | 1           | Cover-Belt            |
| 13          | 46-8091            | 2           | Screw-HWH             |
| 16          | 130-2357           | 1           | Decal-Shroud          |
| 19          | 117-2718           | 1           | Decal-Arrester, Spark |

● Not serviced separately

■ Obtain parts from [www.briggsandstratton.com](http://www.briggsandstratton.com)


## Front Wheel and Height-of-Cut Assembly

## Front Wheel and Height-of-Cut Assembly (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i> |
|-------------|--------------------|-------------|--------------------|
| 1           | 115-1956-03        | 2           | Plate-HOC, Front   |
| 2           | 322-3              | 4           | Screw-HH           |
| 3           | 3296-29            | 6           | Nut-Lock, NI       |
| 4           | 105-1818           | 2           | Bushing-Mount, HOC |
| 5           | 105-1807           | 2           | Arm-Pivot, Front   |
| 6           | 105-1809           | 2           | Arm-Spring         |

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i> |
|-------------|--------------------|-------------|--------------------|
| 7           | 110-0549           | 2           | Knob-HOC           |
| 8           | 105-3048           | 2           | Washer-Flat        |
| 9           | 322-6              | 2           | Screw-HH           |
| 10          | 40-1940            | 2           | Washer             |
| 11          | 614650             | 2           | Bolt-Shoulder      |
| 12          | 115-2894           | 2           | 8 Inch Wheel ASM   |


# Transmission and Rear Wheel Drive Assembly



## Transmission and Rear Wheel Drive Assembly (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>    | <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>    |
|-------------|--------------------|-------------|-----------------------|-------------|--------------------|-------------|-----------------------|
| 1           | 127-6877-03        | 1           | Plate-Rear, LH (HOC)  | 14          | 108-7476           | 3           | Screw-Plastite        |
| 2           | 127-6878-03        | 1           | Plate-Rear, RH (HOC)  | 15          | 110-7191           | 2           | Washer-Thrust         |
| 3           | 322-3              | 4           | Screw-HH              | 16          | 110-9417           | 2           | Gear-Pinion, 15T      |
| 4           | 3296-29            | 4           | Nut-Lock, NI          | 17          | 32151-61           | 2           | Ring-Retaining        |
| 5           | 108-9779           | 2           | Retainer-Bushing, HOC | 18          | 110-1792           | 2           | Wheel Cover ASM       |
| 6           | 104-8699           | 2           | Bearing-Ball          | 18:2        | 614426             | 1           | Washer-Stepped        |
| 7           | 108-9782           | 2           | Bushing-Sleeve        | 19          | 614650             | 2           | Bolt-Shoulder         |
| 8           | 108-9781           | 2           | Arm-Pivot, Rear       | 20          | 119-3822           | 2           | 8 Inch Wheel Gear ASM |
| 9           | 108-9780           | 2           | Arm-Spring            | 23          | 120-7012           | 1           | Shield-Trailing       |
| 10          | 110-0549           | 2           | Knob-HOC              | 24          | 117-1092           | 2           | Screw-PTH             |
| 11          | 121-9178           | 1           | Transmission ASM      | 25          | 3229-11            | 2           | Screw-CARR            |
| 12          | 115-4669           | 1           | Belt-V                | 26          | 3296-16            | 2           | Nut-Lock, NI          |
| 13          | 114-7977-03        | 1           | Bracket-Transmission  |             |                    |             |                       |

# Handle Assembly



## Handle Assembly (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i> | <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>     |
|-------------|--------------------|-------------|--------------------|-------------|--------------------|-------------|------------------------|
| 1           | 119-3810-05        | 1           | Handle             | 14          | 99-1588            | 1           | Bar-Control, Traction  |
| 2           | 3230-6             | 2           | Screw-CARR         | 15          | 3256-23            | 1           | Washer-Plain           |
| 3           | 117-5976           | 2           | Knob-Handle        | 16          | 99-1589            | 1           | Lever-Traction         |
| 4           | 114-7988           | 1           | Guide-Cable        | 17          | 121-9118           | 1           | Spring-Torsion         |
| 5           | 86-9671            | 1           | Guide-Rope         | 18          | 104-8679-03        | 1           | Bail-Brake             |
| 6           | 3296-73            | 1           | Nut-Lock, NI       | 20          | 99-5239            | 1           | Anchor-Cable           |
| 8           | 105-6842           | 1           | Guide-LH           | 21          | 115-8435           | 1           | Cable-Traction         |
| 9           | 105-6841           | 1           | Guide-RH           | 22          | 115-8437           | 1           | Cable-Brake            |
| 12          | 104-8678           | 1           | Handle-Control     | 23          | 131-0894           | 1           | Decal-Traction, Adjust |
| 13          | 117-1019           | 1           | Decal              | 24          | 131-0897           | 1           | Knob-Handle, Locking   |

This exploded view diagram illustrates the assembly of a car stereo unit. The main components are shown in their relative positions, with dashed lines indicating the assembly path. The numbered callouts are as follows:

- 1: Main car stereo unit
- 2: Antenna cable
- 3: Antenna sleeve
- 4: Antenna bracket
- 5: Antenna cable (longer section)
- 6: Mounting bracket
- 7: Mounting plate
- 8: Mounting plate (smaller section)
- 9: Mounting plate (larger section)
- 10: Mounting plate (smaller section)
- 11: Mounting plate (smaller section)
- 12: Mounting plate (smaller section)
- 13: Mounting plate (smaller section)
- 14: Mounting plate (smaller section)
- 15: Mounting plate (smaller section)
- 16: Mounting plate (smaller section)
- 17: Mounting plate (smaller section)
- 18: Mounting plate (smaller section)
- 19: Mounting plate (smaller section)
- 20: Mounting plate (smaller section)
- 21: Mounting plate (smaller section)
- 22: Mounting plate (smaller section)
- 23: Mounting plate (smaller section)

## Electical Assembly (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>  | <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>      |
|-------------|--------------------|-------------|---------------------|-------------|--------------------|-------------|-------------------------|
| 5           | 125-5023           | 1           | Harness-Wire        | 15          | 614249             | 3           | Tie-Cable               |
| 5:1         | 99-6124            | 1           | Fuse-40 Amp         | 17          | 321-50             | 1           | Screw-HH                |
| 6           | 114-7936           | 1           | Tray-Battery        | 18          | 112-8763           | 1           | Decal-Terminal, Battery |
| 7           | 106-8397           | 1           | Battery-Wet         | 19          | 125-2468           | 1           | Housing-Switch, LH      |
| 9           | 120-3329           | 1           | Cover-Battery       | 20          | 125-2469           | 1           | Housing-Switch, RH      |
| 10          | 32144-97           | 1           | Screw-PPH, Plastite | 21          | 125-2470           | 1           | Button-Switch           |
| 12          | 104-7953           | 1           | Decal-Warning       | 22          | 121-9173           | 1           | Switch-Push Button      |
| 13          | 114-1588           | 1           | Charger-Battery     | 23          | 94-4496            | 3           | Screw-PPH               |

# Attachments and Accessories

## For 20334 22in Recycler Lawn Mower

| Product Name                                                                         | Model/Part |
|--------------------------------------------------------------------------------------|------------|
| Traction Assist Handle Kit .....                                                     | 108-8120   |
| Loose Parts Kit .....                                                                | 117-4134   |
| Fuel Stabilizer .05 oz .....                                                         | 130-2393   |
| Toro WPM Maint Kit .....                                                             | 20234      |
| Lawn Striping Kit with 22in Roller .....                                             | 20601      |
| Replacement Drive Belt Kit, 22-inch 2009 and After Rear-Wheel Drive Lawn Mower ..... | 38991      |
| Lawnmower Cover .....                                                                | 490-7462   |
| Replacement Bag .....                                                                | 59310      |
| Replacement Frame and Bag Kit .....                                                  | 59312      |
| 8in Gear Wheel ASM .....                                                             | 59502      |
| 8in Gear Wheel ASM RWD .....                                                         | 59503      |
| 22 Inch Atomic Blade .....                                                           | 59534P     |

**Notes:**



**Count on it.**