



PART NO. 93-8951

**INSTALLATION
INSTRUCTIONS****DECAL KIT – JAPANESE
(FOR WORKMAN 3000)****SAFETY AND INSTRUCTION DECALS**

THE FOLLOWING DECALS ARE TO BE INSTALLED ON THE WORKMAN . USE THE LOCATION DESCRIPTION LISTED BELOW TO DETERMINE THE CORRECT PLACEMENT FOR THE DECALS ON THE PRODUCT. BEFORE INSTALLING DECALS, REMOVE OR THOROUGHLY CLEAN THE ENGLISH DECAL, AND APPLY THE APPROPRIATE TRANSLATED LANGUAGE VERSION IN ITS PLACE (OR OVER IT).

ONLY USE DECALS THAT REPLACE EXISTING DECALS ON MACHINE.
DISCARD UNUSED DECALS.

SHOULD ANY OF THESE DECALS BECOME DAMAGED OR ILLEGIBLE, REPLACE THEM IMMEDIATELY. EACH PART NUMBER IS LISTED BELOW, AND ALSO ON EACH DECAL.
REPLACEMENTS MAY BE ORDERED THROUGH YOUR AUTHORIZED TORO DISTRIBUTOR.

DECAL DESCRIPTION	LOCATION OF DECAL	QTY. REQ.	ENGLISH PART NO.	JAPANESE PART NO.
DECAL-LOAD RATING	UNDER RIGHT SIDE OF DASH	1	87-6050	92-5395
DECAL-SUPERVISOR	ON DASH	1	87-5910	92-5332
DECAL-ATF	ON AXLE TUBE	1	87-6060	92-5473
DECAL-FUEL	ON SKIRT	1	87-5930	92-5325
DECAL-DANGER	ON OPTIONAL REAR PTO	1	87-5990	92-5367
DECAL-AXLE RANGE	ON CONSOLE	1	87-5960	92-5318
DECAL-DUMP HYDRAULICS	ON CONSOLE	1	87-6010	92-5353
DECAL-PARKING BRAKE	ON CONSOLE	1	87-6020	92-5304
DECAL-ROLL OVER	ON ROPS	1	87-5940	92-5388
DECAL-DIFFERENTIAL LOCK	ON CONSOLE	1	87-6000	92-5311
DECAL-FUSE BLOCK	UNDER DASH NEAR FUSE BLOCK	1	87-6670	92-5374
DECAL-WARNING BED SUPPORT	ON LIFT CYLINDERS & BED SUPPORT	3	87-7930	92-6415
DECAL-ROPS	ON ROPS	1	87-5980	92-5381
DECAL-DASH (DIESEL ONLY)	ON DASH	1	87-5900	92-6429
DECAL-DASH (GAS ONLY)	ON DASH	1	87-5890	92-6422
DECAL-DANGER	ON SKIRT	1	87-5920	92-6408
DECAL-WARN SPRING LOADED	ON SPRING CRADLE	1	44-0760	92-6493
DECAL-WARN HOT SURFACE	ON LEFT FRAME RAIL	1	66-6840	92-6479
DECAL-WARN ROTATING MEMBER	ON FAN SUPPORT	1	80-8040	83-6030
DECAL-QUICK REFERENCE (GAS ONLY)	ON REAR SKIRT	1	87-5950	92-5494
DECAL-QUICK REFERENCE (DIESEL ONLY)	ON REAR SKIRT	1	87-7260	92-6401
DECAL-STARTING FLUID (DIESEL ONLY)	ON FRONT OF RADIATOR	1	67-1700	84-6660
DECAL-NO STEP	ON BATTERY COVER	1	36-3400	84-2780
PLATE-WARNING	ON FAN SHROUD	1	76-8750	92-7240
DECAL-DRIVE SHAFT	ON AXLE TUBE	2	87-9080	92-6444
DECAL-CAUTION (DIESEL ONLY)	FRONT OF RADIATOR	1	87-9420	93-3766
DECAL-QUICK REFERENCE (4 WD DIESEL ONLY)	ON SKIRT	1	87-9110	94-1206
DECAL-QUICK REFERENCE (4 WD GAS ONLY)	ON SKIRT	1	87-9100	94-1218
DECAL-DASH (4 WD, GAS ONLY)	ON DASH	1	87-9880	94-1226
DECAL-DASH (4 WD DIESEL ONLY)	ON DASH	1	87-9890	94-1227
DECAL-LOAD RATING	UNDER RIGHT SIDE OF DASH	1	87-9120	94-1228
RIVET	INSTALL WARNING PLATE	2	3290-271	3290-271
INSTALLATION INSTRUCTIONS	-----	1	-----	3317-594

INSERT DECAL LOCATION SHEET INTO OPERATOR'S MANUAL FOR OWNER'S REFERENCE.