



Form No. 3408-982 Rev B

**Count on it.**

# Parts Catalog

## TimeMaster 30in Lawn Mower

Model No. 21200—Serial No. 400000000 and Up



# Ordering Replacement Parts

To order replacement parts, please supply the part number, the quantity, and the description of each part desired.

## Understanding Reference Numbers

Each identified part in an illustration has a reference number. The reference number for a part also appears in the parts list, along with other information about the part.

This catalog uses two special reference number formats, one to indicate parts in a service assembly and another to indicate the quantity of a given part in an illustration.

## Service Assembly Reference Numbers

Parts in service assemblies have reference numbers in the form a:b. The a represents the reference number of the entire service assembly and the b represents a sequential number unique to each part within the service assembly.

For example, a wheel assembly might be identified by reference number 6, the tire by 6:1, the valve by 6:2, and the wheel by 6:3. When you order the assembly identified by reference number 6, you receive all parts identified by reference numbers 6:1, 6:2, and 6:3. However, you may also order any part individually. Reference numbers of this type appear in illustration and in parts lists.

## Reference Numbers Indicating Quantity

In an illustration, if a reference number indicates more than one part, the reference number has the form nX y. The n represents the quantity of the part, the X is the multiplication symbol, and the y represents the reference number.

For example, in an illustration, the reference number 2X 37 means that two of the parts identified by reference number 37 are indicated.

# Contents

Housing Assembly ..... 4

Spindle and Blade Assembly ..... 6

Discharge Chute Assembly ..... 8

Bag Assembly ..... 10

Engine Assembly ..... 12


Front Wheel and Height-of-Cut Assembly ..... 14

Rear Wheel and Height-of-Cut Assembly ..... 16

Handle and Electrical Assembly ..... 18

Attachments and Accessories ..... 20


# Housing Assembly



## Housing Assembly (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>      | <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>     |
|-------------|--------------------|-------------|-------------------------|-------------|--------------------|-------------|------------------------|
| 1           | 136-5873           | 1           | Housing ASM             | 17          | 120-6241           | 1           | Shield-Trailing        |
| 3           | 136-5908-01        | 1           | Frame                   | 18          | 49-2040            | 8           | Screw-HWHTF            |
| 4           | 133-8177           | 1           | Chute                   | 21          | 117-1092           | 2           | Screw-PTH              |
| 5           | 3230-5             | 2           | Screw-CARR              | 22          | 121-2398           | 1           | Decal-Position, Handle |
| 6           | 120-3344           | 1           | Rod-Release, Handle     | 23          | 117-2718           | 1           | Decal-Arrester, Spark  |
| 7           | 120-7018           | 1           | Grip-Lever              | 24          | 3296-29            | 2           | Nut-Lock, NI           |
| 8           | 121-9114           | 1           | Bracket-Door, LH        | 29          | 130-2352-01        | 1           | Baffle-Control         |
| 9           | 121-9115           | 1           | Bracket-Door, RH        | 31          | 32144-86           | 1           | Screw-HWHTF            |
| 10          | 120-7049           | 1           | Belt Cover ASM          | 33          | 1-323283           | 1           | Spacer-Shield          |
| 11          | 120-7048           | 1           | Rear Deflector ASM      | 34          | 323-39             | 1           | Screw-HH               |
| 11:3        | 131-4514           | 1           | Decal-Warning           | 35          | 3296-39            | 1           | Nut-Lock, NI           |
| 12          | 115-2859           | 1           | Spring-Torsion          | 99          | 125-5072           | 1           | Frame Plate Kit        |
| 13          | 114-7924           | 1           | Spring-Torsion          | 99:1        | 125-2542           | 1           | Plate-Frame            |
| 14          | 46-8091            | 3           | Screw-HWH               | 99:2        | 3229-3             | 3           | Screw-CARR             |
| 15          | 107-7497           | 2           | Bracket-Cable, Traction | 99:3        | 3296-42            | 3           | Nut-Lock, NI           |
| 16          | 120-5225           | 1           | Plug-Mulch              |             |                    |             |                        |


# Spindle and Blade Assembly



## Spindle and Blade Assembly (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>         | <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>      |
|-------------|--------------------|-------------|----------------------------|-------------|--------------------|-------------|-------------------------|
| 1           | 121-9107           | 2           | Spindle ASM                | 17          | 131-4529           | 2           | Pulley Kit              |
| 1:2         | 120-7935           | 2           | Spacer                     | 17:2        | 131-4504           | 1           | Adapter-Bore            |
| 1:3         | 100-1048           | 2           | Bearing-Ball               | 17:3        | 125-2533           | 1           | Plug-Cap                |
| 2           | 32144-57           | 9           | Screw                      | 18          | 120-3348           | 1           | Bracket-Idler           |
| 3           | 120-5234           | 1           | Shaft-Spindle              | 19          | 120-7024           | 2           | Screw-Shoulder, HHF     |
| 4           | 120-5235           | 1           | Shaft-Spindle              | 20          | 120-3335           | 1           | Belt-Synchronous        |
| 5           | 121-9100           | 2           | Sprocket                   | 21          | 120-5245-03        | 1           | Guide-Belt, Spindle     |
| 6           | 130-6664           | 1           | Pulley-Brake, Spindle      | 22          | 120-5236           | 2           | Adapter-Blade           |
| 7           | 109-9505           | 2           | Washer-Spring              | 23          | 121-5808           | 1           | Spring-Extension, Brake |
| 8           | 3296-19            | 2           | Nut-Hex                    | 24          | 125-2466           | 2           | Bolt-Blade              |
| 9           | 63-7400            | 1           | Washer-Rebound             | 25          | 49-2040            | 2           | Screw-HWHTF             |
| 10          | 133-8102           | 1           | Brake Arm ASM              | 26          | 120-7082           | 1           | Pulley-Idler            |
| 11          | 121-2305           | 2           | Washer-Friction, Composite | 27          | 322-6              | 1           | Screw-HH                |
| 12          | 120-9490           | 1           | Spacer                     | 28          | 3296-47            | 1           | Nut-Lock, NI            |
| 13          | 9114524            | 1           | Bolt-TAP, HH               | 29          | 116-6358-03        | 2           | Blade-Rotary            |
| 14          | 3256-3             | 4           | Washer-Flat                | 30          | 121-2336           | 1           | Spring-Flat             |
| 15          | 322-7              | 1           | Screw-HH                   | 33          | 322-9              | 1           | Screw-HH                |
| 16          | 3296-29            | 3           | Nut-Lock, NI               | 35          | 133-1964           | 1           | Hose-Coolant            |

# Discharge Chute Assembly






## Discharge Chute Assembly (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>         | <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>    |
|-------------|--------------------|-------------|----------------------------|-------------|--------------------|-------------|-----------------------|
| 1           | 94-8072            | 1           | Decal-Danger               | 8           | 133-9289           | 1           | Fitting-Washout       |
| 6           | 133-2630           | 1           | Side Deflector Service ASM | 9           | 46-8560            | 2           | Screw-HHFTF           |
| 6:1         | 125-5091           | 1           | Deflector-Side             | 10          | 46-6290            | 2           | O-Ring                |
| 6:2         | 127-0721           | 1           | Spring-Torsion, Cover      | 11          | 95-3270            | 1           | Connector-Hose        |
| 6:3         | 112-6416           | 1           | Bracket-Cover              | 12          | 120-9570           | 1           | Decal-Warning         |
| 6:4         | 99-5291            | 1           | Rod-Cover                  | 13          | 125-5092           | 1           | Decal-Placement, Foot |
| 7           | 121-2319           | 1           | Chute-Discharge, Side      |             |                    |             |                       |


# Bag Assembly



## Bag Assembly (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i> |
|-------------|--------------------|-------------|--------------------|
| 1           | 121-5766-03        | 1           | Frame-Bag          |
| 2           | 121-5770           | 1           | Bag-Grass          |

# Engine Assembly




## Engine Assembly (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i> | <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i> |
|-------------|--------------------|-------------|--------------------|-------------|--------------------|-------------|--------------------|
| 2           | 120-3333           | 1           | Pulley-Engine      | 8           | 26-0671            | 1           | Screw-HH           |
| 3           | 121-5765           | 1           | V-Belt             | 11          | 32144-1            | 1           | Screw-Taptite      |
| 4           | 120-9470           | 1           | V-Belt, Traction   | 12          | 131-0889-03        | 1           | Guard-Engine       |
| 5           | 120-7077           | 1           | Guide-Belt         | 13          | 126-2713           | 2           | Screw-HHF          |
| 6           | 95-1727            | 3           | Screw-Taptite      | 14          |                    | 1           | Engine-Briggs      |
| 7           | 3290-465           | 1           | Washer-Belleville  |             |                    |             | 14D9350111F1 ● ■   |

● Not serviced separately

■ Obtain parts from [www.briggsandstratton.com](http://www.briggsandstratton.com)

# Front Wheel and Height-of-Cut Assembly




## Front Wheel and Height-of-Cut Assembly (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>   |
|-------------|--------------------|-------------|----------------------|
| 1           | 46-8091            | 3           | Screw-HWH            |
| 2           | 120-9535           | 1           | Grip-Lever           |
| 3           | 104-8301           | 2           | Nut-HF, NI           |
| 4           | 136-5875           | 2           | Bushing-Pivot, Front |
| 5           | 131-0814           | 1           | Axle-Front           |
| 6           | 120-7037-03        | 1           | Plate-HOC, LH        |
| 7           | 120-7038-03        | 1           | Plate-HOC, RH        |

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>    |
|-------------|--------------------|-------------|-----------------------|
| 8           | 120-7043           | 1           | Arm-Spring            |
| 9           | 125-2510           | 2           | 8 Inch Wheel ASM      |
| 10          | 125-5027           | 1           | Front Cover ASM       |
| 11          | 700057             | 1           | Screw-HWH             |
| 12          | 3230-23            | 6           | Screw-CARR            |
| 13          | 3296-29            | 6           | Nut-Lock, NI          |
| 15          | 130-6658           | 4           | Screw-Flange, Plastic |

# Rear Wheel and Height-of-Cut Assembly






## Rear Wheel and Height-of-Cut Assembly (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>      | <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>     |
|-------------|--------------------|-------------|-------------------------|-------------|--------------------|-------------|------------------------|
| 1           | 1-633295           | 1           | Grip-Lever, Lift        | 17:2        | 130-2369           | 2           | Pin-Snap               |
| 2           | 121-5799           | 1           | Conduit-Convoluted      | 17:3        | 32151-61           | 1           | Ring-Retaining         |
| 3           | 49-2040            | 2           | Screw-HWHTF             | 18          | 120-6233           | 2           | Cover-Gear             |
| 4           | 104-8301           | 2           | Nut-HF, NI              | 19          | 131-0815           | 1           | Axle-Rear              |
| 5           | 104-8699           | 1           | Bearing-Ball            | 20          | 125-2509           | 2           | 10 Inch Wheel Gear ASM |
| 7           | 106-5681           | 1           | Pin-Stop                | 21          | 120-7008           | 1           | Mount-Bearing          |
| 8           | 109-8020           | 2           | Bearing-Ball            | 22          | 120-7026           | 1           | Spring-Extension       |
| 9           | 110-7191           | 2           | Washer-Thrust           | 23          | 120-7027           | 1           | Spring-Extension       |
| 10          | 131-5399           | 2           | Gear-Pinion, 15T        | 24          | 121-5800           | 2           | Conduit-Convoluted     |
| 12          | 120-3342-03        | 1           | Plate-HOC, LH           | 25          | 701243             | 8           | Screw-HWHTF            |
| 13          | 120-3343-03        | 1           | Plate-HOC, RH           | 26          | 32144-4            | 1           | Screw-HWH              |
| 14          | 120-5208           | 1           | Arm-Spring, Rear        | 28          | 36-4780            | 2           | Washer-Plain           |
| 15          | 120-5209           | 1           | Key-Springarm           | 29          | 121-5821           | 1           | Bracket-Stop           |
| 16          | 131-5364           | 2           | Retainer-Bearing        | 30          | 3296-47            | 1           | Nut-Lock, NI           |
| 17          | 131-9665           | 1           | Transmission Kit        | 31          | 125-2497           | 1           | Decal-HOC, Rear        |
| 17:1:1      | 130-2370           | 1           | Transmission Pulley Kit |             |                    |             |                        |

# Handle and Electrical Assembly



## Handle and Electrical Assembly (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>    |
|-------------|--------------------|-------------|-----------------------|
| 1           | 120-5204-05        | 1           | Handle-Lower          |
| 2           | 132-4484-05        | 1           | Handle-Upper          |
| 3           | 105-6842           | 1           | Guide-LH              |
| 4           | 105-6841           | 1           | Guide-RH              |
| 5           | 104-8678           | 1           | Handle-Control        |
| 6           | 99-1588            | 1           | Bar-Control, Traction |
| 7           | 127-6842           | 1           | Lever-Traction        |
| 8           | 120-7025           | 2           | Bolt-Shoulder, HHF    |
| 9           | 32144-1            | 1           | Screw-Taptite         |
| 10          | 133-1998           | 1           | Cable-Brake           |
| 12          | 127-6867           | 1           | Cable-Traction        |
| 14          | 104-7953           | 1           | Decal-Warning         |
| 15          | 132-4516           | 2           | Plug-Square           |
| 17          | 121-9118           | 1           | Spring-Torsion        |
| 18          | 117-1019           | 1           | Decal                 |
| 19          | 108-3788-03        | 1           | Bail-Brake            |
| 20          | 106-9169           | 1           | Screw-HWH             |
| 21          | 107-7462           | 1           | Spring-Torsion        |
| 22          | 107-7463           | 1           | Spacer                |
| 23          | 106-6802           | 1           | Lever                 |
| 24          | 32128-17           | 1           | Nut-Lock, Flange      |
| 25          | 112-8884           | 1           | Knob                  |
| 26          | 3290-337           | 1           | Nut-Speed             |
| 27          | 3296-29            | 2           | Nut-Lock, NI          |
| 28          | 92-2260            | 2           | Screw-Handle          |
| 29          | 117-5976           | 2           | Knob-Handle           |

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>      |
|-------------|--------------------|-------------|-------------------------|
| 30          | 114-7988           | 1           | Guide-Cable             |
| 31          | 130-2343           | 1           | Spacer                  |
| 32          | 104-9368           | 1           | Plug-Dome               |
| 33          | 131-0847           | 1           | Handle-Assist, Traction |
| 34          | 99-6005            | 2           | Bolt-Carriage           |
| 35          | 131-4535           | 2           | Nut-Acorn               |
| 36          | 106-8397           | 1           | Battery-Wet             |
| 37          | 108-3795           | 1           | Housing-Switch, Key     |
| 38          | 321-50             | 1           | Screw-HH                |
| 39          | 92-7729            | 1           | Anchor-Cable, Upper     |
| 40          | 23-0660            | 1           | Switch-Starter          |
| 40:1        | 218-461            | 1           | Nut-HH                  |
| 40:2        | 3254-5             | 1           | Washer-Tooth, Internal  |
| 41          | 108-3796           | 1           | Cover-Switch            |
| 42          | 32144-111          | 2           | Screw-PPH               |
| 43          | 700918             | 1           | Key                     |
| 44          | 114-1588           | 1           | Charger-Battery         |
| 45          | 108-9751           | 1           | Decal-Switch, Ignition  |
| 46          | 136-5895           | 1           | Harness-Wire            |
| 46:4        | 99-6124            | 1           | Fuse-40 Amp ●           |
| 47          | 108-0987           | 1           | Foam-Battery            |
| 48          | 121-2399           | 1           | Decal-Assist, Traction  |
| 49          | 120-3329           | 1           | Cover-Battery           |
| 55          | 132-4470           | 1           | Decal-Traction, Adjust  |
| 56          | 131-0897           | 1           | Knob-Handle, Locking    |
| 99          | 614249             | 2           | Tie-Cable ●             |

● Not illustrated

# Attachments and Accessories

## For 21200 TimeMaster 30in Lawn Mower

| Product Name                                                 | Model/Part |
|--------------------------------------------------------------|------------|
| Briggs 1000 Maintenance Kit, Timemaster 2017 and after ..... | 130-8149   |
| Replacement Blade Kit .....                                  | 20120P     |
| Mower Cover .....                                            | 490-7461   |

**Notes:**

**Notes:**

**Notes:**



**Count on it.**