



Count on it.

Form No. 3388-340 Rev B

Parts Catalog

22in Recycler®

Lawn Mower with SmartStow®

Model No. 20339—Serial No. 315000001 and Up

Model No. 20339C—Serial No. 315000001 and Up



Ordering Replacement Parts

To order replacement parts, please supply the part number, the quantity, and the description of each part desired.

Understanding Reference Numbers

Each identified part in an illustration has a reference number. The reference number for a part also appears in the parts list, along with other information about the part.

This catalog uses two special reference number formats, one to indicate parts in a service assembly and another to indicate the quantity of a given part in an illustration.

Service Assembly Reference Numbers

Parts in service assemblies have reference numbers in the form a:b. The a represents the reference number of the entire service assembly and the b represents a sequential number unique to each part within the service assembly.

For example, a wheel assembly might be identified by reference number 6, the tire by 6:1, the valve by 6:2, and the wheel by 6:3. When you order the assembly identified by reference number 6, you receive all parts identified by reference numbers 6:1, 6:2, and 6:3. However, you may also order any part individually. Reference numbers of this type appear in illustration and in parts lists.

Reference Numbers Indicating Quantity

In an illustration, if a reference number indicates more than one part, the reference number has the form nX y. The n represents the quantity of the part, the X is the multiplication symbol, and the y represents the reference number.

For example, in an illustration, the reference number 2X 37 means that two of the parts identified by reference number 37 are indicated.

Contents

Deck, Side Chute and Rear Door Assembly 4

Rear Bag Assembly 6

Engine and Blade Assembly 8

Transmission and Front Wheel Drive Assembly 10


Height-of-Cut and Rear Wheel Assembly 12

Bag Attachment Assembly 14

Handle Assembly 16

Attachments and Accessories 18


Deck, Side Chute and Rear Door Assembly



Deck, Side Chute and Rear Door Assembly (continued)

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>	<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
1	130-2348	1	Housing ASM	13	3254-5	1	Washer-Tooth, Internal
1:2	94-8072	1	Decal-Danger	14	3218-6	1	Nut-Jam
1:3	112-8867	1	Decal-Port, Washout	15	130-2398	1	Decal-Deck
2	120-5218	1	Baffle-Rear	17	3296-29	2	Nut-Lock, NI
3	114-7963-01	1	Baffle-Front	20	112-6416	1	Bracket-Cover
4	117-4199	1	Rear Deflector ASM	21	99-8445	2	Screw-HWH
4:2	131-4514	1	Decal-Warning	22	99-5291	1	Rod-Cover
5	117-5991	2	Washer-Stepped, Baffle	23	99-5293	1	Spring-Torsion
6	115-8420	1	Shield-Trailing	24	115-8449	1	Deflector-Side
7	114-7924	1	Spring-Torsion	25	115-8447	1	Chute-Discharge, Side
8	115-2859	1	Spring-Torsion	26	117-1092	2	Screw-PTH
10	112-6401	1	Coupling-Hose, Washout Port	27	117-5924	1	Foam-Seal
11	112-6400	1	Port-Washout	32	114-7987	1	Bumper
12	112-6438	1	Washer-Seal, Washout Port	33	105-6849	2	Screw-Forming, Thread
				34	130-6660	2	Cap-Plug


Rear Bag Assembly



Rear Bag Assembly (continued)

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
1	115-4664	1	Grass Bag ASM
2	114-2639-03	1	Frame-Bag

Engine and Blade Assembly



Engine and Blade Assembly (continued)


<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
1		1	Engine-Briggs, 104M020131F1 ●■
3	105-3031-03	1	Guide-Belt
4	106-3999	1	Spacer-Driver
5	106-3987	1	Driver-Blade
6	131-4547-03	1	Blade-22 Inch
7	108-3766-03	1	Support-Blade

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
8	125-2466	1	Bolt-Blade
9	95-1726	3	Screw-Taptite
12	2210-316	1	Stop-Rope
13	130-2397	1	Decal-Shroud
15	117-2718	1	Decal-Arrester, Spark
18	130-6662	1	Decal-Fuel Level

● Not serviced separately

■ Obtain parts from www.briggsandstratton.com


Transmission and Front Wheel Drive Assembly



Transmission and Front Wheel Drive Assembly (continued)

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>	<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
1	115-1305	1	Cover-Belt	11	32151-36	2	Ring-Retaining
2	46-8091	2	Screw-HWH	12	105-3042	2	Knob-Lever, HOC
3	115-1956-03	2	Plate-HOC, Front	13	322-3	4	Screw-HH
4	104-8698	2	Retainer-Bearing, HOC	14	3296-29	4	Nut-Lock, NI
5	105-1807	2	Arm-Pivot, Front	15	130-6733	1	Transmission ASM
6	105-1809	2	Arm-Spring	16	114-7978-03	1	Bracket-Transmission
7	110-1792	2	Wheel Cover ASM	17	110-7191	2	Washer-Thrust
7:2	614426	1	Washer-Stepped	18	32151-61	2	Ring-Retaining
8	614650	2	Bolt-Shoulder	19	108-7476	3	Screw-Plastite
9	119-0311	2	8 Inch Wheel ASM	20	115-4665	2	Gear-Pinion, 13T
10	104-8699	2	Bearing-Ball	21	117-1018	1	V-Belt


Height-of-Cut and Rear Wheel Assembly



Height-of-Cut and Rear Wheel Assembly (continued)

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>	<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
1	114-7993-03	1	Plate-HOC, Rear (LH)	8	322-5	2	Screw-HH
2	114-7994-03	1	Plate-HOC, Rear (RH)	9	105-3042	2	Knob-Lever, HOC
3	115-4651	2	Bushing-Mount, HOC	10	40-1940	2	Washer
4	114-7997	2	Arm-Pivot, Rear	11	614650	2	Bolt-Shoulder
5	115-2899	2	Arm-Spring, Rear	12	119-0313	2	11 Inch Wheel ASM
6	105-3048	2	Washer-Flat	13	3296-29	2	Nut-Lock, NI
7	322-7	2	Screw-HH				

Bag Attachment Assembly



Bag Attachment Assembly (continued)

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
1	115-2866	2	Anchor-Bag
2	46-8091	2	Screw-HWH

This technical drawing is an exploded view of a vehicle chassis assembly. The main components are labeled with numbers 1 through 21. The assembly includes a central frame (5), side rails (10, 15), and various mounting brackets and fasteners. The diagram shows the relative positions and assembly sequence of the parts, with dashed lines indicating alignment and fit. The components are as follows:

- 1: A small fastener or pin.
- 2: A small fastener or pin.
- 3: A small fastener or pin.
- 4: A bracket or mounting plate.
- 5: The main central frame.
- 6: A small fastener or pin.
- 7: A bracket or mounting plate.
- 8: A bracket or mounting plate.
- 8:1, 8:2, 8:3, 8:4, 8:5: Different views or variants of the bracket in 8.
- 9: A small fastener or pin.
- 10: A side rail or frame member.
- 11: A small fastener or pin.
- 12: A side rail or frame member.
- 13: A small fastener or pin.
- 14: A bracket or mounting plate.
- 15: A side rail or frame member.
- 16: A side rail or frame member.
- 17: A bracket or mounting plate.
- 18: A bracket or mounting plate.
- 19: A side rail or frame member.
- 20: A bracket or mounting plate.
- 21: A bracket or mounting plate.

Handle Assembly (continued)

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>	<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
1	127-6813-03	1	Plate-Handle, LH	9	86-9671	1	Guide-Rope
2	127-6814-03	1	Plate-Handle, RH	10	131-0821-03	1	Bail-Brake
3	3274-55	2	Screw-HSBH	11	92-2270	1	Screw-Handle
4	3296-47	2	Nut-Lock, NI	12	112-8818	1	Cable-Brake
5	131-0861-05	1	Handle	14	3296-73	1	Nut-Lock, NI
6	130-2344	2	Bolt-Shoulder	15	131-0835-03	1	Bail-Traction
7	3296-29	2	Nut-Lock, NI	16	119-2379	1	Cable-Traction
8	115-2860	2	Quick Release ASM	17	114-7988	1	Guide-Cable
8:1	109-0917	1	Nut-Push	18	130-6721	2	Clip-Tree
8:2	114-7995	1	Lever	19	127-6847	1	Cover-Bail
8:3	114-7996	1	Anchor-Spring	20	131-0897	1	Knob-Handle, Locking
8:4	115-2858	1	Spring-Compression	21	131-0894	1	Decal-Traction, Adjust
8:5	114-2675	1	Rod-Release				

Attachments and Accessories

For 20339C 22in Recycler Lawn Mower with SmartStow

Product Name	Model/Part
11 Inch Wheel Asm	119-0313
Fuel Stabilizer .05 oz	130-2393
Toro WPM Maintenance Kit	20234
Lawn Striping Kit with 22in Roller	20601
Replacement Drive Belt Kit, 22-inch 2009 and After Front-Wheel Drive Lawn Mower	38990
Smart Stow Walk Power Mower Cover	490-2012
Replacement Bag	59305
Replacement Bag and Frame Kit	59307
8in Gear Wheel ASM	59502
22 Inch Atomic Blade	59534P

Notes:



Count on it.