

# **LAWN-BOY®**

## **Gold Pro Series™ Walk-Behind Mower**

**Model No. 10425 – 8900001 & Up**

**Model No. 10424 – 8900001 & Up**

---

## **Parts Catalog**

## ORDERING REPLACEMENT PARTS

To order replacement parts, please supply: the part number, the quantity, and the description of each part desired.

## Contents

| Description                   | Page | Description                      | Page  |
|-------------------------------|------|----------------------------------|-------|
| Housing Assembly .....        | 1    | Short Block Assembly .....       | 6     |
| Engine & Blade Assembly ..... | 2    | Carburetor Assembly .....        | 7     |
| Handle Assembly .....         | 3    | Lawn–Boy Part Number Index ..... | 8–10  |
| Engine Assembly .....         | 4    | Maintenance .....                | 11–13 |
| Engine Assembly (cont.) ..... | 5    |                                  |       |

**Note:**

## Accessories

| Description            | Model / Parts No. | Description             | Model / Parts No. |
|------------------------|-------------------|-------------------------|-------------------|
| Rear Bagging Kit ..... | Model No. 89800   | Leaf Bag .....          | Model No. 89804   |
| Side Bagging Kit ..... | Model No. 89814   | Leaf Shredder Kit ..... | Model No. 89860   |

## Part Description Abbreviations

Part descriptions in this catalog may include the following abbreviations.

| Abbreviation | Meaning                | Abbreviation | Meaning                           |
|--------------|------------------------|--------------|-----------------------------------|
| AR .....     | as required            | HWHTF .....  | hex washer head<br>thread forming |
| ASM .....    | assembly               | INC .....    | incorporated                      |
| CARR .....   | carriage               | LH .....     | left hand                         |
| DEG .....    | degrees                | PH .....     | pan head                          |
| FH .....     | flat head              | PPH .....    | Phillips pan head                 |
| GA .....     | gauge                  | PTO .....    | power take off                    |
| HF .....     | hex flange             | RH .....     | right hand                        |
| HFW .....    | hex flange washer      | SFH .....    | slotted fillister head            |
| HH .....     | hex head               | SH .....     | square head                       |
| HHF .....    | hex head flange        | SHWH .....   | slotted hex washer head           |
| HHST .....   | hex head self tapping  | SPH .....    | slotted pan head                  |
| HJ .....     | hex jam                | STD .....    | standard                          |
| HOC .....    | height-of-cut          | TAP .....    | self tapping                      |
| HS .....     | hex socket             | TH .....     | truss head                        |
| HSBH .....   | hex socket button head | TTH .....    | Torx truss head                   |
| HSFH .....   | hex socket flat head   | WH .....     | wing head                         |
| HSR .....    | hex socket head        |              |                                   |
| HWH .....    | hex washer head        |              |                                   |

## Important Format Explanations

This catalog uses special formats to convey information in illustrations and parts lists. Specifically, one format is used in conjunction with service assemblies and another with quantities associated with reference numbers.

## Service Assemblies

Parts within service assemblies have reference numbers in the form  $X:Y$ .  $X$  is the reference number of the service assembly and  $Y$  is a sequential number unique to each part within the service assembly.


For example, a wheel assembly might be identified by reference number 6, the tire by 6:1, the valve by 6:2, and the wheel by 6:3. When you order the assembly identified by reference number 6, you receive all parts identified by reference numbers 6:1, 6:2, and 6:3. However, you may also order any part individually.

Reference numbers of this type appear in part lists and as callouts in illustrations.

## Reference Numbers with Quantities

Illustrations may have a quantity in parentheses next to a reference number, in the form  $X (Y)$ .  $X$  is the reference number.  $Y$  in parentheses is the quantity of the part identified by the reference number.

For example, the illustration callout 4 (2) indicates that two parts are used in that instance.




Sheet No.:2

# Housing Assembly

| Ref. No. | Part No. | Qty. | Description         |
|----------|----------|------|---------------------|
| 1        | 614650   | 2    | Bolt–Shoulder       |
| 2        | 684777   | 2    | ASM–Wheel           |
| 3        | 610646   | 4    | Bolt–Adjustment     |
| 4        | 153444   | 4    | Knob & Spring       |
| 5        | 608834   | 4    | Washer              |
| 7        | 93–7368  | 1    | Shield–Trailing     |
| 8        | 609891   | 2    | Screw–HH            |
| 9        | 93–7693  | 2    | Clamp–Rod           |
| 10       | 98–8332  | 1    | Knob–Cover Plate    |
| 11       | 92–8630  | 1    | Mulch Plate–21”     |
| 12       | 39–5770  | 1    | Decal–Danger        |
| 13       | 614677   | 2    | Screw–Sems          |
| 14       | 94–1610  | 3    | Grommet–Plastic     |
| 15       | 99–1562  | 1    | Housing–21” Hp      |
| 17       | 93–7250  | 1    | Decal–Warning       |
| 18       | 608175   | 1    | Toe Bar 21          |
| 19       | 46–6811  | 2    | Screw–HWH           |
| 20       | 3296–39  | 4    | Nut–Lock            |
| 21       | 608833   | 4    | Bracket–Height      |
| 22       | 40–1940  | 4    | Washer              |
| 24       | 684776   | 2    | ASM–Wheel & Tire 6” |
| 26       | 92–1099  | 2    | Bolt–Shoulder       |
| 27       | 3296–52  | 2    | Nut–Lock            |
| *29      | 95–7052  | 1    | Plate–Cover         |

| Ref. No. | Part No. | Qty. | Description |
|----------|----------|------|-------------|
|          |          |      |             |


\* Not illustrated



Sheet No.:3

## Engine & Blade Assembly

| Ref. No. | Part No. | Qty. | Description                 | Ref. No. | Part No. | Qty. | Description |
|----------|----------|------|-----------------------------|----------|----------|------|-------------|
| 1        | 603164   | 1    | Nut-Blade                   |          |          |      |             |
| 2        | 677525   | 1    | ASM-Plate & Collar          |          |          |      |             |
| 3        | 98-4480  | 3    | Screw-Sems                  |          |          |      |             |
| 4        | 95-7621  | 4    | Screw-Tf Acorn Hd           |          |          |      |             |
| 5        | 95-1897  | 1    | Gas Tank                    |          |          |      |             |
| 6        | 98-8344  | 1    | ASM-Fuel/Oil Cap            |          |          |      |             |
| 7        | 47-2480  | 1    | Rope Stop                   |          |          |      |             |
| 8        | 3290-443 | 1    | Staple                      |          |          |      |             |
| 9        | 93-4306  | 1    | Spring-Compression          |          |          |      |             |
| 10       | 95-7420  | 1    | Decal-Recoil                |          |          |      |             |
| 12       | 98-7032  | 1    | ASM-Shroud & Recoil<br>Covr |          |          |      |             |
| 13       | 92-8615  | 1    | Applique-Shroud             |          |          |      |             |
| 15       |          | 1    | Engine ASM Re Cst<br>Hsg Hp |          |          |      |             |
| 16       | 612543   | 1    | Blade-21" Whirl             |          |          |      |             |
| 17       | 92-1630  | 1    | Fan-Mulching                |          |          |      |             |
| 19       | 66-7460  | 1    | Bulb-Primer                 |          |          |      |             |
| 20       | 44-2750  | 1    | Body-Primer                 |          |          |      |             |
| 21       | 314576   | 1    | Screw-Throttle Cable        |          |          |      |             |
| 22       | 306531   | 1    | Nut-Throttle Cable          |          |          |      |             |
| 23       | 98-1386  | 1    | Foam Pad                    |          |          |      |             |
| 24       | 612782   | 1    | Gas Line                    |          |          |      |             |
| 25       | 99-1521  | 1    | Foam Strip                  |          |          |      |             |
| 26       | 99-1522  | 2    | Foam Strip                  |          |          |      |             |




Sheet No.:4

## Handle Assembly

| Ref. No. | Part No. | Qty. | Description          |
|----------|----------|------|----------------------|
| 1        | 3230-29  | 2    | Bolt-CARR            |
| 2        | 613048   | 1    | Handle Section-Lower |
| 3        | 614249   | 2    | Tie Strap            |
| 4        | 614697   | 2    | Screw-Handle         |
| 5        | 98-7134  | 2    | Knob                 |
| 6        | 95-7446  | 1    | Cable-Throttle       |
| 7        | 95-1713  | 1    | Handle Section-Upper |
| 8        | 93-4184  | 1    | Bail-Flywheel Brake  |
| 9        | 92-5412  | 1    | Stop-Pivot           |
| 10       | 612824   | 1    | Clip-Rope            |
| 11       | 612825   | 1    | Handle-Starter       |
| 12       | 321-49   | 1    | Screw-HH             |
| 13       | 93-7383  | 1    | Guide-Rope           |
| 14       | 92-7738  | 1    | Cable-Flywheel Brake |
| 15       | 3296-73  | 2    | Nut-Lock             |
| 16       | 684057   | 1    | ASM-Bracket & Pin    |
| 17       | 32103-29 | 2    | Nut-Wing             |
| 18       | 3253-33  | 2    | Washer-Lock          |
| 19       | 607188   | 4    | Screw                |
| 20       | 684058   | 1    | ASM-Bracket & Pin    |
| 30       | 92-8632  | 1    | Washer               |
| 31       | 321-48   | 1    | Screw-HH             |


| Ref. No. | Part No. | Qty. | Description |
|----------|----------|------|-------------|
|          |          |      |             |



Sheet No.:100

## Engine Assembly


| Ref. No. | Part No. | Qty. | Description              | Ref. No. | Part No. | Qty. | Description             |
|----------|----------|------|--------------------------|----------|----------|------|-------------------------|
| 2        | 94-5776  | 1    | Head                     | 27       | 3290-459 | 2    | Rivet-Self Expand Plas  |
| 3        | 94-5778  | 1    | Gasket-Head              | 28       | 92-2925  | 1    | Strap-Insulation        |
| 4        | 94-5779  | 2    | Stud                     | 29       | 60-9010  | 1    | Strap-Ground            |
| 5        | 94-5780  | 2    | Bolt                     | 30       | 53-4690  | 1    | Stop-Ground Strap       |
| 6        | 50-1170  | 1    | Spark Plug               | 31       | 12-5450  | 1    | Screw-Thread Forming    |
| 7        | 94-5795  | 2    | Intake Gasket            | 32       | 98-7037  | 1    | Brake Switch Lead Wire  |
| 8        | 612507   | 2    | Screw                    | 33       | 607199   | 1    | Key                     |
| 9        | 95-1861  | 1    | Primer Hose              | 35       | 95-1778  | 1    | Gasket-Exhaust          |
| 11       | 95-5574  | 1    | Element-Air Filter       | 37       | 95-5588  | 1    | Air Filter Base ASM     |
| 12       | 95-5577  | 1    | Cover-Air Filter         | 38       | 95-5578  | 1    | Tunnel                  |
| 13       | 610383   | 1    | Retainer-Filter          | 39       | 95-7613  | 1    | Gasket-Filter Base      |
| 14       | 130743   | 1    | Nut                      | 40       | 3290-456 | 4    | Washer-Lock             |
| 15       | 316959   | 1    | Washer-Lock              | 45       | 95-7636  | A/R  | Short Block ASM Service |
| 16       | 95-1786  | 1    | Cup-Starter              | 51       | 98-1388  | 1    | Heat Shield             |
| 17       | 95-1866  | 1    | Flywheel Machined Recoil | 52       | 98-7042  | 1    | Carburetor ASM          |
| 18       | 92-1152  | 1    | Ignition ASM             | 54       | 613208   | 2    | Screw-HWH               |
| 19       | 613208   | 2    | Screw-HWH                | 55       | 98-1392  | 1    | Gasket                  |
| 20       | 95-1868  | 1    | Shroud & Recoil ASM      | 56       | 99-2904  | 1    | Muffler & Guard         |
| 21       | 700094   | 2    | Screw                    | 57       | 611228   | 1    | Bolt                    |
| 22       | 146501   | 2    | Nut-Lock                 | 58       | 98-1394  | 2    | Screw                   |
| 23       | 95-1870  | 1    | Shoulder Screw Brake     | 59       | 98-1557  | 1    | Transfer Tube           |
| 24       | 95-1871  | 1    | Screw (Brake)            | 60       | 98-1591  | 1    | Cover Plate             |
| 25       | 93-4312  | 1    | ASM-Brake Plate          |          |          |      |                         |
| 26       | 84-7820  | 1    | Plate-Mount Brake        |          |          |      |                         |



Sheet No.:100

Engine Assembly (cont.)


| Ref. No. | Part No. | Qty. | Description             | Ref. No. | Part No. | Qty. | Description |
|----------|----------|------|-------------------------|----------|----------|------|-------------|
| 61       | 700822   | 4    | Screw                   |          |          |      |             |
| 62       | 322-17   | 2    | Screw-HH                |          |          |      |             |
| 63       | 98-1383  | 1    | Muffler Plate Machining |          |          |      |             |
| 64       | 95-7615  | 1    | Retainer Hose           |          |          |      |             |
| 66       | 613233   | 2    | Screw-Hhd Washer        |          |          |      |             |
| 67       | 3254-1   | 2    | Washer-Lock             |          |          |      |             |
| 68       | 317893   | 1    | Tie Strap               |          |          |      |             |
| 69       | 681678   | 1    | High Tension Lead       |          |          |      |             |
| 70       | 684698   | 1    | Cover & Terminal        |          |          |      |             |



Sheet No.:101

## Short Block Assembly

| Ref. No. | Part No. | Qty. | Description              | Ref. No. | Part No. | Qty. | Description |
|----------|----------|------|--------------------------|----------|----------|------|-------------|
| 1        | 677982   | 2    | Liner ASM                |          |          |      |             |
| 3        | 611393   | 2    | Screw                    |          |          |      |             |
| 4        | 611396   | A/R  | Oil Seal                 |          |          |      |             |
| 5        | 683911   | A/R  | Needle Bearing           |          |          |      |             |
| 7        | 99-2920  | A/R  | Crankshaft & Bearing ASM |          |          |      |             |
| 9        | 94-5764  | A/R  | Oil Seal                 |          |          |      |             |
| 10       | 94-5765  | A/R  | Ring Retaining           |          |          |      |             |
| 11       | 95-7628  | A/R  | Piston & Conn Rod ASM    |          |          |      |             |
| 12       | 95-7626  | A/R  | Ring Set                 |          |          |      |             |
| 14       | 94-5781  | 6    | Screw-HWH                |          |          |      |             |
| 15       | 98-7046  | A/R  | Ring-Retaining           |          |          |      |             |
| 16       | 95-7629  | 1    | Connecting Rod ASM       |          |          |      |             |
| 17       | 95-7631  | 1    | Cylinder & Ccase ASM     |          |          |      |             |
| 18       | 303712   | 1    | Retaining Ring           |          |          |      |             |
|          | 610372   | A/R  | Sealant                  |          |          |      |             |
|          | 609790   | A/R  | Sealant                  |          |          |      |             |



Sheet No.:200

## Carburetor Assembly

| Ref. No. | Part No. | Qty. | Description          |
|----------|----------|------|----------------------|
| 1        | 95-5581  | 1    | Shaft-Choke          |
| 2        | 94-5788  | 1    | Disc-Choke           |
| 3        | 95-5583  | 1    | Spring-Choke Return  |
| 4        | 98-7042  | 1    | Carb ASM w/Gaskets   |
| 6        | 612383   | 1    | Washer               |
| 7        | 98-7001  | 1    | Nozzle               |
| 8        | 98-1357  | 1    | Mainjet 77.5         |
| 9        | 94-5787  | 1    | Filter-Fuel          |
| 10       | 95-1899  | 1    | Float & Arm ASM      |
| 11       | 98-1362  | 1    | Gasket-Float Chamber |
| 12       | 92-9691  | 1    | Float Chamber        |
| 13       | 608850   | 4    | Screw                |
| 14       | 92-6389  | 1    | Pin                  |
| 16       | 92-9697  | 1    | Float Valve & Seat   |
| 18       | 98-7011  | 1    | Spring-Throttle      |
| 19       | 610834   | 1    | Collar Adjustment    |
| 20       | 98-7047  | 1    | Disc-Throttle        |
| 21       | 92-6376  | 1    | Air Vane & Shaft     |

| Ref. No. | Part No. | Qty. | Description |
|----------|----------|------|-------------|
|          |          |      |             |

# Lawn–Boy Part Number Index

| Part No. | Page No. | Ref. No. | Qty. | Description          |
|----------|----------|----------|------|----------------------|
| 130743   | 4        | 14       | 1    | Nut                  |
| 146501   | 4        | 22       | 2    | Nut–Lock             |
| 153444   | 1        | 4        | 4    | Knob & Spring        |
| 303712   | 6        | 18       | 1    | Retaining Ring       |
| 306531   | 2        | 22       | 1    | Nut–Throttle Cable   |
| 314576   | 2        | 21       | 1    | Screw–Throttle Cable |
| 316959   | 4        | 15       | 1    | Washer–Lock          |
| 317893   | 5        | 68       | 1    | Tie Strap            |
| 603164   | 2        | 1        | 1    | Nut–Blade            |
| 607188   | 3        | 19       | 4    | Screw                |
| 607199   | 4        | 33       | 1    | Key                  |
| 608175   | 1        | 18       | 1    | Toe Bar 21           |
| 608833   | 1        | 21       | 4    | Bracket–Height       |
| 608834   | 1        | 5        | 4    | Washer               |
| 608850   | 7        | 13       | 4    | Screw                |
| 609790   | 6        |          | A/R  | Sealant              |
| 609891   | 1        | 8        | 2    | Screw–HH             |
| 610372   | 6        |          | A/R  | Sealant              |
| 610383   | 4        | 13       | 1    | Retainer–Filter      |
| 610646   | 1        | 3        | 4    | Bolt–Adjustment      |
| 610834   | 7        | 19       | 1    | Collar Adjustment    |
| 611228   | 4        | 57       | 1    | Bolt                 |
| 611393   | 6        | 3        | 2    | Screw                |
| 611396   | 6        | 4        | A/R  | Oil Seal             |
| 612383   | 7        | 6        | 1    | Washer               |
| 612507   | 4        | 8        | 2    | Screw                |
| 612543   | 2        | 16       | 1    | Blade–21” Whirl      |
| 612782   | 2        | 24       | 1    | Gas Line             |
| 612824   | 3        | 10       | 1    | Clip–Rope            |
| 612825   | 3        | 11       | 1    | Handle–Starter       |
| 613048   | 3        | 2        | 1    | Handle Section–Lower |
| 613208   | 4        | 19       | 2    | Screw–HWH            |
| 613208   | 4        | 54       | 2    | Screw–HWH            |
| 613233   | 5        | 66       | 2    | Screw–Hhd Washer     |
| 614249   | 3        | 3        | 2    | Tie Strap            |
| 614650   | 1        | 1        | 2    | Bolt–Shoulder        |
| 614677   | 1        | 13       | 2    | Screw–Sems           |
| 614697   | 3        | 4        | 2    | Screw–Handle         |
| 677525   | 2        | 2        | 1    | ASM–Plate & Collar   |
| 677982   | 6        | 1        | 2    | Liner ASM            |
| 681678   | 5        | 69       | 1    | High Tension Lead    |
| 683911   | 6        | 5        | A/R  | Needle Bearing       |
| 684057   | 3        | 16       | 1    | ASM–Bracket & Pin    |
| 684058   | 3        | 20       | 1    | ASM–Bracket & Pin    |
| 684698   | 5        | 70       | 1    | Cover & Terminal     |
| 684776   | 1        | 24       | 2    | ASM–Wheel & Tire 6”  |
| 684777   | 1        | 2        | 2    | ASM–Wheel            |
| 700094   | 4        | 21       | 2    | Screw                |
| 700822   | 5        | 61       | 4    | Screw                |
| 12–5450  | 4        | 31       | 1    | Screw–Thread Forming |
| 39–5770  | 1        | 12       | 1    | Decal–Danger         |
| 40–1940  | 1        | 22       | 4    | Washer               |
| 44–2750  | 2        | 20       | 1    | Body–Primer          |
| 46–6811  | 1        | 19       | 2    | Screw–HWH            |
| 47–2480  | 2        | 7        | 1    | Rope Stop            |
| 50–1170  | 4        | 6        | 1    | Spark Plug           |
| 53–4690  | 4        | 30       | 1    | Stop–Ground Strap    |
| 60–9010  | 4        | 29       | 1    | Strap–Ground         |
| 66–7460  | 2        | 19       | 1    | Bulb–Primer          |
| 84–7820  | 4        | 26       | 1    | Plate–Mount Brake    |
| 92–1099  | 1        | 26       | 2    | Bolt–Shoulder        |
| 92–1152  | 4        | 18       | 1    | Ignition ASM         |

\*Not Illustrated

# Lawn–Boy Part Number Index (cont.)

| Part No. | Page No. | Ref. No. | Qty. | Description              |
|----------|----------|----------|------|--------------------------|
| 92–1630  | 2        | 17       | 1    | Fan–Mulching             |
| 92–2925  | 4        | 28       | 1    | Strap–Insulation         |
| 92–5412  | 3        | 9        | 1    | Stop–Pivot               |
| 92–6376  | 7        | 21       | 1    | Air Vane & Shaft         |
| 92–6389  | 7        | 14       | 1    | Pin                      |
| 92–7738  | 3        | 14       | 1    | Cable–Flywheel Brake     |
| 92–8615  | 2        | 13       | 1    | Applique–Shroud          |
| 92–8630  | 1        | 11       | 1    | Mulch Plate–21”          |
| 92–8632  | 3        | 30       | 1    | Washer                   |
| 92–9691  | 7        | 12       | 1    | Float Chamber            |
| 92–9697  | 7        | 16       | 1    | Float Valve & Seat       |
| 93–4184  | 3        | 8        | 1    | Bail–Flywheel Brake      |
| 93–4306  | 2        | 9        | 1    | Spring–Compression       |
| 93–4312  | 4        | 25       | 1    | ASM–Brake Plate          |
| 93–7250  | 1        | 17       | 1    | Decal–Warning            |
| 93–7368  | 1        | 7        | 1    | Shield–Trailing          |
| 93–7383  | 3        | 13       | 1    | Guide–Rope               |
| 93–7693  | 1        | 9        | 2    | Clamp–Rod                |
| 94–1610  | 1        | 14       | 3    | Grommet–Plastic          |
| 94–5764  | 6        | 9        | A/R  | Oil Seal                 |
| 94–5765  | 6        | 10       | A/R  | Ring Retaining           |
| 94–5776  | 4        | 2        | 1    | Head                     |
| 94–5778  | 4        | 3        | 1    | Gasket–Head              |
| 94–5779  | 4        | 4        | 2    | Stud                     |
| 94–5780  | 4        | 5        | 2    | Bolt                     |
| 94–5781  | 6        | 14       | 6    | Screw–HWH                |
| 94–5787  | 7        | 9        | 1    | Filter–Fuel              |
| 94–5788  | 7        | 2        | 1    | Disc–Choke               |
| 94–5795  | 4        | 7        | 2    | Intake Gasket            |
| 95–1713  | 3        | 7        | 1    | Handle Section–Upper     |
| 95–1778  | 4        | 35       | 1    | Gasket–Exhaust           |
| 95–1786  | 4        | 16       | 1    | Cup–Starter              |
| 95–1861  | 4        | 9        | 1    | Primer Hose              |
| 95–1866  | 4        | 17       | 1    | Flywheel Machined Recoil |
| 95–1868  | 4        | 20       | 1    | Shroud & Recoil ASM      |
| 95–1870  | 4        | 23       | 1    | Shoulder Screw Brake     |
| 95–1871  | 4        | 24       | 1    | Screw (Brake)            |
| 95–1897  | 2        | 5        | 1    | Gas Tank                 |
| 95–1899  | 7        | 10       | 1    | Float & Arm ASM          |
| 95–5574  | 4        | 11       | 1    | Element–Air Filter       |
| 95–5577  | 4        | 12       | 1    | Cover–Air Filter         |
| 95–5578  | 4        | 38       | 1    | Tunnel                   |
| 95–5581  | 7        | 1        | 1    | Shaft–Choke              |
| 95–5583  | 7        | 3        | 1    | Spring–Choke Return      |
| 95–5588  | 4        | 37       | 1    | Air Filter Base ASM      |
| 95–7052  | 1        | 29       | 1    | Plate–Cover              |
| 95–7420  | 2        | 10       | 1    | Decal–Recoil             |
| 95–7446  | 3        | 6        | 1    | Cable–Throttle           |
| 95–7613  | 4        | 39       | 1    | Gasket–Filter Base       |
| 95–7615  | 5        | 64       | 1    | Retainer Hose            |
| 95–7621  | 2        | 4        | 4    | Screw–Tf Acorn Hd        |
| 95–7626  | 6        | 12       | A/R  | Ring Set                 |
| 95–7628  | 6        | 11       | A/R  | Piston & Conn Rod ASM    |
| 95–7629  | 6        | 16       | 1    | Connecting Rod ASM       |
| 95–7631  | 6        | 17       | 1    | Cylinder & Ccase ASM     |
| 95–7636  | 4        | 45       | A/R  | Short Block ASM Service  |
| 98–1357  | 7        | 8        | 1    | Mainjet 77.5             |
| 98–1362  | 7        | 11       | 1    | Gasket–Float Chamber     |
| 98–1383  | 5        | 63       | 1    | Muffler Plate Machining  |
| 98–1386  | 2        | 23       | 1    | Foam Pad                 |
| 98–1388  | 4        | 51       | 1    | Heat Shield              |
| 98–1392  | 4        | 55       | 1    | Gasket                   |

\*Not Illustrated

# Lawn-Boy Part Number Index (cont.)

| Part No. | Page No. | Ref. No. | Qty. | Description              |
|----------|----------|----------|------|--------------------------|
| 98-1394  | 4        | 58       | 2    | Screw                    |
| 98-1557  | 4        | 59       | 1    | Transfer Tube            |
| 98-1591  | 4        | 60       | 1    | Cover Plate              |
| 98-4480  | 2        | 3        | 3    | Screw-Sems               |
| 98-7001  | 7        | 7        | 1    | Nozzle                   |
| 98-7011  | 7        | 18       | 1    | Spring-Throttle          |
| 98-7032  | 2        | 12       | 1    | ASM-Shroud & Recoil Covr |
| 98-7037  | 4        | 32       | 1    | Brake Switch Lead Wire   |
| 98-7042  | 7        | 4        | 1    | Carb ASM w/Gaskets       |
| 98-7042  | 4        | 52       | 1    | Carburetor ASM           |
| 98-7046  | 6        | 15       | A/R  | Ring-Retaining           |
| 98-7047  | 7        | 20       | 1    | Disc-Throttle            |
| 98-7134  | 3        | 5        | 2    | Knob                     |
| 98-8332  | 1        | 10       | 1    | Knob-Cover Plate         |
| 98-8344  | 2        | 6        | 1    | ASM-Fuel/Oil Cap         |
| 99-1521  | 2        | 25       | 1    | Foam Strip               |
| 99-1522  | 2        | 26       | 2    | Foam Strip               |
| 99-1562  | 1        | 15       | 1    | Housing-21" Hp           |
| 99-2904  | 4        | 56       | 1    | Muffler & Guard          |
| 99-2920  | 6        | 7        | A/R  | Crankshaft & Bearing ASM |
| 321-48   | 3        | 31       | 1    | Screw-HH                 |
| 321-49   | 3        | 12       | 1    | Screw-HH                 |
| 322-17   | 5        | 62       | 2    | Screw-HH                 |
| 3230-29  | 3        | 1        | 2    | Bolt-CARR                |
| 3253-33  | 3        | 18       | 2    | Washer-Lock              |
| 3254-1   | 5        | 67       | 2    | Washer-Lock              |
| 3290-443 | 2        | 8        | 1    | Staple                   |
| 3290-456 | 4        | 40       | 4    | Washer-Lock              |
| 3290-459 | 4        | 27       | 2    | Rivet-Self Expand Plas   |
| 3296-39  | 1        | 20       | 4    | Nut-Lock                 |
| 3296-52  | 1        | 27       | 2    | Nut-Lock                 |
| 3296-73  | 3        | 15       | 2    | Nut-Lock                 |
| 32103-29 | 3        | 17       | 2    | Nut-Wing                 |

[illegible]

[illegible]

13