Form No. 3390-209 Rev B

TORO®

Count on it.

Parts Catalog

Cab Kit

2010 and After Groundsmaster® 4500-D/4700-D Traction Unit

Model No. 30860

Register at www.Toro.com.
Original Instructions (EN)

3390-209 B

Ordering Replacement Parts

To order replacement parts, please supply the part number, the quantity, and the description of each part desired.

Understanding Reference Numbers

Each identified part in an illustration has a reference number. The reference number for a part also appears in the parts list, along with other information about the part.

This catalog uses two special reference number formats, one to indicate parts in a service assembly and another to indicate the quantity of a given part in an illustration.

Service Assembly Reference Numbers

Parts in service assemblies have reference numbers in the form a:b. The a represents the reference number of the entire service assembly and the b represents a sequential number unique to each part within the service assembly.

For example, a wheel assembly might be identified by reference number 6, the tire by 6:1, the valve by 6:2, and the wheel by 6:3. When you order the assembly identified by reference number 6, you receive all parts identified by reference numbers 6:1,6:2, and 6:3. However, you may also order any part individually. Reference numbers of this type appear in illustration and in parts lists.

Reference Numbers Indicating Quantity

In an illustration, if a reference number indicates more than one part, the reference number has the form nX y. The n represents the quantity of the part, the X is the multiplication symbol, and the y represents the reference number.


For example, in an illustration, the reference number 2X 37 means that two of the parts identified by reference number 37 are indicated.

Contents

Mounting, Shielding and Upholstery Assembly 4
Left Side Shielding and Glass Assembly 5
Right Side Shielding and Glass Assembly 6
Front Window Assembly 7
Rear Window Assembly 8
Door Striker, Mirror and Wiper Assembly 9
B-Post Cover Assembly 10
Headliner Assembly 11
Roof, Condenser and Evaporator Assembly 12
Condenser Assembly 13
Heater Evaporator Assembly 14
Cab A/C Heater and Evaporator No. 121-3860 15
Fuse Block and Switchplate Assembly 16
Washer Tank, Heater and Air Conditioning Connection Assembly 17

© 2017—The Toro® Company
8111 Lyndale Avenue South
Bloomington, MN 55420


Contact us at www.Toro.com.
Printed in the USA.
All Rights Reserved



Mounting, Shielding and Upholstery Assembly

Ref.	Part Number	Qty.	Description
1	119-8600	1	Seal-Bulb, 31 Inch
2	119-8601	1	Upholstery-RH
3	119-8602	2	Seal-Bulb
4	119-8603	1	Upholstery-Rear
5	119-8604	1	Upholstery-LH
6	119-8615	4	Isolator-Rubber
7	327-7	4	Screw-HH
8	119-8616	4	Washer-Flat
9	119-8617	4	Washer-Rubber
10	3296-53	4	Nut-Lock, NI
11	119-8605	1	Shielding-Rear
12	119-8606	1	Cover-Steering, Front
13	119-8607	1	Mat-Floor


Ref.	Part Number	Qty.	Description
14	119-8608	1	Bumper-Front
15	119-8609	1	Bracket-Rear, Left
16	119-8610	1	Upholstery-Rear
17	119-8611	1	Bracket-Front
18	119-8612	1	Bracket-Rear, Right
19	32128-20	3	Nut-HF
20	3234-47	7	Screw-HHF
21	119-8619	2	Seal-Bulb, 6 Inch
22	119-8620	1	Upholstery-Shielding, Rear
23	119-8621	1	Seal-Bulb, 12 Inch
24	119-8622	1	Seal-Bulb, 17.75 Inch
25	119-8624	1	Upholstery-Rear,RH
26	119-8623	1	Upholstery-Rear, RH



Left Side Shielding and Glass Assembly

Ref.	Part Number	Qty.	Description
1	115-5586	4	Nut-Panel, Deep
2	3274-65	4	Screw-HSBH
3	119-0043	1	Seal-Bulb, 45 Inch
4	119-0044	1	Panel-Plastic, LH
5	115-7685	6	Bolt-Step
6	115-5572	6	Nut-Flange
7	115-5574	6	Bushing-Thick
8	115-5570	6	Bushing-Thin
9	119-0032	1	Glass-Window, Side
10	119-0049	1	Seal-Bulb, 58 Inch
11	115-5539	1	Latch-Rotary, LH
12	33103-025	3	Screw-HHF
13	114-9525	2	Nut-Lock
14	3274-96	3	Screw-HSBH
15	115-5534	1	Washer


Ref.	Part Number	Qty.	Description
16	115-5590	1	Shock-Gas, Long
17	115-5546	1	Gasket-Handle
18	115-5544	1	Handle-Button, Push
18:1	119-4514	1	Gasket-Large
18:2	119-4515	1	Gasket-Small
19	115-5573	6	Washer-Sealing
20	115-5531	1	LH Upper Hinge ASM
21	115-5533	1	LH Lower Hinge ASM
22	115-5528	3	Washer
23	104-3082	4	Nut-Lock, HHF
24	119-0039	1	Glass-Left Side Door
25	119-0041	1	Handle-Grab, LH
26	119-0040	1	Seal-Bulb, 169 Inch
27	119-0042	1	Bar-Support, LH
28	115-5545	1	Key-Cab



Right Side Shielding and Glass Assembly

Ref.	Part Number	Qty.	Description
1	115-5586	4	Nut-Panel, Deep
2	3274-65	4	Screw-HSBH
3	119-0045	1	Seal-Bulb, 23 Inch
4	119-0046	1	Panel-Plastic, RH
5	115-7685	6	Bolt-Step
6	115-5572	6	Nut-Flange
7	115-5574	6	Bushing-Thick
8	115-5570	6	Bushing-Thin
9	119-0032	1	Glass-Window, Side
10	119-0049	1	Seal-Bulb, 58 Inch
11	33103-025	3	Screw-HHF
12	114-9525	2	Nut-Lock
13	3274-96	3	Screw-HSBH
14	115-5538	1	Latch-Rotary, RH
15	115-5534	1	Washer

Ref.	Part Number	Qty.	Description
16	115-5590	1	Shock-Gas, Long
17	115-5546	1	Gasket-Handle
18	115-5544	1	Handle-Button, Push
18:1	119-4514	1	Gasket-Large
18:2	119-4515	1	Gasket-Small
19	115-5573	6	Washer-Sealing
20	115-5530	1	RH Upper Hinge ASM
21	115-5532	1	RH Lower Hinge ASM
22	115-5528	3	Washer
23	104-3082	4	Nut-Lock, HHF
24	119-0035	1	Glass-Door, Right Side
25	119-0036	1	Seal-Bulb, 174 Inch
26	119-0037	1	Handle-Grab, RH
27	119-0038	1	Bar-Support, RH




Front Window Assembly

Ref.	Part Number	Qty.	Description
1	32128-26	3	Nut-Flange
2	115-5563	3	Hinge ASM
3	115-5597	2	Handle-Latch
4	115-5599	2	Pin-Split
5	115-5548	3	Screw-HSFH
6	115-5549	6	Screw-HSFH
7	115-5598	3	Washer-Rubber
8	115-5566	1	Window Glass Kit
8:1	115-5568	1	Trim-Seal, Bulb


Ref.	Part Number	Qty.	Description
8:2		1	Glass-Window ●
13	115-5565	1	Lower Windshield Glass Kit
13:1	115-5571	4	Bolt-Step
13:2	115-5569	1	Trim-Seal, Bulb
13:3	115-5570	4	Bushing-Thin
13:4	115-5574	4	Bushing-Thick
13:5	115-5572	4	Nut-Flange
13:6		1	Glass-Front, Lower ●

● Not serviced separately



Rear Window Assembly


Ref.	*Part Number*	*Qty.*	*Description*
1	32128-26	3	Nut-Flange
2	119-0033	1	Rear Window ASM
3	115-5563	3	Hinge ASM
4	115-5597	2	Handle-Latch
5	115-5599	2	Pin-Split
6	115-5548	3	Screw-HSFH
7	115-5549	6	Screw-HSFH
8	115-5598	3	Washer-Rubber
9	138-1192	1	Trim-Window, Rear



Door Striker, Mirror and Wiper Assembly


Ref.	Part Number	Qty.	Description
1	117-2777	1	Plate-Striker
2	115-5576	1	Striker
3	115-5579	1	Nut-HH
4	115-5581	2	Washer-Flat
5	3234-13	2	Screw-HHF
6	3256-26	1	Washer-Flat
7	115-5577	1	Guard-Striker
8	115-5585	2	Mirror-Convex
9	115-5584	1	Arm-Mount, Mirror (LH)
10	115-5583	1	Arm-Mount, Mirror (RH)
11	115-5582	2	Nut-Flange, Crimplock
12	115-8831	1	Motor-Wiper

Ref.	Part Number	Qty.	Description
12:1	119-7735	1	Wiper Seal Kit
13	115-8833	1	Arm-Wiper, 22 Inch
14	115-8832	1	Adaptor ASM (W/Gasket)
15	3253-3	2	Washer-Lock
16	329-4	2	Screw-HH
17	115-8834	1	Blade-Wiper, 22 Inch
18	119-8369	1	Washer Nozzle Kit
19	73-5380	1	Nut-Hex
20	119-8368	1	Connector-Barb
21	119-8367	2	Grommet
22	119-8366	1	Line-Washer



B-Post Cover Assembly


Ref.	*Part Number*	*Qty.*	*Description*
1	115-5586	4	Nut-Panel, Deep
2	3274-65	4	Screw-HSBH
3	119-0048	1	Cover-B Post, LH
4	115-5594	1	Screw-HSBH
5	115-5595	1	Hook-Coat
6	119-0047	1	Cover-B Post, RH



Headliner Assembly

Ref.	Part Number	Qty.	Description
1	32128-26	4	Nut-Flange
2	115-5586	5	Nut-Panel, Deep
3	115-5524	1	Mirror-Rear View
4	115-5572	2	Nut-Flange
5	32128-27	5	Nut-Lock, Flange
6	115-5581	2	Washer-Flat
7	115-5570	6	Bushing-Thin
8	115-5558	3	Louver
9	3274-65	2	Screw-HSBH
10	117-5022	5	Screw-Pan
11	99-2932	1	Screw-HSBH
12	115-5553	1	"obs" Ref 121-3892
13	115-5594	2	Screw-HSBH
14	115-5554	1	Cover-Filter, Rear
15	115-5559	1	Louver-Ball


Ref.	Part Number	Qty.	Description
16	115-5557	1	Cover-Filter, Front
17	115-5556	1	Filter-Air, Front
18	115-5525	2	Light-Warning, Rear
19	115-5598	1	Washer-Rubber
20	119-0034	1	Decal-Stereo Hole Cover
21	115-5520	2	Light-Warning, Front
22	115-5521	2	Grommet-Light
23	115-5515	1	Light-Dome, LED
24	115-5513	2	Spacer-Roof, Front
25	115-5514	2	Spacer-Roof, Rear
26	115-5526	1	Mount-Roof
27	115-5550	1	Headliner
28	115-5555	4	Screw-Thumb
30	117-2764	2	Fastener-Mount, Front Roof
31	117-2763	2	Fastener-Mount, Rear Roof



Roof, Condenser and Evaporator Assembly

Ref.	*Part Number*	*Qty.*	*Description*
1	115-8835	1	Hose-Air Duct
2	117-2785	1	Hose ASM
2:1	117-2779	3	O-Ring
2:2	117-2783	1	Cap-Side, High
2:3	117-2781	1	Grommet
3	115-8837	1	Hose ASM
3:1	117-2778	2	O-Ring
3:2	117-2782	1	Grommet
4	115-8838	1	Hose ASM
4:1	117-2778	2	O-Ring
5	117-2786	1	Hose ASM
5:1	117-2780	2	O-Ring
5:2	117-2784	1	Cap-Side, Low
6	115-8845	2	Hose-Drain, Condensation
7	119-4517	1	Clamp-Hose
10	115-8842	1	Hose
11	115-8843	1	Hose


Ref.	*Part Number*	*Qty.*	*Description*
12	115-8844	1	Hose
13	115-8840	1	Valve-Heater
14	2412-141	4	Clamp-Drive, Worm
15	3290-148	2	Nut-HF
16	104-2408	2	Screw-HSBH
17	3290-379	14	Tie-Cable
18	3256-14	2	Washer-Flat
19	67-1300	1	Decal
20	119-4504	1	Roof
21	119-4503	1	Cover-Condenser
22	115-5581	12	Washer-Flat
23	115-5570	8	Bushing-Thin
24	94-5781	4	Screw-HHF
25	3229-4	2	Screw-CARR
26	119-4505	1	Strap-Mounting
27	73-5380	4	Nut-Hex



Condenser Assembly


Ref.	Part Number	Qty.	Description
1	115-5586	4	Nut-Panel, Deep
2	115-8822	4	Mount-Isolator
3	115-5581	4	Washer-Flat
4	115-5570	4	Bushing-Thin
5	3274-65	4	Screw-HSBH
6	119-4516	2	Foam-Side
7	115-8816	1	Coil-Condenser
8	115-8823	4	Coupler-Nut
9	115-8819	4	Screw-HSBH
10	3296-42	1	Nut-Lock, NI
11	3229-4	1	Screw-CARR

Ref.	Part Number	Qty.	Description
12	119-4500	1	Fan-12 Inch
13	3274-69	4	Screw-HSBH
14	119-4511	1	Shroud-Fan
15	119-4513	1	Frame-Screen
16	119-4512	1	Tray-Screen
17	119-4506	1	Spacer-Latch
18	66-2921	2	Washer-Friction
19	119-4507	1	Plate-Latch
20	119-4527	1	Foam-Tray
21	119-4544	2	Foam-End




Heater Evaporator Assembly

Ref.	*Part Number*	*Qty.*	*Description*
1	33103-025	2	Screw-HHF
2	115-5586	4	Nut-Panel, Deep
3	3274-65	4	Screw-HSBH
4	107-1013	8	Nut-Speed, U-Type
5	104-2408	8	Screw-HSBH
6	119-4502	1	Drier-Receiver
7	121-3860	1	A/C Heater ASM
8	115-8829	1	Cover-Top
9	2412-125	2	Clamp-Hose
10	115-8824	1	Mount-Drier
11	115-8828	1	Evaporator-Bottom



Cab A/C Heater and Evaporator No. 121-3860


Ref.	*Part Number*	*Qty.*	*Description*
1	121-3861	1	Fan-Blower
1:1	121-3862	1	Resistor-Fan
2	115-5587	1	Valve-Expansion
3	115-5593	1	Thermostat-Switch, Freeze




Fuse Block and Switchplate Assembly

Ref.	Part Number	Qty.	Description
1	32128-17	2	Nut-Lock, Flange
2	107-1013	5	Nut-Speed, U-Type
3	104-2408	9	Screw-HSBH
4	115-5506	1	Knob
5	115-5510	1	Cover-Access, Fuse
6	117-2787	1	Label-Information, Fuse
7	115-5508	1	Label-Block, Fuse
8	115-5502	1	Switch-Fan, 3-Speed
9	115-5504	2	Knob-Control
10	115-8820	1	Switch-Control, Heat


Ref.	Part Number	Qty.	Description
11	115-5503	1	Nut
12	115-5501	1	Label-Switch
13	115-5500	1	Plate-Switch
14	114-3329	1	Switch-Rocker
15	95-8999	1	Switch
16	99-7420	1	Plug-Hole
17	115-5511	1	Mount-Block, Fuse
18	115-5547	2	Pad-Fastener
19	115-5505	3	Nut-Panel, Spring





YANMAR ENGINE



YANMAR ENGINE







Washer Tank, Heater and Air Conditioning Connection Assembly

Ref.	*Part Number*	*Qty.*	*Description*
1	32128-33	3	Nut-HF
2	115-8848	1	Tank-Fluid, Washer
3	99-6810	3	Screw-HHF
4	119-8613	1	Bracket-Washer Tank
5	119-8614	1	Mylar-Washer Bracket
6	703846	2	Clamp-Hose
7	117-5040	2	Fitting-Straight
8	2412-3	2	Clamp-Hose
9	119-8618	1	Splice-Hose, Radiator, 1.62 Inch

Ref.	*Part Number*	*Qty.*	*Description*
10	117-2780	1	O-Ring
11	117-2779	2	O-Ring
14	127-6385	1	Bracket-Washer Bottle
15	321-14	2	Screw-HH
16	3256-22	2	Washer-Flat
17	104-7201	2	Nut-HF
18	127-6424	1	Splice-Harness, Wire ●

● Not illustrated

Notes:

Notes:



Count on it.