



Count on it.

Form No. 3420-321 Rev A

Parts Catalog

TM5490 5-Gang Trailed Mower Traction Unit

Model No. 02700—Serial No. 400000000 and Up



Ordering Replacement Parts

To order replacement parts, please supply the part number, the quantity, and the description of each part desired.

Understanding Reference Numbers

Each identified part in an illustration has a reference number. The reference number for a part also appears in the parts list, along with other information about the part.

This catalog uses two special reference number formats, one to indicate parts in a service assembly and another to indicate the quantity of a given part in an illustration.

Service Assembly Reference Numbers

Parts in service assemblies have reference numbers in the form a:b. The a represents the reference number of the entire service assembly and the b represents a sequential number unique to each part within the service assembly.

For example, a wheel assembly might be identified by reference number 6, the tire by 6:1, the valve by 6:2, and the wheel by 6:3. When you order the assembly identified by reference number 6, you receive all parts identified by reference numbers 6:1, 6:2, and 6:3. However, you may also order any part individually. Reference numbers of this type appear in illustration and in parts lists.

Reference Numbers Indicating Quantity

In an illustration, if a reference number indicates more than one part, the reference number has the form nX y. The n represents the quantity of the part, the X is the multiplication symbol, and the y represents the reference number.

For example, in an illustration, the reference number 2X 37 means that two of the parts identified by reference number 37 are indicated.

Contents

Chassis Assembly 4

Axle and Mudguard Assembly 6

Axle Assembly No. 111-9901 8

Drawbar Assembly 10

Brake Assembly 12

Fuel Tank Assembly 14

Hydraulic Assembly 16

Hydraulic Lift Assembly 18

Cutterhead Assembly 20

Rear Arm Assembly 22

Front Arm Assembly 24


PTO Shaft Assembly 26

Lightboard Assembly 28

Hose Assembly 30

Attachments and Accessories 32


Chassis Assembly



Chassis Assembly (continued)

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>	<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
1	09691	8	Bolt	8	50-07-019	1	Strip-Sealing
2	70-13-072	3	Decal	9	66-07-015	2	Insert-Tube, Square
3	749150W	1	Chassis-Front	10	HY09485	16	Washer-Plain
4	10-11-017	4	Fitting-Straight	11	111-3910	1	Decal-Warning, Read
5	ZNN1L000U	8	Nut-Nyloc				Manual
6	66-01-140W	1	Chassis-Rear	12	65-13-079	1	Decal-Grease
7	72-07-061	4	Insert-Rectangular	13	63-07-085	8	Cap-Protect


Axle and Mudguard Assembly



Axle and Mudguard Assembly (continued)

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>	<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
1	66-01-180W	2	Plate-Clamping	6	767505	8	Washer-Stepped
2	111-6883	2	Wheel ASM	7	767810	2	Decal
2:1	66-07-012	1	Tire	8	HY767801	2	Mudguard
2:2	111-6884	1	Rim-Wheel	9	ZBH1P100U	4	Bolt
3	111-9901	1	Axle ASM	10	ZBH1P110U	8	Bolt
4	09456	12	Nut	11	ZWP1P000U	24	Washer-Plain

Axle Assembly No. 111-9901



* Includes 7, 8, 10, 20 (Complete Axle Set)


*** Includes One Bearing, One Circlip and Item 13 (Qty 1)

Axle Assembly No. 111-9901 (continued)

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>	<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
2	111-9997	1	Plate-Braking, RH	13	134-0009	2	Nut-Flange
2	111-9996	1	Plate-Braking, LH	14	134-0010	2	Cap-Dust
3	111-9998	2	Eye-Connecting	16	134-0011	2	Bow-Pressure
5	134-0002	2	Lever-Reverse	17	134-0012	2	Screw And Nut
6	134-0003	2	Lock-Hinge, Spread	18	134-0013	2	Spring-Compound
7	134-0004	2	Spring-Extension	19	134-0014	4	Stopper
8	134-0005	1	Kit-Shoe, Brake Set*	20	134-0015	4	Plate-Cover
9	134-0006	2	Bolt-Bearing	21	134-0016	2	Cap-Protector
10	134-0007	4	Spring-Compression	22	134-0017	2	Pin-Split
11	134-0008	2	Axle-Stub	23	134-0018	2	Cable-Shell
12	134-0401	1	Brake Drum ASM	24	134-0019	2	Nut-Hex
12:99	134-0402	5	Stud ●	25	134-0020	2	Cap-End
12:99	134-0021	1	Kit-Bearing*** ●	99	66-11-003	10	Nut-Wheel ●

● Not illustrated


Drawbar Assembly



Drawbar Assembly (continued)

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>	<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
1	10-11-014	1	Pin-Spiral	25	111-2897	1	Cable
2	10-11-100	3	Cap-Nut	26	HY3512	2	Bushing-Flanged
3	111-1856-03	1	Drawbar	27	09441	9	Nut-Hex, NI
4	111-1877	1	Pin-Drawbar	28	09456	7	Nut
5	111-1920	2	Shim-Drawbar	29	09475	18	Washer
6	111-1931-03	1	Hitch-Pickup	30	09491	12	Washer-Plain
7	111-1945-03	1	Seat-Spring	31	09499	4	Washer
8	111-1946-03	1	Seat-Spring	32	09555	2	Washer
9	111-1953	1	Spring-Die	33	09654	5	Bolt
10	111-1955	1	Washers-Spring	34	09757	1	Bolt
11	111-1999-03	1	Body-Handbrake	35	767815	2	Washer-Belleville
12	111-2000-03	1	Handle-Handbrake	36	HY510197	1	Handle-Grip
13	111-2001-03	1	Release-Handbrake	37	ZBH1H120U	2	Bolt
14	111-2003	1	Spring-Handbrake	38	ZDH1H035U	2	Screw-HH
15	111-2004	2	Ratchet-Handbrake	39	ZDH1P060U	4	Screw-Set, HH
16	111-2131-03	1	Stand-PTO	40	ZNH1H000U	1	Nut-Hex
17	111-2132-03	1	Cover-Drawbar	41	ZNN1X000U	3	Nut-Hex, Nyloc
18	111-2156	2	Boss-Handbrake	42	66-13-016	1	Decal-Drawbar
19	111-2487	2	Pin-Spring	43	66-13-023	1	Decal-Warning, Handbrake
20	111-2518-03	1	Handbrake Lever Assembly	44	134-0492	1	Jockey Assembly
21	111-2565	1	Sleeves-Flat	44:1	134-0493	1	Wheel-Jockey
22	111-2641	1	Stop-Handbrake	45	HY09510	2	Bolt-Hex, HD
23	74-11-001	2	Pin	46	134-0491	1	Clamp-Jockey Wheel
24	111-2896	1	Rod-End, Female				


Brake Assembly



Brake Assembly (continued)

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>	<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
1	10-06-031	1	Seal-Dowty	16	09475	16	Washer
2	10-06-032	1	Seal-Dowty	17	09479	4	Washer-Plain
3	30-06-208	1	Adaptor	18	HY09801	1	Screw-Soc, HD
4	10-06-043	1	Adaptor	19	749202	1	Bush
5	65-07-049	2	Spring	20	749204	1	Cylinder-Pin
6	66-05-112	1	Rod-Link, Brake	22	749606	1	Coupling-Release
7	66-07-006	1	Turnbuckle	24	111-9746	2	Cable-Brake
8	66-07-103	1	Cable-Brake	25	749201W	1	Plate-Bar, Balance
9	111-7443	2	Washer-Domed	26	749203W	2	Plate-Fastener
10	03162	8	Screw-HH	27	749605	1	Cylinder
11	09392	2	Screw-HH	28	767110W	1	Cable-Brake
12	09430	1	Nut-Nyloc	29	HY767501	2	Bushing
13	09441	8	Nut-Hex, NI	30	ZNN1J000U	2	Nut-Hex, NI
14	ZNH1H000U	6	Nut-Hex	31	09693	1	Nut-Unf
15	09470	1	Washer				


Fuel Tank Assembly



Fuel Tank Assembly (continued)

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>	<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
1	10-01-205	1	Gasket-Flange	29	09474	4	Washer-Spring
2	10-06-025	2	Filter-Suction	30	09475	4	Washer
3	10-06-035	1	Seal-Dowty	31	09479	4	Washer-Plain
4	10-06-046	1	Adaptor	33	767800	1	Manifold-Rear
5	10-06-072	1	Plug-Blank	34	767802	1	Cover-Rear
6	10-11-029	12	Screw-PPH, Taptite	35	767811	1	Decal
7	50-07-011	4	Ring-Sealing	36	767120C	1	Tank
8	61-13-019	1	Decal-Warning	37	767130C	1	Cover
9	63-01-115	4	Washer	38	HY09485	8	Washer-Plain
11	63-11-010	4	Bolt-HH	39	MA07001	1	Sponge-Adhesive, Self
12	65-01-130	2	Nut-Bar	40	ZNN1J000U	2	Nut-Hex, NI
13	65-01-133W	2	Hinge-Adjuster	41	ZNN1L000U	4	Nut-Nyloc
14	65-01-311C	1	Filler-Flange	42	111-3728	3	Decal
15	65-06-018	1	Gauge-Level, Oil	44	111-3961	2	Decal
16	65-06-312	1	Filler Cap Assembly	46	767143	1	Filter ASM
17	65-07-026	1	Neoprene-Extrusion	46:1	767144	1	Filter-Replacement
21	111-3901	1	Decal-Transmission, Oil	46:2	65-06-328	1	O Ring
22	03162	4	Screw-HH	46:3	111-9285	1	Gauge-Pressure
24	09363	8	Screw-HH	49	66-06-003	2	Cap-BSP
25	09395	2	Screw-HH	50	953806	1	Tee
26	09438	4	Nut-Nyloc	51	10-06-083	1	Fitting-Tee
27	09441	4	Nut-Hex, NI	52	10-06-042	1	Adaptor-BSPP
28	09472	8	Washer-Plain				

Hydraulic Assembly




Hydraulic Assembly (continued)

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>	<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
1	09-06-217	6	Adaptor	40	09474	3	Washer-Spring
2	10-06-030	7	Seal-Dowty	41	09475	6	Washer
3	10-06-031	7	Seal-Dowty	42	09479	1	Washer-Plain
4	10-06-032	23	Seal-Dowty	43	09480	8	Washer-Lock
5	10-06-033	1	Seal-Dowty	44	HY09485	4	Washer-Plain
6	10-06-078	18	Adaptor-BSPP	45	09599	8	Washer-Lock
7	10-06-085	7	Adaptor	46	510048	1	Handlever-Sleeve
8	10-06-106	2	Gasket-Gearbox	47	749611	2	Valve Relief Assembly
9	10-11-033	1	Clamp-Hose, Hi-Torque	47:1	749610	1	Valve-Relief, Pressure
10	10-11-034	3	Clamp-Hose, Hi-Torque	47:2	749609	1	Body-Line
11	15-06-106	5	Adaptor-BSPP	49	767601	1	Pump-Tandem ●
12	25-06-066	3	Elbow-BSP	50	767606	1	Adaptor-BSPP
13	63-06-104	12	Adaptor-BSP	51	767607	2	Elbow-BSPP
13:1	63-06-111	1	Seal-O Ring	52	ZNN1J000U	1	Nut-Hex, NI
14	63-06-105	8	Tee-BSP	53	767803	1	Gearbox
15	63-06-111	1	Seal-O Ring ●	54	70-06-058	1	Seal-Dowty
16	65-01-119	1	Guard-PTO	55	767804	2	Coupling ●
17	65-01-437	2	Spacer	56	767809	1	Manifold
18	65-01-559	2	Washer-Space	57	767816	1	Manifold-Front
19	65-01-560	1	Bracket-Rotary	58	111-9002	2	HYD CW Motor ASM
20	65-01-880W	1	Release-Lever, Backlap	58:1	111-8146	1	Seal Kit ●
21	65-05-012	1	Bushing-Slide	58:2	107-7820	1	Valve-Relief ●
22	65-05-121	1	Pin-Spring	59	111-9001	3	HYD CCW Motor ASM
24	65-06-354W	1	Valve-Cylinder	59:1	111-8146	1	Seal Kit ●
24:1	65-06-518	1	Seal Kit ●	59:2	107-7820	1	Valve-Relief ●
25	65-07-049	2	Spring	60	950631	1	Adaptor
26	65-07-050	1	Spring	61	ZDH1H035U	3	Screw-HH
27	65-07-053	1	Bushing	62	ZDH1L035U	12	Screw-HH
28	70-06-064	2	Adaptor	63	66-06-003	2	Cap-BSP ●
28:1	70-06-169	1	Seal-O Ring O Ring	64	766600	1	Pump ●
29	70-06-213	1	Adaptor-BSPP	65	65-06-330	2	Cap-BSP ●
29:1	70-06-166	1	Seal-O Ring	66	65-06-342W	1	Valve-Rotary
30	70-06-237	1	Adaptor-BSPP	69	09441	1	Nut-Hex, NI
31	70-11-005	1	Pin-Split	70	ZWQ1J000U	10	Washer-Plain
32	03162	1	Screw-HH	71	111-7863	1	Fitting-Elbow, 90
33	03469	3	Washer-Spring	72	66-06-003	4	Cap-BSP
34	09361	3	Screw-HH	74	30-06-201	1	Tee
35	09363	2	Screw-HH	75	65-06-331	1	Adaptor
36	09364	2	Screw-HH	99	50-07-022	30	Tie-Cable
37	09394	1	Bolt	99	50-07-033	14	Tie-Cable
38	09438	4	Nut-Nyloc	99	74-07-020	15	Tie-Cable
39	09472	8	Washer-Plain				

● Not illustrated


Hydraulic Lift Assembly



Hydraulic Lift Assembly (continued)

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>	<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
1	10-01-216W	1	Decal-Plate	16	65-06-013	1	Cross
2	10-06-030	3	Seal-Dowty	17	65-06-303	1	Valve-Check
3	10-06-031	11	Seal-Dowty	18	65-06-332	1	Adaptor-BSP
4	10-06-042	7	Adaptor-BSPP	19	65-06-333	2	Adaptor-BSP
5	10-06-085	1	Adaptor	21	66-06-004	1	Elbow-90 DEG
6	10-07-010	2	Lever-Parking, Control	27	65-13-078	1	Decal-Control
7	10-07-013/U	4	Cable-Control	28	03162	2	Screw-HH
8	10-07-014	1	Lever-Control (Short Handle)	29	09371	6	Bolt
9	10-07-015	3	Lever-Control (Long Handle)	30	09442	11	Nut
10	10-11-032	3	Lever-Tie Rod, Control	31	09475	16	Washer
11	20-06-203	1	Adaptor-Tee	35	767823	4	Valve Cable Connection Kit
12	20-06-204	1	Elbow-90 DEG	37	767135W	1	Lever-Control, Bracket
13	50-06-009	3	Adaptor-BSP	38	767603W	1	Valve-Lift, Control
15	60-06-011	2	Tee-BSP	39	767604W	1	Valve-Override, Control
				40	ZNK1H000U	3	Nut-Domed


Cutterhead Assembly



Cutterhead Assembly (continued)

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>	<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
1	15-11-003	4	Bolt-CARR	18	ZBH1J090U	2	Screw-HH
3	65-01-531	2	Stop-Bump	20	ZBK1J055U	6	Bolt-CARR
4	74-01-313W	2	Plate	21	ZDH1E016U	8	Screw-HH
5	111-4128-03	4	Plate-Box, Roller	22	ZNN1J000U	12	Nut-Hex, NI
6	09430	8	Nut-Nyloc	23	ZWQ1J000U	12	Washer-Plain
8	09257	16	Washer	24	876086W	1	Guard-HOC, LH
12	876041	2	Bracket-Deflector, LH	25	876087W	1	Guard-HOC, RH
13	876042	2	Bracket-Deflector, RH	26	65-01-532	2	Stop-Bump
14	876049	4	Spacer-Deflector	27	74-01-264W	2	Box-Roller
17	876040W	2	Deflector-Rear				

Rear Arm Assembly




Rear Arm Assembly (continued)

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>	<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
1	10-11-017	7	Fitting-Straight	27	09438	4	Nut-Nyloc
2	10-11-100	10	Cap-Nut	28	09441	6	Nut-Hex, NI
3	25-07-007	6	Bushing-Tension	29	09449	2	Nut
4	61-01-222	2	Roller	30	09454	2	Nut-Hex
5	61-07-003	4	Buffer-Rubber	31	09472	8	Washer-Plain
6	63-01-185W	3	Retainer-Pin	32	09475	12	Washer
7	63-07-027	1	Zerk-Grease, BSP (90 DEG)	33	HY09485	11	Washer-Plain
8	65-07-052	4	Bushing	34	09491	4	Washer-Plain
9	66-01-181	2	Follower-Cam	35	09555	10	Washer
10	66-05-006W	2	Bushing-Retaining, Front	36	09568	4	Bolt-HH
11	66-05-007W	2	Bushing-Retaining, Rear	37	09571	3	Screw-HH
12	66-05-107	1	Pin-Cylinder, Pivot	38	09599	3	Washer-Lock
13	09763	2	Setscrew	39	09650	3	Nut-Hex, Nyloc
14	70-01-471W	2	Bracket-Stop, Bump	40	767552	2	Pin-Diverter, Actuator
15	70-05-113	3	Pin-Arm, Front	41	767815	6	Washer-Belleville
16	70-13-077	3	Decal-Danger	42	767818	2	Bushing-Glacier
17	74-01-230W	1	Arm-Center	43	767819	2	Washer-Thrust
18	74-01-240W	1	Wing-Arm, LH	44	953601	3	Valve-3 Port, Diverter
19	74-01-250W	1	Wing-Arm, RH	44:1	953607	1	Seal Kit ●
20	74-05-108	3	Pin-Wing, Arm	45	111-7922-01	2	Plate-Latch, LH
21	74-05-114	1	Pin-Arm, Pivot	46	111-7921-01	1	Plate-Latch, RH
22	74-06-012W	2	Cylinder-Hydraulic	47	09371	2	Bolt
22:1	74-06-022	1	Seal Kit ●	48	ZBH1H075U	4	Bolt
23	74-06-058W	1	Cylinder-Hydraulic	49	ZBH1J075U	2	Bolt-HH
23:1	50-06-013	1	Seal Kit ●	50	ZDH1J045U	4	Screw-HH
24	74-11-002	2	Pin-Split	51	ZNN1J000U	11	Nut-Hex, NI
25	09392	5	Screw-HH	52	ZNN1X000U	10	Nut-Hex, Nyloc
26	09417	1	Setscrew	53	ZWQ1J000U	26	Washer-Plain

● Not illustrated

Front Arm Assembly




Front Arm Assembly (continued)

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>	<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
1	10-11-017	4	Fitting-Straight	17	09415	2	Screw-HH
2	10-11-100	8	Cap-Nut	18	09417	2	Setscrew
3	25-07-007	2	Bushing-Tension	19	09441	4	Nut-Hex, NI
4	61-01-222	2	Roller	20	09454	2	Nut-Hex
5	63-01-185W	2	Retainer-Pin	21	09475	8	Washer
6	63-06-001W	2	Cylinder	22	HY09485	8	Washer-Plain
6:1	50-06-013	1	Seal Kit ●	23	09491	4	Washer-Plain
7	65-07-052	4	Bushing	24	09555	12	Washer
8	66-01-130W	1	Arm-Front, RH	25	09599	2	Washer-Lock
9	66-01-131W	1	Arm-Front, LH	26	09650	2	Nut-Hex, Nyloc
10	70-05-113	4	Pin-Arm, Front	27	767815	4	Washer-Belleville
11	70-13-077	2	Decal-Danger	28	953601	2	Valve-3 Port, Diverter
12	74-01-402	2	Valve-Diverter, Plate	28:1	953607	1	Seal Kit ●
13	74-05-109	2	Pin-Center, Ram	29	111-7922-01	1	Plate-Latch, LH
14	74-11-001	2	Pin	30	111-7921-01	1	Plate-Latch, RH
15	74-11-002	2	Pin-Split	31	ZNN1X000U	8	Nut-Hex, Nyloc
16	09371	4	Bolt				

● Not illustrated


PTO Shaft Assembly



PTO Shaft Assembly (continued)

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>	<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
1	749812	1	PTO Shaft	1:3:2	111-0689	1	Guard-Inner
1:1	111-0685	2	Journal-Cross, Wide (Angle)	1:3:3	111-0687	1	Shield-Angle, Wide
1:2	111-0686	1	Cross Kit	1:3:4	111-0690	1	Flexible-Cone
1:3	111-0692	1	Guard-Complete	1:3:5	111-0691	2	Chain
1:3:1	111-0688	1	Guard-Outer				

Lightboard Assembly




Lightboard Assembly (continued)

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>	<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
1	66-01-230W	1	Bracket-Lightboard, LH	3:6:1	66-09-009	1	Lens-Side, Red
2	66-01-231W	1	Bracket-Lightboard, RH	3:6:2	66-09-010	1	Lens-Clear, Side
3	111-9960	1	Light Kit ASM	3:6:3	70-09-118	1	Bulb ●
3:1	111-9961	2	Reflector, Triangle	3:7	66-09-011	1	Box-Junction
3:2	111-9962	1	Light-Combination, LH	3:8	66-09-012	1	Plug
3:2:1	70-09-119	1	Bulb ●	3:9	09437	2	Nut
3:2:2	70-09-117	1	Bulb-Indicator ●	3:10	09472	2	Washer-Plain
3:3	111-9963	1	Light-Combination, RH	3:11	09473	2	Washer-Shakeproof ●
3:3:1	70-09-119	1	Bulb ●	4	66-01-232W	2	Plate-Lightboard, Securing
3:3:2	70-09-117	1	Bulb-Indicator ●	5	09397	4	Bolt
3:4	66-09-005	1	Lamp ASM	6	ZWQ1J000U	8	Washer-Plain
3:4:1	70-09-118	1	Bulb ●	7	ZNN1J000U	4	Nut-Hex, NI
3:5	111-9964	1	Light-Fog ●	8	ZBH1H080U	4	Bolt
3:5:1	70-09-117	1	Bulb-Indicator ●	9	09475	8	Washer
3:6	66-09-008	2	Lamp-Position, Side	10	09441	4	Nut-Hex, NI

● Not illustrated

Hose Assembly



Hose Assembly (continued)

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>	<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
1	749604	1	Hose	20	66-06-126	1	Hose
2	749607	1	Hose	21	66-06-127	2	Hose
3	111-8152	1	Hose	22	66-06-128	2	Hose
3:3		1	Coupling-Straight ●■	23	66-06-134	1	Hose
3:3:1	134-0279	1	O-Ring ●	24	70-06-103	2	Hose
4	65-06-451	1	Hose	25	70-06-179	1	Hose
5	66-06-105	3	Hose	26	767609	1	Hose
6	66-06-108	2	Hose	27	767610	1	Hose
7	66-06-111	1	Hose	28	767612	1	Hose
8	749614	1	Hose	29	767613	1	Hose
9	767617	1	Hose	30	767614	1	Hose
10	950681	1	Hose	31	767615	2	Hose
11	65-06-113	2	Hose	32	767620	1	Hose
12	65-06-454	1	Hose	33	767621	1	Hose
13	65-06-455	1	Hose	34	767622	1	Hose
14	66-06-106	1	Hose	35	66-06-112	2	Hose
15	66-06-114	1	Hose	36	66-06-124	1	Hose
16	66-06-119	1	Hose	37	66-06-120	1	Hose
17	66-06-122	1	Hose	38	66-06-109	1	Hose
18	66-06-123	1	Hose	47	111-8150	1	Hose
19	66-06-125	1	Hose	48	111-8153	1	Hose

● Not illustrated

■ Not serviced separately

Attachments and Accessories

For 02700 TM5490 5-Gang Trailed Mower Traction Unit

Product Name	Model/Part
Mk.3 200mm 4-Blade LH-Helix Cutter Unit	02805
Mk.3 200mm 6-Blade LH-Helix Cutter Unit	02806
Mk.3 200mm 8-Blade LH-Helix Cutter Unit	02807
Mk.3 200mm 10-Blade LH-Helix Cutter Unit	02808
Mk.3 250mm 4-Blade LH-Helix Cutter Unit	02815
Mk.3 250mm 6-Blade LH-Helix Cutter Unit	02816
Mk.3 250mm 8-Blade LH-Helix Cutter Unit	02817
Floating Cutting Unit, Fitting Kit	02824
Electric Lift Kit.....	02861

Notes:

Notes:

Notes:



Count on it.