Form No. 3420-322 Rev A

TORO®

Count on it.

Parts Catalog

TM7490 7-Gang Trailed Mower

Traction Unit

Model No. 02701—Serial No. 401330001 and Up

Register at www.Toro.com.
Original Instructions (EN)

CE

3420-322 A

Ordering Replacement Parts

To order replacement parts, please supply the part number, the quantity, and the description of each part desired.

Understanding Reference Numbers

Each identified part in an illustration has a reference number. The reference number for a part also appears in the parts list, along with other information about the part.

This catalog uses two special reference number formats, one to indicate parts in a service assembly and another to indicate the quantity of a given part in an illustration.

Service Assembly Reference Numbers

Parts in service assemblies have reference numbers in the form a:b. The a represents the reference number of the entire service assembly and the b represents a sequential number unique to each part within the service assembly.

For example, a wheel assembly might be identified by reference number 6, the tire by 6:1, the valve by 6:2, and the wheel by 6:3. When you order the assembly identified by reference number 6, you receive all parts identified by reference numbers 6:1,6:2, and 6:3. However, you may also order any part individually. Reference numbers of this type appear in illustration and in parts lists.

Reference Numbers Indicating Quantity

In an illustration, if a reference number indicates more than one part, the reference number has the form nX y. The n represents the quantity of the part, the X is the multiplication symbol, and the y represents the reference number.

For example, in an illustration, the reference number 2X 37 means that two of the parts identified by reference number 37 are indicated.


Contents

Chassis Assembly 4
Axle and Mudguard Assembly 6
Axle Assembly No. 111-9901 8
Drawbar Assembly 10
Brake Assembly 12
Tank Assembly 14
Hydraulic Assembly 16
Hydraulic Lift Assembly 18
Cutterhead Assembly 20
Rear Arm Assembly 22
Front Arm Assembly 24
Wing Arm Assembly 26
PTO Shaft Assembly 28
Lightboard Assembly 30
No. 1 Hose Kit Assembly No. 111-4102 32
No. 2 Hose Kit Assembly No. 111-4102 34
No. 3 Hose Kit Assembly No. 111-4102 36
Attachments and Accessories 38

© 2018—The Toro® Company
8111 Lyndale Avenue South
Bloomington, MN 55420

Contact us at www.Toro.com.
Printed in the USA.
All Rights Reserved


Chassis Assembly



Chassis Assembly (continued)

Ref.	Part Number	Qty.	Description
1	09691	8	Bolt
2	70-13-072	3	Decal
3	749150W	1	Chassis-Front
4	10-11-017	4	Fitting-Straight
5	ZNN1L000U	8	Nut-Nyloc
6	66-01-140W	1	Chassis-Rear
7	72-07-061	4	Insert-Rectangular
8	50-07-019	1	Strip-Sealing
9	66-07-015	2	Insert-Tube, Square
10	HY09485	16	Washer-Plain
11	111-3910	1	Decal-Warning, Read Manual
12	65-13-079	1	Decal-Grease


Axle and Mudguard Assembly



Axle and Mudguard Assembly (continued)

Ref.	Part Number	Qty.	Description
1	66-01-180W	2	Plate-Clamping
2	111-6883	2	Wheel ASM
2:1	66-07-012	1	Tire
2:2	111-6884	1	Rim-Wheel
3	111-9901	1	Axle ASM
4	09456	12	Nut
6	767505	8	Washer-Stepped
7	767810	2	Decal
8	HY767801	2	Mudguard
9	ZBH1P100U	4	Bolt
10	ZBH1P110U	8	Bolt
11	ZWP1P000U	24	Washer-Plain

Axle Assembly No. 111-9901




Axle Assembly No. 111-9901 (continued)

Ref.	Part Number	Qty.	Description
2	111-9997	1	Plate-Braking, RH
2	111-9996	1	Plate-Braking, LH
3	111-9998	2	Eye-Connecting
5	134-0002	2	Lever-Reverse
6	134-0003	2	Lock-Hinge, Spread
7	134-0004	2	Spring-Extension
8	134-0005	1	Kit-Shoe, Brake Set*
9	134-0006	2	Bolt-Bearing
10	134-0007	4	Spring-Compression
11	134-0008	2	Axle-Stub
12	134-0401	1	Brake Drum ASM
12:99	134-0402	5	Stud ●
12:99	134-0021	1	Kit-Bearing*** ●
13	134-0009	2	Nut-Flange
14	134-0010	2	Cap-Dust
16	134-0011	2	Bow-Pressure
17	134-0012	2	Screw And Nut
18	134-0013	2	Spring-Compound
19	134-0014	4	Stopper
20	134-0015	4	Plate-Cover
21	134-0016	2	Cap-Protector
22	134-0017	2	Pin-Split
23	134-0018	2	Cable-Shell
24	134-0019	2	Nut-Hex
25	134-0020	2	Cap-End
99	66-11-003	10	Nut-Wheel ●

● Not illustrated


Drawbar Assembly



Drawbar Assembly (continued)

Ref.	Part Number	Qty.	Description
1	10-11-014	1	Pin-Spiral
2	10-11-100	3	Cap-Nut
3	111-1856-03	1	Drawbar
4	111-1877	1	Pin-Drawbar
5	111-1920	2	Shim-Drawbar
6	111-1931-03	1	Hitch-Pickup
7	111-1945-03	1	Seat-Spring
8	111-1946-03	1	Seat-Spring
9	111-1953	1	Spring-Die
10	111-1955	1	Washers-Spring
11	111-1999-03	1	Body-Handbrake
12	111-2000-03	1	Handle-Handbrake
13	111-2001-03	1	Release-Handbrake
14	111-2003	1	Spring-Handbrake
15	111-2004	2	Ratchet-Handbrake
16	111-2131-03	1	Stand-PTO
17	111-2132-03	1	Cover-Drawbar
18	111-2156	2	Boss-Handbrake
19	111-2487	2	Pin-Spring
20	111-2518-03	1	Handbrake Lever Assembly
21	111-2565	1	Sleeves-Flat
22	111-2641	1	Stop-Handbrake
23	74-11-001	2	Pin
24	111-2896	1	Rod-End, Female
25	111-2897	1	Cable
26	HY3512	2	Bushing-Flanged
27	09441	9	Nut-Hex, NI
28	09456	7	Nut
29	09475	18	Washer
30	09491	12	Washer-Plain
31	09499	4	Washer
32	09555	2	Washer
33	09654	5	Bolt
34	09757	1	Bolt
35	767815	2	Washer-Belleville
36	HY510197	1	Handle-Grip
37	ZBH1H120U	2	Bolt
38	ZDH1H035U	2	Screw-HH
39	ZDH1P060U	4	Screw-Set, HH
40	ZNH1H000U	1	Nut-Hex
41	ZNN1X000U	3	Nut-Hex, Nyloc
42	66-13-015	1	Decal-Drawbar
43	66-13-023	1	Decal-Warning, Handbrake
44	134-0492	1	Jockey Assembly
44:1	134-0493	1	Wheel-Jockey
45	HY09510	2	Bolt-Hex, HD
46	134-0491	1	Clamp-Jockey Wheel


Brake Assembly



Brake Assembly (continued)

Ref.	Part Number	Qty.	Description
1	10-06-031	1	Seal-Dowty
2	10-06-032	1	Seal-Dowty
3	30-06-208	1	Adaptor
4	10-06-043	1	Adaptor
5	65-07-049	2	Spring
6	66-05-112	1	Rod-Link, Brake
7	66-07-006	1	Turnbuckle
8	66-07-103	1	Cable-Brake
9	111-7443	2	Washer-Domed
10	03162	8	Screw-HH
11	09392	2	Screw-HH
12	09430	1	Nut-Nyloc
13	09441	8	Nut-Hex, NI
14	ZNH1H000U	6	Nut-Hex
15	09470	1	Washer
16	09475	16	Washer
17	09479	4	Washer-Plain
18	HY09801	1	Screw-Soc, HD
19	749202	1	Bush
20	749204	1	Cylinder-Pin
22	749606	1	Coupling-Release
24	111-9746	2	Cable-Brake
25	749201W	1	Plate-Bar, Balance
26	749203W	2	Plate-Fastener
27	749605	1	Cylinder
28	767110W	1	Cable-Brake
29	HY767501	2	Bushing
30	ZNN1J000U	2	Nut-Hex, NI
31	09693	1	Nut-Unf


Tank Assembly



Tank Assembly (continued)

Ref.	Part Number	Qty.	Description
1	10-01-205	1	Gasket-Flange
2	10-06-025	2	Filter-Suction
3	10-06-035	1	Seal-Dowty
4	10-06-046	1	Adaptor
5	10-06-072	1	Plug-Blank
6	10-11-029	12	Screw-PPH, Taptite
7	50-07-011	4	Ring-Sealing
8	61-13-019	1	Decal-Warning
9	63-01-115	4	Washer
11	63-11-010	4	Bolt-HH
12	65-01-130	2	Nut-Bar
13	65-01-133W	2	Hinge-Adjuster
14	65-01-311C	1	Filler-Flange
15	65-06-018	1	Gauge-Level, Oil
16	65-06-312	1	Filler Cap Assembly
17	65-07-026	1	Neoprene-Extrusion
21	111-3901	1	Decal-Transmission, Oil
22	03162	4	Screw-HH
23	09262	4	Washer
24	09363	8	Screw-HH
25	09395	2	Screw-HH
26	09438	4	Nut-Nyloc
27	09441	4	Nut-Hex, NI
28	09472	8	Washer-Plain
29	09474	4	Washer-Spring
30	09475	4	Washer
31	09479	4	Washer-Plain
32	767145	1	Filter Assy
32:1	65-06-328	1	O Ring
32:2	767146	1	Filter Replacement
32:3	111-9285	1	Gauge-Pressure
33	767800	1	Manifold-Rear
34	767802	1	Cover-Rear
35	767811	1	Decal
36	767120C	1	Tank
37	767130C	1	Cover
38	HY09485	8	Washer-Plain
39	MA07001	1	Sponge-Adhesive, Self
40	ZNN1J000U	2	Nut-Hex, NI
41	ZNN1L000U	4	Nut-Nyloc
42	111-3728	3	Decal
43	111-3962	2	Decal
49	66-06-003	2	Cap-BSP
50	953806	1	Tee
51	10-06-083	1	Fitting-Tee
52	10-06-042	1	Adaptor-BSPP

Hydraulic Assembly




Hydraulic Assembly (continued)

Ref.	Part Number	Qty.	Description
1	09-06-217	6	Adaptor
2	10-06-030	7	Seal-Dowty
3	10-06-031	7	Seal-Dowty
4	10-06-032	33	Seal-Dowty
5	10-06-033	1	Seal-Dowty
6	10-06-078	26	Adaptor-BSPP
7	10-06-085	7	Adaptor
8	10-06-106	2	Gasket-Gearbox
9	10-11-033	1	Clamp-Hose, Hi-Torque
10	10-11-034	3	Clamp-Hose, Hi-Torque
11	15-06-106	7	Adaptor-BSPP
12	25-06-066	5	Elbow-BSP
13	63-06-104	16	Adaptor-BSP
13:1	63-06-111	1	Seal-O Ring
14	63-06-105	10	Tee-BSP
16	65-01-119	1	Guard-PTO
17	65-01-437	2	Spacer
18	65-01-559	2	Washer-Space
19	65-01-560	1	Bracket-Rotary
20	65-01-880W	1	Release-Lever, Backlap
21	65-05-012	1	Bushing-Slide
22	65-05-121	1	Pin-Spring
23	65-06-343W	1	Valve-3 Bank, Rotary
24	65-06-354W	1	Valve-Cylinder
24:1	65-06-518	1	Seal Kit ●
25	65-07-049	2	Spring
26	65-07-050	1	Spring
27	65-07-053	1	Bushing
28	70-06-064	2	Adaptor
28:1	70-06-169	1	Seal-O Ring O Ring
29	70-06-213	1	Adaptor-BSPP
29:1	70-06-166	1	Seal-O Ring
30	70-06-237	1	Adaptor-BSPP
31	70-11-005	1	Pin-Split
32	03162	1	Screw-HH
33	03469	3	Washer-Spring
34	09361	3	Screw-HH
35	09363	2	Screw-HH
36	09364	2	Screw-HH
37	09394	1	Bolt
38	09438	4	Nut-Nyloc
39	09472	8	Washer-Plain
40	09474	3	Washer-Spring
41	09475	6	Washer
42	09479	1	Washer-Plain
43	09480	8	Washer-Lock
44	HY09485	4	Washer-Plain
45	09599	8	Washer-Lock
46	510048	1	Handlever-Sleeve
47	749611	3	Valve Relief Assembly
47:1	749610	1	Valve-Relief, Pressure
47:2	749609	1	Body-Line
48	767600	1	Pump-Tandem
48:1	767860	1	Seal Kit ●
49	767601	1	Pump-Tandem
50	767606	1	Adaptor-BSPP
51	767607	2	Elbow-BSPP
52	ZNN1J000U	1	Nut-Hex, NI
53	767803	1	Gearbox
54	70-06-058	1	Seal-Dowty
55	767804	2	Coupling ●
56	767809	1	Manifold
57	767816	1	Manifold-Front
58	111-9002	3	HYD CW Motor ASM
58:1	111-8146	1	Seal Kit ●
58:2	107-7820	1	Valve-Relief ●
59	111-9001	4	HYD CCW Motor ASM
59:1	111-8146	1	Seal Kit ●
59:2	107-7820	1	Valve-Relief ●
60	950631	1	Adaptor
61	ZDH1H035U	3	Screw-HH
62	ZDH1L035U	12	Screw-HH
67	767623	1	Adaptor
67:1	70-06-166	1	Seal-O Ring
69	09441	1	Nut-Hex, NI
70	ZWQ1J000U	10	Washer-Plain
71	111-7863	1	Fitting-Elbow, 90 ●
72	66-06-003	4	Cap-BSP
73	60-06-011	1	Tee-BSP
74	65-06-013	1	Cross
75	65-06-331	1	Adaptor
99	50-07-022	30	Tie-Cable
99	50-07-033	14	Tie-Cable
99	74-07-020	15	Tie-Cable

● Not illustrated


Hydraulic Lift Assembly



Hydraulic Lift Assembly (continued)

Ref.	Part Number	Qty.	Description
1	10-01-216W	1	Decal-Plate
2	10-06-030	5	Seal-Dowty
3	10-06-031	11	Seal-Dowty
4	10-06-042	7	Adaptor-BSPP
5	10-06-085	1	Adaptor
6	10-07-010	2	Lever-Parking, Control
7	10-07-013/U	4	Cable-Control
8	10-07-014	1	Lever-Control (Short Handle)
9	10-07-015	3	Lever-Control (Long Handle)
10	10-11-032	3	Lever-Tie Rod, Control
11	20-06-203	1	Adaptor-Tee
12	20-06-204	1	Elbow-90 DEG
13	50-06-009	3	Adaptor-BSP
15	60-06-011	3	Tee-BSP
16	65-06-013	1	Cross
17	65-06-303	1	Valve-Check
18	65-06-332	1	Adaptor-BSP
19	65-06-333	2	Adaptor-BSP
21	66-06-004	1	Elbow-90 DEG
22	66-06-005	2	Adaptor-BSP
27	66-13-013	1	Decal
28	03162	2	Screw-HH
29	09371	6	Bolt
30	09442	11	Nut
31	09475	16	Washer
35	767823	4	Valve Cable Connection Kit
37	767135W	1	Lever-Control, Bracket
38	767603W	1	Valve-Lift, Control
39	767604W	1	Valve-Override, Control
40	ZNK1H000U	3	Nut-Domed


Cutterhead Assembly



Cutterhead Assembly (continued)

Ref.	Part Number	Qty.	Description
1	15-11-003	12	Bolt-CARR
2	876099	2	Washer-Spring
3	65-01-531	2	Stop-Bump
4	74-01-313W	2	Plate
5	111-4128-03	4	Plate-Box, Roller
6	09430	16	Nut-Nyloc
7	09449	4	Nut
8	09257	32	Washer
9	09491	2	Washer-Plain
10	ZNB1L000U	2	Nut-Other
11	749035	2	Guide-Hose
12	876041	4	Bracket-Deflector, LH
13	876042	4	Bracket-Deflector, RH
14	876049	8	Spacer-Deflector
15	749105W	2	Plate-Latch
16	749107C	2	Latch
17	876040W	4	Deflector-Rear
18	ZBH1J090U	2	Screw-HH
20	ZBK1J055U	10	Bolt-CARR
21	ZDH1E016U	16	Screw-HH
22	ZNN1J000U	28	Nut-Hex, NI
23	ZWQ1J000U	24	Washer-Plain
24	876086W	1	Guard-HOC, LH
25	876087W	1	Guard-HOC, RH
26	65-01-532	2	Stop-Bump
27	74-01-264W	2	Box-Roller

Rear Arm Assembly




Rear Arm Assembly (continued)

Ref.	Part Number	Qty.	Description
1	10-11-017	7	Fitting-Straight
2	10-11-100	10	Cap-Nut
3	25-07-007	6	Bushing-Tension
4	61-01-222	2	Roller
5	61-07-003	4	Buffer-Rubber
6	63-01-185W	3	Retainer-Pin
7	63-07-027	1	Zerk-Grease, BSP (90 DEG)
8	65-07-052	4	Bushing
9	66-01-181	2	Follower-Cam
10	66-05-006W	2	Bushing-Retaining, Front
11	66-05-007W	2	Bushing-Retaining, Rear
12	66-05-107	1	Pin-Cylinder, Pivot
13	09763	2	Setscrew
14	70-01-471W	2	Bracket-Stop, Bump
15	70-05-113	3	Pin-Arm, Front
16	70-13-077	3	Decal-Danger
17	74-01-230W	1	Arm-Center
18	74-01-240W	1	Wing-Arm, LH
19	74-01-250W	1	Wing-Arm, RH
20	74-05-108	3	Pin-Wing, Arm
21	74-05-114	1	Pin-Arm, Pivot
22	74-06-012W	2	Cylinder-Hydraulic
22:1	74-06-022	1	Seal Kit ●
23	74-06-058W	1	Cylinder-Hydraulic
23:1	50-06-013	1	Seal Kit ●
24	74-11-002	2	Pin-Split
25	09392	5	Screw-HH
26	09417	1	Setscrew
27	09438	4	Nut-Nyloc
28	09441	6	Nut-Hex, NI
29	09449	2	Nut
30	09454	2	Nut-Hex
31	09472	8	Washer-Plain
32	09475	12	Washer
33	HY09485	11	Washer-Plain
34	09491	4	Washer-Plain
35	09555	10	Washer
36	09568	4	Bolt-HH
37	09571	3	Screw-HH
38	09599	3	Washer-Lock
39	09650	3	Nut-Hex, Nyloc
40	767552	2	Pin-Diverter, Actuator
41	767815	6	Washer-Belleville
42	767818	2	Bushing-Glacier
43	767819	2	Washer-Thrust
44	953601	3	Valve-3 Port, Diverter
44:1	953607	1	Seal Kit ●
45	111-7922-01	2	Plate-Latch, LH
46	111-7921-01	1	Plate-Latch, RH
47	09371	2	Bolt
48	ZBH1H075U	4	Bolt
49	ZBH1J075U	2	Bolt-HH
50	ZDH1J045U	4	Screw-HH
51	ZNN1J000U	11	Nut-Hex, NI
52	ZNN1X000U	10	Nut-Hex, Nyloc
53	ZWQ1J000U	26	Washer-Plain

● Not illustrated

Front Arm Assembly




Front Arm Assembly (continued)

Ref.	Part Number	Qty.	Description
1	10-11-017	4	Fitting-Straight
2	10-11-100	8	Cap-Nut
3	25-07-007	2	Bushing-Tension
4	61-01-222	2	Roller
5	63-01-185W	2	Retainer-Pin
6	63-06-001W	2	Cylinder
6:1	50-06-013	1	Seal Kit ●
7	65-07-052	4	Bushing
8	66-01-130W	1	Arm-Front, RH
9	66-01-131W	1	Arm-Front, LH
10	70-05-113	4	Pin-Arm, Front
11	70-13-077	2	Decal-Danger
12	74-01-402	2	Valve-Diverter, Plate
13	74-05-109	2	Pin-Center, Ram
14	74-11-001	2	Pin
15	74-11-002	2	Pin-Split
16	09371	4	Bolt
17	09415	2	Screw-HH
18	09417	2	Setscrew
19	09441	4	Nut-Hex, NI
20	09454	2	Nut-Hex
21	09475	8	Washer
22	HY09485	8	Washer-Plain
23	09491	4	Washer-Plain
24	09555	12	Washer
25	09599	2	Washer-Lock
26	09650	2	Nut-Hex, Nyloc
27	767815	4	Washer-Belleville
28	953601	2	Valve-3 Port, Diverter
28:1	953607	1	Seal Kit ●
29	111-7922-01	1	Plate-Latch, LH
30	111-7921-01	1	Plate-Latch, RH
31	ZNN1X000U	8	Nut-Hex, Nyloc

● Not illustrated

Wing Arm Assembly




Wing Arm Assembly (continued)

Ref.	Part Number	Qty.	Description
1	10-11-017	2	Fitting-Straight
2	10-11-100	8	Cap-Nut
3	25-07-007	4	Bushing-Tension
4	63-01-185W	2	Retainer-Pin
5	63-01-969	2	Spacer-Skid, Rear
6	66-05-103	2	Pin-Pivot, Front
7	66-05-105	2	Pin-Pivot, Rear
8	66-06-001W	2	Cylinder-Hydraulic
8:1	74-06-013	1	Center Arm Hydraulic Clyinder Kit
8:1:30	74-06-058W	1	Cylinder-Hydraulic
8:1:30:1	50-06-013	1	Seal Kit ●
8:2	10-11-017	2	Fitting-Straight
9	66-11-002	2	Bolt
10	70-13-077	2	Decal-Danger
11	74-01-402	2	Valve-Diverter, Plate
12	74-05-108	2	Pin-Wing, Arm
13	74-05-112	2	Pin-Wing, Cylinder
14	74-11-001	2	Pin
15	03162	4	Screw-HH
16	09371	4	Bolt
17	09441	12	Nut-Hex, NI
18	09447	2	Nut
19	09475	24	Washer
20	09550	4	Nut-Plain
21	09555	8	Washer
22	09571	2	Screw-HH
23	09599	2	Washer-Lock
24	09611	2	Bolt-HH
25	09650	2	Nut-Hex, Nyloc
26	09690	4	Bolt
27	749002	2	Rod-Spring
28	749553	2	Pin-Head, Pivot
29	767817	4	Bushing
30	767821	2	Spring
31	767880	8	Bushing-Flanged
32	953601	2	Valve-3 Port, Diverter
32:1	953607	1	Seal Kit ●
33	749001W	2	Bracket-Spring
34	749005W	1	Cylinder-Wing, LH
35	749010W	1	Arm-Wing, RH
36	749015W	1	Arm-Wing, LH
37	749040W	1	Cylinder-Wing, RH
38	767118W	2	Plate-Slider
39	111-7922-01	1	Plate-Latch, LH
40	111-7921-01	1	Plate-Latch, RH
41	HY09485	4	Washer-Plain
42	ZDH1J045U	2	Screw-HH
43	ZNN1J000U	2	Nut-Hex, NI
44	ZNN1X000U	8	Nut-Hex, Nyloc
45	ZWQ1J000U	8	Washer-Plain
46	HY749701	4	Spring
47	111-3903	2	Decal-Warning
49	ZNH1H000U	4	Nut-Hex
50	74-07-018	2	Clamp-Exhaust
51	749554	2	Pin
52	749804	2	Decal

● Not illustrated


PTO Shaft Assembly



PTO Shaft Assembly (continued)

Ref.	Part Number	Qty.	Description
1	749812	1	PTO Shaft
1:1	111-0685	2	Journal-Cross, Wide (Angle)
1:2	111-0686	1	Cross Kit
1:3	111-0692	1	Guard-Complete
1:3:1	111-0688	1	Guard-Outer
1:3:2	111-0689	1	Guard-Inner
1:3:3	111-0687	1	Shield-Angle, Wide
1:3:4	111-0690	1	Flexible-Cone
1:3:5	111-0691	2	Chain

Lightboard Assembly




Lightboard Assembly (continued)


Ref.	Part Number	Qty.	Description
1	66-01-230W	1	Bracket-Lightboard, LH
2	66-01-231W	1	Bracket-Lightboard, RH
3	111-9960	1	Light Kit ASM
3:1	111-9961	2	Reflector, Triangle
3:2	111-9962	1	Light-Combination, LH
3:2:1	70-09-119	1	Bulb ●
3:2:2	70-09-117	1	Bulb-Indicator ●
3:3	111-9963	1	Light-Combination, RH
3:3:1	70-09-119	1	Bulb ●
3:3:2	70-09-117	1	Bulb-Indicator ●
3:4	66-09-005	1	Lamp ASM
3:4:1	70-09-118	1	Bulb ●
3:5	111-9964	1	Light-Fog ●
3:5:1	70-09-117	1	Bulb-Indicator ●
3:6	66-09-008	2	Lamp-Position, Side
3:6:1	66-09-009	1	Lens-Side, Red
3:6:2	66-09-010	1	Lens-Clear, Side
3:6:3	70-09-118	1	Bulb ●
3:7	66-09-011	1	Box-Junction
3:8	66-09-012	1	Plug
3:9	09437	2	Nut
3:10	09472	2	Washer-Plain
3:11	09473	2	Washer-Shakeproof ●
4	66-01-232W	2	Plate-Lightboard, Securing
5	09397	4	Bolt
6	ZWQ1J000U	8	Washer-Plain
7	ZNN1J000U	4	Nut-Hex, NI
8	ZBH1H080U	4	Bolt
9	09475	8	Washer
10	09441	4	Nut-Hex, NI

● Not illustrated

No. 1 Hose Kit Assembly No. 111-4102



Brake Ram to Bulkhead




Bulkhead to Tractor

No. 1 Hose Kit Assembly No. 111-4102 (continued)

Ref.	*Part Number*	*Qty.*	*Description*
1	749604	1	Hose
2	749607	1	Hose

No. 2 Hose Kit Assembly No. 111-4102




No. 2 Hose Kit Assembly No. 111-4102 (continued)

Ref.	Part Number	Qty.	Description
3	111-8152	1	Hose
4	65-06-451	1	Hose
5	66-06-105	4	Hose
6	66-06-108	2	Hose
7	66-06-110	1	Hose ●
8	66-06-111	3	Hose
9	749614	1	Hose
10	767617	1	Hose
11	767619	1	Hose ●
12	950681	1	Hose

● Not illustrated

No. 3 Hose Kit Assembly No. 111-4102



No. 3 Hose Kit Assembly No. 111-4102 (continued)

Ref.	Part Number	Qty.	Description
13	65-06-113	2	Hose
14	65-06-454	1	Hose ●
15	65-06-455	1	Hose
16	65-06-471	1	Hose ●
17	66-06-106	1	Hose
18	66-06-114	1	Hose
19	66-06-119	1	Hose ●
20	66-06-120	2	Hose
21	66-06-121	1	Hose ●
22	66-06-122	1	Hose
23	66-06-123	1	Hose
24	66-06-125	1	Hose
25	66-06-126	1	Hose
26	66-06-127	2	Hose ●
27	66-06-128	2	Hose
28	66-06-134	1	Hose
29	70-06-103	2	Hose ●
30	70-06-179	1	Hose
31	111-0140	1	Hose ●
32	749600	1	Hose ●
33	749602	2	Hose ●
34	749615	1	Hose ●
35	767608	1	Hose ●
36	767609	1	Hose ●
37	767610	1	Hose
38	767612	2	Hose ●
39	767613	1	Hose ●
40	767614	1	Hose ●
41	767615	3	Hose ●
42	767620	1	Hose ●
43	767621	1	Hose ●
44	767622	1	Hose ●
45	HY749601	1	Hose ●
46	66-06-124	1	Hose ●
47	111-8150	1	Hose ●
48	111-8153	1	Hose ●

● Not illustrated

Attachments and Accessories

For 02701 TM7490 7-Gang Trailed Mower Traction Unit

Product Name	Model/Part
Mk.3 200mm 4-Blade LH-Helix Cutter Unit	02805
Mk.3 200mm 6-Blade LH-Helix Cutter Unit	02806
Mk.3 200mm 8-Blade LH-Helix Cutter Unit	02807
Mk.3 200mm 10-Blade LH-Helix Cutter Unit	02808
Mk.3 250mm 4-Blade LH-Helix Cutter Unit	02815
Mk.3 250mm 6-Blade LH-Helix Cutter Unit	02816
Mk.3 250mm 8-Blade LH-helix Cutter Unit	02817
Floating 200mm (8in) Cutting Unit Fitting Kit	02825
Electric Lift Kit	02861

Notes:



Count on it.