




MODEL NO. 21060-8900001 & UP
MODEL NO. 21061-8900001 & UP
MODEL NO. 21062-8900001 & UP

PARTS CATALOG

34cm Electric Recycler[®] Mower




C-2778

CHASSIS ASSEMBLY

Ref. No.	Part No.	Description	No. Used	Ref. No.	Part No.	Description	No. Used
1	95-6500	Housing	1	13	95-6697	Spacer	1
2	95-6503	Axle - Rear	1	14	95-6565	Push Nut	1
3	95-6502	Axle - Front	1	†15		Indicator - HOC	1
4	95-6665	Wheel Assembly (Incl. Ref. # 5 & 7)	3	†16		U-Clip - Indicator	1
5	95-6543	Cover - Wheel	3	17	95-6505	Balance Spring - HOC	1
6	95-6716	Cover - Wheel	1	18	95-6700	Plate - Axle Front	1
7	95-6544	Spring Clamp - Wheel	4	19	95-6699	Plate - Axle Rear	1
8	95-6563	Cover Knob	1	20	95-6560	Screw	5
9	95-6562	Knob - HOC	1	21	95-6521	Decal - Recycler 34cm	1
10	95-6506	Latch - HOC	1	22	95-6666	Smartwheel Assembly (Incl. Ref. # 6 & 7)	1
11	95-6564	Spring - HOC	1	23	95-6709	Decal - HOC	1
12	95-6719	Rod - HOC (Incl. Ref. # 23)	1				

† Not Serviced Separately




C-2779

MOTOR AND BLADE ASSEMBLY

Ref. No.	Part No.	Description	No. Used
1	95-6533	Motor	1
2	95-6723	Screw	4
3	95-6548	Fan	1
4	95-6520	Adapter - Motor	1
5	95-6624	Baffle - Motor	1
6	95-6632	Capacitor	1
7	95-6584	Clip - Capacitor	1
8	95-6598	Screw	1
9	95-6620	U-Clip	1
10	95-6714	Shroud - Motor (Incl. Ref. #17)	1

Ref. No.	Part No.	Description	No. Used
11	95-6622	Screw	1
12	95-6582	Blade	1
13	95-6547	Retainer - Blade	1
14	95-6549	Screw - Blade	1
15	95-6619	Snap on Nut - Shroud	2
16	95-6623	Screw	2
17	92-2289	Plate - Logo	1
18	95-6532	Screw	2
19	95-6692	Release - Cable	1




C-2780

HANDLE ASSEMBLY

Ref. No.	Part No.	Description	No. Used	Ref. No.	Part No.	Description	No. Used
1	95-6515	Handle Lower	1	*	95-6631	Switch Assembly (Only On: 21061)	1
2	95-6517	Handle Upper	1	13	95-6598	Screw - Switch Assembly	2
3	95-6718	Bolt & Screw Set - Handle	2	14	95-6596	Mount - Bail	1
5	95-6713	Adjusting Knob - Handle (Incl. Ref. #11)	2	15	95-6598	Screw - Mount	1
6	95-6567	Adjusting Disk - Handle	2	16	95-6535	Rod	1
7	95-6568	Holding Disk - Handle	2	17	95-6529	Bail	1
8	95-6703	Bolt	2	18	95-6602	Clamp - Bail	1
9	95-6571	Flange Nut	2	19	95-6597	Cable Holder	1
10	95-6702	Clamp	2	20	95-6630	Switch Assembly (Only On: 21062)	1
11	95-6569	Nut	2	*	95-6685	Cord-Extension (Only On: 21062)	1
12	95-6605	Switch Assembly (Only on: 21060)	1				

* Not Illustrated



C-2781

BAG AND RECYCLING ASSEMBLY

Ref. No.	Part No.	Description	No. Used
1	95-6712	Rear Door (Incl. Ref. #13)	1
2	95-6530	Spring - Rear Door	1
3	95-6508	Handle	1
4	95-6622	Screw	2
5	95-6578	Recycler Plug	1
6	95-6577	Kicker - Middle	1

Ref. No.	Part No.	Description	No. Used
7	95-6576	Kicker - Front	1
8	95-6560	Screw	3
9	95-6553	Frame - Bag	1
10	95-6551	Bag	1
11	95-6555	Ramp - Bag	1
12	95-6708	Screw	1
13	95-6572	Decal - Safety	1