




MODEL NO. 22400-80293 &amp; UP

# PARTS CATALOG

## AUGER HEAD ATTACHMENT for Toro Siteworks Systems




C-2786

## AUGER HEAD ASSEMBLY

| Ref. No. | Part No. | Description          | No. Used |
|----------|----------|----------------------|----------|
| 1        | 98-8256  | Hydraulic Motor      | 1        |
| *        | 56-6890  | Seal Kit for 98-8256 | 1        |
| 2        | 340-6    | O-Ring Nipple        | 2        |
| 3        | 98-8258  | Drive Housing        | 1        |
| 4        | 99-5032  | Gasket               | 1        |
| 5        | 98-8260  | Gear Planetary       | 1        |
| 6        | 98-8261  | Breather Assembly    | 1        |
| 7        | 98-2705  | Mount - Drive Head   | 1        |
| 7:1      | 98-8252  | Decal Warning        | 2        |
| 8        | 99-1406  | Pin - Pivot          | 2        |

| Ref. No. | Part No. | Description    | No. Used |
|----------|----------|----------------|----------|
| 10       | 3274-4   | Screw - SHCS   | 4        |
| 11       | 325-12   | Screw - HH     | 2        |
| 12       | 3256-26  | Washer         | 4        |
| 13       | 3296-23  | Nut - Hex      | 2        |
| 14       | 98-2703  | Nut - Nylock   | 4        |
| 15       | 326-1    | Screw - HH     | 4        |
| *        | 98-8257  | Hoses          | 2        |
| *        | 98-4698  | Male Coupler   | 1        |
| *        | 98-4699  | Female Coupler | 1        |

\* Not Illustrated



C-2754


HYDRAULIC MOTOR AND ASSEMBLY

| Ref. No. | Part No. | Description    | No. Used |
|----------|----------|----------------|----------|
| †1       |          | Seal – Dust    | 1        |
| †2       |          | Seal – O–Ring  | 4        |
| †3       |          | Seal – Shaft   | 1        |
| †4       |          | Back–up Washer | 1        |
| †5       |          | Seal – Shaft   | 1        |

| Ref. No. | Part No. | Description                | No. Used |
|----------|----------|----------------------------|----------|
| †6       |          | Seal – Inner               | 1        |
| †7       |          | Seal – Outer               | 1        |
| *        | 56-6890  | Seal Kit (Incl. Ref # 1-7) | 1        |

† Not Serviced Separately

\* Not Illustrated



C-2745

# PLANETARY GEAR ASSEMBLY

| Ref. No. | Part No. | Description        | No. Used |
|----------|----------|--------------------|----------|
| 1        | 98-8264  | Round Output Shaft | 1        |
| 2        | 60-3830  | Oil Seal           | 1        |
| 3        | 60-3840  | Bearing Cone       | 1        |
| 4        | 60-3850  | Bearing Cup        | 2        |
| 5        | 60-3890  | Bolt               | 6        |
| 6        | 60-3910  | Flat Washer        | 6        |
| 7        | 98-8265  | Hub                | 1        |
| 9        | 60-3880  | Bearing Cone       | 1        |
| 10       | 62-6450  | Retaining Ring     | 1        |

| Ref. No. | Part No. | Description        | No. Used |
|----------|----------|--------------------|----------|
| 11       | 98-8266  | Ring Gear          | 1        |
| 12       | 98-8267  | Carrier Assembly   | 1        |
| 13       | 98-8268  | Sun Gear           | 1        |
| 14       | 60-3980  | Thrust Washer      | 1        |
| 15       | 98-8271  | Cover              | 1        |
| 16       | 98-8269  | Magnetic Pipe Plug | 1        |
| 17       | 98-8270  | Bolt               | 8        |

# TORO PART NUMBER INDEX

| Part No. | Description          | Pg. Ref.<br>No. No. Qty. | Part No. | Description        | Pg. Ref.<br>No. No. Qty. |
|----------|----------------------|--------------------------|----------|--------------------|--------------------------|
| 56-6890  | Seal Kit             | 2 * 1                    | 98-8261  | Breather Assembly  | 1 6 1                    |
| 56-6890  | Seal Kit for 98-8256 | 1 * 1                    | 98-8264  | Round Output Shaft | 3 1 1                    |
| 60-3830  | Oil Seal             | 3 2 1                    | 98-8265  | Hub                | 3 7 1                    |
| 60-3840  | Bearing Cone         | 3 3 1                    | 98-8266  | Ring Gear          | 3 11 1                   |
| 60-3850  | Bearing Cup          | 3 4 2                    | 98-8267  | Carrier Assembly   | 3 12 1                   |
| 60-3880  | Bearing Cone         | 3 9 1                    | 98-8268  | Sun Gear           | 3 13 1                   |
| 60-3890  | Bolt                 | 3 5 6                    | 98-8269  | Magnetic Pipe Plug | 3 16 1                   |
| 60-3910  | Flat Washer          | 3 6 6                    | 98-8270  | Bolt               | 3 17 8                   |
| 60-3980  | Thrust Washer        | 3 14 1                   | 98-8271  | Cover              | 3 15 1                   |
| 62-6450  | Retaining Ring       | 3 10 1                   | 99-1406  | Pin - Pivot        | 1 8 2                    |
| 98-2703  | Nut - Nylock         | 1 14 4                   | 99-5032  | Gasket             | 1 4 1                    |
| 98-2705  | Mount - Drive Head   | 1 7 1                    | 325-12   | Screw - HH         | 1 11 2                   |
| 98-4698  | Male Coupler         | 1 * 1                    | 326-1    | Screw - HH         | 1 15 4                   |
| 98-4699  | Female Coupler       | 1 * 1                    | 3256-26  | Washer             | 1 12 4                   |
| 98-8252  | Decal Warning        | 1 7:1 2                  | 3274-4   | Screw - SHCS       | 1 10 4                   |
| 98-8256  | Hydraulic Motor      | 1 1 1                    | 3296-23  | Nut - Hex          | 1 13 2                   |
| 98-8257  | Hoses                | 1 * 2                    | 340-6    | O-Ring Nipple      | 1 2 2                    |
| 98-8258  | Drive Housing        | 1 3 1                    |          |                    |                          |
| 98-8260  | Gear Planetary       | 1 5 1                    |          |                    |                          |