



**Count on it.**

Form No. 380-0019 Rev B

# Parts Catalog

## 650 Series Golf Sprinkler

Model No. 650 SERIES



# Ordering Replacement Parts

To order replacement parts, please supply the part number, the quantity, and the description of each part desired.

## Understanding Reference Numbers

Each identified part in an illustration has a reference number. The reference number for a part also appears in the parts list, along with other information about the part.

This catalog uses two special reference number formats, one to indicate parts in a service assembly and another to indicate the quantity of a given part in an illustration.

## Service Assembly Reference Numbers

Parts in service assemblies have reference numbers in the form a:b. The a represents the reference number of the entire service assembly and the b represents a sequential number unique to each part within the service assembly.

For example, a wheel assembly might be identified by reference number 6, the tire by 6:1, the valve by 6:2, and the wheel by 6:3. When you order the assembly identified by reference number 6, you receive all parts identified by reference numbers 6:1, 6:2, and 6:3. However, you may also order any part individually. Reference numbers of this type appear in illustration and in parts lists.

## Reference Numbers Indicating Quantity


In an illustration, if a reference number indicates more than one part, the reference number has the form nX y. The n represents the quantity of the part, the X is the multiplication symbol, and the y represents the reference number.

For example, in an illustration, the reference number 2X 37 means that two of the parts identified by reference number 37 are indicated.

# Contents

650 Series ..... 4

# 650 Series



## 650 Series (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>                                             | <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>                                                              |
|-------------|--------------------|-------------|----------------------------------------------------------------|-------------|--------------------|-------------|---------------------------------------------------------------------------------|
| 1           | 3-2095             | 1           | Plug, Cap, Rubber Cover                                        | 16          | 35-1106            | 1           | Screen, Molded                                                                  |
| 2           | 35-8563            | 1           | Cap Assy., Rubber Cover                                        | 17          |                    | 1           | Body Assy. (See Golf Sprinkler Body Assembly Section.) ♦                        |
| 3           | 9-5355             | 1           | Rubber Cover, Rounded Flange (See Service Item 650-02)         | 18          |                    | 1           | Pilot Valve Assy. (See Pilot Valve Assembly Section.) ♦                         |
| 4           | 3-2510             | 1           | Screw, Machine, 5/16-18 X 11/16"                               | 650-02      |                    |             | Kit, Rubber Cover (Includes Items 1-3) ●▲                                       |
| 5           | 89-8461            | 1           | Cap                                                            | 35-7638     |                    |             | Nozzle Assy., W/O Main Nozzle, 650 (Includes Items 4, 5, 7, 8, 9 & 12) ●▲       |
| 6           | 35-6119            | 1           | Snap Ring, Riser                                               | 89-4795     |                    |             | Nozzle Assy., W/O Main Nozzle And Cap, 650 (Includes Items 7, 8, 9 & 12) ●▲     |
| 7           |                    | 1           | Nozzle Base Assy., 656/658 (Use 89-4853 Or 89-4852) ♦          | 89-4852     |                    |             | Nozzle Assy., W/O Main Nozzle, 658 (Includes Items 4, 5, 7, 8, 9, 12 & 13) ●▲   |
| 7           |                    | 1           | Nozzle Base Assy., 651/652, 654/655 (Use 89-4795 Or 35-7638) ♦ | 89-4853     |                    |             | Nozzle Assy., W/O Main Nozzle And Cap, 658 (Includes Items 7, 8, 9, 12 & 13) ●▲ |
| 8           | 35-5846            | 1           | Retainer, Spring                                               | 102-0840    |                    |             | Nozzle, Inner/Intermediate, Blank, Red ●▲                                       |
| 9           | 35-6289            | 1           | Spring, Nozzle                                                 | 363-3397    |                    |             | Plug, Da, 7/16", 52-57 Nozzles ●▲                                               |
| 10          | 35-7658            | 1           | Nozzle, Main, #54 (Includes Item 11)                           | 995-09      |                    |             | Valve Removal Tool ■▲                                                           |
| 10          | 35-7659            | 1           | Nozzle, Main, #55 (Includes Item 11)                           | 995-15      |                    |             | Selector Tool (Flag Key) ■▲                                                     |
| 10          | 35-7660            | 1           | Nozzle, Main, #56 (Includes Item 11)                           | 995-16      |                    |             | Riser Pliers ■▲                                                                 |
| 10          | 35-7661            | 1           | Nozzle, Main, #57 (Includes Item 11)                           | 995-18      |                    |             | Spring Collar Installation Tool ■▲                                              |
| 10          | 35-7662            | 1           | Nozzle, Main, #58 (Includes Item 11)                           | 995-79      |                    |             | Nut Driver, 7/16" (For Inner And Intermediate Nozzles) ■▲                       |
| 10          | 35-9839            | 1           | Nozzle, Main, #59                                              | 995-83      |                    |             | Multi-Purpose Tool ■▲                                                           |
| 11          | 89-3942            | 1           | Nozzle, Inner, 83 Blue (Pre-November 2003)                     | 995-100     |                    |             | Valve Snap Ring Pliers With Screen Remover ■▲                                   |
| 11          | 89-4738            | 1           | Nozzle, Inner, Red                                             | 995-101     |                    |             | Valve Insertion Tool ■▲                                                         |
| 12          | 89-4785            | 1           | Nozzle, Back, Green                                            |             |                    |             |                                                                                 |
| 13          | 3-2093             | 1           | Plate, Retainer                                                |             |                    |             |                                                                                 |
| 14          | 363-4103           | 1           | O-Ring, Body                                                   |             |                    |             |                                                                                 |
| 15          | 9-5187             | 1           | Stator, 34/59                                                  |             |                    |             |                                                                                 |
| 15          | 9-5188             | 1           | Stator, 54                                                     |             |                    |             |                                                                                 |
| 15          | 9-5186             | 1           | Stator, 55/56                                                  |             |                    |             |                                                                                 |
| 15          | 9-5190             | 1           | Stator, 57                                                     |             |                    |             |                                                                                 |
| 15          | 9-5192             | 1           | Stator, 58                                                     |             |                    |             |                                                                                 |

● SERVICE ITEMS  
▲ Not illustrated

■ SERVICE TOOLS  
♦ Not serviced separately

**Notes:**

**Notes:**



**Count on it.**