




MODEL NO. 03224

**PARTS
CATALOG**
**STANDARD SEAT KIT
For Reelmaster® 3100D**


T-3098-1

SEAT ASSEMBLY

Ref. No.	Part No.	Description	No. Used	Ref. No.	Part No.	Description	No. Used
1	92-6280	Seat Assembly (Incl. Ref. #4-7, 14 & 15)	1	8	95-8910	Belt-Seat	1
2	3212-4	Screw-HH	2	9	92-8991	Adjuster w/Latch	1
3	3253-6	Washer-Lock Spring	2	10	32128-25	Nut-Hex. Flange	4
4	351-80	Clip-Edging	1	11	322-2	Screw-HH	4
5	351-78	Edging	1	12	3255-8	Washer-Lock/Ext.	4
6	92-6533	Kit-Cushion Repair	1	13	92-8990	Adjuster-Seat	1
7	92-6534	Shell-Seat	1	14	321-3	Screw-HH	2
				15	92-6282	Switch-Seat	1