



Count on it.

Form No. 3420-896 Rev A

Parts Catalog

LC1P65FC Zone-Start Engine

Model No. 136-7909



Ordering Replacement Parts

To order replacement parts, please supply the part number, the quantity, and the description of each part desired.

Understanding Reference Numbers

Each identified part in an illustration has a reference number. The reference number for a part also appears in the parts list, along with other information about the part.

This catalog uses two special reference number formats, one to indicate parts in a service assembly and another to indicate the quantity of a given part in an illustration.

Service Assembly Reference Numbers

Parts in service assemblies have reference numbers in the form a:b. The a represents the reference number of the entire service assembly and the b represents a sequential number unique to each part within the service assembly.

For example, a wheel assembly might be identified by reference number 6, the tire by 6:1, the valve by 6:2, and the wheel by 6:3. When you order the assembly identified by reference number 6, you receive all parts identified by reference numbers 6:1, 6:2, and 6:3. However, you may also order any part individually. Reference numbers of this type appear in illustration and in parts lists.

Reference Numbers Indicating Quantity

In an illustration, if a reference number indicates more than one part, the reference number has the form nX y. The n represents the quantity of the part, the X is the multiplication symbol, and the y represents the reference number.

For example, in an illustration, the reference number 2X 37 means that two of the parts identified by reference number 37 are indicated.

Contents







Shroud, Flywheel and Fuel Tank Assembly 4

Dipstick, Brake and Governor Arm Assembly 6

Dipstick and Gasket Assembly. 8

Seal and Gasket Kit No. 127-9144 10

Shroud, Flywheel and Fuel Tank Assembly




Shroud, Flywheel and Fuel Tank Assembly (continued)

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
1	119-1990	1	Shroud ASM
2	121-4160	1	Recoil And Blower Shroud Kit
3	119-1970	1	Flywheel And Fan Kit
4	121-4162	1	Fuel Tank Kit

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
4:1	121-4163	1	Cap-Fuel
5	121-4167	1	Fuel Line Kit
6	121-4168	1	Air Vane Kit
7	119-1994	1	Flywheel Shield Kit

Dipstick, Brake and Governor Arm Assembly




Dipstick, Brake and Governor Arm Assembly (continued)

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
1	121-4279	1	Dipstick And Fill Tube Kit
11	119-1991	1	Brake ASM Recoil Kit
47	119-1968	1	Governor Arm Kit
48	127-9144	1	Seal And Gasket Kit
48:1	121-0019	1	Seal-Oil

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
48:2	121-0020	1	Gasket-Breather
48:3	121-0021	1	Seal-Oil
48:4	120-4459	1	Gasket-Cover, Case
48:5	121-0022	1	Seal-Oil

Dipstick and Gasket Assembly




Dipstick and Gasket Assembly (continued)

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
1	121-4175	1	Thermal Control Kit
4	120-4451	1	Lock-Throttle
6	121-4193	2	Rod-Push
9	119-1902	1	Tube-Breather
10	119-1909	1	Air Filter And Prefilter Kit
11	121-4177	1	Air Cleaner ASM Kit
12	127-9146	1	Internal Carb Kit With Gaskets
12	136-7907	1	Carb Replacement Kit
13	121-0367	2	Stud-Intake
15	121-0043	4	Bolt-Flange
16	136-7869	1	Intake Rocker Arm ASM
17	136-7868	1	Exhaust Rocker Arm ASM
23	121-4199	1	Spark Plug

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
24	136-7912	1	Ignition ASM
25	121-4277	1	Muffler And Shield Kit
26	121-0045	2	Stud-Exhaust
27	121-4188	1	Valve Cover Kit
48	127-9144	1	Seal And Gasket Kit
48:6	121-4184	2	Gasket-Carburetor
48:7	120-4446	1	Insulator-Carburetor
48:8	121-4183	1	Gasket-Intake
48:9	121-4197	1	Gasket-Head
48:10	121-4190	1	Gasket-Valve Cover
48:11	121-0034	1	Gasket-Exhaust
49	136-7915	1	Complete Head ASM
50	136-7907	1	Carb Replacement Kit
99	121-4242	1	High Altitude Kit ●

● Not illustrated

Seal and Gasket Kit No. 127-9144



Seal and Gasket Kit No. 127-9144 (continued)

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
1	121-0019	1	Seal-Oil
2	121-0020	1	Gasket-Breather
3	121-0021	1	Seal-Oil
4	120-4459	1	Gasket-Cover, Case
5	121-0022	1	Seal-Oil
6	121-4184	2	Gasket-Carburetor

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
7	120-4446	1	Insulator-Carburetor
8	121-4183	1	Gasket-Intake
9	121-4197	1	Gasket-Head
10	121-4190	1	Gasket-Valve Cover
11	121-0034	1	Gasket-Exhaust
12	121-4179	1	Gasket-Air Cleaner



Count on it.