


EASY-EMPTY GRASS CATCHER

FOR LAWN TRACTORS WITH 38" DECKS

MODEL NO. 79117-990001 & UP


**PARTS
CATALOG**


C-2707

EASY-EMPTY GRASS CATCHER

Ref. No.	Part No.	Description	No. Used
1	94-6030	Duct	1
2	32144-34	Screw - Self Tapping	30
3	28-7760	Ring - Retaining	1
4	28-7770	Seal	1
5	74-3320	Frame	1
6	72-2510	Bag - Front	1
7	72-2640	Seal	1
8	72-2540	Bracket - Hinge	2
9	321-39	Screw - Button Head	4
10	3256-61	Washer - Flat	20
11	235-21	Grip - Handle	1
12	72-2660	Handle - Dump	1
13	3269-4	Rivet - Pop	18
14	92-2511	Decal - Warning	1
15	72-2630	Channel - Dump Handle	1

Ref. No.	Part No.	Description	No. Used
16	3296-42	Nut - Lock	1
17	28-7840	Screen Bag	1
18	2410-70	Plug	6
19	92-1754	Decal - Easy-Empty	1
20	72-2520	Basket - Grass	1
21	72-2650	Frame - Grass Basket	2
23	3296-42	Nut - Lock	8
24	72-2620	Plate - Backup	2
25	321-10	Bolt	8
26	3290-282	Rivet - Pop	4
29	3256-55	Washer - Flat	5
30	3290-355	Pin - Cotter	2
31	72-2550	Guide - Dump Handle	1
32	321-11	Bolt	1
33	72-2530	Latch	1




C-2504

CHUTE ASSEMBLY #94-6036

Ref. No.	Part No.	Description	No. Used
1	120210	Elbow - Bagger	1
2	117344	Latch - Flexible Draw	1
3	94-6033	Latch - Bagger Elbow	1
4	3269-13	Rivet - Pop	2
5	3290-412	Rivet - Pop	5
6	28-8050	Bracket - Mounting Chute	1

Ref. No.	Part No.	Description	No. Used
9	28-8070	Lanyard	1
10	93-1122	Decal - Danger	1
11	28-8130	Pin - Lock, Chute	1
12	3256-22	Washer - Flat	3
*	94-6036	Chute Assembly (Incl. Ref. #1-12)	1

*Not Illustrated



C-2505

MOUNTING HARDWARE

Ref. No.	Part No.	Description	No. Used
1	3296-29	Nut	4
2	322-5	Screw - Cap	4
3	94-1976	Bracket - Channel	1
4	322-3	Screw - Cap	1

Ref. No.	Part No.	Description	No. Used
5	94-1979	Bracket - Bagger Mounting	1
6	25-1530	Pin - Mounting, Lower	1

PART NUMBER INDEX

Part No.	Description	Pg. No.	Ref. No.	Qty.	Part No.	Description	Pg. No.	Ref. No.	Qty.
117344	Latch – Flexible Draw	2	2	1	94-1979	Bracket – Bagger Mounting	3	5	1
120210	Elbow – Bagger	2	1	1	94-6030	Duct	1	1	1
25-1530	Pin – Mounting, Lower	3	6	1	94-6033	Latch – Bagger Elbow	2	3	1
28-7760	Ring – Retaining	1	3	1	94-6036	Chute Assembly	2	*	
28-7770	Seal	1	4	1	235-21	Grip – Handle	1	11	1
28-7840	Screen Bag	1	17	1	2410-70	Plug	1	18	6
28-8050	Bracket – Mounting Chute	2	6	1	321-10	Bolt	1	25	8
28-8070	Lanyard	2	9	1	321-11	Bolt	1	32	1
28-8130	Pin – Lock, Chute	2	11	1	321-39	Screw – Button Head	1	9	4
72-2510	Bag – Front	1	6	1	322-3	Screw – Cap	3	4	1
72-2520	Basket – Grass	1	20	1	322-5	Screw – Cap	3	2	4
72-2530	Latch	1	33	1	3256-22	Washer – Flat	2	12	3
72-2540	Bracket – Hinge	1	8	2	3256-55	Washer – Flat	1	29	5
72-2550	Guide – Dump Handle	1	31	1	3256-61	Washer – Flat	1	10	20
72-2620	Plate – Backup	1	24	2	3269-4	Rivet – Pop	1	13	18
72-2630	Channel – Dump Handle	1	15	1	3269-13	Rivet – Pop	2	4	2
72-2640	Seal	1	7	1	3290-282	Rivet – Pop	1	26	4
72-2650	Frame – Grass Basket	1	21	2	3290-355	Pin – Cotter	1	30	2
72-2660	Handle – Dump	1	12	1	3290-412	Rivet – Pop	2	5	5
74-3320	Frame	1	5	1	3296-29	Nut	3	1	4
92-1754	Decal – Easy-Empty	1	19	1	3296-42	Nut – Lock	1	16	1
92-2511	Decal – Warning	1	14	1	3296-42	Nut – Lock	1	23	8
93-1122	Decal – Danger	2	10	1	32144-34	Screw – Self Tapping	1	2	30
94-1976	Bracket – Channel	3	3	1					