



Form No. 3411-158 Rev B

**Count on it.**

# Parts Catalog

## TimeCutter® MX 5050

### Riding Mower

Model No. 74770—Serial No. 400000000 and Up



# Ordering Replacement Parts

To order replacement parts, please supply the part number, the quantity, and the description of each part desired.

## Understanding Reference Numbers

Each identified part in an illustration has a reference number. The reference number for a part also appears in the parts list, along with other information about the part.

This catalog uses two special reference number formats, one to indicate parts in a service assembly and another to indicate the quantity of a given part in an illustration.

## Service Assembly Reference Numbers

Parts in service assemblies have reference numbers in the form a:b. The a represents the reference number of the entire service assembly and the b represents a sequential number unique to each part within the service assembly.

For example, a wheel assembly might be identified by reference number 6, the tire by 6:1, the valve by 6:2, and the wheel by 6:3. When you order the assembly identified by reference number 6, you receive all parts identified by reference numbers 6:1, 6:2, and 6:3. However, you may also order any part individually. Reference numbers of this type appear in illustration and in parts lists.

## Reference Numbers Indicating Quantity


In an illustration, if a reference number indicates more than one part, the reference number has the form nX y. The n represents the quantity of the part, the X is the multiplication symbol, and the y represents the reference number.

For example, in an illustration, the reference number 2X 37 means that two of the parts identified by reference number 37 are indicated.

# Contents

|                                                        |    |
|--------------------------------------------------------|----|
| Frame Assembly . . . . .                               | 4  |
| Deck Lift Assembly . . . . .                           | 6  |
| Caster, Wheel and Tire Assembly . . . . .              | 8  |
| Traction Drive Assembly . . . . .                      | 10 |
| LH Transaxle Assembly No. 130-6960 . . . . .           | 12 |
| RH Transaxle Assembly No. 130-6961 . . . . .           | 14 |
| Brake Assembly . . . . .                               | 16 |
| Tire Assembly . . . . .                                | 18 |
| Seat Assembly . . . . .                                | 20 |
| Seat Assembly No. 131-4147 . . . . .                   | 22 |
| Motion Control Assembly . . . . .                      | 24 |
| Engine and Muffler Assembly . . . . .                  | 26 |
| Body Styling and Fuel Assembly . . . . .               | 28 |
| Battery and Electrical Assembly . . . . .              | 30 |
| 50 Inch Deck Assembly . . . . .                        | 32 |
| 50 Inch Deck and Decal Assembly No. 131-3614 . . . . . | 34 |
| Decal and Floor Mat Assembly . . . . .                 | 36 |
| Frame Decal Assembly . . . . .                         | 38 |
| Clutch Assembly . . . . .                              | 40 |
| Attachments and Accessories . . . . .                  | 42 |


# Frame Assembly



## Frame Assembly (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i> | <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>      |
|-------------|--------------------|-------------|--------------------|-------------|--------------------|-------------|-------------------------|
| 1           | 130-0699-01        | 1           | Frame ASM          | 18          | 131-0901-01        | 1           | Mount-Hydro, Front (RH) |
| 2           | 117-7337-03        | 1           | Brace-Seat, Rear   | 19          | 131-0902-01        | 1           | Mount-Hydro, Front (LH) |
| 3           | 131-1039-03        | 1           | Support-Pod, Wide  | 20          | 130-6946-01        | 1           | Crossmember-Rear, Wide  |
| 4           | 119-3431-03        | 2           | Support-Tank, Rear | 21          | 117-1232-03        | 1           | Bracket-Hitch           |
| 5           | 131-0914-03        | 1           | Bracket-Battery    | 25          | 121-2989           | 2           | Decal-Bypass            |
| 6           | 125-1726-01        | 1           | Axle ASM           | 27          | 32144-70           | 18          | Screw-Thd Roll, HWH     |
| 10          | 116-4348           | 2           | Cap-Grease         | 28          | 3234-29            | 4           | Screw-HHF               |
| 11          | 109-3678           | 4           | Bearing-Ball       | 29          | 3234-42            | 6           | Screw-HHF               |
| 13          | 132-0892           | 1           | Footrest ASM       | 30          | 3234-47            | 8           | Screw-HHF               |
| 13:2        | 99-4693            | 1           | Decal              | 34          | 104-8300           | 12          | Nut-HF, NI              |
| 13:3        | 132-0869           | 1           | Decal-Danger       | 35          | 104-8301           | 6           | Nut-HF, NI              |
| 16          | 130-0701-03        | 1           | Guard-Engine, Wide |             |                    |             |                         |

# Deck Lift Assembly



## Deck Lift Assembly (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>    | <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i> |
|-------------|--------------------|-------------|-----------------------|-------------|--------------------|-------------|--------------------|
| 1           | 132-6878-03        | 1           | Lift-Deck, Wide       | 16          | 3296-29            | 2           | Nut-Lock, NI       |
| 2           | 119-8875           | 2           | Bracket-Lift          | 17          | 120-2294-03        | 1           | Bracket-Footlift   |
| 3           | 32144-70           | 4           | Screw-Thd Roll, HWH   | 18          | 256-156            | 2           | Bushing-Flange     |
| 4           | 119-3427-03        | 1           | Lever-Lift            | 19          | 3234-42            | 2           | Screw-HHF          |
| 5           | 1-633268           | 1           | Grip-Lever            | 20          | 104-8301           | 2           | Nut-HF, NI         |
| 6           | 3-6498             | 2           | Washer-Thrust         | 21          | 132-6939-03        | 1           | Pedal ASM          |
| 7           | 3234-36            | 2           | Screw-HHF             | 22          | 120-2242           | 1           | Rod-Footlift       |
| 8           | 104-8300           | 2           | Nut-HF, NI            | 23          | 3256-26            | 5           | Washer-Flat        |
| 9           | 121-1759           | 2           | Spacer                | 24          | 119-8810           | 1           | Pin-Pivot          |
| 10          | 131-3933           | 1           | Plate-Footlift        | 25          | 133-4319           | 1           | Rod-Mount, Deck    |
| 12          | 119-3347           | 1           | Arm-Lift, Rear (Wide) | 26          | 3296-19            | 1           | Nut-Hex            |
| 13          | 108-7840           | 2           | Link-Lift             | 27          | 3272-11            | 5           | Pin-Cotter         |
| 14          | 108-7845           | 2           | Block-Pivot           | 28          | 1-806005           | 1           | Pin-Cotter         |
| 15          | 120-5499           | 2           | Screw-HSBH            |             |                    |             |                    |

# Caster, Wheel and Tire Assembly




## Caster, Wheel and Tire Assembly (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>            | <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i> |
|-------------|--------------------|-------------|-------------------------------|-------------|--------------------|-------------|--------------------|
| 1           | 119-3349-01        | 2           | Fork-Caster                   | 2:99        | 232-46             | 1           | Tube-Inner●        |
| 2           | 119-3473           | 2           | 13 Inch Wheel And Tire<br>ASM | 3           | 119-3475           | 2           | Spanner            |
| 2:1         | 119-3471           | 1           | Tire-13 Inch                  | 4           | 325-37             | 2           | Screw-HH           |
| 2:3         | 114-1640           | 2           | Bushing-Flange                | 5           | 3296-45            | 2           | Nut-Lock, NI       |
| 2:4         | 232-27             | 1           | Stem-Valve                    | 6           | 117-7394           | 2           | Washer-Thrust      |
| 2:5         | 302-5              | 1           | Fitting-Grease                | 7           | 3256-68            | 2           | Washer-Flat        |
|             |                    |             |                               | 8           | 3234-47            | 2           | Screw-HHF          |

● Not illustrated

# Traction Drive Assembly



## Traction Drive Assembly (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>           | <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i> |
|-------------|--------------------|-------------|------------------------------|-------------|--------------------|-------------|--------------------|
| 1           | 119-3353           | 1           | Spacer                       | 18          | 323-11             | 2           | Screw-HH           |
| 2           | 119-8822           | 1           | Pulley-Idler                 | 19          | 323-9              | 2           | Screw-HH           |
| 3           | 119-3327           | 1           | Spacer-Arm, Idler            | 22          | 323-7              | 2           | Screw-HH           |
| 4           | 119-3326           | 1           | Arm-Idler                    | 23          | 104-8301           | 6           | Nut-HF, NI         |
| 5           | 106-2176           | 1           | Pulley-Idler                 | 24          | 3256-23            | 6           | Washer-Plain       |
| 6           | 5-4460             | 1           | Washer-Pivot                 | 25          | 322-11             | 4           | Screw-HH           |
| 7           | 3230-8             | 1           | Screw-CARR                   | 26          | 322-13             | 4           | Screw-HH           |
| 8           | 3256-3             | 1           | Washer-Flat                  | 27          | 3234-29            | 4           | Screw-HHF          |
| 9           | 322-7              | 1           | Screw-HH                     | 29          | 130-7048           | 1           | Rod-Bypass, LH     |
| 10          | 104-8300           | 14          | Nut-HF, NI                   | 30          | 130-7047           | 1           | Rod-Bypass, RH     |
| 11          | 130-6976           | 1           | V-Belt                       | 31          | 119-8952           | 2           | Washer             |
| 12          | 104-6415           | 1           | Spring-Return, Pedal         | 32          | 3290-307           | 2           | Pin-Cotter         |
| 14          | 121-0745-01        | 2           | Mount-Hydro                  | 33          | 136-4182           | 2           | Hose-Hydro         |
| 15          | 130-6960           | 1           | LH Hydro Transmission<br>ASM | 34          | 136-4183           | 2           | Breather Kit       |
| 16          | 130-6961           | 1           | RH Hydro Transmission<br>ASM | 35          | 614249             | 2           | Tie-Cable ●        |
| 17          | 130-0718-01        | 1           | Plate-Cross, Hydro           | 36          | 117-1193           | 4           | Clamp-Hose         |
|             |                    |             |                              | 37          | 242-50             | 8           | Nut-Lug            |

● Not illustrated


This diagram illustrates the exploded view of a mechanical assembly, likely a pump or motor. The components are numbered as follows:

- 1**: Main housing or base.
- 2**: Top cover plate.
- 3**: Screws for the top cover.
- 4**: Small pins or spacers.
- 5**: Gasket or seal for the top cover.
- 6**: Nut or cap nut.
- 7**: Pin or screw.
- 8**: Pin or screw.
- 9**: Pin or screw.
- 10**: Pin or screw.
- 11**: Pin or screw.
- 12**: Pin or screw.
- 13**: Pin or screw.
- 14**: Pin or screw.
- 15**: Pin or screw.
- 16**: Pin or screw.
- 17**: Pin or screw.
- 18**: Pin or screw.
- 19**: Pin or screw.
- 20**: Pin or screw.
- 21**: Pin or screw.
- 22**: Pin or screw.
- 23**: Pin or screw.
- 24**: Pin or screw.
- 25**: Pin or screw.
- 26**: Pin or screw.
- 27**: Pin or screw.
- 28**: Pin or screw.
- 29**: Pin or screw.
- 30**: Pin or screw.
- 31**: Pin or screw.
- 32**: Pin or screw.
- 33**: Pin or screw.
- 34**: Pin or screw.
- 35**: Pin or screw.
- 36**: Pin or screw.
- 37**: Pin or screw.
- 38**: Pin or screw.
- 39**: Pin or screw.
- 40**: Pin or screw.
- 41**: Pin or screw.
- 42**: Pin or screw.
- 43**: Pin or screw.
- 44**: Pin or screw.
- 45**: Pin or screw.
- 46**: Pin or screw.
- 47**: Pin or screw.
- 48**: Pin or screw.
- 49**: Pin or screw.
- 50**: Pin or screw.
- 51**: Pin or screw.
- 52**: Pin or screw.
- 53**: Pin or screw.
- 54**: Pin or screw.

# LH Transaxle Assembly No. 130-6960 (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>       | <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>    |
|-------------|--------------------|-------------|--------------------------|-------------|--------------------|-------------|-----------------------|
| 1           | 125-0037           | 1           | Main Housing Kit         | 29          | 94-1933            | 2           | Washer                |
| 2           | 132-0939           | 1           | RH Side Cover Kit        | 30          | 125-0000           | 1           | Gear-43T              |
| 3           | 117-5359           | 16          | Screw-HHF                | 31          | 114-1693           | 1           | Gear-11T              |
| 4           | 114-1678           | 4           | O-Ring                   | 32          | 104-5329           | 1           | Pin-Jackshaft         |
| 5           | 104-2189           | 1           | Plug-Thread, Straight    | 33          | 104-2169           | 1           | Ring-Retaining        |
| 6           | 109-3321           | 1           | Element-Oil Filter, HYD  | 34          | 114-1694           | 1           | Gear-54T              |
| 7           | 106-8676           | 1           | Seal-Lip                 | 35          | 120-7975           | 1           | Spacer                |
| 8           | 106-8677           | 1           | Ring-Retaining, External | 36          | 126-0789           | 1           | Bearing-Ball          |
| 9           | 114-1685           | 1           | Rod-Bypass               | 37          | 120-7976           | 1           | Bearing-Ball          |
| 10          | 106-8679           | 1           | Ring-Retaining, Internal | 38          | 104-2144           | 1           | Seal                  |
| 11          | 112-9852           | 1           | Arm-Bypass               | 39          | 109-5939           | 1           | Hub Kit               |
| 12          | 106-8681           | 1           | Ring-Retaining, External | 40          | 114-1697           | 1           | Pawl-Brake            |
| 13          | 104-5304           | 1           | Swashplate-Trunnion      | 41          | 114-1698           | 1           | Shaft-Brake, Inboard  |
| 14          | 104-5313           | 1           | Seal-Lip                 | 42          | 125-0021           | 1           | Handle-Brake          |
| 15          | 104-2116           | 1           | Stud                     | 43          | 131-0906           | 1           | Ring-Retaining, EXT   |
| 16          | 112-9853           | 1           | Puck-Friction            | 44          | 104-2120           | 3           | Screw                 |
| 17          | 104-5308           | 1           | Spacer                   | 45          | 120-7981           | 1           | Guard-Filter, RH      |
| 18          | 104-5310           | 1           | Seal-Lip                 | 46          | 109-3278           | 1           | Adapter-Straight      |
| 19          | 104-5309           | 1           | Ring-Retaining           | 46:1        | 237-42             | 1           | O-Ring                |
| 20          | 112-4154           | 1           | Bearing-Thrust           | 47          | 115-5057           | 1           | Cover-Nut, Axle       |
| 21          | 114-1689           | 1           | Motor Cylinder Block Kit | 48          | 121-5745           | 1           | Spacer                |
| 22          | 94-6922            | 1           | Bearing-Thrust           | 49          | 109-3537           | 1           | Seal Kit              |
| 23          | 110-8561           | 1           | Pump Block ASM           | 50          | 132-0940           | 1           | RH Center Section Kit |
| 24          | 104-5339           | 1           | Washer-Flat              | 51          | 121-5746           | 1           | Fan Pulley Kit        |
| 25          | 104-5340           | 1           | Ring-Retaining           | 52          | 114-8468           | 1           | Input Shaft Kit       |
| 26          | 121-5749           | 1           | Gear-16T                 | 53          | 117-5362           | 1           | Control Arm Kit       |
| 27          | 114-1691           | 1           | Shaft-Motor              | 54          | 114-8470           | 1           | Axle Shaft Kit        |
| 28          | 104-5360           | 1           | Washer                   |             |                    |             |                       |

# RH Transaxle Assembly No. 130-6961



## RH Transaxle Assembly No. 130-6961 (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>       | <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>   |
|-------------|--------------------|-------------|--------------------------|-------------|--------------------|-------------|----------------------|
| 1           | 121-5748           | 1           | Main Housing Kit         | 29          | 94-1933            | 2           | Washer               |
| 2           | 132-0938           | 1           | LH Side Cover Kit        | 30          | 125-0000           | 1           | Gear-43T             |
| 3           | 117-5359           | 16          | Screw-HHF                | 31          | 114-1693           | 1           | Gear-11T             |
| 4           | 114-1678           | 4           | O-Ring                   | 32          | 104-5329           | 1           | Pin-Jackshaft        |
| 5           | 104-2189           | 1           | Plug-Thread, Straight    | 33          | 104-2169           | 1           | Ring-Retaining       |
| 6           | 109-3321           | 1           | Element-Oil Filter, HYD  | 34          | 114-1694           | 1           | Gear-54T             |
| 7           | 106-8676           | 1           | Seal-Lip                 | 35          | 120-7975           | 1           | Spacer               |
| 8           | 106-8677           | 1           | Ring-Retaining, External | 36          | 126-0789           | 1           | Bearing-Ball         |
| 9           | 114-1685           | 1           | Rod-Bypass               | 37          | 120-7976           | 1           | Bearing-Ball         |
| 10          | 106-8679           | 1           | Ring-Retaining, Internal | 38          | 104-2144           | 1           | Seal                 |
| 11          | 107-2490           | 1           | Arm-Bypass               | 39          | 109-5939           | 1           | Hub Kit              |
| 12          | 106-8681           | 1           | Ring-Retaining, External | 40          | 114-1697           | 1           | Pawl-Brake           |
| 13          | 104-5304           | 1           | Swashplate-Trunnion      | 41          | 114-1698           | 1           | Shaft-Brake, Inboard |
| 14          | 104-5313           | 1           | Seal-Lip                 | 42          | 125-0021           | 1           | Handle-Brake         |
| 15          | 104-2116           | 1           | Stud                     | 43          | 131-0906           | 1           | Ring-Retaining, EXT  |
| 16          | 112-9853           | 1           | Puck-Friction            | 44          | 104-2120           | 3           | Screw                |
| 17          | 104-5308           | 1           | Spacer                   | 45          | 120-7979           | 1           | Guard-Filter, LH     |
| 18          | 104-5310           | 1           | Seal-Lip                 | 46          | 109-3278           | 1           | Adapter-Straight     |
| 19          | 104-5309           | 1           | Ring-Retaining           | 46:1        | 237-42             | 1           | O-Ring               |
| 20          | 112-4154           | 1           | Bearing-Thrust           | 47          | 115-5057           | 1           | Cover-Nut, Axle      |
| 21          | 114-1689           | 1           | Motor Cylinder Block Kit | 48          | 121-5745           | 1           | Spacer               |
| 22          | 94-6922            | 1           | Bearing-Thrust           | 49          | 109-3537           | 1           | Seal Kit             |
| 23          | 110-8561           | 1           | Pump Block ASM           | 50          | 125-0036           | 1           | Center Section Kit   |
| 24          | 104-5339           | 1           | Washer-Flat              | 51          | 121-5746           | 1           | Fan Pulley Kit       |
| 25          | 104-5340           | 1           | Ring-Retaining           | 52          | 114-8468           | 1           | Input Shaft Kit      |
| 26          | 121-5749           | 1           | Gear-16T                 | 53          | 117-5362           | 1           | Control Arm Kit      |
| 27          | 114-1691           | 1           | Shaft-Motor              | 54          | 114-8470           | 1           | Axle Shaft Kit       |
| 28          | 104-5360           | 1           | Washer                   |             |                    |             |                      |


This exploded perspective view illustrates the assembly of a vehicle suspension system. The components are numbered as follows:

- 1**: Lower control arm
- 2**: Lower control arm bracket
- 3**: Lower control arm bushing
- 4**: Lower control arm bushing
- 5**: Lower control arm pin
- 6**: Lower control arm pin
- 7**: Lower control arm pin
- 8**: Lower control arm pin
- 9**: Lower control arm pin
- 10**: Lower control arm pin
- 11**: Lower control arm pin
- 12**: Lower control arm pin
- 13**: Lower control arm pin

## Brake Assembly (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>   | <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i> |
|-------------|--------------------|-------------|----------------------|-------------|--------------------|-------------|--------------------|
| 1           | 130-0790-03        | 1           | Bracket-Mount, Brake | 8           | 119-8812           | 1           | Rod-Brake, LH      |
| 2           | 132-0935           | 1           | Brake Box ASM        | 9           | 3296-42            | 2           | Nut-Lock, NI       |
| 3           | 132-6949           | 1           | Cover-Connector      | 10          | 119-8952           | 6           | Washer             |
| 4           | 32144-4            | 2           | Screw-HWH            | 11          | 121-5654           | 4           | Spring-Compression |
| 5           | 32144-36           | 4           | Screw-PPH            | 12          | 119-8857           | 2           | Mount-Pivot        |
| 6           | 94-4496            | 2           | Screw-PPH            | 13          | 3290-307           | 4           | Pin-Cotter         |
| 7           | 119-8811           | 1           | Rod-Brake, RH        |             |                    |             |                    |

# Tire Assembly




## Tire Assembly (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>       |
|-------------|--------------------|-------------|--------------------------|
| 1           | 131-3673           | 2           | 2 Ply Tire And Wheel ASM |
| 1:2         | 131-3680           | 1           | Tire-2 Ply               |

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i> |
|-------------|--------------------|-------------|--------------------|
| 1:3         | 232-27             | 1           | Stem-Valve         |
| 1:4         | 93-3893            | 1           | Tube-Inner ●       |

● Not illustrated


Seat Assembly



## Seat Assembly (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>  | <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>  |
|-------------|--------------------|-------------|---------------------|-------------|--------------------|-------------|---------------------|
| 1           | 92-7054            | 3           | Spring-Compression  | 12          | 132-9353           | 2           | Latch-Seat          |
| 2           | 3234-29            | 3           | Screw-HHF           | 14          | 107069             | 1           | Clip                |
| 3           | 104-8300           | 7           | Nut-HF, NI          | 15          | 131-1038           | 1           | Bracket-Stop, Seat  |
| 4           | 136-5571-03        | 1           | Pan-Seat, Deluxe    | 16          | 99-6810            | 1           | Screw-HHF           |
| 5           | 115-4966           | 1           | Rod-Stop            | 17          | 131-4008-03        | 1           | Bracket-Latch, Seat |
| 6           | 1-413088           | 2           | Bushing-Lever, Lift | 18          | 32144-70           | 2           | Screw-Thd Roll, HWH |
| 7           | 3290-250           | 2           | Pin-Cotter          | 19          | 3274-55            | 2           | Screw-HSBH          |
| 8           | 131-4147           | 1           | Seat ASM            | 20          | 19-1470            | 2           | Screw-Shoulder      |

# Seat Assembly No. 131-4147




## Seat Assembly No. 131-4147 (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>   |
|-------------|--------------------|-------------|----------------------|
| 2           | 131-4149           | 1           | Cushion-Seat, Back   |
| 3           | 131-4151           | 1           | Cushion-Seat, Bottom |
| 4           | 131-4153           | 1           | Track ASM            |
| 5           | 131-4154           | 1           | Bushing ASM          |

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i> |
|-------------|--------------------|-------------|--------------------|
| 6           | 131-4155           | 1           | Armrest Kit        |
| 7           | 131-4156           | 1           | Shell              |
| 8           | 82-2190            | 1           | Switch-Bail        |
| 9           | 110-4163           | 2           | Cushion-Rest, Arm  |


# Motion Control Assembly



## Motion Control Assembly (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i> | <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>     |
|-------------|--------------------|-------------|--------------------|-------------|--------------------|-------------|------------------------|
| 1           | 136-4155-03        | 1           | Control Box ASM    | 18          | 110-6810           | 2           | Stud-Damper            |
| 2           | 119-3470           | 2           | Actuator Arm ASM   | 19          | 3296-42            | 4           | Nut-Lock, NI           |
| 2:2         | 256-156            | 2           | Bushing-Flange     | 20          | 3256-24            | 4           | Washer-Flat            |
| 3           | 120-2273           | 2           | Washer-Nylon       | 21          | 323-6              | 4           | Screw-HH               |
| 4           | 115-5098-05        | 2           | Lever-Control      | 22          | 117-5385           | 2           | Retainer               |
| 5           | 121-0730           | 1           | Handle-Control, LH | 23          | 32144-70           | 4           | Screw-Thd Roll, HWH    |
| 5:1         | 121-0726           | 1           | Grip               | 24          | 32144-1            | 4           | Screw-Taptite          |
| 6           | 121-0731           | 1           | Handle-Control, RH | 25          | 117-5388           | 2           | Rod-Hydro              |
| 6:1         | 121-0726           | 1           | Grip               | 26          | 119-8842           | 2           | Mount-Rod, Hydro       |
| 7           | 131-1062           | 1           | Speed Control ASM  | 27          | 3256-23            | 2           | Washer-Plain           |
| 8           | 115-5099           | 2           | Bolt-Pivot         | 28          | 1-603807           | 2           | Spring-Return, Neutral |
| 9           | 104-8301           | 4           | Nut-HF, NI         | 29          | 119-3303           | 2           | Pin-Rod, Hydro         |
| 10          | 117-1240           | 2           | Washer             | 30          | 93-6079            | 2           | Spacer-Nylon           |
| 11          | 119-8925           | 2           | Washer-Belleville  | 31          | 321-3              | 2           | Screw-HH               |
| 12          | 117-1198           | 2           | Bolt-Pivot         | 32          | 3296-56            | 2           | Nut-Lock, NI           |
| 13          | 3234-47            | 6           | Screw-HHF          | 33          | 119-8935           | 1           | Knob-RH                |
| 14          | 104-8300           | 10          | Nut-HF, NI         | 34          | 119-8936           | 1           | Knob-LH                |
| 15          | 119-8952           | 2           | Washer             | 35          | 94-4496            | 1           | Screw-PPH              |
| 16          | 120-7950           | 2           | Screw-Shoulder     | 36          | 119-8876           | 2           | Spring-Return          |
| 17          | 131-0964           | 2           | Damper             |             |                    |             |                        |

# Engine and Muffler Assembly




## Engine and Muffler Assembly (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>                           | <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i> |
|-------------|--------------------|-------------|----------------------------------------------|-------------|--------------------|-------------|--------------------|
| 1           |                    | 1           | Engine-Kohler 24HP 7000 Series Autochoke ● ■ | 5           | 32144-109          | 4           | Screw-Taptite      |
| 1:1         | 110-6697           | 2           | Gasket-Exhaust                               | 6           | 3256-24            | 3           | Washer-Flat        |
| 1:3         | 281-2              | 1           | Plug-Pipe, SQH                               | 7           | 117-1261           | 1           | Hose-Drain, Oil    |
| 2           | 130-0676           | 1           | Muffler                                      | 8           | 614249             | 1           | Tie-Cable          |
| 3           | 131-1071-03        | 1           | Shield-Heat                                  | 9           | 3274-10            | 4           | Screw-HSH          |
| 4           | 46-8560            | 2           | Screw-HHFTF                                  | 10          | 3253-4             | 4           | Washer-Lock        |

● Not serviced separately

■ Obtain parts from [www.kohlerplus.com](http://www.kohlerplus.com)


# Body Styling and Fuel Assembly



## Body Styling and Fuel Assembly (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>      | <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>        |
|-------------|--------------------|-------------|-------------------------|-------------|--------------------|-------------|---------------------------|
| 1           | 119-3338           | 1           | Pod-RH                  | 11          | 120-7950           | 6           | Screw-Shoulder            |
| 2           | 119-3337           | 1           | Pod-LH                  | 12          | 609830             | 2           | Spring                    |
| 3           | 107069             | 3           | Clip                    | 13          | 131-1006           | 1           | Cable-Throttle            |
| 4           | 119-3377-03        | 1           | Plate-Control           | 17          | 120-5461           | 1           | Cap-Fuel, Ratcheting      |
| 6           | 131-4162           | 1           | Decal-Panel, Control    | 19          | 119-8814           | 1           | Decal-Lever, Control (LH) |
| 7           | 119-3395-03        | 1           | Support-Tank, Front     | 20          | 119-8815           | 1           | Decal-Lever, Control (RH) |
| 8           | 32144-70           | 2           | Screw-Thd Roll, HWH     | 25          | 109-0273           | 1           | Hose-Fuel                 |
| 9           | 119-3324           | 1           | Fuel Tank ASM           | 26          | 108-9698           | 1           | Hose-Fuel                 |
| 9:1         | 121-0793           | 1           | Connector-Elbow, 90 DEG | 27          | 2412-98            | 3           | Clamp-Hose                |
| 9:2         | 46-6560            | 2           | Bushing                 | 28          | 614249             | 3           | Tie-Cable                 |
| 9:4         | 117-7400           | 1           | Fitting-Plastic         | 29          | 117-5399           | 1           | Adaptor-Orifice           |
| 10          | 3258-166           | 3           | Screw-PRH               | 30          | 110-1876           | 1           | Hose-Fuel                 |

## Battery and Electrical Assembly




## Battery and Electrical Assembly (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i> |
|-------------|--------------------|-------------|--------------------|
| 1           | 136-7482           | 1           | Harness-Wire       |
| 1:1:1       | 109103             | 1           | Fuse-Blade, 30 Amp |
| 1:1:2       | 109102             | 1           | Fuse-Blade, 25 Amp |
| 2           | 105-1692           | 1           | Battery            |
| 3           | 117-1197           | 1           | Solenoid           |
| 4           | 117-2221           | 1           | Switch-Ignition    |
| 5           | 63-8360            | 1           | Key-Ignition       |
| 6           | 103-5221           | 1           | Switch-PTO         |
| 7           | 110-6765           | 2           | Switch             |
| 9           | 32144-4            | 2           | Screw-HWH          |
| 10          | 3256-22            | 2           | Washer-Flat        |

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>      |
|-------------|--------------------|-------------|-------------------------|
| 11          | 321-3              | 1           | Screw-HH                |
| 12          | 3229-1             | 1           | Bolt-CARR               |
| 13          | 32128-33           | 1           | Nut-HF                  |
| 14          | 32103-22           | 1           | Nut-Wing                |
| 15          | 104-2466           | 1           | Holddown-Battery        |
| 16          | 3220-2             | 2           | Nut-Jam                 |
| 17          | 119-8897           | 1           | Cable-Battery, Red      |
| 18          | 121-0711           | 1           | Cable-Battery, Positive |
| 19          | 121-5726           | 1           | Cable-Battery, Black    |
| 20          | 120-2244           | 1           | Hourmeter               |
| 25          | 32128-33           | 1           | Nut-HF ●                |

● Not illustrated


# 50 Inch Deck Assembly



## 50 Inch Deck Assembly (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>  | <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>         |
|-------------|--------------------|-------------|---------------------|-------------|--------------------|-------------|----------------------------|
| 1           | 131-3614           | 1           | Deck And Decal ASM  | 30:3        | 38-7820            | 2           | Bearing-Ball               |
| 6           | 131-4138           | 1           | Bracket-Hanger, RH  | 31          | 32144-41           | 12          | Screw-Taptite              |
| 7           | 131-3935           | 1           | Bracket-Hanger, LH  | 32          | 117-7268           | 3           | Shaft-Spindle              |
| 8           | 3231-2             | 2           | Bolt-CARR           | 33          | 115-5059-03        | 3           | Blade-Hi Lift              |
| 9           | 120-7024           | 1           | Screw-Shoulder, HHF | 34          | 3290-465           | 3           | Washer-Belleville          |
| 10          | 3230-22            | 5           | Screw-CARR          | 35          | 26-0671            | 3           | Screw-HH                   |
| 11          | 110-0618           | 1           | Pin-Clevis          | 36          | 125-5575           | 3           | Pulley                     |
| 12          | 131-0955           | 1           | Rod-Level, Deck     | 37          | 3219-6             | 3           | Nut-Hex                    |
| 13          | 104-8301           | 7           | Nut-HF, NI          | 38          | 110-9981           | 1           | Washer-Plain               |
| 14          | 104-8300           | 8           | Nut-HF, NI          | 39          | 120-2229           | 2           | Washer                     |
| 15          | 3256-23            | 1           | Washer-Plain        | 40          | 114-0463           | 2           | Washer-Friction, Composite |
| 16          | 1-806003           | 1           | Pin-Cotter          | 41          | 115-4986           | 1           | Spacer                     |
| 17          | 108-7890           | 2           | Cover-Belt          | 42          | 114-8540           | 1           | Arm-Idler                  |
| 19          | 32144-4            | 4           | Screw-HWH           | 43          | 106-2175           | 3           | Pulley-Idler, Flat         |
| 20          | 95-2747            | 2           | Fitting-Washout     | 44          | 3256-24            | 2           | Washer-Flat                |
| 21          | 46-6290            | 2           | O-Ring              | 45          | 323-9              | 4           | Screw-HH                   |
| 23          | 95-3270            | 1           | Connector-Hose      | 46          | 119-8820           | 1           | V-Belt                     |
| 24          | 131-3962           | 1           | Cover ASM W/Decal   | 47          | 1-603414           | 1           | Spring-Extension           |
| 24:2        | 93-7009            | 1           | Decal-Danger        | 48          | 112-3973           | 1           | Hook-Return, Spring        |
| 25          | 120-7951-03        | 1           | Baffle-Cutoff       | 49          | 121-0739           | 1           | Deflector-Discharge        |
| 27          | 1-603299           | 3           | Roller-Scalp, Anti  | 50          | 121-2983           | 1           | Spring-Torsion             |
| 28          | 109-8854           | 1           | Pin-Chute           | 52          | 112-3977           | 3           | Bolt-Shoulder              |
| 30          | 121-0751           | 3           | Spindle ASM         | 56          | 121-0792           | 1           | Decal-Deck                 |
| 30:1        | 117-7267           | 1           | Spindle             | 57          | 32144-1            | 6           | Screw-Taptite              |
| 30:2        | 120-7935           | 2           | Spacer              | 68          | 322-2              | 2           | Screw-HH                   |

# 50 Inch Deck and Decal Assembly No. 131-3614




## 50 Inch Deck and Decal Assembly No. 131-3614 (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>  |
|-------------|--------------------|-------------|---------------------|
| 3           | 93-7009            | 1           | Decal-Danger        |
| 4           | 132-0872           | 2           | Decal-Danger, Deck  |
| 5           | 99-3943            | 1           | Decal-Routing, Belt |

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i> |
|-------------|--------------------|-------------|--------------------|
| 7           | 112-9840           | 1           | Decal-Scalp, Anti  |
| 8           | 322-2              | 2           | Screw-HH           |
| 9           | 104-8300           | 2           | Nut-HF, NI         |


# Decal and Floor Mat Assembly



## Decal and Floor Mat Assembly (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i> |
|-------------|--------------------|-------------|--------------------|
| 1           | 131-3655           | 1           | Decal-Timecutter   |
| 3           | 132-6895           | 1           | Mat-Floor          |
| 4           | 117-2382           | 4           | Plug-Plastic       |


# Frame Decal Assembly



## Frame Decal Assembly (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i> | <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>             |
|-------------|--------------------|-------------|--------------------|-------------|--------------------|-------------|--------------------------------|
| 1           | 106-8717           | 1           | Decal-Service, CE  | 3           | 131-3947           | 1           | Decal-Control, Speed           |
| 2           | 119-8870           | 1           | Decal-HOC          | 4           | 121-5684           | 1           | Decal-Location, Service Dealer |

# Clutch Assembly



## Clutch Assembly (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i> | <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i> |
|-------------|--------------------|-------------|--------------------|-------------|--------------------|-------------|--------------------|
| 1           | 119-8885           | 1           | Stop-Clutch        | 5           | 104-8301           | 1           | Nut-HF, NI         |
| 2           | 130-6854           | 1           | Pulley-Engine      | 6           | 120-2217           | 1           | Isolator-Clutch    |
| 3           | 127-3410           | 1           | Clutch-PTO         | 7           | 3212-19            | 1           | Screw-HH           |
| 4           | 3234-42            | 1           | Screw-HHF          | 8           | 112843             | 1           | Washer             |

# Attachments and Accessories

## For 74770 TimeCutter MX 5050 Riding Mower

| Product Name                                   | Model/Part |
|------------------------------------------------|------------|
| All Season Synthetic Oil.....                  | 117-0066   |
| Bagging Enhancement Kit .....                  | 121-5692   |
| Striping Kit .....                             | 121-5706   |
| Jack Mount Kit .....                           | 126-5251   |
| Jack Kit .....                                 | 127-6666   |
| Fuel Stabilizer .05 oz .....                   | 130-2393   |
| 4-Cycle Fuel, Snow And Lawn 32oz Can .....     | 131-3823   |
| Attachment Mount Kit .....                     | 131-3966   |
| Toro Premium Fuel Treatment 12 Oz Bottle ..... | 131-6572   |
| Weight Kit .....                               | 131-7658   |
| Seat ASM .....                                 | 136-5598   |
| 10w30 4-cycle Engine Oil (32oz Bottle) .....   | 38280      |
| Toro 4-cycle Sae 30 Oil (32oz Bottle).....     | 38903      |
| Storage Cover .....                            | 490-7516   |
| Blade Kit .....                                | 79016P     |
| 50in Recycler Kit.....                         | 79024      |
| Assist Handle and Step Kit .....               | 79339      |
| 50in Bagger .....                              | 79395      |

**Notes:**



**Count on it.**