



Count on it.

Parts Catalog

Base 72in Mower

Groundsmaster® 3320/3280-D Traction Unit

Model No. 30404—Serial No. 312000001 and Up



Ordering Replacement Parts

To order replacement parts, please supply the part number, the quantity, and the description of each part desired.

Understanding Reference Numbers

Each identified part in an illustration has a reference number. The reference number for a part also appears in the parts list, along with other information about the part.

This catalog uses two special reference number formats, one to indicate parts in a service assembly and another to indicate the quantity of a given part in an illustration.

Service Assembly Reference Numbers

Parts in service assemblies have reference numbers in the form a:b. The a represents the reference number of the entire service assembly and the b represents a sequential number unique to each part within the service assembly.

For example, a wheel assembly might be identified by reference number 6, the tire by 6:1, the valve by 6:2, and the wheel by 6:3. When you order the assembly identified by reference number 6, you receive all parts identified by reference numbers 6:1, 6:2, and 6:3. However, you may also order any part individually. Reference numbers of this type appear in illustration and in parts lists.

Reference Numbers Indicating Quantity

In an illustration, if a reference number indicates more than one part, the reference number has the form nX y. The n represents the quantity of the part, the X is the multiplication symbol, and the y represents the reference number.

For example, in an illustration, the reference number 2X 37 means that two of the parts identified by reference number 37 are indicated.

Contents

Roller, Belt and Pulley Assembly 4

Low Driven Spindle Assembly No. 119-4776..... 5

Deck Assembly No. 120-6647 6

Caster Arm Assembly 7

Cover and Gearbox Assembly 8


Gear Box Assembly No. 108-1370 9

Lift Arm and Rear Height-of-Cut Assembly..... 10

Left Hand Lift Arm Assembly No. 117-0806 11

Right Hand Lift Arm Assembly No. 117-0800..... 12


Attachments and Accessories 13



Roller, Belt and Pulley Assembly


Ref.	Part Number	Qty.	Description
1	112-1479	2	Skid-Bumper, Deck
2	104-8301	5	Nut-HF, NI
3	68-6710	1	Roller
4	3234-42	1	Screw-HHF
5	68-6840	1	Shaft-Roller
6	119-4776	3	Low-Driven Spindle ASM
8	104-8301	24	Nut-HF, NI
10	3231-33	4	Screw-CARR
11	3269-24	8	Rivet
12	9136144	2	Screw-HWHTF
13	120-6647	1	Deck ASM
14	108-1908	1	Spacer-Idler
15	3233-34	1	Screw-CARR
16	107-4738	1	Belt-HH
17	107-4725	1	Pulley

Ref.	Part Number	Qty.	Description
18	01-268-0160	2	Pulley-Idler
19	100-3102	1	Washer-Flat
20	3296-23	1	Nut-Lock, NI
21	108-1926	1	Washer
22	108-1921	1	Spring-Torsion
23	108-1930	1	Idler Arm ASM
23:2	93-4510	2	Bushing-Caster
25	32120-84	1	Ring-Snap, External
26	3296-45	1	Nut-Lock, NI
27	108-1924	1	Spacer-Idler
28	108-1993	1	Screw-HSBH
29	302-5	1	Fitting-Grease
30	108-1914	2	Pad-Bumper
33	120-6603-03	3	Ring-Doubler




Low Driven Spindle Assembly No. 119-4776

Ref.	Part Number	Qty.	Description
1	3296-60	1	Nut-Lock, NI
2	104-3546	1	Pulley-Driven, Low
4	119-4775	1	Spindle Housing ASM
4:2	104-3549	1	Bearing Spacer Set
4:3	110-8297	1	Bearing ASM
4:4	253-154	2	Seal-Oil
4:5	302-60	1	Fitting-Grease
5	69-6950	1	Spacer-Shaft, Spindle
6	104-3554	1	Shaft-Spindle
7	104-8322	1	Washer-Hardened
8	106-7159	1	O-Ring



Deck Assembly No. 120-6647


Ref.	Part Number	Qty.	Description
2	120-6604	2	Decal-Danger
3	117-4979	4	Decal-Warning, Shields
4	100-5622	2	Decal-HOC
5	32148-9	7	Insert-Nut
6	93-7818	2	Decal-Torque, Blade Bolt
7	108-1986	2	Decal-HOC, Rear
8	57-0280	1	Decal
9	108-1988	1	Decal-Routing, Belt
10	115-4505	1	Decal-Warning
11	120-6603-03	3	Ring-Doubler



Caster Arm Assembly

Ref.	Part Number	Qty.	Description
1	92-9727	2	HOC Cap ASM
1:1	92-5581	1	Ring-Retaining
1:2	92-5583	1	Washer-Cap
1:3	92-9726	1	Spring-Compression
1:4	92-8861	1	Cap-HOC
2	69-1510	10	Spacer
3	69-6860	4	Washer-Thrust
4	121-6447	1	LH Castor Arm ASM
4:2	69-6470	2	Bushing-Castor
4:3	302-5	1	Fitting-Grease
5	121-6444	1	Castor Arm ASM-RH
5:2	69-6470	2	Bushing-Castor
5:3	302-5	1	Fitting-Grease
6	104-0762-01	2	Fork-Castor


Ref.	Part Number	Qty.	Description
7	3296-53	2	Nut-Lock, NI
8	93-9938	2	Wheel ASM
8:1	93-9939	1	Tire
8:2	68-8950	1	Tube-Inner (W/Valve)
8:3	93-4241	1	Spacer-Bearing, Inner
8:4	120-3366	2	Bearing
8:6	32128-16	4	Nut-HHF
8:7	93-4242	1	Plate
8:8	93-4239	1	Rim-Wheel, Half
8:9	93-5980	1	Hub
8:10	95-2741	1	Rim-Wheel, Half
9	327-24	2	Screw-HH
10	3234-41	10	Screw-HHF
11	104-8301	10	Nut-HF, NI



Cover and Gearbox Assembly


Ref.	Part Number	Qty.	Description
1	104-8301	4	Nut-HF, NI
2	63-8410	4	Washer
3	108-1928-03	2	Bracket-Gearbox
4	63-9750	4	Mount
5	3231-26	4	Screw-CARR
6	108-1341-03	1	Cover-Deck, RH Rear (Outer)
7	119-4808-03	1	Cover-Deck, RH Front (Outer)
8	119-4807-03	1	Cover-Deck, RH (Inner)
9	119-4806-03	1	Cover-Deck, LH (Inner)
10	119-4805-03	1	Cover-Deck, LH (Outer)
11	3253-21	4	Washer-Lock
12	3257-5	1	Key-Woodruff

Ref.	Part Number	Qty.	Description
13	108-1370	1	Gearbox Replacement Kit
14	3296-23	2	Nut-Lock, NI
15	29-4820	2	Roller
16	325-18	2	Screw-HH
17	3234-42	3	Screw-HHF
19	117-6989	4	Fractional Turn Oval Head Stud ASM
21	23-1640	1	Bushing-Taperlock
21:1	3247-4	2	Screw-Set
23	323-4	4	Screw-HH
24	93-6697	1	Decal-Lube
25	1-804254	13	Nut-Lock, HH
26	106-6778	13	Bushing-Latch, Swell
27	106-6777	13	Handle-Latch, Swell



Gear Box Assembly No. 108-1370


<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
1	107-2932	1	Cap-Oil
2	107-2933	1	Plug
3	117-9247	2	Seal
4	107-2935	1	Cap-Oil
5	107-2936	1	Plug-Filler, Dipstick



Lift Arm and Rear Height-of-Cut Assembly


Ref.	Part Number	Qty.	Description
1	110-0641	2	Collar-HOC
2	107-7915	4	Washer-Thrust
3	3290-256	2	Pin-Hair
4	107-7904	2	Pin-Clevis
5	325-12	2	Screw-HH
6	3296-45	2	Nut-Lock, NI
7	105-2808	2	End-Rod
8	3220-5	2	Nut-Jam
9	107-7284	2	Tube-HOC
10	117-0806	1	LH Lift Arm ASM

Ref.	Part Number	Qty.	Description
11	117-0800	1	RH Lift Arm ASM
12	107-3457	2	Pin-Clevis
13	98-2330	2	Pivot Pin ASM
13:2	32121-67	1	Pin-Spring
13:3	32121-61	1	Pin-Roll
14	3272-24	2	Pin-Cotter
15	3213-20	2	Screw-HH
16	3290-467	2	Pin-Hair
17	3256-6	2	Washer-Flat



Left Hand Lift Arm Assembly No. 117-0806

Ref.	Part Number	Qty.	Description
2	256-268	2	Bushing
3	302-5	2	Fitting-Grease
4	105-7441	1	Bearing-Spherical
5	32151-34	1	Ring-Retaining
6	119-2200	1	Pad-Rubber, Rear HOC
7	119-2230	1	Pad-Plastic, Rear HOC
8	110-0606	3	Rivet-Blind
9	3269-26	3	Washer-Plain



Right Hand Lift Arm Assembly No. 117-0800

Ref.	Part Number	Qty.	Description
2	302-5	2	Fitting-Grease
3	256-268	2	Bushing
4	105-7441	1	Bearing-Spherical
5	32151-34	1	Ring-Retaining
6	119-2200	1	Pad-Rubber, Rear HOC
7	119-2230	1	Pad-Plastic, Rear HOC
8	110-0606	3	Rivet-Blind
9	3269-26	3	Washer-Plain

Attachments and Accessories

For 30404 Base 72in Mower Groundsmaster 3320/3280-D Traction Unit

Product Name	Model/Part
Bahiagrass Baffle Kit	105-7269
Blade-Rotary.....	108-1958
Castor Wheel Kit.....	110-4767
Guardian Blade and Belt Kit.....	110-4769
Skid Replacement Kit	112-9570
Rear Discharge Completion Kit.....	30303
72in Guardian Recycler Completion Kit	30304
72in Guardian Fine Recycler Completion Kit	30346
8in Foam Filled Wheel ASM	93-5974

Notes:

Notes:



Count on it.