



Form No. 380-0053 Rev B

Count on it.

Parts Catalog

Sentinel V2 Series Controllers

Model No. SENTINEL V2 SERIES



Ordering Replacement Parts

To order replacement parts, please supply the part number, the quantity, and the description of each part desired.

Understanding Reference Numbers

Each identified part in an illustration has a reference number. The reference number for a part also appears in the parts list, along with other information about the part.

This catalog uses two special reference number formats, one to indicate parts in a service assembly and another to indicate the quantity of a given part in an illustration.

Service Assembly Reference Numbers

Parts in service assemblies have reference numbers in the form a:b. The a represents the reference number of the entire service assembly and the b represents a sequential number unique to each part within the service assembly.

For example, a wheel assembly might be identified by reference number 6, the tire by 6:1, the valve by 6:2, and the wheel by 6:3. When you order the assembly identified by reference number 6, you receive all parts identified by reference numbers 6:1, 6:2, and 6:3. However, you may also order any part individually. Reference numbers of this type appear in illustration and in parts lists.

Reference Numbers Indicating Quantity

In an illustration, if a reference number indicates more than one part, the reference number has the form nX y. The n represents the quantity of the part, the X is the multiplication symbol, and the y represents the reference number.

For example, in an illustration, the reference number 2X 37 means that two of the parts identified by reference number 37 are indicated.

Contents

Sentinel Central Control System 4

Sentinel Satellite - Wall Mount 6

Sentinel Satellite - Pedestal Mount 8


Sentinel Remote Transceiver 10

Sentinel Map To Assy - Sm Metal Wall Mt 12

Sentinel Map To Assy - Plastic Pedestal Cabinet 14

Sentinel Two-Wire Decoder - Wall Mount 16

Sentinel Central Control System



Sentinel Central Control System (continued)


<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>	<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
1	102-2376	1	Central Interface Module Assembly ▲	9		1	Power Supply, Telephone Modem ■
2	102-2375	1	Cpu Cable Assembly	10		1	Computer Cable Assembly, Telephone Modem ■
3	102-2377	1	Power Supply, Central Interface Module, 115/16 V A.C., 1 Amp	11		1	Computer Cable Assembly, Adapter ■
4	102-2379	1	Base Antenna Assembly (Includes Items 5 & 6 And Wall-Mount Brackets)	12		1	Cable Assembly, Telephone ■
5	102-4908	1	Grounding Assembly, Antenna (Includes Item 6 And Insulation Kit)	13	102-3407	1	Fuse, 1 Amp, Slow Blow (10-Pack)
6	363-1553	1	Lug, Grounding		102-4929		Tripod Stand, Antenna ●
7	102-2378	1	Antenna Cable, 50' (15 M)		102-2447	1	Programming Kit, Radio Frequency ▲ ●
8	102-2384	1	Phone Modem Assembly (Includes Items 9-11)				

● Not illustrated

▲ Order Through Finished Goods Distribution System - Minneapolis

■ Not serviced separately

Sentinel Satellite - Wall Mount




Sentinel Satellite - Wall Mount (continued)

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>	<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
1	102-2370	1	Enclosure, Tall Wall Mount W/O Backplate (Includes Items 1-6)	14	102-4927	1	Output Cable, 14", 24-48 Station ■
2	102-4917	1	Door Assembly W/Lock Mechanism (Includes Items 3 & 4)	14	102-4928	1	Output Cable, 18", 36-48 Station ■
3	102-4919	2	Lock Assembly, Door (Includes Lock, Keys, And Rod Mechanism)	15	102-4913	1	Control Module Assembly, Satellite, 12 Station ■
4	363-2789	1	Key, Ch-71	15	102-2373	1	Control Module Assembly, Satellite, 24 Station ■
5	102-4912	1	Antenna Assembly, Pancake Type	15	102-4914	1	Control Module Assembly, Satellite, 36 Station ■
6	102-4931	2	Filter, Enclosure Vent Louver	15	102-2372	1	Control Module Assembly, Satellite, 48 Station ■
7	102-4910	1	Back Plate Assembly (Includes Items 8-11)	16	102-4956	1	Control Module Assembly, Mapto, 12 Station ■
8		1	Mounting Bracket, Junction Box ●	16	102-4957	1	Control Module Assembly, Mapto, 24 Station ■
9	363-1553	1	Lug, Grounding	16	102-4958	1	Control Module Assembly, Mapto, 36 Station ■
10	363-4635	1	Toggle Switch W/ Receptacle	16	102-4959	1	Control Module Assembly, Mapto, 48 Station ■
11	102-2369	1	Power Transformer, 115/24 V A.C., 50 Va	17	102-4955	1	Cable Assembly, Data Retrieval
12	102-4918	1	Mounting Bracket, Satellite Module	18		1	Terminal Strip ●
13	102-2368	1	Output Pc Board ■	19	102-3406	2	Fuse, 2 Amp , Slow-Blow (10-Pack)
14	102-4926	1	Output Cable, 6", 12-48 Station ■				

● Not serviced separately

■ Order Through Finished Goods Distribution System - Minneapolis

Sentinel Satellite - Pedestal Mount



Sentinel Satellite - Pedestal Mount (continued)

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>	<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
1	102-2371	1	Enclosure, Pedestal W/O Backplate (Includes Items 1-7)	14	102-4913	1	Control Module Assembly, Satellite, 12 Station ♦
2	102-4916	1	Door Assembly, Pedestal Enclosure W/Lock (Includes Items 3 & 4)	14	102-2373	1	Control Module Assembly, Satellite, 24 Station ♦
3	102-4930	2	Lock Assembly, Door W/Keys	14	102-4914	1	Control Module Assembly, Satellite, 36 Station ♦
4	363-2789	1	Key, Ch-71	14	102-2372	1	Control Module Assembly, Satellite, 48 Station ♦
5	102-4915	1	Top Assembly, Pedestal Enclosure W/Antenna (Includes Item 6)	15	102-4956	1	Control Module Assembly, Mapto, 12 Station ♦
6	102-4912	1	Antenna Assembly, Pancake Type	15	102-4957	1	Control Module Assembly, Mapto, 24 Station ♦
7	102-4931	2	Filter, Enclosure Vent Louver	15	102-4958	1	Control Module Assembly, Mapto, 36 Station ♦
8	102-4910	1	Back Plate Assembly (Includes Items 9-11 & 17)	15	102-4959	1	Control Module Assembly, Mapto, 48 Station ♦
9		1	Mounting Bracket, Junction Box ▲	16	102-3406	4	Fuse, 2 Amp , Slow-Blow (10-Pack)
10	363-4635	1	Junction Box W/Transformer	17	102-4955	1	Cable Assembly, Data Retrieval (Includes Item 16)
11	102-2369	1	Power Transformer, 115/24 V A.C., 50 Va	18		1	Terminal Strip ▲
12	102-2368	1	Output Pc Board ♦	19	363-1553	1	Lug, Grounding
13	102-4924	1	Output Cable, 24", 12-48 Station ♦		102-3406	2	Fuse, 2 Amp , Slow-Blow (10-Pack)(Used In Control Module Assembly) ■ ●
13	102-4925	1	Output Cable, 30", 24-48 Station ♦				


● SERVICE ITEMS

▲ Not serviced separately

♦ Order Through Finished Goods Distribution System - Minneapolis

■ Not illustrated

Sentinel Remote Transceiver




Sentinel Remote Transceiver (continued)

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>	<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
1	102-4920	1	Enclosure, Wall-Mount, Small, W/O Back Plate (Includes Items 2-4)	11	102-2386	1	Control Module Assembly, Remote Transceiver
2	102-4923	1	Door Assembly W/Lock (Includes Items 3 & 4)	12	102-2377	1	Power Supply, Central Interface Module, 115/16 V A.C., 1A
3	102-4930	1	Lock Assembly, Door W/Keys	13	102-2379	1	Base Antenna Assembly (Includes Item 14 And Wall Mount Brackets)
4	363-2789	1	Key, Ch-71 (Includes 2 Keys)	14	102-4908	1	Grounding Assembly, Antenna (Includes Item 15 And Insulation Kit)
5	102-4921	1	Back Plate, Small	15	363-1553	1	Lug, Grounding
6	102-4918	1	Mounting Bracket, Satellite Module	16	102-2378	1	Antenna Cable, 50' (15 M)
7	102-4922	1	Junction Box Assembly, Srta		102-3407	1	Fuse, 1 Amp, Slow Blow, 3Ag ●
8	102-2384	1	Phone Modem Assembly (Includes Items 9 & 10)		102-4929		Tripod Stand, Antenna ●
9	102-2385	1	Cable Assembly, Telephone Modem				
10		1	Power Supply, Telephone Modem ■				

● Not illustrated

■ Not serviced separately

Sentinel Map To Assy - Sm Metal Wall Mt




Sentinel Map To Assy - Sm Metal Wall Mt (continued)

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>	<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
1	102-3527	1	Cover, Outer Door (Includes Items 2 And 3)	10	102-2372	1	Control Module Assembly, Satellite, 48 Station ■
2	102-3529	1	Lock Assembly, Door With Keys	11	102-4956	1	Control Module Assembly, Mapto, 12 Station ■
3	360-0565	2	Keys, 2 With Ring	11	102-4957	1	Control Module Assembly, Mapto, 24 Station ■
4	102-3537	4	Rear Case (Includes Items 5 & 6)	11	102-4958	1	Control Module Assembly, Mapto, 36 Station ■
5	102-3535	1	Cover, Power Supply	11	102-4959	1	Control Module Assembly, Mapto, 48 Station ■
6		1	Terminal Block, 3-Position ●	12	102-4928	1	Cable Assembly, Output, 18"
7	102-3534	2	Transformer, 120 V A.C., 60 Hz, 50 Va	13		1	Cable Assembly, Data Retrieval ●
8		1	Cover, Inner Door ●	14	102-4912	1	Antenna Assembly, Pancake Type
9		1	Output Board ●	15	363-1553	2	Lug, Grounding
10	102-4913	1	Control Module Assembly, Satellite, 12 Station ■	16	102-3406	4	Fuse, 2 Amp , Slow-Blow (10-Pack)
10	102-2373	1	Control Module Assembly, Satellite, 24 Station ■				
10	102-4914	1	Control Module Assembly, Satellite, 36 Station ■				

● Not serviced separately

■ Order Through Finished Goods Distribution System - Minneapolis

Sentinel Map To Assy - Plastic Pedestal Cabinet



Sentinel Map To Assy - Plastic Pedestal Cabinet (continued)


<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>	<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
1	102-4913	1	Control Module Assembly, Satellite, 12 Station ▲	5	102-4955	1	Cable Assembly, Data Retrieval (Includes Item 7) ▲
1	102-2373	1	Control Module Assembly, Satellite, 24 Station ▲	6		1	Mounting Bracket Assy., Control Module ●
1	102-4914	1	Control Module Assembly, Satellite, 36 Station ▲	7		1	Back Plate Assembly ●
1	102-2372	1	Control Module Assembly, Satellite, 48 Station ▲	8		1	Terminal Strip ●
2	102-4956	1	Control Module Assembly, Mapto, 12 Station ▲	9	363-4635	1	Toggle Switch W/ Receptacle
2	102-4957	1	Control Module Assembly, Mapto, 24 Station ▲	10	102-2369	1	Power Transformer, 115/24 Vac, 60 Hz, 50 Va
2	102-4958	1	Control Module Assembly, Mapto, 36 Station ▲	11	102-2368	1	Output Pcb Assembly ■
2	102-4959	1	Control Module Assembly, Mapto, 48 Station ▲	12	363-1553	1	Lug, Grounding
3	102-3406	1	Fuse, 2 Amp , Slow-Blow (10-Pack)	13	102-4912	1	Antenna Assembly, Pancake Type
4	102-4924	2	Cable Assembly, Output, 24" ▲	14		1	Ground Plane, Antenna ●
4	102-4925	2	Cable Assembly, Output, 30" ▲	15		1	Satellite Plastic Pedestal & Components (See Satellite Plastic Pedestal Section For Details.) ●

● Not serviced separately

▲ Order Through Finished Goods Distribution System - Minneapolis

■ Quantity Varies With Model

Sentinel Two-Wire Decoder - Wall Mount



Sentinel Two-Wire Decoder - Wall Mount (continued)

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>	<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
1	102-5918SK	1	Timing Mechanism Assy., Gateway (Stand-Alone)	12	118-4717SK	1	Motherboard Assembly, Gateway, AC Decoder
1	118-4728SK	1	Timing Mechanism Assy., Gateway (Remote)	13	118-2749SK	1	Pcb Assy., Gateway Daughterboard
2	102-5049	1	Panel, Gateway, Decoder (Stand-Alone Models Only)	13	118-4718SK	1	Daughterboard Assembly, AC Decoder
2	118-3736	1	Panel, Gateway, Downloadable/Remote	14	363-8506	8	Fuse, 5 X 20Mm, Fast, 3.15A, 250V
3	118-0496	1	Power Supply Cover, Gateway, Decoder	15	102-6461	1	Fiber Optic Converter Kit, Gateway To Central Computer
4	102-5048SK	1	Door, Gateway Decoder	16	118-3101SK	1	Digital Radio Interface Board, Gateway
5	363-3785	1	Lock Assy. W/Keys	17	118-3442SK	1	Radio Module, Transceiver, Rv-M7-UC
6	118-0880	1	Cabinet, Gateway Decoder	18	89-9026	1	Standard Modem, Svc.
7	118-0540	1	Power Supply, AC/Dc, Gateway, Decoder	19	102-9176	1	Cable, 40-Pos (A To A)
8	118-0475	1	Power Supply Bracket, Upper	20	118-3329	1	Cable, Int Bd To Tm (B To B)
9	102-9741	1	Ttf, Filter Assembly	21	118-3330	1	Cable, Int Bd To Modem (C To C)
10	363-3361	1	Switch, Circuit Breaker, 1.5A	22	118-3103	1	Harness, Db9 (D To D)
11	102-4766SK	1	Wire Harness, Terminal Block To Switch	23	118-3104	1	Cable, Bnc To Bnc, Radio (E To E)
12	118-2750SK	1	Motherboard Assembly With Tricomm, Gateway Decoder				

Notes:

Notes:



Count on it.