Form No. 3422-566 Rev A

TORO®

Count on it.

Parts Catalog

Trans Pro 100

Tow-Behind Trailer

Model No. 04240—Serial No. 402950001 and Up

Register at www.Toro.com.
Original Instructions (EN)

CE

3422-566 A

Ordering Replacement Parts

To order replacement parts, please supply the part number, the quantity, and the description of each part desired.

Understanding Reference Numbers

Each identified part in an illustration has a reference number. The reference number for a part also appears in the parts list, along with other information about the part.

This catalog uses two special reference number formats, one to indicate parts in a service assembly and another to indicate the quantity of a given part in an illustration.

Service Assembly Reference Numbers

Parts in service assemblies have reference numbers in the form a:b. The a represents the reference number of the entire service assembly and the b represents a sequential number unique to each part within the service assembly.

For example, a wheel assembly might be identified by reference number 6, the tire by 6:1, the valve by 6:2, and the wheel by 6:3. When you order the assembly identified by reference number 6, you receive all parts identified by reference numbers 6:1,6:2, and 6:3. However, you may also order any part individually. Reference numbers of this type appear in illustration and in parts lists.

Reference Numbers Indicating Quantity

In an illustration, if a reference number indicates more than one part, the reference number has the form nX y. The n represents the quantity of the part, the X is the multiplication symbol, and the y represents the reference number.


For example, in an illustration, the reference number 2X 37 means that two of the parts identified by reference number 37 are indicated.

Contents

Trailer Main Tub Assembly 4
Tongue Assembly 5
Ramp Assembly 6
Hub and Wheel Assembly 7
Hub and Axle Assembly No. 117-8255 8
Attachments and Accessories 9


© 2018—The Toro® Company
8111 Lyndale Avenue South
Bloomington, MN 55420

Contact us at www.Toro.com.
Printed in the USA.
All Rights Reserved




Trailer Main Tub Assembly

Ref.	Part Number	Qty.	Description
1	104-0545	1	Bed ASM
1:1	98-8688	1	Decal-Caution
1:2	98-8687	1	Decal-Pressure, Air
2	32128-21	14	Nut-HF
3	98-8761-01	2	Guide-Wheel
4	3231-21	12	Screw-CARR
6	108-3156	4	Bracket-Rod
7	106-5354	4	Spring-Latch
10	98-8756	1	Spacer-Stop
11	323-38	1	Screw-HH
13	105-5392	12	Rivet-Drive
14	98-8776	1	Mat-Bed
15	98-8777	3	Spacer
16	136-8502	3	Rod-Trailer, Rear
17	136-8501	1	Rod-Trailer, Front (RH)
18	323-20	1	Screw-HH
19	98-8694	2	Decal
20	133-8061	1	Decal-Warning




Tongue Assembly

Ref.	*Part Number*	*Qty.*	*Description*
1	323-13	4	Screw-HH
2	98-8779-01	2	Hitch-Trailer
4	32128-21	4	Nut-HF
5	99-4543-01	1	Tongue-Trailer
6	98-8780	4	Spacer-Hitch




Ramp Assembly

Ref.	*Part Number*	*Qty.*	*Description*
1	104-0546	1	Ramp ASM
1:1	98-8676	1	Decal-Caution
2	98-8775	1	Mat-Ramp
3	105-5392	8	Rivet-Drive
4	9202634	1	Washer
5	3272-7	3	Pin-Cotter
6	98-8754	1	Latch-Ramp
7	98-8759	1	Hinge-Rod
8	66-1210	1	Decal



Hub and Wheel Assembly

Ref.	*Part Number*	*Qty.*	*Description*
1	117-8255	2	Hub And Axle ASM
2	98-8691	2	Wheel ASM
2:1	232-27	1	Stem-Valve
2:2	99-4506	1	Tire
2:3	99-4507	1	Rim
3	232-37	2	Tube
4	3231-22	8	Screw-CARR
5	32128-21	8	Nut-HF



Hub and Axle Assembly No. 117-8255

Ref.	*Part Number*	*Qty.*	*Description*
2	117-5115	2	Hub And Bearing ASM
2:1	117-8251	1	Hub ASM
2:1:2	114-3918	4	Stud-Wheel
2:1:3	254-72	2	Bearing-Cup, Tapered
2:2	254-94	2	Bearing-Cone, Tapered
2:3	112-1690	1	Seal-Oil
2:4	241-119	1	Cap-Dust
2:5	242-50	4	Nut-Lug
3	117-8259	1	Washer-Spindle
4	117-8260	1	Nut
5	93-0307	1	Nut-Lock, Retainer
6	3272-18	1	Pin-Cotter

Attachments and Accessories

For 04240 Trans Pro 100 Tow-Behind Trailer

Product Name	Model/Part
18in Rail Conversion Kit	110-7345
18in Transport Conversion Kit, Trans Pro 100	136-8567
Rail Ramp Kit TP100	138-5011

Notes:

Notes:



Count on it.