



Count on it.

Form No. 3388-316 Rev B

Parts Catalog

Cab Kit

Workman® HDX Utility Vehicle

Model No. 07392—Serial No. 315000001 and Up



Ordering Replacement Parts

To order replacement parts, please supply the part number, the quantity, and the description of each part desired.

Understanding Reference Numbers

Each identified part in an illustration has a reference number. The reference number for a part also appears in the parts list, along with other information about the part.

This catalog uses two special reference number formats, one to indicate parts in a service assembly and another to indicate the quantity of a given part in an illustration.

Service Assembly Reference Numbers

Parts in service assemblies have reference numbers in the form a:b. The a represents the reference number of the entire service assembly and the b represents a sequential number unique to each part within the service assembly.

For example, a wheel assembly might be identified by reference number 6, the tire by 6:1, the valve by 6:2, and the wheel by 6:3. When you order the assembly identified by reference number 6, you receive all parts identified by reference numbers 6:1, 6:2, and 6:3. However, you may also order any part individually. Reference numbers of this type appear in illustration and in parts lists.

Reference Numbers Indicating Quantity

In an illustration, if a reference number indicates more than one part, the reference number has the form nX y. The n represents the quantity of the part, the X is the multiplication symbol, and the y represents the reference number.

For example, in an illustration, the reference number 2X 37 means that two of the parts identified by reference number 37 are indicated.

Contents


Frame, Mount and Seal Assembly 4

Roof, Wiper Motor and Console Assembly 6

Window and Latch Assembly 8

Attachments and Accessories 10


Frame, Mount and Seal Assembly



Frame, Mount and Seal Assembly (continued)

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>	<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
2	125-9805-03	1	Mount-Cab, RH	22	130-5857-03	1	Plate-Seal, RH-Floor
3	125-9802-03	1	Mount-Cab, LH	23	130-5859-03	1	Cover-Panel, RH-Lower
4	110-5954	4	Mount-Center, Bonded	24	125-9840-01	1	Plate-Panel, RH (Seal)
5	3234-40	4	Screw-HF	25	125-9978-03	1	Plate-Panel, Rear
6	98-4799	2	Spacer	26	125-9842	2	Foam-Seal, Side
7	114-0019	4	Washer-Plain	27	125-9843	1	Foam-Seal, Rear (Center)
8	3296-25	4	Nut-Lock, NI	28	125-9844	2	Foam-Seal, Rear
9	125-9633-03	2	Bracket-Mount, Front	29	125-9622	22	Rivet-Blind
10	125-9640-03	1	Mount-LH	30	127-9945	1	Foam-Upholstrey, Center
11	3234-42	4	Screw-HHF	31	127-9946	2	Foam-Upholstrey, Side
12	104-7201	2	Nut-HF	32	130-0450	2	Foam-Interior, Side
13	86-1990	2	Washer-Thrust	33	130-0449	1	Foam-Interior, Rear
14	325-4	2	Screw-HH	34	127-9984	1	Trim-Seal, Bulb
15	99-5107	2	Nut-Lock	35	93-9850	1	Decal-ROPS, CE
16	104-8301	4	Nut-HF, NI	36	117-4955	2	Decal-Danger, ROPS (CE)
17	125-9641-03	1	Mount-RH	40	130-5964	2	Decal-Window, Pin
18	130-5856-03	1	Plate-Seal, LH-Floor	41	121-9777	2	Spring-Compression
19	32104-17	10	Screw-HWH	42	130-5583	1	Strap-Mount, Manual
20	130-5858-03	1	Cover-Panel, LH-Lower	43	3229-3	2	Screw-CARR
21	125-9841-01	1	Plate-Panel, LH (Seal)	46	107069	1	Clip


Roof, Wiper Motor and Console Assembly



Roof, Wiper Motor and Console Assembly (continued)

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>	<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
1	125-9970	1	Roof	19	130-5438	2	Foam-Strip
2	107069	12	Clip	20	125-9603-03	1	Plate-Cover, Fuse
3	119-0872	10	Washer-Sealing, Bonded	21	125-7438	2	Knob-Screw, Thumb
4	120-4654	10	Screw-HHF	22	106-8737	2	Nut-Retainer
5	127-9990-03	1	Bracket-Motor, Wiper	23	130-5437	1	Foam-Plug, Console
6	32144-11	3	Screw-HWHTF	24	42862	1	Block-Terminal, Ground
7	127-9874	1	Motor-Wiper	25	42863	1	Strip-Jumper
8	127-9878	1	Arm-Wiper	26	130-5727-03	1	Mount-Block, Fuse
9	130-5430	1	Blade-Wiper	27	130-5408	1	Trim-Seal, Bulb
10	125-9972	1	Console-Roof, Top	28	3230-1	2	Bolt-CARR
11	32105-15	2	Screw-HWH	29	104-8300	2	Nut-HF, NI
12	104-7201	2	Nut-HF	30	122-0308	1	Harness-Wire, Headliner
13	125-7437	1	Light-Dome	31	114-4899	12	Plug-Plastic
14	119-8355	1	Switch-Rocker	32	130-5488	1	Plug-Console
15	99-7420	3	Plug-Hole	33	130-5609-03	2	Strap-Support, Console
16	130-5444	1	Console Panel ASM	34	130-5617	1	Foam-Strip
16:1	130-5439	1	Decal-Console	35	3256-1	2	Washer-Flat
17	104-2408	8	Screw-HSBH	36	3290-379	4	Tie-Cable
18	120-4578	8	Nut-HF				

Window and Latch Assembly



Window and Latch Assembly (continued)

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>	<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
1	125-9521	6	Screw-Shoulder, HSH	12	125-9793	2	Link-Window
2	125-9537	6	Bushing-Flange	13	125-9792	2	Handle-Window
3	130-5698	1	Rear Window ASM	14	3274-14	2	Screw-HSH
3:2	125-9848	1	Trim-Window, Rear	15	120-9681	8	Nut-Lock, NI
4	125-9982	18	Bushing-Flange	16	3274-59	2	Screw-HSH
5	130-5815	6	Washer-Backup	17	125-9987	2	Mount-Latch
6	104-8300	10	Nut-HF, NI	18	127-9850	2	Pin-Release, Quick
7	121-8441	2	Washer-Spacer	19	119-9812	2	Bolt-Shoulder
8	121-8535	2	Hinge-Window	20	104-7201	2	Nut-HF
9	125-9520	4	Screw-Shoulder, HSH	21	125-9676	2	Washer-Backup
10	130-5697	1	Front-Upper Window ASM	29	130-0590	2	Mount-Tab
10:2	127-9962	1	Seal-Trim, Windshield	30	1-807513	4	Bolt-CARR
11	127-9933	2	Plate-Backer, Windshield				

Attachments and Accessories

For 07392 Cab Kit Workman HDX Utility Vehicle

Product Name	Model/Part
Door Kit with Sliding Window	07393
Exterior Mirror Kit.....	130-5448
Interior Mirror Kit.....	130-5449
Beacon Kit	130-5484
Work Light Kit	130-5485
Windshield Washer Fluid Kit, 2015 and after Workman MD/HD Series Utility Vehicle	130-5615

Notes:



Count on it.