



Form No. 3376-211 Rev D

**Count on it.**

# Parts Catalog

## Groundsmaster® 4110 Rotary Mower

Model No. 30602—Serial No. 313000001 and Up



# Ordering Replacement Parts

To order replacement parts, please supply the part number, the quantity, and the description of each part desired.

## Understanding Reference Numbers

Each identified part in an illustration has a reference number. The reference number for a part also appears in the parts list, along with other information about the part.

This catalog uses two special reference number formats, one to indicate parts in a service assembly and another to indicate the quantity of a given part in an illustration.

## Service Assembly Reference Numbers

Parts in service assemblies have reference numbers in the form a:b. The a represents the reference number of the entire service assembly and the b represents a sequential number unique to each part within the service assembly.

For example, a wheel assembly might be identified by reference number 6, the tire by 6:1, the valve by 6:2, and the wheel by 6:3. When you order the assembly identified by reference number 6, you receive all parts identified by reference numbers 6:1, 6:2, and 6:3. However, you may also order any part individually. Reference numbers of this type appear in illustration and in parts lists.

## Reference Numbers Indicating Quantity

In an illustration, if a reference number indicates more than one part, the reference number has the form nX y. The n represents the quantity of the part, the X is the multiplication symbol, and the y represents the reference number.

For example, in an illustration, the reference number 2X 37 means that two of the parts identified by reference number 37 are indicated.

# Contents

|                                                                      |    |
|----------------------------------------------------------------------|----|
| Front Frame and Steering Assembly .....                              | 6  |
| Planetary Assembly No. 105-4500 .....                                | 8  |
| Brake Assembly No. 100-3070-03 .....                                 | 9  |
| Brake Assembly No. 100-3069-03 .....                                 | 10 |
| Rear Cover and Battery Assembly .....                                | 11 |
| Frame and Bumper Assembly .....                                      | 12 |
| Flywheel, Motor Mount and Compressor Assembly .....                  | 13 |
| Radiator and Fan Assembly .....                                      | 14 |
| Fan Mounting and Hardlines Assembly .....                            | 16 |
| Hydraulic Motor Assembly No. 117-4769 .....                          | 17 |
| Engine, Intake and Exhaust Assembly .....                            | 18 |
| Piston Pump and Gear Pump Assembly .....                             | 19 |
| Four-Section Gear Pump Assembly No. 120-8906 .....                   | 21 |
| Piston Pump Assembly No. 120-9059 .....                              | 22 |
| Combination Manifold Assembly .....                                  | 24 |
| Combination Manifold Assembly No. 120-8842 .....                     | 26 |
| Manifold Block Assembly .....                                        | 28 |
| Left Power-Take-Off Manifold Assembly No. 121-1536 .....             | 30 |
| Rear Traction Manifold Assembly No. 121-1530 .....                   | 31 |
| Center and Right Power-Take-Off Manifold Assembly No. 121-1537 ..... | 32 |
| Drive Motor, Steer Valve and Filter Head Assembly .....              | 33 |
| Hydraulic Motor Assembly No. 120-8913 .....                          | 34 |
| Steering Valve Assembly No. 114-4900 .....                           | 35 |
| Hydraulic Reservoir Assembly .....                                   | 36 |
| Traction Hydraulic Assembly .....                                    | 37 |
| Lift, Steer and Fan Hydraulic Assembly .....                         | 38 |
| Oil Cooler Hydraulic Assembly .....                                  | 40 |
| Rear Axle and Steering Cylinder Assembly .....                       | 42 |
| Bevel Pinion Shaft Assembly Rear Axle Assembly No. 110-4750 .....    | 44 |
| Differential Assembly Rear Axle Assembly No. 110-4750 .....          | 45 |
| Axle Support Assembly Rear Axle Assembly No. 110-4750 .....          | 46 |
| Bevel Gear Case Assembly Rear Axle Assembly No. 110-4750 .....       | 47 |
| Bevel Gear Shaft Assembly Rear Axle Assembly No. 110-4750 .....      | 48 |
| Axle Case Assembly Rear Axle Assembly No. 110-4750 .....             | 49 |
| Axle Assembly Rear Axle Assembly No. 110-4750 .....                  | 50 |
| Hydraulic Motor Assembly No. 120-8814 .....                          | 51 |
| Steering Cylinder Assembly No. 121-1534 .....                        | 52 |
| Hydraulic Fitting Assembly .....                                     | 53 |
| Hose and Tube Routing Assembly .....                                 | 54 |
| Fuel Tank and Air Cleaner Assembly .....                             | 55 |
| Air Cleaner Assembly No. 99-5410 .....                               | 56 |
| Hood and Screen Assembly .....                                       | 57 |
| Fuel / Water Separator Assembly .....                                | 58 |
| Traction Pedal Assembly .....                                        | 59 |
| Brake Pedal Assembly .....                                           | 61 |
| Seat Base and Seat Assembly .....                                    | 62 |
| Air Ride Seat Suspension Assembly No. 108-1488 .....                 | 64 |
| Cloth Premium Seat Assembly No. 117-9429 .....                       | 66 |
| Parking Brake, Steering Tower and Power Center Assembly .....        | 67 |
| Fender, Tool Box and Cover Assembly .....                            | 69 |
| Fender and Step Support Assembly .....                               | 70 |
| Acoustic Foam Assembly .....                                         | 71 |
| Front Deck Lift-Arm Assembly .....                                   | 72 |
| Gear Motor Assembly No. 99-5489 .....                                | 74 |

## Contents (continued)

|                                                           |     |
|-----------------------------------------------------------|-----|
| Hydraulic Cylinder Assembly No. 120-8822 .....            | 75  |
| Front Deck Hose Routing Assembly .....                    | 76  |
| Front Deck Hydraulic Fitting Assembly .....               | 78  |
| Platform Harness and Fuse Assembly .....                  | 79  |
| Rear Harness Assembly .....                               | 80  |
| Battery Cable and Grounds Assembly .....                  | 81  |
| Engine Harness Assembly .....                             | 82  |
| Arm-Rest Control Panel Assembly .....                     | 83  |
| Cab Light Switch Assembly .....                           | 85  |
| Headlamp and Slow-Moving-Vehicle Decal Assembly .....     | 86  |
| Head Light Assembly No. 114-5928 .....                    | 87  |
| Right-Front Window Assembly .....                         | 88  |
| Right-Rear Window Assembly .....                          | 89  |
| Panel and Washer-Fluid Tank Assembly .....                | 90  |
| Left Door Assembly .....                                  | 91  |
| Left-Front Window Assembly .....                          | 92  |
| Front-Upper Window Assembly .....                         | 93  |
| Front-Lower Window Assembly .....                         | 94  |
| Rear Window Assembly .....                                | 95  |
| Door Striker, Wiper and Mirror Assembly .....             | 96  |
| Wiper Assembly No. 119-8350 .....                         | 97  |
| Headliner Assembly .....                                  | 98  |
| Roof and Hose Assembly .....                              | 99  |
| Switchplate and Fuseblock Assembly .....                  | 100 |
| Heater Evaporator Assembly .....                          | 101 |
| Condensor Assembly .....                                  | 102 |
| Rear Weight Assembly .....                                | 103 |
| Deck Pad and Hardware Assembly .....                      | 104 |
| Center Deck Assembly .....                                | 105 |
| Low Driven Spindle Assembly No. 119-4776 .....            | 107 |
| Wing Lift Cylinder Assembly No. 107-0190 .....            | 108 |
| High Driven Spindle Assembly No. 119-4549 .....           | 109 |
| Right Hand and Left Hand Deck Installation Assembly ..... | 110 |
| Caster Wheel Assembly .....                               | 112 |
| Spindle and Blade Assembly .....                          | 114 |
| Driving Spindle Assembly No. 119-4547 .....               | 115 |
| Double Driven Spindle Assembly No. 119-5298 .....         | 116 |
| Deck Cover Assembly .....                                 | 117 |
| Rear Discharge Baffle Assembly .....                      | 118 |
| Cylinder Block Assembly .....                             | 119 |
| Gear Housing Assembly .....                               | 120 |
| Flywheel Housing and Oil Sump Assembly .....              | 121 |
| Cylinder Head and Bonnet Assembly .....                   | 122 |
| Suction Manifold Assembly .....                           | 124 |
| Exhaust Manifold and Silencer Assembly .....              | 125 |
| Camshaft and Driving Gear Assembly .....                  | 126 |
| Turbine Assembly .....                                    | 127 |
| Crankshaft and Piston Assembly .....                      | 128 |
| Lubrication and Oil System Assembly .....                 | 129 |
| Lubrication Oil Line Assembly .....                       | 130 |
| Cooling Water System Assembly .....                       | 131 |
| Fuel Injection Pump Assembly .....                        | 132 |
| Governor Assembly .....                                   | 134 |
| Fuel Injection Valve Assembly .....                       | 135 |


Contents (continued)

Starting Motor Assembly ..... 136

Generator Assembly ..... 137

Gasket Set..... 138

Attachments and Accessories ..... 139




## Front Frame and Steering Assembly

| Ref. | Part Number | Qty. | Description              |
|------|-------------|------|--------------------------|
| 1    | 99-5107     | 6    | Nut-Lock                 |
| 2    | 3256-26     | 6    | Washer-Flat              |
| 3    | 3272-30     | 4    | Pin-Cotter               |
| 4    | 3256-29     | 8    | Washer-Flat              |
| 5    | 110-6006    | 2    | Pin-Clevis               |
| 6    | 93-7972     | 4    | Ring-Retaining, Internal |
| 7    | 100-3046    | 2    | Shaft-Brake, Splined     |
| 8    | 105-4500    | 2    | Planetary ASM            |
| 9    |             | 2    | Wheel And Tire ASM ●     |
| 9:1  | 119-8313    | 1    | Tire                     |
| 9:2  | 120-4175    | 1    | Rim                      |
| 9:3  | 232-27      | 1    | Stem-Valve               |
| 10   | 32121-110   | 2    | Pin-Roll, Slotted        |
| 11   | 100-3017    | 2    | Pin-Arm, Lift            |
| 12   | 100-6116    | 4    | Screw-HHF                |
| 13   | 93-7984     | 2    | Gasket                   |
| 14   | 100-3070-03 | 1    | Brake ASM                |
| 15   | 33106-090   | 8    | Screw-HHF                |

| Ref. | Part Number | Qty. | Description         |
|------|-------------|------|---------------------|
| 16   | 3218-4      | 2    | Nut-Jam             |
| 17   | 3296-49     | 2    | Nut-Lock, NI        |
| 18   | 33106-030   | 12   | Screw-HHF           |
| 19   | 325-13      | 2    | Screw-HH            |
| 20   | 323-8       | 1    | Screw-HH            |
| 21   | 93-5988     | 3    | Hub-Pivot           |
| 22   | 114-5907-03 | 1    | Lever-Tilt          |
| 23   | 114-4854    | 1    | Spacer-Cup          |
| 24   | 93-5446     | 1    | Cap-Vinyl           |
| 25   | 100-3069-03 | 1    | Brake ASM           |
| 26   | 120-4085-03 | 1    | Frame-Front         |
| 27   | 9547        | 4    | Washer-Thrust       |
| 28   | 323-7       | 2    | Screw-HH            |
| 29   | 114-0167    | 1    | Steering Column ASM |
| 29:1 | 256-132     | 2    | Bushing-Flange      |
| 30   | 93-5428     | 1    | Shaft-Steering      |
| 31   | 32151-29    | 2    | Ring-Retaining      |
| 32   | 93-5439     | 1    | Seal-Steering       |

● Not serviced separately




## Front Frame and Steering Assembly (continued)

| Ref. | Part Number | Qty. | Description           |
|------|-------------|------|-----------------------|
| 33   | 93-5429     | 1    | Collar-Foam           |
| 34   | 98-1471     | 1    | Wheel-Steering        |
| 34:1 | 98-1468     | 1    | Cover-Wheel, Steering |
| 35   | 3256-27     | 1    | Washer-Flat           |

| Ref. | Part Number | Qty. | Description |
|------|-------------|------|-------------|
| 36   | 108-9342    | 1    | Nut-Hex     |
| 37   | 98-1459     | 1    | Decal       |
| 38   | 242-50      | 16   | Nut-Lug     |
| 39   | 104-8301    | 3    | Nut-HF, NI  |

● Not serviced separately




## Planetary Assembly No. 105-4500

| Ref. | Part Number | Qty. | Description       |
|------|-------------|------|-------------------|
| 1    |             | 1    | Spindle ■         |
| 2    | 105-8122    | 1    | Seal-Boot         |
| 4    | 105-8120    | 1    | Bearing-Cone      |
| 5    | 105-8119    | 1    | Bearing-Cup       |
| 6    | 105-8124    | 8    | Stud-Wheel        |
| 7    | 105-8125    | 16   | Bolt-Head, Socket |
| 8    | 3253-18     | 16   | Washer-Lock       |
| 9    |             | 1    | Housing ■         |
| 10   | 105-8121    | 1    | Pin-Dowel         |
| 11   | 105-8117    | 1    | Bearing-Cup       |
| 12   | 105-8118    | 1    | Bearing-Cone      |
| 16   | 105-8113    | 1    | Gear-Ring         |
| 17   | 105-8132    | 1    | Ring-Retaining    |
| 18   | 353-990     | 2    | Plug ASM          |
| 18:1 | 237-78      | 1    | O-Ring            |
| 19   | 105-8138    | 1    | Cap-End           |
| 21   | 105-8133    | 1    | Plug-Thrust       |
| 22   | 105-8123    | 1    | Washer-Thrust     |
| 23   | 105-8131    | 1    | Ring-Retaining    |

| Ref. | Part Number | Qty. | Description           |
|------|-------------|------|-----------------------|
| 24   | 105-8114    | 1    | Gear-Primary          |
| 25   | 105-8115    | 1    | Shaft-Drive           |
| 26   | 105-8129    | 1    | Carrier-Primary       |
| 27   | 105-8139    | 1    | Gear-Secondary        |
| 28   | 105-8130    | 1    | Carrier-Secondary     |
| 29   | 105-8136    | 1    | Shim Kit              |
| 29:1 |             | 1    | Ring-Snap ■           |
| 29:2 |             | 1    | Shim-Bearing, 2.9Mm ■ |
| 29:3 |             | 1    | Shim-Bearing, 2.8Mm ■ |
| 29:4 |             | 1    | Shim-Bearing, 2.7Mm ■ |
| 29:5 |             | 1    | Shim-Bearing, 2.6Mm ■ |
| 29:6 |             | 1    | Shim-Bearing, 2.5Mm ■ |
| 29:7 |             | 1    | Shim-Bearing, 2.4Mm ■ |
| 30   | 105-8137    | 1    | Seal Kit ●            |
| 30:1 |             | 1    | O Ring-Flange Cap ■   |
| 30:2 |             | 1    | Seal-Oil ■            |
| 30:3 |             | 2    | O Ring-End Cap ■      |
| 30:4 | 237-78      | 2    | O-Ring                |


● Not illustrated

■ Not serviced separately




## Brake Assembly No. 100-3070-03

| Ref. | Part Number | Qty. | Description       |
|------|-------------|------|-------------------|
| 2    | 93-7977     | 1    | Seal              |
| 3    | 93-7978     | 1    | Rod-Pull          |
| 4    | 93-7983     | 2    | Pin-Clevis        |
| 5    | 93-7980     | 2    | Link              |
| 6    | 93-7979     | 2    | Pin-Hitch         |
| 7    | 93-7986     | 4    | Disc-Stationary   |
| 8    | 104-4278    | 3    | Disc-Rotating     |
| 9    | 93-7976     | 1    | Ring-Retaining    |
| 10   | 93-7984     | 1    | Gasket            |
| 11   | 104-4279    | 1    | Actuator-Rotating |
| 12   | 93-7987     | 3    | Spring-Extension  |
| 13   | 93-7985     | 3    | Ball              |
| 14   | 353-990     | 2    | Plug ASM          |
| 14:1 | 237-78      | 1    | O-Ring            |



## Brake Assembly No. 100-3069-03


| Ref. | Part Number | Qty. | Description       |
|------|-------------|------|-------------------|
| 2    | 93-7977     | 1    | Seal              |
| 3    | 93-7978     | 1    | Rod-Pull          |
| 4    | 93-7983     | 2    | Pin-Clevis        |
| 5    | 93-7980     | 2    | Link              |
| 6    | 93-7979     | 2    | Pin-Hitch         |
| 7    | 93-7986     | 4    | Disc-Stationary   |
| 8    | 104-4278    | 3    | Disc-Rotating     |
| 9    | 93-7976     | 1    | Ring-Retaining    |
| 10   | 93-7984     | 1    | Gasket            |
| 11   | 104-4280    | 1    | Actuator-Rotating |
| 12   | 93-7987     | 3    | Spring-Extension  |
| 13   | 93-7985     | 3    | Ball              |
| 14   | 353-990     | 2    | Plug ASM          |
| 14:1 | 237-78      | 1    | O-Ring            |



## Rear Cover and Battery Assembly

| Ref. | Part Number | Qty. | Description           |
|------|-------------|------|-----------------------|
| 1    | 105-0777    | 2    | Strip-Foam            |
| 2    | 105-0778    | 2    | Strip-Foam            |
| 3    | 104-2287-03 | 1    | Cover-Frame           |
| 4    | 3256-3      | 2    | Washer-Flat           |
| 5    | 32104-6     | 2    | Screw-HH, TAP         |
| 8    | 120-4118-03 | 1    | Plate-Mounting, Valve |
| 9    | 63-9750     | 4    | Mount                 |
| 10   | 1-303352    | 4    | Washer-Spindle        |


| Ref. | Part Number | Qty. | Description      |
|------|-------------|------|------------------|
| 11   | 63-8410     | 4    | Washer           |
| 12   | 33115-035   | 4    | Screw-HH         |
| 13   | 3230-23     | 2    | Screw-CARR       |
| 14   | 121-1512-03 | 1    | Shield-Battery   |
| 15   | 104-8300    | 2    | Nut-HF, NI       |
| 16   | 3231-5      | 1    | Screw-CARR       |
| 17   | 66-2490     | 1    | Retainer-Battery |
| 18   | 104-8301    | 1    | Nut-HF, NI       |



## Frame and Bumper Assembly

| Ref. | Part Number | Qty. | Description    |
|------|-------------|------|----------------|
| 1    | 120-4110-03 | 1    | Frame          |
| 2    | 106-4278-03 | 1    | Bumper         |
| 3    | 325-5       | 4    | Screw-HH       |
| 4    | 3256-26     | 4    | Washer-Flat    |
| 5    | 32128-23    | 4    | Nut-HF         |
| 6    | 105-8278    | 1    | Decal          |
| 7    | 2412-138    | 1    | R-Clamp        |
| 8    | 3234-1      | 2    | Screw-HHF      |
| 9    | 104-8301    | 8    | Nut-HF, NI     |
| 10   | 240-7       | 2    | Grommet-Rubber |
| 11   | 56-7971     | 2    | Clamp-Tube     |
| 12   | 3230-5      | 1    | Screw-CARR     |
| 13   | 104-8300    | 3    | Nut-HF, NI     |

| Ref. | Part Number | Qty. | Description                |
|------|-------------|------|----------------------------|
| 14   | 121-1508-03 | 1    | Bracket-Bulkhead           |
| 15   | 323-6       | 4    | Screw-HH                   |
| 16   | 322-10      | 1    | Screw-HH                   |
| 17   | 69-9760     | 1    | Coverplate                 |
| 18   | 56-7976     | 2    | Clamp-Tube                 |
| 19   | 240-2       | 3    | Grommet-Rubber             |
| 20   | 121-1481-03 | 1    | Plate-Mount, Bulkhead (LH) |
| 21   | 2412-147    | 1    | Clamp-R                    |
| 22   | 120-9086-03 | 1    | Plate-Mount, Tube          |
| 23   | 3234-11     | 2    | Screw-HHF                  |
| 24   | 3230-7      | 1    | Bolt-CARR                  |
| 25   | 56-7974     | 2    | Clamp-Tube                 |
| 26   | 69-9761     | 1    | Plate-Cover                |




## Flywheel, Motor Mount and Compressor Assembly

| Ref. | Part Number | Qty. | Description               |
|------|-------------|------|---------------------------|
| 1    | 117-5663    | 8    | Screw-HH                  |
| 2    | 107-1413    | 8    | Washer-Hardened           |
| 3    | 115-6657-03 | 1    | Plate-Flywheel            |
| 4    | 99-5132     | 8    | Bolt                      |
| 5    | 87-7510     | 8    | Washer-Flat               |
| 6    | 120-4176    | 1    | Coupling-Spring, Flywheel |
| 7    | 120-4066-03 | 2    | Mount-Motor, Front        |
| 8    | 33114-020   | 2    | Screw-HH                  |
| 9    | 3253-4      | 2    | Washer-Lock               |
| 10   | 121-5636    | 1    | Tab-Harness               |
| 11   | 48-9590     | 23   | Washer-Lock               |
| 12   | 33115-025   | 16   | Screw-HH                  |
| 13   | 104-8301    | 13   | Nut-HF, NI                |
| 14   | 63-7400     | 4    | Washer-Rebound            |
| 15   | 53-9682     | 4    | Mount-Engine              |
| 16   | 120-4068-03 | 1    | Mount-Motor               |
| 17   | 323-5       | 8    | Screw-HH                  |
| 18   | 323-14      | 4    | Screw-HH                  |
| 19   | 3234-47     | 2    | Screw-HHF                 |


| Ref. | Part Number | Qty. | Description           |
|------|-------------|------|-----------------------|
| 20   | 121-1618-03 | 1    | Bracket-Exhaust       |
| 21   | 121-1608-03 | 1    | Mount-Compressor      |
| 22   | 322-13      | 2    | Screw-HH              |
| 27   | 33115-020   | 3    | Screw-HH              |
| 28   | 121-6580    | 1    | Bracket-Harness       |
| 29   | 3255-9      | 1    | Washer-Lock           |
| 30   | 3231-5      | 1    | Screw-CARR            |
| 31   | 98-3095     | 1    | Pulley-Idler          |
| 32   | 121-8177    | 1    | Pulley-Single         |
| 33   | 33115-035   | 3    | Screw-HH              |
| 34   | 110-6254    | 1    | Belt-V                |
| 35   | 119-0103    | 1    | Compressor            |
| 36   | 33115-110   | 2    | Screw-HH              |
| 37   | 33095-00    | 4    | Washer-Flat           |
| 38   | 33015-00    | 2    | Nut-Hex               |
| 39   | 119-0128    | 1    | Fitting-Elbow, 90 DEG |
| 41   | 117-2779    | 1    | O-Ring                |
| 42   | 117-2780    | 2    | O-Ring                |
| 43   | 115-8882    | 1    | Conduit-Convolutd     |

# Radiator and Fan Assembly



## Radiator and Fan Assembly (continued)


| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>      | <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>      |
|-------------|--------------------|-------------|-------------------------|-------------|--------------------|-------------|-------------------------|
| 1           | 121-1479           | 1           | LH Radiator Support ASM | 24          | 2412-110           | 1           | Clamp-Band/Screw        |
| 1:1         | 93-7272            | 1           | Decal-Warning           | 25          | 121-1474           | 1           | Hose-Inlet, Air Cleaner |
| 1:3         | 100-2196           | 1           | Pad-Foam                | 26          | 121-3080           | 1           | Radiator/Oil Cooler     |
| 2           | 121-1684           | 1           | Foam-Radiator           | 26:1        | 115-7766           | 1           | Cap-Radiator            |
| 3           | 104-8300           | 12          | Nut-HF, NI              | 26:1:1      | 106-6755           | 1           | Decal-Cap, Radiator     |
| 4           | 92-2379            | 3           | Clamp-Hose              | 27          | 114-3828           | 1           | Seal-Bulb               |
| 5           | 110-4112           | 1           | Hose-Fuel               | 28          | 121-1478           | 1           | RH Radiator Support ASM |
| 6           | 104-8301           | 6           | Nut-HF, NI              | 28:1        | 93-7272            | 1           | Decal-Warning           |
| 7           | 93-5954            | 2           | Plug-Foam               | 28:3        | 100-2196           | 1           | Pad-Foam                |
| 8           | 3234-11            | 6           | Screw-HHF               | 29          | 93-7272            | 1           | Decal-Warning           |
| 9           | 3234-47            | 13          | Screw-HHF               | 30          | 120-9025-03        | 1           | Bracket-Intake          |
| 10          | 104-2226           | 1           | Strip-Foam              | 31          | 93-7275            | 1           | Decal-Fluid, Starting   |
| 11          | 120-8968-03        | 1           | Bracket-Hose            | 32          | 281-13             | 1           | Plug-Pipe               |
| 12          | 92-6064            | 2           | Clamp-R                 | 33          | 321-11             | 2           | Screw-HH                |
| 13          | 121-1685           | 1           | Foam-Radiator, Lower    | 34          | 114-4902           | 1           | Plate-Cover             |
| 14          | 110-9662           | 1           | Hose-Fuel               | 35          | 114-4901           | 1           | Clamp                   |
| 15          | 120-5571           | 1           | Coolant Reservoir ASM   | 36          | 322-4              | 2           | Screw-HH                |
| 15:1        | 87-7050            | 1           | Cap-Reservoir           | 37          | 104-7201           | 2           | Nut-HF                  |
| 16          | 120-8921-03        | 1           | Mount-Tank              | 38          | 120-8984           | 1           | Bracket-Clamp           |
| 17          | 3256-3             | 7           | Washer-Flat             | 39          | 100-5565           | 1           | Fitting-STR             |
| 18          | 322-1              | 6           | Screw-HH                | 39:1        | 237-146            | 1           | O-Ring                  |
| 19          | 121-1477           | 1           | Hose-Radiator, Lower    | 39:2        | 340-65             | 1           | O-Ring                  |
| 20          | 2412-111           | 4           | Clamp                   | 40          | 106-2030           | 1           | Plug-Hex, Hollow        |
| 21          | 121-1476           | 1           | Hose-Radiator, Upper    | 40:1        | 237-146            | 1           | O-Ring                  |
| 22          | 121-1517           | 1           | Shroud-Radiator, Lower  | 41          | 304-46             | 1           | Draincock               |
| 23          | 121-1515           | 1           | Shroud-Radiator, Upper  |             |                    |             |                         |



## Fan Mounting and Hardlines Assembly

| Ref. | Part Number | Qty. | Description      |
|------|-------------|------|------------------|
| 1    | 99-6810     | 6    | Screw-HHF        |
| 2    | 324-5       | 2    | Screw-HH         |
| 3    | 3256-25     | 2    | Washer-Flat      |
| 4    | 340-2       | 1    | Fitting-Straight |
| 4:1  | 237-22      | 1    | O-Ring           |
| 4:2  | 237-42      | 1    | O-Ring           |
| 5    | 340-4       | 2    | Fitting-STR      |
| 5:1  | 237-30      | 1    | O-Ring           |
| 5:2  | 237-79      | 1    | O-Ring           |
| 6    | 120-8935-03 | 1    | Bracket-Fan      |
| 7    | 117-2364    | 1    | Hub-Fan          |
| 8    | 114-3825    | 1    | Fan              |
| 9    | 340-70      | 1    | Nut-Lock         |
| 10   | 340-127     | 2    | Nut-Bulkhead     |
| 11   | 121-1518    | 1    | Shim-Support     |


| Ref. | Part Number | Qty. | Description           |
|------|-------------|------|-----------------------|
| 12   | 121-1554    | 1    | Tube-HYD              |
| 12:1 | 237-30      | 1    | O-Ring                |
| 13   | 121-1555    | 1    | Tube ASM              |
| 13:1 | 237-22      | 1    | O-Ring                |
| 14   | 121-1553    | 1    | Tube-HYD              |
| 14:1 | 237-30      | 1    | O-Ring                |
| 15   | 115-8486    | 4    | Screw-HH              |
| 16   | 80-6990     | 4    | Washer-Hardened       |
| 17   | 3296-48     | 2    | Nut-Lock, NI          |
| 18   | 104-7201    | 6    | Nut-HF                |
| 19   | 117-4769    | 1    | HYD Motor ASM         |
| 20   | 340-129     | 1    | Fitting-Elbow, 90 DEG |
| 20:1 | 237-146     | 1    | O-Ring                |
| 20:2 | 340-65      | 1    | O-Ring                |



## Hydraulic Motor Assembly No. 117-4769

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>      |
|-------------|--------------------|-------------|-------------------------|
| 1           | 115-4110           | 1           | Seal Kit                |
| 1:1         |                    | 2           | Seal-Shaft ●            |
| 1:2         |                    | 2           | Seal-Plate, Balancing ● |
| 1:3         |                    | 2           | Seal-Anti Extrusion ●   |
| 1:4         |                    | 2           | O-Ring (Housing) ●      |


● Not serviced separately



## Engine, Intake and Exhaust Assembly

| Ref. | Part Number | Qty. | Description              |
|------|-------------|------|--------------------------|
| 1    | 120-4112    | 1    | Engine-Yanmar, T4I       |
| 2    | 120-8916-03 | 1    | Mount-Controller         |
| 3    | 99-7430     | 2    | Relay                    |
| 4    | 104-7201    | 1    | Nut-HF                   |
| 5    | 321-3       | 1    | Screw-HH                 |
| 6    | 99-7435     | 2    | Relay-Power              |
| 7    | 3296-2      | 1    | Nut-Lock, NI             |
| 8    | 104-8300    | 3    | Nut-HF, NI               |
| 9    | 3256-3      | 3    | Washer-Flat              |
| 10   | 3290-134    | 1    | Screw                    |
| 11   | 110-5702    | 1    | Hose-Fuel                |
| 12   | 322-16      | 3    | Screw-HH                 |
| 13   | 121-1589    | 1    | Hose-Outlet, Air Cleaner |


| Ref. | Part Number | Qty. | Description              |
|------|-------------|------|--------------------------|
| 14   | 2412-130    | 1    | Clamp-Hose               |
| 15   | 121-1590    | 1    | Hose-Outlet, Air Cleaner |
| 16   | 2412-110    | 1    | Clamp-Band/Screw         |
| 17   | 18-2130     | 1    | Clamp                    |
| 18   | 121-1616    | 1    | Pipe-Exhaust             |
| 19   | 2412-98     | 1    | Clamp-Hose               |
| 20   | 108-3284    | 1    | Hose-Fuel                |
| 21   | 92-2379     | 1    | Clamp-Hose               |
| 22   | 121-1591    | 1    | Controller-Engine        |
| 23   | 2412-130    | 2    | Clamp-Hose               |
| 24   | 117-9410    | 2    | Fitting-Straight         |
| 25   | 2412-141    | 2    | Clamp-Drive, Worm        |
| 26   | 121-1709    | 1    | Belt-V                   |



## Piston Pump and Gear Pump Assembly

| Ref. | Part Number | Qty. | Description           |
|------|-------------|------|-----------------------|
| 1    | 121-1525    | 2    | Screw-HH              |
| 2    | 87-7270     | 4    | Washer-Thrust         |
| 3    | 120-8906    | 1    | Pump-Gear, 4-Section  |
| 4    | 340-157     | 2    | Fitting-HYD, Tee      |
| 4:1  | 237-79      | 1    | O-Ring                |
| 4:2  | 237-30      | 2    | O-Ring                |
| 5    | 340-9       | 1    | Fitting-STR           |
| 5:1  | 237-58      | 1    | O-Ring                |
| 5:2  | 237-81      | 1    | O-Ring                |
| 6    | 86-5480     | 2    | Nipple-Test           |
| 7    | 340-77      | 1    | Fitting-Elbow, 90 DEG |
| 7:1  | 237-22      | 1    | O-Ring                |
| 7:2  | 237-42      | 1    | O-Ring                |
| 8    | 100-5530    | 1    | Fitting-45 DEG        |
| 8:1  | 237-58      | 1    | O-Ring                |
| 8:2  | 237-81      | 1    | O-Ring                |
| 9    | 121-1524    | 2    | Screw-HH              |
| 10   | 107-9447    | 1    | O-Ring                |
| 11   | 117-3681    | 1    | Fitting-HYD, 90 DEG   |
| 11:1 | 237-81      | 1    | O-Ring                |
| 12   | 2412-129    | 3    | Clamp-Hose            |


| Ref. | Part Number | Qty. | Description         |
|------|-------------|------|---------------------|
| 13   | 120-9059    | 1    | Piston Pump ASM     |
| 14   | 121-1647    | 1    | Hose-HYD            |
| 15   | 100-5616    | 2    | Fitting             |
| 16   | 340-2       | 1    | Fitting-Straight    |
| 16:1 | 237-22      | 1    | O-Ring              |
| 16:2 | 237-42      | 1    | O-Ring              |
| 17   | 121-1492    | 1    | Fitting-90          |
| 17:1 | 237-80      | 1    | O-Ring              |
| 17:2 | 237-65      | 1    | O-Ring              |
| 18   | 340-159     | 1    | Fitting-HYD, 90 DEG |
| 18:1 | 237-22      | 2    | O-Ring              |
| 19   | 104-3797    | 2    | Fitting-Straight    |
| 19:1 | 237-146     | 1    | O-Ring              |
| 19:2 | 340-65      | 1    | O-Ring              |
| 20   | 99-3017     | 1    | Fitting             |
| 20:1 | 237-81      | 1    | O-Ring              |
| 21   | 2412-34     | 2    | Clamp-Hose          |
| 22   | 121-1682    | 1    | Fitting-Tee         |
| 22:1 | 237-101     | 1    | O-Ring              |
| 23   | 353-988     | 1    | Plug-Hex            |
| 23:1 | 237-79      | 1    | O-Ring              |



## Piston Pump and Gear Pump Assembly (continued)

| Ref. | Part Number | Qty. | Description  |
|------|-------------|------|--------------|
| 24   | 120-8815    | 1    | Hose-Suction |


| Ref. | Part Number | Qty. | Description |
|------|-------------|------|-------------|
| 25   | 120-9050    | 1    | Hose-HYD    |
| 26   | 354-79      | 4    | Cap-Dust    |



## Four-Section Gear Pump Assembly No. 120-8906


| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i> |
|-------------|--------------------|-------------|--------------------|
| 1           | 115-3776           | 1           | Seal Kit           |
| 2           | 115-3775           | 4           | Bolt               |
| 3           | 121-1722           | 4           | Washer             |
| 4           | 120-6284           | 3           | Hub-Connecting     |

# Piston Pump Assembly No. 120-9059



## Piston Pump Assembly No. 120-9059 (continued)


| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>    | <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>          |
|-------------|--------------------|-------------|-----------------------|-------------|--------------------|-------------|-----------------------------|
| 1           | 125-5266           | 2           | Screen                | 20          | 125-5281           | 4           | Screw                       |
| 2           | 75-0170            | 2           | Plug-Thread, Straight | 21          | 125-5282           | 4           | Screw                       |
| 2:1         | 92-8777            | 1           | O-Ring                | 22          | 125-5287           | 1           | Plate-Thrust                |
| 3           | 107-4352           | 2           | Plug                  | 23          | 121-1731           | 1           | Valve-Relief, High Pressure |
| 4           | 121-1723           | 1           | Cylinder Block Kit    | 24          | 125-5291           | 1           | Valve-Relief, High Pressure |
| 5           | 121-1724           | 1           | Plate-Valve, CW       | 25          | 121-1732           | 1           | Swash Plate Bearing Kit     |
| 6           | 121-1725           | 1           | Servo Piston ASM      | 26          | 125-5295           | 1           | Control Kit (12 Volt)       |
| 7           | 125-5270           | 6           | Screw                 | 26:1        | 125-5272           | 6           | Screw                       |
| 8           | 125-5276           | 2           | Orifice (0.8)         | 26:2        | 125-5273           | 1           | Nut-Seal                    |
| 9           | 121-1726           | 4           | Screw                 | 26:3        | 125-5302           | 1           | Plug                        |
| 10          | 125-5300           | 4           | Plug ASM              | 26:4        | 125-5266           | 1           | Screen                      |
| 11          | 121-1727           | 2           | Screw                 | 26:5        | 125-5269           | 1           | Ring-Locking                |
| 12          | 125-5301           | 1           | Plug                  | 26:6        | 125-5274           | 6           | Screw                       |
| 13          | 121-1728           | 1           | Shaft                 | 26:7        | 125-5294           | 2           | Coil Kit                    |
| 14          | 125-5279           | 1           | Bearing-Roller        | 26:8        | 125-5283           | 1           | Gasket-Control              |
| 15          | 125-5280           | 1           | Ring-Retaining        | 26:9        | 125-5288           | 2           | O-Ring                      |
| 16          | 121-1729           | 1           | Shaft Seal Kit        | 27          | 125-5303           | 2           | Plug ASM                    |
| 17          | 125-5284           | 1           | Adapter               | 28          | 125-5297           | 1           | Charge Relief Kit           |
| 18          | 125-5285           | 1           | Seal-Adapter          | 29          | 121-1733           | 1           | Overhaul Seal Kit           |
| 19          | 121-1730           | 1           | Coupling              |             |                    |             |                             |



## Combination Manifold Assembly


| Ref. | Part Number | Qty. | Description                  |
|------|-------------|------|------------------------------|
| 1    | 120-8842    | 1    | HYD Combination Manifold ASM |
| 2    | 92-2650     | 3    | Spacer-Clutch                |
| 3    | 63-9750     | 3    | Mount                        |
| 4    | 63-8410     | 3    | Washer                       |
| 5    | 323-7       | 3    | Screw-HH                     |
| 6    | 75-1310     | 1    | Filter-HYD                   |
| 7    | 3234-1      | 3    | Screw-HHF                    |
| 8    | 121-1542    | 1    | Plate-Mount, Hose            |
| 9    | 353-508     | 5    | Plug-HH                      |
| 9:1  | 237-42      | 1    | O-Ring                       |
| 10   | 2412-126    | 1    | R-Clamp                      |
| 11   | 104-8301    | 1    | Nut-HF, NI                   |
| 12   | 340-4       | 4    | Fitting-STR                  |
| 12:1 | 237-30      | 1    | O-Ring                       |
| 12:2 | 237-79      | 1    | O-Ring                       |
| 13   | 340-77      | 1    | Fitting-Elbow, 90 DEG        |
| 13:1 | 237-22      | 1    | O-Ring                       |
| 13:2 | 237-42      | 1    | O-Ring                       |
| 14   | 86-5480     | 1    | Nipple-Test                  |
| 15   | 354-79      | 1    | Cap-Dust                     |

| Ref. | Part Number | Qty. | Description       |
|------|-------------|------|-------------------|
| 16   | 340-7       | 1    | Fitting-Straight  |
| 16:1 | 237-65      | 1    | O-Ring            |
| 16:2 | 237-80      | 1    | O-Ring            |
| 17   | 120-8975    | 1    | Fitting-Straight  |
| 17:1 | 237-42      | 1    | O-Ring            |
| 18   | 340-2       | 1    | Fitting-Straight  |
| 18:1 | 237-22      | 1    | O-Ring            |
| 18:2 | 237-42      | 1    | O-Ring            |
| 19   | 120-8979    | 1    | Fitting-Straight  |
| 19:1 | 237-42      | 1    | O-Ring            |
| 20   | 100-4887    | 1    | Fitting-Elbow, 90 |
| 20:1 | 237-42      | 1    | O-Ring            |
| 21   | 2412-36     | 2    | Clamp-Hose        |
| 22   | 119-4854    | 1    | Fitting-STR       |
| 22:1 | 237-30      | 1    | O-Ring            |
| 22:2 | 237-79      | 1    | O-Ring            |
| 23   | 353-512     | 1    | Plug              |
| 23:1 | 237-78      | 1    | O-Ring            |
| 24   | 87-5730     | 1    | Hose              |
| 25   | 340-1       | 2    | Fitting-Straight  |



## Combination Manifold Assembly (continued)


| Ref. | Part Number | Qty. | Description |
|------|-------------|------|-------------|
| 25:1 | 237-21      | 1    | O-Ring      |
| 25:2 | 237-42      | 1    | O-Ring      |



## Combination Manifold Assembly No. 120-8842

| Ref. | Part Number | Qty. | Description             |
|------|-------------|------|-------------------------|
| 3    | 110-5973    | 2    | Orifice-0.030           |
| 4    | 112-6538    | 2    | Orifice (.063 Inch)     |
| 5    | 110-8883    | 1    | Plug-Orifice (0.040)    |
| 6    | 117-0115    | 4    | Plug                    |
| 6:1  | 237-78      | 1    | O-Ring                  |
| 7    | 353-990     | 14   | Plug ASM                |
| 7:1  | 237-78      | 1    | O-Ring                  |
| 9    | 114-2873    | 1    | Check Valve ASM         |
| 9:1  | 105-9156    | 1    | Seal Kit                |
| 10   | 105-9321    | 3    | Check Valve ASM         |
| 10:1 | 105-9156    | 1    | Seal Kit                |
| 11   | 115-5409    | 1    | Compensator ASM         |
| 11:1 | 110-8908    | 1    | Spool Valve Seal Kit    |
| 12   | 125-7560    | 1    | Relief Valve ASM        |
| 12:1 | 105-9156    | 1    | Seal Kit                |
| 13   | 125-7559    | 1    | Relief Valve ASM        |
| 13:1 | 105-9156    | 1    | Seal Kit                |
| 14   | 125-7558    | 1    | Relief Valve ASM        |
| 14:1 | 105-9156    | 1    | Seal Kit                |
| 15   | 127-3663    | 1    | Valve-Pressure Reducing |
| 15:1 | 105-9154    | 1    | Seal Kit                |


| Ref. | Part Number | Qty. | Description                   |
|------|-------------|------|-------------------------------|
| 16   | 107-7516    | 1    | Solenoid Valve ASM            |
| 16:1 | 105-9156    | 1    | Seal Kit                      |
| 16:2 | 110-2634    | 1    | Nut-Coil                      |
| 17   | 112-9206    | 3    | Solenoid Valve ASM            |
| 17:1 | 105-9156    | 1    | Seal Kit                      |
| 17:2 | 110-2634    | 1    | Nut-Coil                      |
| 18   | 115-5400    | 4    | Solenoid Valve ASM            |
| 18:1 | 107-7813    | 1    | Seal Kit                      |
| 18:2 | 110-2634    | 1    | Nut-Coil                      |
| 19   | 115-3023    | 1    | Solenoid Valve ASM            |
| 19:1 | 110-8908    | 1    | Spool Valve Seal Kit          |
| 20   | 125-7556    | 1    | Solenoid Valve ASM            |
| 20:1 | 107-7813    | 1    | Seal Kit                      |
| 21   | 115-5405    | 1    | Solenoid Valve ASM            |
| 21:1 | 115-5413    | 1    | Seal Kit                      |
| 21:2 | 110-2634    | 1    | Nut-Coil                      |
| 22   | 125-7555    | 1    | Proportional Relief Valve ASM |
| 22:1 | 110-6316    | 1    | Seal Kit                      |
| 23   | 125-7554    | 1    | Valve-Solenoid                |
| 23:1 | 125-7561    | 1    | Seal Kit                      |



## Combination Manifold Assembly No. 120-8842 (continued)

| Ref. | Part Number | Qty. | Description             |
|------|-------------|------|-------------------------|
| 24   | 115-8733    | 2    | Screw-HSH               |
| 25   | 110-0497    | 5    | Coil-Solenoid           |
| 26   | 110-6344    | 6    | Coil-12V, Dc            |
| 27   | 125-7553    | 1    | E-Coil, 12Vdc           |
| 28   | 125-7552    | 3    | Orifice-Check, .070 DIA |
| 29   | 340-2       | 2    | Fitting-Straight        |
| 29:1 | 237-22      | 1    | O-Ring                  |


| Ref. | Part Number | Qty. | Description                |
|------|-------------|------|----------------------------|
| 29:2 | 237-42      | 1    | O-Ring                     |
| 30   | 104-3779    | 1    | Connector-Swivel, Straight |
| 30:1 | 237-42      | 1    | O-Ring                     |
| 31   | 125-7551    | 1    | Nipple-Filter              |
| 32   | 125-7550    | 1    | Nut-Coil                   |
| 33   | 110-2634    | 11   | Nut-Coil                   |



## Manifold Block Assembly

| Ref. | Part Number | Qty. | Description             |
|------|-------------|------|-------------------------|
| 1    | 3234-11     | 4    | Screw-HHF               |
| 3    | 59-7410     | 3    | Fitting-Diagnostic      |
| 3:1  | 237-42      | 1    | O-Ring                  |
| 4    | 340-142     | 2    | Fitting-Elbow-90        |
| 4:1  | 237-58      | 1    | O-Ring                  |
| 4:2  | 237-81      | 1    | O-Ring                  |
| 5    | 100-5530    | 3    | Fitting-45 DEG          |
| 5:1  | 237-58      | 1    | O-Ring                  |
| 5:2  | 237-81      | 1    | O-Ring                  |
| 6    | 121-1536    | 1    | Manifold-PTO, Left      |
| 7    | 323-42      | 2    | Screw-HH                |
| 8    | 340-101     | 1    | Fitting-HYD, 45 DEG     |
| 8:1  | 237-30      | 1    | O-Ring                  |
| 8:2  | 237-79      | 1    | O-Ring                  |
| 9    | 121-1530    | 1    | Manifold-Traction, Rear |
| 10   | 340-2       | 1    | Fitting-Straight        |
| 10:1 | 237-22      | 1    | O-Ring                  |
| 10:2 | 237-42      | 1    | O-Ring                  |
| 11   | 104-3509    | 1    | Fitting-HYD, 45 DEG     |
| 11:1 | 237-146     | 1    | O-Ring                  |
| 11:2 | 340-65      | 1    | O-Ring                  |


| Ref. | Part Number | Qty. | Description                    |
|------|-------------|------|--------------------------------|
| 12   | 340-9       | 3    | Fitting-STR                    |
| 12:1 | 237-58      | 1    | O-Ring                         |
| 12:2 | 237-81      | 1    | O-Ring                         |
| 13   | 3234-1      | 2    | Screw-HHF                      |
| 14   | 340-86      | 1    | Fitting-Tee                    |
| 14:1 | 237-22      | 2    | O-Ring                         |
| 14:2 | 237-42      | 1    | O-Ring                         |
| 15   | 340-77      | 3    | Fitting-Elbow, 90 DEG          |
| 15:1 | 237-22      | 1    | O-Ring                         |
| 15:2 | 237-42      | 1    | O-Ring                         |
| 16   | 121-1537    | 2    | Manifold-PTO, Center And Right |
| 17   | 92-6058     | 2    | Fitting-STR                    |
| 17:1 | 237-81      | 1    | O-Ring                         |
| 17:2 | 237-58      | 1    | O-Ring                         |
| 18   | 120-8982    | 2    | Fitting-45 DEG                 |
| 18:1 | 237-58      | 1    | O-Ring                         |
| 18:2 | 237-81      | 1    | O-Ring                         |
| 19   | 104-8301    | 2    | Nut-HF, NI                     |
| 20   | 120-8825    | 1    | Fitting-Tee                    |
| 20:1 | 340-65      | 2    | O-Ring                         |



## Manifold Block Assembly (continued)


| Ref. | Part Number | Qty. | Description |
|------|-------------|------|-------------|
| 20:2 | 237-81      | 1    | O-Ring      |
| 21   | 353-508     | 1    | Plug-HH     |

| Ref. | Part Number | Qty. | Description |
|------|-------------|------|-------------|
| 21:1 | 237-42      | 1    | O-Ring      |
| 22   | 354-79      | 3    | Cap-Dust    |



## Left Power-Take-Off Manifold Assembly No. 121-1536


| Ref. | Part Number | Qty. | Description                |
|------|-------------|------|----------------------------|
| 3    | 353-990     | 1    | Plug ASM                   |
| 3:1  | 237-78      | 1    | O-Ring                     |
| 4    | 117-8315    | 1    | Orifice (.025 Inch)        |
| 6    | 112-6538    | 1    | Orifice (.063 Inch)        |
| 7    | 114-5512    | 1    | Valve-Relief, 600 PSI      |
| 7:1  | 105-9156    | 1    | Seal Kit                   |
| 8    | 105-9153    | 1    | Element-Logic, Vented      |
| 8:1  | 119-2159    | 1    | Seal Kit                   |
| 9    | 125-4327    | 1    | Valve-Directional, Pilot   |
| 9:1  | 114-5515    | 1    | Seal Kit                   |
| 10   | 117-0227    | 1    | Valve-Relief, Proportional |
| 10:1 | 105-9156    | 1    | Seal Kit                   |
| 10:2 | 119-2160    | 1    | Nut-Coil                   |
| 11   | 110-2630    | 1    | Coil-12Vdc                 |



## Rear Traction Manifold Assembly No. 121-1530

| Ref. | Part Number | Qty. | Description              |
|------|-------------|------|--------------------------|
| 3    | 107-7525    | 1    | Plug-Orifice (.050 Inch) |
| 4    |             | 1    | Plug ●                   |
| 5    | 353-990     | 1    | Plug ASM                 |
| 5:1  | 237-78      | 1    | O-Ring                   |
| 6    | 125-4328    | 1    | Valve-Check              |
| 6:1  | 125-4336    | 1    | Seal Kit                 |
| 7    | 125-4329    | 1    | Valve-Reducing           |
| 7:1  | 125-4334    | 1    | Seal Kit                 |
| 8    | 125-4331    | 1    | Valve-Relief             |
| 8:1  | 110-6316    | 1    | Seal Kit                 |


● Not serviced separately



## Center and Right Power-Take-Off Manifold Assembly No. 121-1537

| Ref. | Part Number | Qty. | Description                |
|------|-------------|------|----------------------------|
| 1    |             | 1    | Manifold Block ●           |
| 3    | 117-8315    | 1    | Orifice (.025 Inch)        |
| 4    | 353-990     | 1    | Plug ASM                   |
| 4:1  | 237-78      | 1    | O-Ring                     |
| 5    |             | 1    | Plug ●                     |
| 6    | 114-5512    | 1    | Valve-Relief, 600 PSI      |
| 6:1  | 105-9156    | 1    | Seal Kit                   |
| 7    | 105-9153    | 1    | Element-Logic, Vented      |
| 7:1  | 119-2159    | 1    | Seal Kit                   |
| 8    | 125-4327    | 1    | Valve-Directional, Pilot   |
| 8:1  | 114-5515    | 1    | Seal Kit                   |
| 9    | 117-0227    | 1    | Valve-Relief, Proportional |
| 9:1  | 105-9156    | 1    | Seal Kit                   |
| 9:2  | 119-2160    | 1    | Nut-Coil                   |
| 10   | 110-2630    | 1    | Coil-12Vdc                 |


● Not serviced separately



## Drive Motor, Steer Valve and Filter Head Assembly

| Ref. | Part Number | Qty. | Description                |
|------|-------------|------|----------------------------|
| 1    | 94-2621     | 1    | Element-Filter             |
| 2    | 121-1577    | 1    | Head-Filter                |
| 3    | 104-3509    | 1    | Fitting-HYD, 45 DEG        |
| 3:1  | 237-146     | 1    | O-Ring                     |
| 3:2  | 340-65      | 1    | O-Ring                     |
| 4    | 3234-1      | 4    | Screw-HHF                  |
| 5    | 23-8910     | 1    | Stem-Barb-90               |
| 5:1  | 237-146     | 1    | O-Ring                     |
| 6    | 2412-34     | 1    | Clamp-Hose                 |
| 7    | 104-3779    | 1    | Connector-Swivel, Straight |
| 7:1  | 237-42      | 1    | O-Ring                     |
| 8    | 120-8913    | 2    | HYD Motor ASM              |
| 9    | 106-9888    | 4    | Washer-Flat                |
| 10   | 33116-120   | 4    | Screw-HH                   |
| 11   | 340-157     | 1    | Fitting-HYD, Tee           |
| 11:1 | 237-79      | 1    | O-Ring                     |
| 11:2 | 237-30      | 2    | O-Ring                     |
| 12   | 340-139     | 2    | Fitting-Elbow 90           |
| 12:1 | 237-81      | 1    | O-Ring                     |
| 12:2 | 237-65      | 1    | O-Ring                     |


| Ref. | Part Number | Qty. | Description           |
|------|-------------|------|-----------------------|
| 13   | 340-148     | 2    | Fitting-Tee           |
| 13:1 | 237-81      | 1    | O-Ring                |
| 13:2 | 237-58      | 2    | O-Ring                |
| 14   | 340-98      | 1    | Fitting-Elbow, 90 DEG |
| 14:1 | 237-79      | 1    | O-Ring                |
| 14:2 | 237-30      | 1    | O-Ring                |
| 15   | 340-2       | 2    | Fitting-Straight      |
| 15:1 | 237-22      | 1    | O-Ring                |
| 15:2 | 237-42      | 1    | O-Ring                |
| 16   | 114-4900    | 1    | Steering Valve ASM    |
| 17   | 120-8979    | 2    | Fitting-Straight      |
| 17:1 | 237-42      | 1    | O-Ring                |
| 18   | 340-137     | 1    | Fitting               |
| 18:1 | 237-21      | 1    | O-Ring                |
| 18:2 | 237-42      | 1    | O-Ring                |
| 19   | 340-87      | 1    | Fitting-Elbow-45      |
| 19:1 | 237-22      | 1    | O-Ring                |
| 19:2 | 237-42      | 1    | O-Ring                |
| 20   | 237-166     | 2    | O-Ring                |



7 = all items with \* are included in overhaul seal kit


## Hydraulic Motor Assembly No. 120-8913

| Ref. | Part Number | Qty. | Description        |
|------|-------------|------|--------------------|
| 1    | 67-9090     | 2    | Plug               |
| 2    | 75-0070     | 3    | Plug               |
| 3    | 107-4352    | 1    | Plug               |
| 4    | 121-1734    | 1    | Plate-Valve        |
| 5    | 121-1735    | 1    | Cylinder Block Kit |
| 6    | 69-3190     | 1    | Seal-Lip           |
| 7    | 121-1736    | 1    | Overhaul Seal Kit  |



## Steering Valve Assembly No. 114-4900


| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i> |
|-------------|--------------------|-------------|--------------------|
| 1           | 115-5480           | 1           | Seal Kit           |



## Hydraulic Reservoir Assembly

| Ref. | Part Number | Qty. | Description       |
|------|-------------|------|-------------------|
| 1    | 120-9077    | 1    | Reservoir-HYD     |
| 2    | 323-20      | 1    | Screw-HH          |
| 3    | 108-1605    | 2    | Bumper-Recess     |
| 4    | 121-1456    | 1    | Spacer-Thin       |
| 5    | 104-8301    | 1    | Nut-HF, NI        |
| 6    | 115-9793    | 1    | Breather          |
| 7    | 104-0790    | 3    | Bushing           |
| 8    | 114-0002    | 3    | Pipe-Stand        |
| 9    | 2412-129    | 1    | Clamp-Hose        |
| 10   | 93-7498     | 1    | Plug-Plastic      |
| 11   | 237-101     | 1    | O-Ring            |
| 12   | 112-6365    | 1    | Dipstick          |
| 14   | 104-7546    | 1    | Tank Strainer ASM |
| 14:1 | 340-136     | 1    | O-Ring            |
| 15   | 322-7       | 1    | Screw-HH          |

| Ref. | Part Number | Qty. | Description       |
|------|-------------|------|-------------------|
| 16   | 3256-22     | 1    | Washer-Flat       |
| 17   | 121-1533    | 1    | Spacer-Thick      |
| 18   | 110-3510    | 1    | Nut-Retainer      |
| 19   | 121-1557-03 | 1    | Mount-Tank        |
| 20   | 104-8300    | 1    | Nut-HF, NI        |
| 21   | 3256-82     | 1    | Washer-Flat       |
| 22   | 322-13      | 1    | Screw-HH          |
| 23   | 353-508     | 1    | Plug-HH           |
| 23:1 | 237-42      | 1    | O-Ring            |
| 24   | 2412-34     | 1    | Clamp-Hose        |
| 25   | 120-8810    | 1    | Hose-Strainer     |
| 26   | 115-5436    | 4    | Clamp-Hose, Crimp |
| 27   | 114-4920    | 1    | Hose              |
| 28   | 121-1521    | 1    | Hose              |
| 29   | 3256-24     | 1    | Washer-Flat       |




## Traction Hydraulic Assembly

| Ref. | Part Number | Qty. | Description |
|------|-------------|------|-------------|
| 1    | 121-1552    | 1    | Tube ASM    |
| 1:1  | 237-22      | 3    | O-Ring      |
| 2    | 120-9079    | 2    | Tube-HYD    |
| 3    | 121-1624    | 1    | Tube-HYD    |
| 4    | 322-11      | 1    | Screw-HH    |
| 5    | 69-9761     | 1    | Plate-Cover |
| 6    | 120-3200    | 2    | Clamp-Tube  |
| 7    | 104-8300    | 1    | Nut-HF, NI  |
| 8    | 340-70      | 1    | Nut-Lock    |
| 10   | 104-2807    | 1    | Hose-HYD    |
| 11   | 104-4584    | 1    | Hose-HYD    |

| Ref. | Part Number | Qty. | Description        |
|------|-------------|------|--------------------|
| 12   | 115-4384    | 1    | Hose-HYD           |
| 13   | 120-8834    | 1    | Tube-PTO, LH To RH |
| 14   | 104-2234    | 1    | Hose-HYD           |
| 15   | 121-1480    | 1    | Tube-HYD           |
| 16   | 120-8961    | 1    | Tube-Return, Front |
| 17   | 121-1564    | 1    | Hose-HYD           |
| 18   | 121-1563    | 1    | Hose-HYD           |
| 19   | 121-1505    | 1    | Hose-HYD           |
| 20   | 121-1581    | 1    | Tube-Tee           |
| 20:1 | 340-65      | 1    | O-Ring             |


# Lift, Steer and Fan Hydraulic Assembly



## Lift, Steer and Fan Hydraulic Assembly (continued)


| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i> | <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>         |
|-------------|--------------------|-------------|--------------------|-------------|--------------------|-------------|----------------------------|
| 1           | 120-9074           | 1           | Tube-Fan           | 11          | 340-71             | 2           | Fitting-Straight, Bulkhead |
| 2           | 120-8966           | 1           | Tube-Drain, Fan    | 11:1        | 237-22             | 2           | O-Ring                     |
| 2:1         | 237-22             | 1           | O-Ring             | 12          | 340-70             | 2           | Nut-Lock                   |
| 3           | 120-9075           | 1           | Tube-Fan, M2       | 13          | 121-1567           | 1           | Hose-HYD                   |
| 4           | 59-7410            | 2           | Fitting-Diagnostic | 14          | 121-1565           | 1           | Tube-Tee                   |
| 4:1         | 237-42             | 1           | O-Ring             | 14:1        | 237-22             | 3           | O-Ring                     |
| 5           | 121-1523           | 1           | Tube-HYD           | 15          | 121-1510           | 1           | Tube-HYD                   |
| 6           | 117-3123           | 2           | HYD Hose ASM       | 16          | 121-1566           | 1           | Hose-HYD                   |
| 7           | 120-9078           | 1           | Tube-HYD           | 17          | 120-8848           | 1           | Tube-HYD                   |
| 7:1         | 237-22             | 5           | O-Ring             | 18          | 3290-378           | 4           | Tie-Cable                  |
| 8           | 121-1509           | 1           | Tube-HYD           | 19          | 121-1544           | 2           | Cover-Hose                 |
| 8:1         | 237-30             | 3           | O-Ring             | 20          | 121-1504           | 1           | Hose-HYD                   |
| 8:2         | 237-65             | 1           | O-Ring             | 21          | 121-1491           | 2           | Hose-HYD                   |
| 9           | 340-127            | 2           | Nut-Bulkhead       | 22          | 121-1503           | 1           | Hose-HYD                   |
| 10          | 121-1522           | 1           | Tube-HYD           | 23          | 354-79             | 2           | Cap-Dust                   |

# Oil Cooler Hydraulic Assembly



## Oil Cooler Hydraulic Assembly (continued)


| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i> | <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>     |
|-------------|--------------------|-------------|--------------------|-------------|--------------------|-------------|------------------------|
| 1           | 120-9060           | 1           | Hose-HYD           | 5           | 69-8910            | 2           | Washer                 |
| 2           | 121-1612           | 1           | Tube ASM           | 6           | 240-7              | 1           | Grommet-Rubber         |
| 2:1         | 237-30             | 1           | O-Ring             | 7           | 69-8900            | 1           | Spacer                 |
| 2:2         | 340-152            | 1           | Cap-HYD            | 8           | 340-126            | 1           | Nut-Bulkhead           |
| 2:3         | 340-65             | 1           | O-Ring             | 9           | 120-8838           | 1           | Tube-PTO, Front Return |
| 3           | 121-1626           | 1           | Tube-HYD           | 10          | 121-1572           | 1           | Hose-HYD               |
| 4           | 121-1507           | 1           | Tube ASM           | 11          | 117-0686           | 1           | Hose-HYD               |
| 4:1         | 237-58             | 1           | O-Ring             | 12          | 115-4384           | 1           | Hose-HYD               |



## Rear Axle and Steering Cylinder Assembly

| Ref. | Part Number | Qty. | Description            | Ref. | Part Number | Qty. | Description              |
|------|-------------|------|------------------------|------|-------------|------|--------------------------|
| 1    | 110-4750    | 1    | Drive Axle ASM         | 15   | 32120-15    | 2    | Ring-Snap, EXT           |
| 2    | 340-126     | 2    | Nut-Bulkhead           | 16   | 100-3053    | 1    | Gear-45 Tooth            |
| 3    | 240-2       | 2    | Grommet-Rubber         | 17   | 106-1140    | 1    | Gasket                   |
| 4    | 120-9069-03 | 1    | Plate-Mount, Bulkhead  | 18   | 104-2353    | 2    | Pin-Dowel                |
| 5    | 43-0090     | 4    | Screw-HH               | 19   | 95-7541     | 1    | Plate-Cover              |
| 6    | 48-9590     | 4    | Washer-Lock            | 20   | 32120-76    | 2    | Ring-Snap, EXT           |
| 7    | 3272-12     | 2    | Pin-Cotter             | 21   | 104-0755    | 1    | Pinion-27 Tooth          |
| 8    | 92-5836     | 1    | Washer                 | 22   | 237-166     | 1    | O-Ring                   |
| 9    | 100-3796    | 1    | Spacer-Joint, Ball     | 23   | 3256-26     | 8    | Washer-Flat              |
| 10   | 32136-14    | 2    | Nut-Hst                | 24   | 325-7       | 2    | Screw-HH                 |
| 11   | 353-989     | 2    | Plug-Hex, Hollow       | 25   | 120-8814    | 1    | HYD Motor ASM            |
| 11:1 | 237-42      | 1    | O-Ring                 | 26   | 33114-020   | 6    | Screw-HH                 |
| 12   | 93-5268     | 10   | Nut-Lug                | 27   | 3253-4      | 6    | Washer-Lock              |
| 13   |             | 2    | Tire And Wheel ASM ●   | 28   | 121-1535    | 1    | Steering Cylinder ASM    |
| 13:1 | 120-8910    | 1    | Tire-Off Road          | 28:1 | 106-6774    | 1    | Joint-Ball               |
| 13:2 | 120-8909    | 1    | Rim                    | 28:2 | 100-3795    | 1    | Joint-Ball               |
| 13:3 | 232-27      | 1    | Stem-Valve             | 28:3 | 32151-104   | 2    | Ring-Retaining, External |
| 14   | 74-5700     | 1    | Bearing-Needle, Roller | 28:4 | 302-5       | 1    | Fitting-Grease           |

● Not serviced separately




## Rear Axle and Steering Cylinder Assembly (continued)

| Ref. | Part Number | Qty. | Description               |
|------|-------------|------|---------------------------|
| 28:5 | 302-60      | 1    | Fitting-Grease            |
| 28:6 | 121-1534    | 1    | HYD Steering Cylinder ASM |
| 29   | 302-33      | 2    | Fitting-Grease            |
| 30   | 3296-68     | 1    | Nut-Lock, NI              |
| 31   | 92-1765     | 1    | Washer-Thrust             |
| 32   | 325-6       | 6    | Screw-HH                  |

| Ref. | Part Number | Qty. | Description    |
|------|-------------|------|----------------|
| 33   | 120-8895-03 | 1    | Mount-Rear     |
| 34   | 99-5107     | 6    | Nut-Lock       |
| 35   | 98-7077     | 1    | Pin-Axle, Rear |
| 36   | 32144-14    | 1    | Screw-HWHTF    |
| 37   | 99-8431     | 2    | Washer-Thrust  |
| 38   | 99-8432     | 2    | Washer-Thrust  |


● Not serviced separately



## Bevel Pinion Shaft Assembly Rear Axle Assembly No. 110-4750

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>    |
|-------------|--------------------|-------------|-----------------------|
| 1           | 106-1093           | 1           | Ring And Pinion Set   |
| 2           | 99-7570            | 2           | Bearing-Roller, Taper |
| 3           | 95-7534            | 1           | Case-Bearing          |
| 4           | 106-1065           | 2           | O-Ring                |
| 5           | 99-7572            | 1           | Collar-Seal, Oil      |
| 6           | 106-1066           | 1           | O-Ring                |
| 7           | 99-7574            | 1           | Seal-Oil              |
| 8           | 99-7559            | 1           | Washer-Lock           |
| 9           | 99-7560            | 1           | Nut-Lock              |
| 10          | 99-7550            | 2           | Shim 0.1              |


| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i> |
|-------------|--------------------|-------------|--------------------|
| 10          | 99-7551            | 2           | Shim 0.2           |
| 11          | 95-7533            | 1           | Case-Gear          |
| 12          | 99-7575            | 2           | Bolt               |
| 13          | 98-7735            | 2           | Stud               |
| 14          | 99-7527            | 2           | Washer-Spring      |
| 15          | 99-7526            | 2           | Nut                |
| 16          | 95-7541            | 1           | Plate-Cover        |
| 17          | 106-1140           | 1           | Gasket             |
| 18          | 104-2353           | 2           | Pin-Dowel          |



## Differential Assembly Rear Axle Assembly No. 110-4750


| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>  |
|-------------|--------------------|-------------|---------------------|
| 1           | 95-7503            | 1           | Differential ASM    |
| 2           | 106-1093           | 1           | Ring And Pinion Set |
| 3           | 95-7502            | 1           | Case-Differential   |
| 4           | 99-7576            | 8           | Bolt                |
| 5           | 3253-4             | 8           | Washer-Lock         |
| 6           | 99-7578            | 1           | Shaft-Differential  |
| 7           | 99-7579            | 2           | Pinion-Differential |
| 8           | 99-7580            | 2           | Washer-Differential |
| 9           | 99-7581            | 2           | Gear-Differential   |

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>  |
|-------------|--------------------|-------------|---------------------|
| 10          | 99-7582            | 2           | Washer-Differential |
| 10          | 99-7583            | 2           | Washer-Differential |
| 10          | 99-7584            | 2           | Washer-Differential |
| 11          | 99-7588            | 1           | Pin-Spring          |
| 12          | 99-7562            | 2           | Bearing-Ball        |
| 13          | 99-7585            | 2           | Shim 0.1            |
| 13          | 99-7586            | 2           | Shim 0.2            |
| 13          | 99-7587            | 2           | Shim 0.4            |



## Axle Support Assembly Rear Axle Assembly No. 110-4750


| Ref. | Part Number | Qty. | Description         |
|------|-------------|------|---------------------|
| 1    | 95-7508     | 1    | Support-Axle        |
| 2    | 95-7506     | 1    | Support-Axle        |
| 3    | 106-1067    | 1    | O-Ring              |
| 4    | 95-7537     | 2    | Bushing-Flanged     |
| 5    | 99-7590     | 2    | Washer-Seal         |
| 6    | 99-7589     | 2    | Plug                |
| 7    | 110-4812    | 1    | Axle Vent ASM       |
| 7:3  | 110-4815    | 1    | Insert-Filter, Foam |
| 8    | 99-7592     | 8    | Bolt                |
| 9    | 106-1068    | 2    | O-Ring              |
| 10   | 104-2377    | 1    | Extension-Vent      |
| 11   | 104-8643    | 1    | Plug                |
| 12   | 104-8644    | 1    | O-Ring              |



## Bevel Gear Case Assembly Rear Axle Assembly No. 110-4750


| Ref. | Part Number | Qty. | Description         |
|------|-------------|------|---------------------|
| 1    | 110-4752    | 2    | Case-Gear, Bevel    |
| 2    | 110-4754    | 2    | Seal-Oil            |
| 3    | 104-2378    | 2    | Bushing             |
| 4    | 106-1069    | 2    | O-Ring              |
| 5    | 104-2373    | 2    | Knuckle             |
| 6    | 104-2374    | 8    | Bolt                |
| 7    | 100-3768    | 1    | LH Steering Arm ASM |
| 7:2  | 104-8634    | 1    | Bushing             |
| 7:3  | 106-1104    | 2    | Fitting-Grease      |
| 8    | 100-3766    | 1    | RH Steering Arm ASM |
| 8:2  | 104-8634    | 1    | Bushing             |
| 8:3  | 106-1104    | 2    | Fitting-Grease      |
| 10   | 95-7547     | 2    | Shim 0.1            |
| 10   | 95-7548     | 2    | Shim 0.2            |
| 10   | 95-7549     | 2    | Shim 0.3            |
| 11   | 99-7597     | 4    | Pin-Dowel           |

| Ref.   | Part Number | Qty. | Description                 |
|--------|-------------|------|-----------------------------|
| 12     | 104-2375    | 4    | Bolt                        |
| 13     | 99-7599     | 8    | Bolt                        |
| 14     | 99-7525     | 4    | Stud                        |
| 15     | 99-7526     | 4    | Nut                         |
| 16     | 99-7527     | 4    | Washer-Spring               |
| 18     | 106-1141    | 1    | Steering Tie Rod ASM        |
| 18:2   | 106-1113    | 2    | Tie Rod End ASM - RH Thread |
| 18:2:1 | 100-3853    | 1    | Cover-Dust                  |
| 18:2:2 | 100-3854    | 1    | Nut-Castle                  |
| 18:2:3 | 110-4755    | 1    | Fitting-Grease              |
| 18:2:4 | 3272-11     | 1    | Pin-Cotter                  |
| 18:5   | 100-3855    | 2    | Bolt                        |
| 18:6   | 99-7527     | 2    | Washer-Spring               |
| 18:7   | 99-7526     | 2    | Nut                         |




## Bevel Gear Shaft Assembly Rear Axle Assembly No. 110-4750

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>       |
|-------------|--------------------|-------------|--------------------------|
| 1           | 95-7509            | 1           | Shaft-Gear, Differential |
| 2           | 95-7512            | 1           | Shaft-Gear, Differential |
| 3           | 95-7517            | 2           | Gear-Bevel, 15 Tooth     |
| 4           | 99-7530            | 4           | Bearing-Ball             |
| 5           | 99-7552            | 2           | Shim 0.1                 |
| 5           | 99-7553            | 2           | Shim 0.2                 |
| 5           | 99-7554            | 2           | Shim 0.5                 |
| 6           | 99-7531            | 2           | Clip                     |
| 7           | 110-4753           | 2           | Shaft-Gear, Bevel        |
| 8           | 95-7519            | 2           | Gear-Bevel, 17 Tooth     |
| 9           | 99-7532            | 2           | Bearing-Roller, Taper    |
| 10          | 99-7558            | 2           | Collar                   |




## Axle Case Assembly Rear Axle Assembly No. 110-4750

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>    |
|-------------|--------------------|-------------|-----------------------|
| 1           | 110-4751           | 2           | Case-Axle             |
| 2           | 99-7535            | 2           | Plug                  |
| 3           | 99-7536            | 2           | Washer-Seal           |
| 4           | 95-7527            | 2           | Gear-Bevel, 17 Tooth  |
| 5           | 99-7532            | 2           | Bearing-Roller, Taper |
| 6           | 100-2560           | 2           | Cover                 |
| 7           | 106-1070           | 2           | O-Ring                |
| 8           | 99-7589            | 2           | Plug                  |
| 9           | 99-7590            | 2           | Washer-Seal           |
| 10          | 100-2562           | 8           | Bolt                  |
| 11          | 106-1102           | 2           | Bolt-Stop             |
| 12          | 106-1103           | 2           | Nut                   |



## Axle Assembly Rear Axle Assembly No. 110-4750

| Ref. | Part Number | Qty. | Description          |
|------|-------------|------|----------------------|
| 1    | 95-7522     | 2    | Axle                 |
| 2    | 99-7564     | 2    | Seal-Oil             |
| 3    | 95-7544     | 4    | Clip                 |
| 4    | 95-7523     | 2    | Spacer               |
| 5    | 99-7555     | 2    | Shim 0.3             |
| 5    | 99-7556     | 2    | Shim 0.2             |
| 5    | 99-7557     | 2    | Shim 0.5             |
| 6    | 95-7524     | 2    | Gear-Bevel, 29 Tooth |
| 7    | 99-7534     | 2    | Bearing-Ball         |
| 8    | 95-7521     | 2    | Cover-Axle           |
| 9    | 106-1071    | 2    | O-Ring               |
| 10   | 99-7561     | 2    | Bearing-Ball         |
| 11   | 99-7539     | 2    | Clip                 |
| 12   | 99-7596     | 12   | Bolt                 |
| 13   | 99-7563     | 10   | Stud                 |




8 = all items with \* are included in overhaul seal kit

## Hydraulic Motor Assembly No. 120-8814

| Ref. | Part Number | Qty. | Description            |
|------|-------------|------|------------------------|
| 1    | 92-1352     | 2    | Plug                   |
| 2    | 69-3080     | 5    | Plug                   |
| 2:1  |             | 1    | O-Ring ●               |
| 3    | 69-3130     | 2    | Plug                   |
| 3:1  |             | 1    | O-Ring ●               |
| 4    | 121-1734    | 1    | Plate-Valve            |
| 5    | 110-6472    | 1    | Cylinder Block Kit ASM |
| 6    | 69-3190     | 1    | Seal-Lip               |
| 7    | 67-9090     | 1    | Plug                   |
| 8    | 121-1736    | 1    | Overhaul Seal Kit      |


● Not serviced separately



## Steering Cylinder Assembly No. 121-1534

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i> |
|-------------|--------------------|-------------|--------------------|
| 1           | 125-4302           | 1           | Seal Kit           |
| 1:1         |                    | 1           | O-Ring ●           |
| 1:2         |                    | 1           | Backup ●           |
| 1:3         |                    | 1           | Bp Seal ●          |
| 1:4         |                    | 1           | Bt Seal ●          |
| 1:5         |                    | 1           | Dust Seal ●        |
| 1:6         |                    | 1           | O-Ring ●           |


● Not serviced separately



## Hydraulic Fitting Assembly


| Ref. | Part Number | Qty. | Description           |
|------|-------------|------|-----------------------|
| 1    | 340-77      | 2    | Fitting-Elbow, 90 DEG |
| 1:1  | 237-22      | 1    | O-Ring                |
| 1:2  | 237-42      | 1    | O-Ring                |
| 2    | 340-142     | 2    | Fitting-Elbow-90      |
| 2:1  | 237-58      | 1    | O-Ring                |
| 2:2  | 237-81      | 1    | O-Ring                |
| 3    | 340-98      | 1    | Fitting-Elbow, 90 DEG |
| 3:1  | 237-79      | 1    | O-Ring                |

| Ref. | Part Number | Qty. | Description         |
|------|-------------|------|---------------------|
| 3:2  | 237-30      | 1    | O-Ring              |
| 4    | 340-2       | 1    | Fitting-Straight    |
| 4:1  | 237-22      | 1    | O-Ring              |
| 4:2  | 237-42      | 1    | O-Ring              |
| 5    | 340-159     | 1    | Fitting-HYD, 90 DEG |
| 5:1  | 237-22      | 2    | O-Ring              |
| 6    | 110-8829    | 1    | Sender-Temperature  |
| 6:1  | 237-42      | 1    | O-Ring              |



## Hose and Tube Routing Assembly


| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i> |
|-------------|--------------------|-------------|--------------------|
| 1           | 120-9067           | 1           | HYD Tube ASM       |
| 1:1         | 237-58             | 1           | O-Ring             |
| 2           | 120-9068           | 1           | Tube ASM           |
| 2:1         | 237-58             | 1           | O-Ring             |
| 4           | 121-1520           | 1           | Hose-HYD           |
| 5           | 121-1459           | 1           | Hose-HYD           |
| 6           | 121-1458           | 1           | Hose-HYD           |
| 7           | 121-1500           | 1           | Hose-HYD           |
| 8           | 121-1501           | 1           | Hose-HYD           |
| 9           | 121-1544           | 3           | Cover-Hose         |
| 10          | 3290-379           | 4           | Tie-Cable          |
| 11          | 121-1683           | 1           | Hose-HYD           |



## Fuel Tank and Air Cleaner Assembly

| Ref. | Part Number | Qty. | Description           |
|------|-------------|------|-----------------------|
| 1    | 3231-10     | 2    | Screw-CARR            |
| 2    | 32151-72    | 2    | Ring-Retaining        |
| 3    | 63-8410     | 2    | Washer                |
| 4    | 104-8301    | 6    | Nut-HF, NI            |
| 5    | 121-1678    | 1    | Decal-Service         |
| 6    | 120-4195    | 1    | Tank-Fuel             |
| 7    | 2412-98     | 2    | Clamp-Hose            |
| 8    | 104-5228    | 2    | Fitting-Elbow, 90 DEG |
| 9    | 120-8908    | 1    | Pipe-Stand            |
| 10   | 46-6560     | 3    | Bushing               |
| 11   | 92-2379     | 1    | Clamp-Hose            |
| 12   | 3253-15     | 5    | Washer-Lock           |
| 13   | 32122-24    | 5    | Screw-PTH             |
| 14   | 120-8912    | 1    | Sender-Fuel           |
| 15   | 62-7650     | 1    | Gasket                |
| 16   | 119-8266    | 1    | Cap-Fuel (Biodiesel)  |
| 17   | 121-1514-03 | 1    | Bracket-Latch, RH     |
| 18   | 120-4190-03 | 1    | Support-Tank          |
| 19   | 104-8300    | 2    | Nut-HF, NI            |


| Ref. | Part Number | Qty. | Description        |
|------|-------------|------|--------------------|
| 20   | 120-4193-03 | 1    | Bracket-Fuel Tank  |
| 21   | 3230-1      | 2    | Bolt-CARR          |
| 22   | 3256-3      | 2    | Washer-Flat        |
| 23   | 104-8300    | 2    | Nut-HF, NI         |
| 24   | 99-5414     | 1    | Strap-Cleaner, Air |
| 24:1 | 108-1512    | 2    | Spring             |
| 24:2 | 3256-22     | 2    | Washer-Flat        |
| 24:3 | 33113-050   | 2    | Screw-HH           |
| 24:4 | 33093-00    | 2    | Washer-Flat        |
| 24:5 | 33023-00    | 2    | Nut-Lock           |
| 25   | 104-3563    | 1    | Indicator          |
| 25:1 | 94-1416     | 1    | Adapter-Indicator  |
| 26   | 99-5410     | 1    | Air Cleaner ASM    |
| 27   | 322-6       | 2    | Screw-HH           |
| 28   | 32144-1     | 4    | Screw-Taptite      |
| 29   | 121-1513-03 | 1    | Bracket-Latch, LH  |
| 30   | 323-6       | 4    | Screw-HH           |
| 31   | 115-2368    | 1    | Hose-Fuel          |



## Air Cleaner Assembly No. 99-5410

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i> |
|-------------|--------------------|-------------|--------------------|
| 1           | 104-4258           | 1           | Valve-Vacuator     |
| 3           | 104-4259           | 1           | Cover              |
| 5           |                    | 1           | Body ASM ●         |
| 6           | 108-3814           | 1           | Filter-Air         |
| 7           | 108-3816           | 1           | Filter-Air         |


● Not serviced separately



## Hood and Screen Assembly


| Ref. | Part Number | Qty. | Description             |
|------|-------------|------|-------------------------|
| 1    | 120-9090    | 1    | Hood ASM                |
| 1:1  | 106-6754    | 1    | Decal-Danger            |
| 1:2  | 66-1210     | 2    | Decal                   |
| 2    | 120-9099-03 | 1    | Pivot-Hood              |
| 3    | 114-3823    | 1    | Seal-Bulb               |
| 4    | 104-8300    | 2    | Nut-HF, NI              |
| 5    | 121-1470    | 2    | Pivot-Screen            |
| 6    | 3290-467    | 2    | Pin-Hair                |
| 7    | 120-4196-03 | 1    | Support-Hood            |
| 8    | 46-8092     | 4    | Screw-Plastite          |
| 9    | 65-5100     | 2    | Handle-Door             |
| 10   | 104-3590    | 1    | Seal-Bulb               |
| 11   | 104-3588-03 | 2    | Pivot-Screen            |
| 12   | 94-5626     | 2    | Flexible Draw Latch ASM |
| 12:1 | 103-4080    | 1    | Latch-Rubber            |
| 12:2 | 103-4081    | 1    | Latch-Keeper            |
| 13   | 104-3580    | 2    | Seal-Corner, Screen     |
| 14   | 32144-109   | 8    | Screw-Thd Form HWH      |

| Ref. | Part Number | Qty. | Description       |
|------|-------------|------|-------------------|
| 15   | 120-8949-03 | 1    | Support-Hood, LH  |
| 16   | 104-8313    | 2    | Rod-Hood          |
| 17   | 283-67      | 2    | Pin-Clevis        |
| 18   | 2412-134    | 2    | Clamp-R           |
| 19   | 3290-307    | 2    | Pin-Cotter        |
| 20   | 120-9096-03 | 1    | Screen-Hood, Rear |
| 21   | 120-9097-03 | 1    | Screen-Hood, Top  |
| 22   | 3229-1      | 24   | Bolt-CARR         |
| 23   | 3230-2      | 2    | Bolt-CARR         |
| 24   | 117-2382    | 43   | Plug-Plastic      |
| 25   | 120-9087    | 2    | Seal-Foam         |
| 26   | 32128-33    | 2    | Nut-HF            |
| 27   | 32104-4     | 2    | Screw             |
| 28   | 321-4       | 2    | Screw-HH          |
| 32   | 119-0055    | 1    | Decal-Hood        |
| 33   | 104-7201    | 24   | Nut-HF            |
| 34   | 120-8948-03 | 1    | Support-Hood, RH  |
| 35   | 3269-4      | 8    | Rivet-Pop         |



## Fuel / Water Seperator Assembly


| Ref. | Part Number | Qty. | Description        |
|------|-------------|------|--------------------|
| 1    | 3230-22     | 2    | Screw-CARR         |
| 2    | 3229-11     | 1    | Screw-CARR         |
| 3    | 3229-3      | 1    | Screw-CARR         |
| 4    | 92-2379     | 4    | Clamp-Hose         |
| 5    | 110-8806    | 1    | Pump-Fuel          |
| 6    | 104-7201    | 2    | Nut-HF             |
| 7    | 353-781     | 2    | Fitting-Elb, 90    |
| 8    | 3256-23     | 2    | Washer-Plain       |
| 9    | 3296-29     | 2    | Nut-Lock, NI       |
| 10   | 110-9044    | 1    | Separator-Filter   |
| 10:1 | 110-9049    | 1    | Filter-Spin On     |
| 11   | 110-8817    | 1    | Bracket-Pump, Fuel |
| 12   | 110-6186    | 1    | Hose-Fuel          |
| 13   | 110-3256    | 1    | Hose-Fuel          |



## Traction Pedal Assembly


| Ref. | Part Number | Qty. | Description           |
|------|-------------|------|-----------------------|
| 1    | 3230-1      | 6    | Bolt-CARR             |
| 2    | 110-5986-01 | 1    | Pedal-Traction        |
| 3    | 93-5347     | 1    | Abrasive-Pedal        |
| 4    | 93-5368     | 1    | Abrasive-Pedal        |
| 5    | 323-7       | 1    | Screw-HH              |
| 6    | 2411-36     | 1    | Bearing-End, Rod      |
| 7    | 3219-3      | 1    | Nut-Hex               |
| 8    | 104-8300    | 10   | Nut-HF, NI            |
| 9    | 117-5450    | 1    | Shaft-Pedal, Traction |
| 10   | 32121-78    | 1    | Pin-Roll              |
| 11   | 321-37      | 2    | Screw-HH              |
| 12   | 117-5459    | 2    | Block-Clamp           |
| 13   | 3296-59     | 1    | Nut-Lock, NI          |
| 14   | 322-14      | 1    | Screw-HH              |
| 15   | 104-7201    | 2    | Nut-HF                |
| 16   | 3253-4      | 1    | Washer-Lock           |
| 17   | 256-236     | 1    | Bearing-Mount, Flange |
| 18   | 117-5455    | 1    | Plate-Cover           |
| 19   | 117-5454    | 1    | Plate-Butterfly       |
| 20   | 117-5453-01 | 1    | Bracket-Butterfly     |
| 21   | 3230-22     | 1    | Screw-CARR            |

| Ref. | Part Number | Qty. | Description                   |
|------|-------------|------|-------------------------------|
| 22   | 93-7960     | 1    | Spacer                        |
| 23   | 114-7728    | 2    | Screw-Threadlock              |
| 24   | 322-3       | 5    | Screw-HH                      |
| 25   | 3296-9      | 6    | Nut-Hex                       |
| 26   | 117-5451-01 | 1    | Bracket-Sensor                |
| 27   | 117-5445    | 1    | Bushing Hub ASM               |
| 27:1 | 95-7497     | 1    | Bushing-Wheel                 |
| 28   | 114-5609    | 1    | Sensor-Position               |
| 29   | 114-5595    | 1    | Plate-Capture                 |
| 30   | 114-5608    | 2    | Spacer-Standoff               |
| 31   | 32105-25    | 2    | Screw-SHH                     |
| 32   | 117-5446    | 1    | Shaft-Spring                  |
| 33   | 3256-5      | 1    | Washer-Flat                   |
| 34   | 84-9100     | 1    | Spring                        |
| 35   | 92-7610     | 1    | Retainer-Spring               |
| 36   | 3256-24     | 1    | Washer-Flat                   |
| 37   | 3296-6      | 1    | Nut-Lock                      |
| 38   | 117-5452-01 | 1    | Bracket-Spring                |
| 39   | 120-4087    | 1    | Platform ASM                  |
| 39:2 | 114-0846    | 1    | Decal-Instructions, Operating |



## Traction Pedal Assembly (continued)


| Ref. | Part Number | Qty. | Description           |
|------|-------------|------|-----------------------|
| 39:3 | 117-2718    | 1    | Decal-Arrester, Spark |
| 39:4 | 114-0849    | 1    | Decal-Pedal, Traction |



## Brake Pedal Assembly


| Ref. | Part Number | Qty. | Description        |
|------|-------------|------|--------------------|
| 1    | 120-4163-01 | 1    | Cover-Brake        |
| 2    | 117-5458    | 4    | Screw-HHF          |
| 3    | 99-3410     | 2    | Switch             |
| 4    | 108-9824    | 2    | Nut-Switch         |
| 5    | 3234-33     | 3    | Screw-HHF          |
| 6    | 32144-69    | 2    | Screw-HWHTF        |
| 7    | 2412-4      | 2    | Clamp-R            |
| 9    | 120-8899    | 1    | Cable-Brake, LH    |
| 10   | 322-6       | 1    | Screw-HH           |
| 11   | 120-4167    | 1    | Pin-Flag           |
| 12   | 3256-69     | 4    | Washer-Flat        |
| 13   | 63-7880     | 1    | Pin-Latch, Brake   |
| 14   | 32121-50    | 1    | Pin-Spring         |
| 15   | 93-8742     | 2    | Footpad-Brake      |
| 16   | 120-4170    | 1    | LH Brake Pedal ASM |

| Ref. | Part Number | Qty. | Description        |
|------|-------------|------|--------------------|
| 16:2 | 256-42      | 2    | Bushing            |
| 16:3 | 302-60      | 1    | Fitting-Grease     |
| 17   | 120-8898    | 1    | Cable-Brake, RH    |
| 18   | 93-5262     | 2    | Spring-Extension   |
| 19   | 283-61      | 2    | Pin-Yoke           |
| 20   | 100-5540    | 2    | Strap-Brake        |
| 21   | 75-1430     | 1    | RH Brake Pedal ASM |
| 21:2 | 256-42      | 2    | Bushing            |
| 21:3 | 302-5       | 1    | Fitting-Grease     |
| 22   | 3272-6      | 2    | Pin-Cotter         |
| 23   | 104-8300    | 3    | Nut-HF, NI         |
| 24   | 322-4       | 2    | Screw-HH           |
| 25   | 120-4168    | 2    | Plate-Support      |
| 29   | 107069      | 3    | Clip               |
| 30   | 121-1596-01 | 1    | Cover-Brakes       |



## Seat Base and Seat Assembly

| Ref. | Part Number | Qty. | Description          | Ref. | Part Number | Qty. | Description           |
|------|-------------|------|----------------------|------|-------------|------|-----------------------|
| 1    | 3230-23     | 6    | Screw-CARR           | 22   | 3256-6      | 4    | Washer-Flat           |
| 2    | 119-0000-03 | 1    | Channel-Support      | 23   | 110-5954    | 4    | Mount-Center, Bonded  |
| 3    | 112-7449-03 | 1    | Bracket-Support      | 24   | 115-5519    | 4    | Washer-Plain          |
| 4    | 104-8300    | 6    | Nut-HF, NI           | 25   | 99-5107     | 4    | Nut-Lock              |
| 5    | 3212-8      | 1    | Screw-HH             | 26   | 93-5338     | 1    | Rod-Prop              |
| 6    | 3256-25     | 4    | Washer-Flat          | 27   | 3256-23     | 3    | Washer-Plain          |
| 7    | 117-4798-03 | 1    | Arm-Support          | 28   | 3272-5      | 2    | Pin-Cotter            |
| 8    | 108-8646    | 1    | Screw-HH, Lock       | 29   | 283-83      | 2    | Pin-Clevis            |
| 9    | 112-7405    | 1    | Nut-Hex, Coupling    | 30   | 119-1416    | 2    | Pin-Cotter, Locking   |
| 10   | 17-7190     | 1    | Spacer-Finger        | 31   | 702093      | 2    | Screw-HH              |
| 11   | 104-8301    | 4    | Nut-HF, NI           | 32   | 117-9428    | 1    | Seat / Suspension ASM |
| 12   | 110-0413    | 1    | Seatbelt-Retractable | 32:1 | 108-1488    | 1    | Seat Suspension ASM   |
| 13   | 3212-4      | 1    | Screw-HH             | 32:2 | 117-9429    | 1    | Matrix Cloth Seat ASM |
| 14   | 120-9017-03 | 1    | Latch-Seat           | 33   | 3256-82     | 1    | Washer-Flat           |
| 15   | 119-1415    | 1    | Pin-Cotter, Locking  | 34   | 5979        | 1    | Bushing-Nyliner       |
| 16   | 120-9018    | 1    | Rod-Latch            | 35   | 95-1821-03  | 1    | Spring-Compression    |
| 17   | 119-1414    | 2    | Pin-Cotter, Locking  | 36   | 120-4078-03 | 1    | Plate-Seat            |
| 18   | 283-57      | 2    | Pin-Clevis           | 37   | 2412-133    | 2    | Clamp-R               |
| 19   | 83-1040     | 4    | Washer-Flat          | 38   | 32104-116   | 2    | Screw-HWHTF           |
| 20   | 323-9       | 4    | Screw-HH             | 39   | 104-7050    | 1    | Tube-Manual           |
| 21   | 325-35      | 2    | Screw-HH             | 40   | 104-7048    | 1    | Cap-Housing           |




## Seat Base and Seat Assembly (continued)

| Ref. | Part Number | Qty. | Description |
|------|-------------|------|-------------|
| 41   | 3255-8      | 1    | Washer-Lock |

| Ref. | Part Number | Qty. | Description |
|------|-------------|------|-------------|
| 42   | 322-3       | 1    | Screw-HH    |
| 43   | 117-4059    | 1    | Nut-Hex     |

# Air Ride Seat Suspension Assembly No. 108-1488




# Air Ride Seat Suspension Assembly No. 108-1488 (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>   | <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i> |
|-------------|--------------------|-------------|----------------------|-------------|--------------------|-------------|--------------------|
| 1           | 108-8026           | 1           | Cover ASM            | 9:1         |                    | 1           | Nut ■              |
| 1:1         | 39-5710            | 2           | Plug-Plastic         | 9:2         |                    | 5           | Tie-Wire ■         |
| 2           | 108-8027           | 1           | Cover                | 9:3         |                    | 4           | Tie-Wire ■         |
| 2:1         |                    | 2           | Rivet ■              | 9:4         |                    | 1           | Screw ■            |
| 3           | 108-8028           | 1           | Level Indicator Kit  | 9:5         |                    | 1           | Compressor ■       |
| 3:1         |                    | 2           | Rivet ■              | 9:6         |                    | 1           | Plate-Mounting ■   |
| 3:2         |                    | 2           | Washer ■             | 9:7         |                    | 1           | Nipple-Hose ■      |
| 4           | 108-8029           | 1           | Valve-Control, Air   | 9:8         |                    | 2           | Clamp ■            |
| 4:1         |                    | 1           | Handle ■             | 10          | 108-8035           | 1           | Bellows ASM        |
| 4:2         |                    | 3           | Screw ■              | 10:1        | 39-5710            | 23          | Plug-Plastic       |
| 5           | 108-8030           | 1           | Shock Absorber Kit   | 11          | 108-8036           | 1           | Stop Kit           |
| 5:1         |                    | 4           | Washer ■             | 11:1        |                    | 2           | Screw ■            |
| 5:2         |                    | 4           | C-Clip ■             | 12          | 107-1213           | 2           | Bumper Set         |
| 5:3         |                    | 2           | Pin ■                | 13          | 108-8037           | 4           | Roller             |
| 6           | 108-8031           | 1           | Air Spring Kit       | 14          | 108-8038           | 1           | Wear Parts Kit ●   |
| 6:1         |                    | 1           | Air Spring ■         | 14:1        |                    | 4           | Spacer ■           |
| 6:3         |                    | 2           | Cable Tie ■          | 14:2        | 39-5710            | 2           | Plug-Plastic       |
| 6:6         |                    | 2           | Screw ■              | 14:3        |                    | 1           | Bumper ■           |
| 6:7         |                    | 1           | Washer ■             | 14:4        |                    | 4           | Support-Housing ■  |
| 6:8         |                    | 1           | Nipple-Hose ■        | 14:5        |                    | 2           | Roller ■           |
| 7           | 108-8032           | 1           | Air Tube ASM         | 14:6        | 107-1213           | 2           | Bumper Set         |
| 7:1         |                    | 1           | Nipple-Hose ■        | 14:7        |                    | 2           | Screw ■            |
| 7:2         |                    | 7           | Tie-Wire ■           | 14:8        | 108-8037           | 4           | Roller             |
| 7:3         |                    | 4           | Tie-Wire ■           | 14:9        |                    | 9           | Tie-Wire ■         |
| 7:4         |                    | 1           | Nipple-Hose ■        | 14:10       |                    | 4           | Tie-Wire ■         |
| 8           | 108-8033           | 1           | Connecting Cable ASM | 14:11       |                    | 1           | Nipple-Hose ■      |
| 8:1         |                    | 8           | Tie-Wire ■           | 14:12       |                    | 1           | Screw ■            |
| 8:2         |                    | 4           | Tie-Wire ■           | 15          | 119-2161           | 1           | Tether Kit         |
| 9           | 108-8034           | 1           | Compressor Kit       |             |                    |             |                    |

● Not illustrated

■ Not serviced separately




## Cloth Premium Seat Assembly No. 117-9429

| Ref. | Part Number | Qty. | Description             |
|------|-------------|------|-------------------------|
| 1    | 117-9415    | 1    | Backrest Cushion ASM    |
| 1:1  | 119-7742    | 4    | Screw-Cushion           |
| 2    | 117-9416    | 1    | Seat Cushion ASM        |
| 2:1  | 119-7742    | 3    | Screw-Cushion           |
| 3    | 108-8018    | 1    | Cover-Armrest           |
| 4    | 108-8019    | 1    | LH Armrest ASM          |
| 4:1  | 82-9650     | 1    | Nut                     |
| 4:2  | 107-1198    | 1    | Washer                  |
| 5    | 108-8021    | 1    | Cover-Armrest           |
| 6    | 108-8022    | 2    | Cover-Black             |
| 7    | 108-8024    | 1    | Switch Kit              |
| 7:1  |             | 3    | Wire Tie ●              |
| 7:2  |             | 4    | Rivet ●                 |
| 7:3  |             | 1    | Sensor-Seat Switch ●    |
| 7:4  |             | 2    | Spring-Compression ●    |
| 7:5  |             | 2    | Bumper-Pressure Plate ● |

| Ref. | Part Number | Qty. | Description           |
|------|-------------|------|-----------------------|
| 7:6  |             | 1    | Spring-Extension ●    |
| 7:7  |             | 1    | Plate-Mounting ●      |
| 7:8  |             | 1    | Magnet ●              |
| 8    | 108-8025    | 1    | Adjustment Rail Set   |
| 8:1  |             | 1    | Rail-Adjustment, RH ● |
| 8:2  |             | 1    | Rail-Adjustment, LH ● |
| 8:3  |             | 1    | Stop-Rail ●           |
| 8:4  |             | 1    | Handle ●              |
| 8:5  |             | 3    | Screw ●               |
| 8:6  |             | 3    | Washer ●              |
| 8:7  |             | 1    | Screw ●               |
| 9    | 110-6189    | 1    | Switch Kit            |
| 9:1  |             | 1    | Switch ●              |
| 9:2  |             | 3    | Wire Tie ●            |
| 9:3  |             | 2    | Rivet ●               |


● Not serviced separately



## Parking Brake, Steering Tower and Power Center Assembly


| Ref. | Part Number | Qty. | Description           |
|------|-------------|------|-----------------------|
| 1    | 233-17      | 1    | Knob                  |
| 2    | 71-8310     | 1    | Spring-Compression    |
| 3    | 114-0195    | 1    | Rod-Parking, Brake    |
| 4    | 3272-10     | 1    | Pin-Cotter            |
| 5    | 3256-26     | 2    | Washer-Flat           |
| 6    | 63-7900-03  | 1    | Rack                  |
| 7    | 3256-22     | 2    | Washer-Flat           |
| 8    | 3272-5      | 1    | Pin-Cotter            |
| 9    | 3229-34     | 1    | Screw-CARR            |
| 10   | 100-4872    | 1    | Plate-Switch, Neutral |
| 11   | 100-1270    | 1    | Switch-Proximity      |
| 12   | 13-0480     | 1    | Spring                |
| 13   | 104-7201    | 9    | Nut-HF                |
| 14   | 114-0190-03 | 1    | Pivot-Parking, Brake  |
| 15   | 3296-2      | 3    | Nut-Lock, NI          |
| 16   | 117-5499    | 1    | Spacer-Deflector      |
| 17   | 55-9620     | 1    | Spacer-Plate, Pivot   |
| 18   | 3274-9      | 1    | Screw-HSH             |
| 19   | 3234-33     | 10   | Screw-HHF             |

| Ref. | Part Number | Qty. | Description                 |
|------|-------------|------|-----------------------------|
| 20   | 120-4136-01 | 1    | Cover-Steering Tower, Front |
| 21   | 62-5550     | 1    | Decal                       |
| 22   | 120-4165    | 1    | Steering Tower ASM          |
| 22:1 | 32148-6     | 8    | Insert-Nut                  |
| 22:2 | 120-4130    | 1    | Decal-Steering Tower, LH    |
| 22:3 | 114-0845    | 1    | Decal-Column, Steering      |
| 22:4 | 120-4129    | 1    | Decal-Steering Tower, RH    |
| 23   | 107069      | 7    | Clip                        |
| 24   | 3234-4      | 2    | Screw-HHF                   |
| 25   | 119-7769    | 1    | Switch-Rocker, On/None/On   |
| 26   | 3229-3      | 8    | Screw-CARR                  |
| 27   | 120-4093-03 | 1    | Mount-Power                 |
| 28   | 99-7435     | 3    | Relay-Power                 |
| 29   | 3296-12     | 2    | Nut-Lock, NI                |
| 30   | 3290-134    | 7    | Screw                       |
| 31   | 42862       | 1    | Block-Terminal, Ground      |
| 32   | 42863       | 1    | Strip-Jumper                |
| 33   | 321-3       | 1    | Screw-HH                    |
| 34   | 107-1013    | 5    | Nut-Speed, U-Type           |



## Parking Brake, Steering Tower and Power Center Assembly (continued)


| Ref. | Part Number | Qty. | Description              | Ref. | Part Number | Qty. | Description |
|------|-------------|------|--------------------------|------|-------------|------|-------------|
| 35   | 107-8034    | 1    | Switch-Rocker, On-Off-On | 38   | 114-5502    | 1    | Clip-Fuse   |
| 36   | 114-3321    | 2    | Controller-Tec           | 39   | 99-7420     | 3    | Plug-Hole   |
| 37   | 120-4127-03 | 1    | Mount-Relay              | 40   | 94-5627     | 1    | Plug        |



## Fender, Tool Box and Cover Assembly


| Ref. | Part Number | Qty. | Description        |
|------|-------------|------|--------------------|
| 1    | 121-1579-03 | 1    | Plate-Fender, RH   |
| 2    | 120-4113    | 1    | Fender-RH          |
| 3    | 3231-22     | 4    | Screw-CARR         |
| 4    | 104-8301    | 4    | Nut-HF, NI         |
| 5    | 120-4125    | 1    | Housing-Tool Box   |
| 6    | 3234-4      | 4    | Screw-HHF          |
| 7    | 107069      | 4    | Clip               |
| 8    | 120-4124    | 1    | Tool Box Cover ASM |
| 8:1  | 117-2754    | 1    | Decal-Warning      |
| 8:1  | 117-2766    | 1    | Decal-Warning, CE  |
| 9    | 120-4122    | 1    | Rod-Hinge          |
| 10   | 104-7545    | 1    | Bracket-Latch      |
| 11   | 58-4250     | 1    | Catch-Magnetic     |
| 12   | 3256-22     | 2    | Washer-Flat        |

| Ref. | Part Number | Qty. | Description       |
|------|-------------|------|-------------------|
| 13   | 32104-95    | 2    | Screw-HWH         |
| 14   | 120-4126    | 1    | Cover-Controllers |
| 15   | 87-6630     | 4    | Washer-Plain      |
| 16   | 3274-69     | 2    | Screw-HSBH        |
| 17   | 120-4115    | 1    | Cover-Battery     |
| 18   | 121-1588    | 1    | Rod-Hinge         |
| 19   | 3290-467    | 1    | Pin-Hair          |
| 20   | 3274-31     | 2    | Screw-HSBH        |
| 21   | 121-1586-03 | 1    | Mount-Cover       |
| 22   | 121-1587    | 1    | Latch-Cover       |
| 23   | 104-7201    | 2    | Nut-HF            |
| 24   | 3269-23     | 3    | Rivet-Pop         |
| 29   | 121-1594    | 2    | Decal-Smart Power |
| 30   | 121-1599    | 1    | Decal-Fuses       |



## Fender and Step Support Assembly


| Ref. | Part Number | Qty. | Description        |
|------|-------------|------|--------------------|
| 1    | 3231-22     | 4    | Screw-CARR         |
| 2    | 120-4116    | 1    | Pad-Step, Abrasive |
| 3    | 3230-28     | 4    | Screw-CARR         |
| 4    | 120-4117-03 | 1    | Plate-Step         |
| 5    | 121-1585    | 1    | Fender-LH          |
| 6    | 104-8301    | 4    | Nut-HF, NI         |
| 7    | 104-8300    | 4    | Nut-HF, NI         |
| 8    | 120-8900-03 | 1    | Support-Step       |



## Acoustic Foam Assembly


| Ref. | Part Number | Qty. | Description          |
|------|-------------|------|----------------------|
| 1    | 121-1666    | 1    | Foam-Column, Front   |
| 2    | 115-8813    | 1    | Foam-Column, Rear    |
| 3    | 115-8841-01 | 1    | Bracket-Foam, Pawl   |
| 4    | 104-7201    | 2    | Nut-HF               |
| 5    | 3234-33     | 2    | Screw-HHF            |
| 6    | 115-8808    | 1    | Foam-Strip, Front    |
| 7    | 115-8809    | 1    | Foam-Plug, RH        |
| 8    | 121-1681    | 1    | Foam-Steering, Front |
| 9    | 121-1680    | 1    | Foam-Steering, Rear  |
| 10   | 115-8815    | 1    | Foam-Plug, Brake     |
| 11   | 115-8814    | 1    | Foam-Pawl, Brake     |
| 12   | 121-1675    | 1    | Foam-Brake, Center   |
| 13   | 121-1674    | 2    | Foam-Plug, Brakes    |
| 14   | 121-1742    | 1    | Foam-Seal, Rear      |
| 15   | 121-1743    | 1    | Mat-Floor            |

# Front Deck Lift-Arm Assembly



## Front Deck Lift-Arm Assembly (continued)


| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>   | <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>        |
|-------------|--------------------|-------------|----------------------|-------------|--------------------|-------------|---------------------------|
| 2           | 99-5489            | 3           | Gear Motor ASM       | 16          | 322-12             | 1           | Screw-HH                  |
| 3           | 104-3541           | 3           | Hub-Spider           | 17          | 3230-22            | 1           | Screw-CARR                |
| 4           | 104-3542           | 3           | Spider               | 18          | 325-17             | 4           | Screw-HH                  |
| 5           | 120-9015-01        | 1           | Support-Damper       | 19          | 322-17             | 1           | Screw-HH                  |
| 6           | 115-5455           | 1           | End-Rod, Clevis      | 20          | 3234-29            | 2           | Screw-HHF                 |
| 7           | 104-8331           | 1           | End-Rod, Spherical   | 21          | 95-6231            | 2           | Chain-HOC                 |
| 8           | 105-3249           | 1           | Damper               | 22          | 104-0108           | 2           | U-Bolt                    |
| 9           | 115-2142           | 1           | Spacer               | 23          | 3296-25            | 4           | Nut-Lock, NI              |
| 10          | 115-5454           | 1           | Pin-Spring           | 24          | 3256-26            | 8           | Washer-Flat               |
| 11          | 120-9013           | 1           | LH Lift Arm ASM      | 25          | 3217-9             | 4           | Nut-HH                    |
| 11:1        | 104-0015           | 2           | Bushing-Flange       | 26          | 3234-42            | 6           | Screw-HHF                 |
| 11:2        | 302-11             | 2           | Fitting-Lube, 45 DEG | 27          | 3290-467           | 2           | Pin-Hair                  |
| 11:3        | 105-7468           | 1           | Stud-Tapered         | 28          | 283-55             | 2           | Pin-Clevis                |
| 11:4        | 105-7441           | 1           | Bearing-Spherical    | 29          | 32128-23           | 4           | Nut-HF                    |
| 11:5        | 32128-42           | 1           | Nut-HF               | 30          | 86-1440            | 2           | Washer-Flat               |
| 11:6        | 32151-34           | 1           | Ring-Retaining       | 31          | 3296-41            | 2           | Nut-Lock NI               |
| 12          | 105-7325           | 2           | Pin                  | 32          | 120-8822           | 2           | HYD Cylinder ASM          |
| 13          | 302-5              | 2           | Fitting-Grease       | 33          | 121-1499-03        | 1           | Plate-Mount, Bulkhead, RH |
| 14          | 120-9012           | 1           | RH Lift Arm ASM      | 34          | 121-1494-03        | 1           | Plate-Mount, Bulkhead, LH |
| 14:1        | 104-0015           | 2           | Bushing-Flange       | 35          | 340-126            | 4           | Nut-Bulkhead              |
| 14:2        | 302-11             | 2           | Fitting-Lube, 45 DEG | 36          | 69-8910            | 8           | Washer                    |
| 14:3        | 105-7468           | 1           | Stud-Tapered         | 37          | 69-8900            | 4           | Spacer                    |
| 14:4        | 105-7441           | 1           | Bearing-Spherical    | 38          | 240-7              | 4           | Grommet-Rubber            |
| 14:5        | 32128-42           | 1           | Nut-HF               | 39          | 3234-41            | 4           | Screw-HHF                 |
| 14:6        | 32151-34           | 1           | Ring-Retaining       | 40          | 104-8301           | 4           | Nut-HF, NI                |
| 15          | 104-8300           | 5           | Nut-HF, NI           | 41          | 115-5442-01        | 2           | Support-Hub               |



## Gear Motor Assembly No. 99-5489

| Ref. | Part Number | Qty. | Description       |
|------|-------------|------|-------------------|
| 1    | 3257-3      | 1    | Key-Woodruff      |
| 2    | 110-8815    | 1    | Nut-Hex           |
| 3    | 104-4284    | 1    | Seal Kit          |
| 3:1  |             | 2    | Anti-Ext Ring ●   |
| 3:2  |             | 2    | Seal ●            |
| 3:3  |             | 2    | O-Ring ●          |
| 3:4  |             | 1    | Seal-Lip, Shaft ● |
| 4    | 104-4283    | 1    | Washer-Tab        |

● Not serviced separately




## Hydraulic Cylinder Assembly No. 120-8822

| Ref. | Part Number | Qty. | Description    |
|------|-------------|------|----------------|
| 1    | 125-4300    | 1    | Seal Kit       |
| 1:1  |             | 1    | O-Ring ●       |
| 1:2  |             | 1    | Backup ●       |
| 1:3  |             | 1    | Bp Seal ●      |
| 1:4  |             | 1    | Wear Ring ●    |
| 1:5  |             | 1    | Bt Seal ●      |
| 1:6  |             | 1    | Dust Seal ●    |
| 1:7  |             | 1    | O-Ring ●       |
| 2    | 302-60      | 1    | Fitting-Grease |


● Not serviced separately

# Front Deck Hose Routing Assembly



## Front Deck Hose Routing Assembly (continued)


| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i> | <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i> |
|-------------|--------------------|-------------|--------------------|-------------|--------------------|-------------|--------------------|
| 1           | 95-8843            | 2           | Hose-HYD           | 12          | 121-1496           | 1           | Tube-HYD           |
| 2           | 120-8987           | 2           | Hose-HYD           | 12:1        | 237-58             | 1           | O-Ring             |
| 3           | 121-1457           | 2           | Hose-HYD           | 13          | 121-1497           | 1           | Tube-HYD           |
| 4           | 76-6550            | 1           | Hose-HYD           | 13:1        | 237-58             | 1           | O-Ring             |
| 5           | 121-1540           | 1           | Hose-HYD           | 14          | 121-1498           | 1           | Tube-HYD           |
| 6           | 121-1541           | 1           | Hose-HYD           | 14:1        | 237-58             | 1           | O-Ring             |
| 7           | 120-9054           | 2           | Hose-HYD           | 16          | 322-12             | 2           | Screw-HH           |
| 8           | 106-3691           | 1           | Hose-HYD           | 17          | 69-9761            | 2           | Plate-Cover        |
| 9           | 85-4940            | 1           | Hose-HYD           | 18          | 94-8105            | 4           | Clamp-Tube         |
| 11          | 121-1495           | 1           | Tube-HYD           | 19          | 3290-379           | 8           | Tie-Cable          |
| 11:1        | 237-58             | 1           | O-Ring             | 20          | 104-8300           | 2           | Nut-HF, NI         |



## Front Deck Hydraulic Fitting Assembly


| Ref. | Part Number | Qty. | Description           |
|------|-------------|------|-----------------------|
| 1    | 340-9       | 3    | Fitting-STR           |
| 1:1  | 237-58      | 1    | O-Ring                |
| 1:2  | 237-81      | 1    | O-Ring                |
| 2    | 340-142     | 3    | Fitting-Elbow-90      |
| 2:1  | 237-58      | 1    | O-Ring                |
| 2:2  | 237-81      | 1    | O-Ring                |
| 3    | 340-77      | 3    | Fitting-Elbow, 90 DEG |
| 3:1  | 237-22      | 1    | O-Ring                |
| 3:2  | 237-42      | 1    | O-Ring                |

| Ref. | Part Number | Qty. | Description       |
|------|-------------|------|-------------------|
| 4    | 340-82      | 2    | Fitting-Elbow, 90 |
| 4:1  | 237-42      | 1    | O-Ring            |
| 4:2  | 237-21      | 1    | O-Ring            |
| 5    | 340-2       | 2    | Fitting-Straight  |
| 5:1  | 237-22      | 1    | O-Ring            |
| 5:2  | 237-42      | 1    | O-Ring            |
| 6    | 340-92      | 4    | Fitting-Straight  |
| 6:1  | 237-78      | 1    | O-Ring            |
| 6:2  | 237-21      | 1    | O-Ring            |





## Platform Harness and Fuse Assembly

| Ref. | Part Number | Qty. | Description                    |
|------|-------------|------|--------------------------------|
| 1    | 120-6343    | 1    | Harness-Wire, Platform         |
| 1:10 | 121-8861    | 3    | Fuse-Mini Blade, 2 Amp         |
| 1:11 | 121-8865    | 6    | Fuse-Mini Blade, 7.5 Amp       |
| 1:12 | 121-8866    | 4    | Fuse-Mini Blade, 10 Amp        |
| 1:22 | 32180-043   | 1    | Resistor-120 Ohm               |
| 1:23 | 114-3342    | 1    | Fuse-Maxi, 60 Amp              |
| 2    | 122-0078    | 1    | Harness-Wire, Cab Interconnect |
| 3    | 93-3922     | 4    | Mount-Tie, Cable               |
| 4    | 100-2894    | 4    | Tie-Cable                      |




## Rear Harness Assembly

| Ref. | Part Number | Qty. | Description        |
|------|-------------|------|--------------------|
| 1    | 120-6344    | 1    | Harness-Wire, Rear |
| 3    | 3290-379    | 1    | Tie-Cable          |




## Battery Cable and Grounds Assembly

| Ref. | Part Number | Qty. | Description                |
|------|-------------|------|----------------------------|
| 1    | 122-0071    | 1    | Cable-Battery, Positive    |
| 2    | 32180-030   | 2    | Clip-Tie                   |
| 3    | 121-8898    | 1    | Cable-Battery, Negative    |
| 4    | 121-8897    | 1    | Cable-Battery, Positive    |
| 5    | 54-3094     | 1    | Cable                      |
| 6    | 108-9470    | 1    | Harness-Wire, Fusible Link |
| 7    | 33004-00    | 2    | Nut-HF                     |



## Engine Harness Assembly


| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>   |
|-------------|--------------------|-------------|----------------------|
| 1           | 119-4351           | 1           | Harness-Wire, Engine |
| 1:14        | 100-4918           | 1           | Diode                |



## Arm-Rest Control Panel Assembly

| Ref. | Part Number | Qty. | Description            |
|------|-------------|------|------------------------|
| 1    | 104-8300    | 3    | Nut-HF, NI             |
| 2    | 3234-42     | 2    | Screw-HHF              |
| 3    | 32144-112   | 10   | Screw-HWH              |
| 4    | 108-7604    | 1    | Cover-LH               |
| 5    | 3296-12     | 1    | Nut-Lock, NI           |
| 6    | 120-4155    | 1    | Panel ASM              |
| 6:2  | 121-3884    | 1    | Decal-Console, Upper   |
| 6:3  | 3269-17     | 2    | Rivet-Pop              |
| 6:4  | 121-3889    | 1    | Step-Elevated, Switch  |
| 6:5  | 121-3887    | 1    | Decal-Console, Display |
| 6:6  | 120-4159    | 1    | Decal-Console, Lower   |
| 7    | 121-5159    | 1    | Ignition Switch ASM    |
| 7:2  | 121-5160    | 1    | Nut-Hex                |
| 7:3  | 121-5161    | 1    | Nut-Face               |
| 7:4  | 121-5162    | 1    | Ignition Key Set       |
| 8    | 120-6310    | 1    | LCD Display ASM        |
| 8:1  | 120-4630    | 1    | Nut-Display            |
| 8:2  | 120-6311    | 1    | Decal-Display          |
| 9    | 2412-74     | 1    | R-Clamp                |
| 10   | 80-9330     | 1    | Audio Alarm ASM        |
| 10:1 | 104-5107    | 1    | Nut-Plastic, Knurled   |


| Ref. | Part Number | Qty. | Description                 |
|------|-------------|------|-----------------------------|
| 11   | 93-9999     | 1    | Switch-PTO, On-On-None      |
| 12   | 100-1535    | 5    | Switch, (On)-Off-(On)       |
| 13   | 112-7404    | 1    | Angle-Mounting              |
| 14   | 94-2413     | 5    | Nut-U                       |
| 15   | 107069      | 2    | Clip                        |
| 16   | 3234-5      | 6    | Screw-HHF                   |
| 17   | 104-8301    | 2    | Nut-HF, NI                  |
| 18   | 99-7420     | 1    | Plug-Hole                   |
| 19   | 3290-409    | 2    | Rivet                       |
| 20   | 117-2380-03 | 1    | Panel-Switches, Control Arm |
| 21   | 108-7602    | 1    | Rest-Arm                    |
| 22   | 99-7411     | 1    | Point-Power                 |
| 23   | 99-7416     | 1    | Cap                         |
| 24   | 121-1592    | 1    | Decal-Lift                  |
| 25   | 110-0542    | 2    | Spacer-Flange               |
| 26   | 115-8849-03 | 1    | Plate-Cover                 |
| 27   | 3234-21     | 2    | Screw-HHF                   |
| 28   | 114-4899    | 2    | Plug-Plastic                |
| 29   | 3250-22     | 1    | Screw-PPH                   |
| 30   | 108-7605    | 1    | Cover-RH                    |



## Arm-Rest Control Panel Assembly (continued)


| Ref. | Part Number | Qty. | Description   |
|------|-------------|------|---------------|
| 31   | 114-3329    | 1    | Switch-Rocker |

| Ref. | Part Number | Qty. | Description |
|------|-------------|------|-------------|
| 32   | 121-1630    | 1    | Plate-Cover |
| 33   | 32144-18    | 2    | Screw-HWH   |




## Cab Light Switch Assembly

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i> |
|-------------|--------------------|-------------|--------------------|
| 1           | 95-8999            | 1           | Switch             |




## Headlamp and Slow-Moving-Vehicle Decal Assembly

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i> |
|-------------|--------------------|-------------|--------------------|
| 2           | 120-0250           | 1           | Decal-Warning      |
| 3           | 114-5928           | 2           | Headlight ASM      |
| 4           | 119-0124           | 1           | Decal-Warning      |
| 5           | 119-5292           | 1           | Tubing-Convoluted  |
| 6           | 119-5291           | 1           | Tubing-Convoluted  |
| 7           | 119-5294           | 2           | Tubing-Convoluted  |



## Head Light Assembly No. 114-5928


| Ref. | Part Number | Qty. | Description            |
|------|-------------|------|------------------------|
| 1    | 3217-6      | 1    | Nut-Hex                |
| 2    | 3217-9      | 1    | Nut-HH                 |
| 3    | 322-12      | 1    | Screw-HH               |
| 4    | 3253-4      | 1    | Washer-Lock            |
| 5    | 3253-7      | 1    | Washer-Lock            |
| 6    | 92-6595     | 1    | Lamp-Beam, Sealed      |
| 7    | 92-6596     | 1    | Bezel                  |
| 8    | 92-6597     | 1    | Bracket-Mounting       |
| 9    | 92-6598     | 1    | Bolt-Carriage, Drilled |
| 10   | 92-6599     | 4    | Screw                  |



## Right-Front Window Assembly

| Ref. | Part Number | Qty. | Description              |
|------|-------------|------|--------------------------|
| 1    | 115-7685    | 6    | Bolt-Step                |
| 2    | 115-5570    | 6    | Bushing-Thin             |
| 3    | 127-3674    | 1    | Window-RH, Front         |
| 3:1  | 127-3673    | 1    | Seal-Bulb, Double        |
| 3:2  |             | 1    | Glass-Window, RH Front ● |
| 4    | 115-5574    | 6    | Bushing-Thick            |
| 5    | 115-5572    | 6    | Nut-Flange               |


● Not serviced separately



## Right-Rear Window Assembly

| Ref. | Part Number | Qty. | Description             |
|------|-------------|------|-------------------------|
| 1    | 115-7685    | 6    | Bolt-Step               |
| 2    | 115-5570    | 6    | Bushing-Thin            |
| 3    | 127-3677    | 1    | Window-RH Rear          |
| 3:1  | 127-3676    | 1    | Seal-Bulb, Double       |
| 3:2  |             | 1    | Glass-Window, RH Rear ● |
| 4    | 115-5574    | 6    | Bushing-Thick           |
| 5    | 115-5572    | 6    | Nut-Flange              |

● Not serviced separately




## Panel and Washer-Fluid Tank Assembly

| Ref. | Part Number | Qty. | Description        |
|------|-------------|------|--------------------|
| 1    | 127-3682    | 1    | Cover-Right        |
| 2    | 3269-26     | 7    | Washer-Plain       |
| 3    | 32144-93    | 3    | Screw-PPHTF        |
| 4    | 127-3659    | 1    | Cover-Hose, RH     |
| 5    | 127-3658    | 1    | Cover-Hose, LH     |
| 6    | 104-2408    | 4    | Screw-HSBH         |
| 7    | 3274-65     | 2    | Screw-HSBH         |
| 8    | 127-3656    | 1    | Rear Panel ASM     |
| 8:1  | 127-3657    | 1    | Seal-Bulb          |
| 9    | 120-3067    | 1    | Nut-Flange         |
| 10   | 119-8363    | 1    | Pin-Latch          |
| 11   | 1-633630    | 1    | Grommet            |
| 12   | 321-2       | 3    | Screw-HH           |
| 13   | 127-3662    | 1    | Mount-Bottle       |
| 14   | 32144-10    | 2    | Screw-HWH          |
| 15   | 115-8848    | 1    | Tank-Fluid, Washer |
| 16   | 115-5572    | 3    | Nut-Flange         |
| 17   | 115-5555    | 4    | Screw-Thumb        |
| 18   | 104-7201    | 20   | Nut-HF             |
| 19   | 3290-148    | 4    | Nut-HF             |

| Ref. | Part Number | Qty. | Description      |
|------|-------------|------|------------------|
| 20   | 115-5576    | 1    | Striker          |
| 21   | 115-5577    | 1    | Guard-Striker    |
| 22   | 117-2777    | 2    | Plate-Striker    |
| 23   | 3234-13     | 2    | Screw-HHF        |
| 24   | 115-5581    | 2    | Washer-Flat      |
| 25   | 115-5579    | 1    | Nut-HH           |
| 26   | 127-3670    | 2    | Washer-Hinge     |
| 27   | 119-8389    | 8    | Screw-FH         |
| 28   | 32128-17    | 8    | Nut-Lock, Flange |
| 29   | 127-3683    | 2    | Stop-Deck        |
| 30   | 3229-3      | 18   | Screw-CARR       |
| 31   | 127-3684    | 5    | Track-Slider     |
| 32   | 127-3685    | 3    | Track-Slider     |
| 33   | 127-3686    | 1    | Foam             |
| 34   | 127-3687    | 1    | Seal-Bulb        |
| 35   | 127-3688    | 1    | Seal-Bulb        |
| 36   | 127-3689    | 1    | Seal-Bulb        |
| 37   | 127-3690    | 1    | Tape-Traction    |
| 38   | 127-3691    | 1    | Seal-Foam        |
| 39   | 127-3693    | 2    | Plug             |






## Left-Front Window Assembly

| Ref. | Part Number | Qty. | Description              |
|------|-------------|------|--------------------------|
| 1    | 115-7685    | 6    | Bolt-Step                |
| 2    | 115-5570    | 6    | Bushing-Thin             |
| 3    | 127-3675    | 1    | Window-LH, Front         |
| 3:1  | 127-3673    | 1    | Seal-Bulb, Double        |
| 3:2  |             | 1    | Glass-Window, LH Front ● |
| 4    | 115-5574    | 6    | Bushing-Thick            |
| 5    | 115-5572    | 6    | Nut-Flange               |


● Not serviced separately



## Front-Upper Window Assembly

| Ref. | Part Number | Qty. | Description                  |
|------|-------------|------|------------------------------|
| 1    | 115-7685    | 4    | Bolt-Step                    |
| 2    | 115-5572    | 4    | Nut-Flange                   |
| 3    | 115-5570    | 4    | Bushing-Thin                 |
| 4    | 115-7687    | 2    | Mount-Glass, Bushing (Hinge) |
| 5    | 115-7688    | 1    | LH Hinge ASM                 |
| 5:3  | 115-7696    | 1    | Washer-Hinge, Brass          |
| 6    | 115-7689    | 1    | RH Hinge ASM                 |
| 6:3  | 115-7696    | 1    | Washer-Hinge, Brass          |
| 7    | 115-5597    | 2    | Handle-Latch                 |
| 8    | 121-1718    | 1    | Front Upper Glass ASM        |
| 8:1  | 121-1717    | 1    | Seal-Bulb, Double            |
| 8:2  |             | 1    | Glass-Upper, Front ●         |
| 9    | 115-5581    | 4    | Washer-Flat                  |


● Not serviced separately



## Front-Lower Window Assembly

| Ref. | Part Number | Qty. | Description                 |
|------|-------------|------|-----------------------------|
| 1    | 115-5572    | 4    | Nut-Flange                  |
| 2    | 115-5574    | 4    | Bushing-Thick               |
| 3    | 115-5570    | 4    | Bushing-Thin                |
| 4    | 115-5571    | 4    | Bolt-Step                   |
| 5    | 121-1719    | 1    | *obs* Front Lower Glass ASM |
| 5:1  | 121-1712    | 1    | Seal-Bulb, Double           |
| 5:2  |             | 1    | Glass-Lower, Front ●        |

● Not serviced separately




## Rear Window Assembly

| Ref. | Part Number | Qty. | Description                  |
|------|-------------|------|------------------------------|
| 1    | 115-7685    | 6    | Bolt-Step                    |
| 2    | 115-5572    | 6    | Nut-Flange                   |
| 3    | 115-5581    | 4    | Washer-Flat                  |
| 4    | 115-5570    | 8    | Bushing-Thin                 |
| 5    | 115-7687    | 2    | Mount-Glass, Bushing (Hinge) |
| 6    | 115-7688    | 1    | LH Hinge ASM                 |
| 6:3  | 115-7696    | 1    | Washer-Hinge, Brass          |
| 7    | 115-7689    | 1    | RH Hinge ASM                 |


| Ref. | Part Number | Qty. | Description             |
|------|-------------|------|-------------------------|
| 7:3  | 115-7696    | 1    | Washer-Hinge, Brass     |
| 8    | 120-0369    | 1    | Mount-Latch, Escape     |
| 9    | 104-8301    | 1    | Nut-HF, NI              |
| 10   | 120-0366    | 1    | Latch-Escape Window, RH |
| 11   | 3231-44     | 1    | Screw-CARR              |
| 12   | 127-3652    | 1    | Rear Window ASM         |
| 12:1 | 127-3651    | 1    | Seal-Bulb, Double       |
| 12:2 |             | 1    | Glass-Window, Rear ●    |

● Not serviced separately




## Door Striker, Wiper and Mirror Assembly

| Ref. | Part Number | Qty. | Description            |
|------|-------------|------|------------------------|
| 1    | 115-5583    | 1    | Arm-Mount, Mirror (RH) |
| 2    | 115-5584    | 1    | Arm-Mount, Mirror (LH) |
| 3    | 115-5585    | 2    | Mirror-Convex          |
| 4    | 115-5582    | 2    | Nut-Flange, Crimplock  |
| 5    | 119-8350    | 1    | Wiper ASM              |
| 6    | 119-8367    | 1    | Grommet                |
| 7    | 119-8368    | 1    | Connector-Barb         |
| 8    | 121-3672    | 1    | Hose-Washer            |



## Wiper Assembly No. 119-8350


| Ref. | Part Number | Qty. | Description          |
|------|-------------|------|----------------------|
| 1    | 119-8351    | 1    | Wiper Motor ASM      |
| 1:2  | 3253-3      | 1    | Washer-Lock          |
| 1:3  | 33113-025   | 1    | Screw-HH             |
| 1:4  | 112-2844    | 2    | Nut-HF               |
| 2    | 119-8352    | 1    | Arm-Wiper, 20 Inch   |
| 3    | 119-8353    | 1    | Blade-Wiper, 22 Inch |
| 3:2  | 47-2830     | 2    | Screw                |



## Headliner Assembly

| Ref. | Part Number | Qty. | Description              |
|------|-------------|------|--------------------------|
| 1    | 32128-26    | 4    | Nut-Flange               |
| 2    | 115-5586    | 5    | Nut-Panel, Deep          |
| 3    | 115-5524    | 1    | Mirror-Rear View         |
| 4    | 115-5572    | 2    | Nut-Flange               |
| 5    | 115-5581    | 6    | Washer-Flat              |
| 6    | 115-5570    | 10   | Bushing-Thin             |
| 7    | 115-5558    | 3    | Louver                   |
| 8    | 3274-65     | 2    | Screw-HSBH               |
| 9    | 117-5022    | 1    | Screw-Pan                |
| 10   | 117-5011    | 1    | Screw                    |
| 11   | 121-3892    | 1    | Filter-Air, Cab Exterior |
| 12   | 115-5594    | 2    | Screw-HSBH               |
| 13   | 115-5554    | 1    | Cover-Filter, Rear       |
| 14   | 115-5559    | 1    | Louver-Ball              |
| 15   | 115-5557    | 1    | Cover-Filter, Front      |

| Ref. | Part Number | Qty. | Description                |
|------|-------------|------|----------------------------|
| 16   | 121-3891    | 1    | Filter-Air, Cab Interior   |
| 17   | 115-5525    | 2    | Light-Warning, Rear        |
| 18   | 115-5598    | 1    | Washer-Rubber              |
| 19   | 115-5520    | 2    | Light-Warning, Front       |
| 20   | 115-5521    | 2    | Grommet-Light              |
| 21   | 115-5515    | 1    | Light-Dome, LED            |
| 22   | 115-5513    | 2    | Spacer-Roof, Front         |
| 23   | 115-5514    | 2    | Spacer-Roof, Rear          |
| 24   | 115-5526    | 1    | Mount-Roof                 |
| 25   | 115-5555    | 4    | Screw-Thumb                |
| 26   | 73-5380     | 4    | Nut-Hex                    |
| 27   | 117-2764    | 2    | Fastener-Mount, Front Roof |
| 28   | 117-2763    | 2    | Fastener-Mount, Rear Roof  |
| 29   | 119-5287    | 1    | Headliner                  |
| 30   | 119-5288    | 1    | Roof                       |




## Roof and Hose Assembly

| Ref. | Part Number | Qty. | Description             |
|------|-------------|------|-------------------------|
| 1    | 115-5581    | 8    | Washer-Flat             |
| 2    | 115-5570    | 4    | Bushing-Thin            |
| 3    | 3296-42     | 4    | Nut-Lock, NI            |
| 4    | 3229-4      | 2    | Screw-CARR              |
| 5    | 119-4505    | 1    | Strap-Mounting          |
| 6    | 115-5552    | 1    | Cover-Condenser         |
| 7    | 115-8840    | 1    | Valve-Heater            |
| 8    | 2412-141    | 4    | Clamp-Drive, Worm       |
| 9    | 3290-379    | 2    | Tie-Cable               |
| 10   | 115-8835    | 1    | Hose-Air Duct           |
| 11   | 127-3678    | 1    | Hose ASM (Comp To Cond) |
| 11:1 | 117-2779    | 2    | O-Ring                  |
| 11:2 | 117-2783    | 1    | Cap-Side, High ●        |
| 11:3 | 117-2781    | 1    | Grommet                 |
| 12   | 115-8837    | 1    | Hose ASM                |
| 12:1 | 117-2778    | 2    | O-Ring                  |
| 12:2 | 117-2782    | 1    | Grommet                 |

| Ref. | Part Number | Qty. | Description                 |
|------|-------------|------|-----------------------------|
| 13   | 115-8838    | 1    | Hose ASM                    |
| 13:1 | 117-2778    | 2    | O-Ring                      |
| 14   | 127-3679    | 1    | Hose ASM (Comp To Evap)     |
| 14:1 | 117-2780    | 2    | O-Ring                      |
| 14:2 | 117-2784    | 1    | Cap-Side, Low ●             |
| 15   | 115-8845    | 2    | Hose-Drain, Condensation    |
| 16   | 127-3680    | 1    | Hose (Heater To Water Pump) |
| 17   | 127-3681    | 1    | Hose (Thermostat To Valve)  |
| 18   | 115-8844    | 1    | Hose                        |
| 19   | 67-1300     | 1    | Decal                       |
| 20   | 104-2408    | 2    | Screw-HSBH                  |
| 21   | 3256-14     | 2    | Washer-Flat                 |
| 22   | 119-4517    | 2    | Clamp-Hose                  |
| 23   | 32128-17    | 2    | Nut-Lock, Flange            |
| 24   | 117-2782    | 2    | Grommet                     |


● Not illustrated



## Switchplate and Fuseblock Assembly

| Ref. | Part Number | Qty. | Description          |
|------|-------------|------|----------------------|
| 1    | 115-5502    | 1    | Switch-Fan, 3-Speed  |
| 2    | 115-8820    | 1    | Switch-Control, Heat |
| 3    | 115-5503    | 1    | Nut                  |
| 4    | 107-1013    | 5    | Nut-Speed, U-Type    |
| 5    | 104-2408    | 9    | Screw-HSBH           |
| 6    | 115-5504    | 2    | Knob-Control         |
| 7    | 115-5500    | 1    | Plate-Switch         |
| 8    | 115-5501    | 1    | Label-Switch         |
| 9    | 119-8355    | 1    | Switch-Rocker        |
| 10   | 95-8999     | 1    | Switch               |
| 11   | 115-5510    | 1    | Cover-Access, Fuse   |


| Ref. | Part Number | Qty. | Description             |
|------|-------------|------|-------------------------|
| 12   | 117-2787    | 1    | Label-Information, Fuse |
| 13   | 115-5508    | 1    | Label-Block, Fuse       |
| 14   | 32128-17    | 2    | Nut-Lock, Flange        |
| 15   | 115-5506    | 1    | Knob                    |
| 16   | 119-8356    | 1    | Harness-Wire            |
| 16:1 | 109355      | 3    | Fuse-Blade, 15 Amp      |
| 16:2 | 109103      | 1    | Fuse-Blade, 30 Amp      |
| 17   | 115-5547    | 2    | Pad-Fastener            |
| 18   | 115-5511    | 1    | Mount-Block, Fuse       |
| 19   | 115-5505    | 3    | Nut-Panel, Spring       |
| 20   | 99-7420     | 1    | Plug-Hole               |



## Heater Evaporator Assembly

| Ref.  | Part Number | Qty. | Description               |
|-------|-------------|------|---------------------------|
| 1     | 121-3860    | 1    | A/C Heater ASM            |
| 1:1   | 121-3861    | 1    | Fan-Blower                |
| 1:1:1 | 121-3862    | 1    | Resistor-Fan              |
| 1:2   | 115-5587    | 1    | Valve-Expansion           |
| 1:3   | 115-5593    | 1    | Thermostat-Switch, Freeze |
| 2     | 115-8829    | 1    | Cover-Top                 |
| 3     | 33103-025   | 2    | Screw-HHF                 |
| 4     | 120-0380    | 1    | Mount-Drier               |
| 5     | 115-8828    | 1    | Evaporator-Bottom         |


| Ref. | Part Number | Qty. | Description       |
|------|-------------|------|-------------------|
| 6    | 2412-125    | 2    | Clamp-Hose        |
| 7    | 107-1013    | 8    | Nut-Speed, U-Type |
| 8    | 115-5586    | 4    | Nut-Panel, Deep   |
| 9    | 119-4502    | 1    | Drier-Receiver    |
| 10   | 104-2408    | 8    | Screw-HSBH        |
| 11   | 3274-65     | 4    | Screw-HSBH        |
| 12   | 120-0378    | 1    | Seal-36 Inch      |
| 13   | 120-0379    | 1    | Seal-16 Inch      |



## Condensor Assembly


| Ref. | Part Number | Qty. | Description    |
|------|-------------|------|----------------|
| 1    | 115-5570    | 4    | Bushing-Thin   |
| 2    | 115-8816    | 1    | Coil-Condenser |
| 3    | 119-4511    | 1    | Shroud-Fan     |
| 4    | 120-0457    | 1    | Fan-Condensor  |
| 5    | 115-8822    | 4    | Mount-Isolator |
| 6    | 115-8823    | 4    | Coupler-Nut    |
| 7    | 3274-69     | 4    | Screw-HSBH     |
| 8    | 3274-65     | 4    | Screw-HSBH     |
| 9    | 115-8819    | 4    | Screw-HSBH     |
| 10   | 115-5581    | 4    | Washer-Flat    |
| 11   | 107069      | 4    | Clip           |

| Ref. | Part Number | Qty. | Description     |
|------|-------------|------|-----------------|
| 12   | 119-4527    | 1    | Foam-Tray       |
| 13   | 119-4513    | 1    | Frame-Screen    |
| 14   | 119-4544    | 2    | Foam-End        |
| 15   | 119-4512    | 1    | Tray-Screen     |
| 16   | 119-4516    | 2    | Foam-Side       |
| 17   | 3296-42     | 1    | Nut-Lock, NI    |
| 18   | 119-4507    | 1    | Plate-Latch     |
| 19   | 66-2921     | 2    | Washer-Friction |
| 20   | 119-4506    | 1    | Spacer-Latch    |
| 21   | 3229-5      | 1    | Screw-CARR      |




## Rear Weight Assembly

| Ref. | Part Number | Qty. | Description  |
|------|-------------|------|--------------|
| 1    | 3296-23     | 10   | Nut-Lock, NI |
| 2    | 3256-26     | 18   | Washer-Flat  |
| 3    | 119-0131-03 | 6    | Plate-Weight |
| 4    | 325-7       | 2    | Screw-HH     |
| 5    | 119-0130-03 | 1    | Mount-Weight |
| 6    | 9114314     | 4    | Screw-HH     |
| 7    | 325-14      | 4    | Screw-HH     |
| 8    | 24-5790-03  | 3    | Weight-Rear  |



## Deck Pad and Hardware Assembly


| Ref. | Part Number | Qty. | Description         |
|------|-------------|------|---------------------|
| 1    | 119-8389    | 8    | Screw-FH            |
| 2    | 119-8373    | 1    | Glide-Deck Stop, LH |
| 3    | 119-8372    | 1    | Stop-Deck, LH       |
| 4    | 32128-17    | 8    | Nut-Lock, Flange    |
| 5    | 323-42      | 4    | Screw-HH            |
| 6    | 3256-24     | 4    | Washer-Flat         |
| 7    | 104-8301    | 8    | Nut-HF, NI          |
| 8    | 119-8370    | 1    | Stop-Deck, RH       |
| 9    | 119-8371    | 1    | Glide-Deck Stop, RH |
| 10   | 127-3692    | 1    | Step-Cab            |
| 11   | 3231-2      | 4    | Bolt-CARR           |



## Center Deck Assembly

| Ref. | Part Number | Qty. | Description              |
|------|-------------|------|--------------------------|
| 1    | 110-3297    | 1    | Center Deck ASM          |
| 1:1  | 32148-9     | 9    | Insert-Nut               |
| 1:2  | 100-6578    | 3    | Decal-Danger             |
| 1:3  | 93-7818     | 1    | Decal-Torque, Blade Bolt |
| 1:4  | 100-5622    | 1    | Decal-HOC                |
| 1:5  | 106-4250    | 1    | Decal-HOC, RH            |
| 1:6  | 106-4251    | 1    | Decal-HOC, LH            |
| 1:7  | 105-0786    | 2    | Pad-Plastic              |
| 1:8  | 3269-8      | 8    | Rivet-Blind              |
| 1:9  | 93-6674     | 2    | Decal-Warning            |
| 1:10 | 120-6604    | 1    | Decal-Danger             |
| 1:12 | 58-6520     | 2    | Decal-Grease             |
| 2    | 119-4776    | 3    | Low-Driven Spindle ASM   |
| 4    | 108-8077    | 4    | V-Belt, Deck             |
| 5    | 3-6498      | 16   | Washer-Thrust            |
| 6    | 110-6128    | 4    | Idler Arm ASM            |
| 6:2  | 256-76      | 2    | Bushing                  |
| 6:3  | 302-5       | 1    | Fitting-Grease           |
| 7    | 110-9596    | 4    | Pulley-Idler             |
| 8    | 100-3102    | 4    | Washer-Flat              |
| 9    | 3296-45     | 2    | Nut-Hex                  |


| Ref. | Part Number | Qty. | Description             |
|------|-------------|------|-------------------------|
| 10   | 32151-34    | 4    | Ring-Retaining          |
| 11   | 32128-42    | 2    | Nut-HF                  |
| 12   | 105-7441    | 4    | Bearing-Spherical       |
| 13   | 105-7468    | 2    | Stud-Tapered            |
| 14   | 302-60      | 4    | Fitting-Grease          |
| 15   | 107-0190    | 2    | HYD Cylinder ASM        |
| 16   | 108-1993    | 1    | Screw-HSBH              |
| 17   | 105-7443    | 4    | Spacer-Pilot            |
| 18   | 327-14      | 2    | Screw-HH                |
| 19   | 3296-53     | 2    | Nut-Lock, NI            |
| 20   | 119-4549    | 1    | High-Driven Spindle ASM |
| 21   | 3256-27     | 2    | Washer-Flat             |
| 22   | 3296-41     | 2    | Nut-Lock NI             |
| 23   | 32120-72    | 4    | Ring-Snap               |
| 24   | 68-6840     | 1    | Shaft-Roller            |
| 25   | 3234-11     | 1    | Screw-HHF               |
| 26   | 68-6710     | 1    | Roller                  |
| 27   | 117-5717    | 1    | Harness-Wire, Deck      |
| 28   | 119-0081    | 1    | Mount-Switch, RH        |
| 29   | 115-5300    | 2    | Proximity Switch ASM    |
| 29:1 | 117-3207    | 2    | Nut-Hex                 |



## Center Deck Assembly (continued)

| Ref. | Part Number | Qty. | Description                 |
|------|-------------|------|-----------------------------|
| 29:2 | 117-3208    | 2    | Washer-Lock, Internal Tooth |
| 30   | 3296-56     | 8    | Nut-Lock, NI                |
| 31   | 3256-22     | 4    | Washer-Flat                 |
| 32   | 119-0080    | 1    | Mount-Switch, LH            |
| 33   | 3229-1      | 4    | Bolt-CARR                   |
| 34   | 104-8301    | 45   | Nut-HF, NI                  |
| 35   | 29-4820     | 2    | Roller                      |
| 36   | 325-17      | 2    | Screw-HH                    |
| 37   | 106-7179    | 2    | Pad-Foam                    |
| 38   | 106-7227    | 4    | Support-Pad                 |


| Ref. | Part Number | Qty. | Description      |
|------|-------------|------|------------------|
| 39   | 32104-95    | 8    | Screw-HWH        |
| 40   | 325-7       | 3    | Screw-HH         |
| 41   | 3253-7      | 4    | Washer-Lock      |
| 42   | 9202424     | 3    | Spacer           |
| 43   | 104-0858    | 4    | Bolt-Shoulder    |
| 44   | 68-0090     | 4    | Screw-Adjusting  |
| 45   | 9114524     | 4    | Bolt-TAP, HH     |
| 46   | 32128-26    | 8    | Nut-Flange       |
| 47   | 32128-14    | 8    | Nut-HF           |
| 48   | 107938      | 4    | Spring-Extension |



## Low Driven Spindle Assembly No. 119-4776

| Ref.  | Part Number | Qty. | Description           |
|-------|-------------|------|-----------------------|
| 1     | 3296-60     | 1    | Nut-Lock, NI          |
| 2     | 104-3546    | 1    | Pulley-Driven, Low    |
| 4     | 119-4775    | 1    | Spindle Housing ASM   |
| 4:1   |             | 1    | Spindle ASM ●         |
| 4:1:2 | 114-8195    | 8    | Bolt-Ribbed Neck      |
| 4:2   | 104-3549    | 1    | Bearing Spacer Set    |
| 4:3   | 110-8297    | 1    | Bearing ASM           |
| 4:4   | 253-154     | 2    | Seal-Oil              |
| 4:5   | 302-60      | 1    | Fitting-Grease        |
| 5     | 69-6950     | 1    | Spacer-Shaft, Spindle |
| 6     | 104-3554    | 1    | Shaft-Spindle         |
| 7     | 104-8322    | 1    | Washer-Hardened       |
| 8     | 106-7159    | 1    | O-Ring                |


● Not serviced separately



## Wing Lift Cylinder Assembly No. 107-0190

| Ref. | Part Number | Qty. | Description      |
|------|-------------|------|------------------|
| 1    | 107-0247    | 1    | Seal Kit         |
| 1:1  |             | 1    | O-Ring ●         |
| 1:2  |             | 1    | O-Ring ●         |
| 1:3  |             | 1    | Seal ●           |
| 1:4  |             | 1    | Back-Up ●        |
| 1:5  |             | 1    | Wiper ●          |
| 1:6  |             | 1    | Seal W/O-Ring ●  |
| 2    |             | 1    | Locknut ●        |
| 3    |             | 1    | Piston ●         |
| 4    |             | 1    | Head ●           |
| 5    |             | 1    | Ring-Retaining ● |
| 6    |             | 1    | Rod ASM ●        |


● Not serviced separately



## High Driven Spindle Assembly No. 119-4549

| Ref.  | Part Number | Qty. | Description           |
|-------|-------------|------|-----------------------|
| 1     | 104-3554    | 1    | Shaft-Spindle         |
| 2     | 69-6950     | 1    | Spacer-Shaft, Spindle |
| 3     | 119-4775    | 1    | Spindle Housing ASM   |
| 3:1   |             | 1    | Spindle ASM ●         |
| 3:1:2 | 114-8195    | 8    | Bolt-Ribbed Neck      |
| 3:2   | 104-3549    | 1    | Bearing Spacer Set    |
| 3:3   | 110-8297    | 1    | Bearing ASM           |
| 3:4   | 253-154     | 2    | Seal-Oil              |
| 3:5   | 302-60      | 1    | Fitting-Grease        |
| 4     | 106-7159    | 1    | O-Ring                |
| 5     | 104-3548    | 1    | Pulley-Driven, High   |
| 6     | 104-8322    | 1    | Washer-Hardened       |
| 7     | 3296-60     | 1    | Nut-Lock, NI          |


● Not serviced separately



## Right Hand and Left Hand Deck Installation Assembly


| Ref. | Part Number | Qty. | Description              |
|------|-------------|------|--------------------------|
| 1    | 110-3298    | 1    | RH Deck ASM              |
| 1:1  | 120-6604    | 1    | Decal-Danger             |
| 1:2  | 100-6578    | 2    | Decal-Danger             |
| 1:3  | 93-7818     | 1    | Decal-Torque, Blade Bolt |
| 1:4  | 100-5622    | 1    | Decal-HOC                |
| 1:5  | 32148-9     | 4    | Insert-Nut               |
| 2    | 105-7430-01 | 1    | RH Skid ASM              |
| 3    | 3234-42     | 4    | Screw-HHF                |
| 4    | 104-8301    | 4    | Nut-HF, NI               |
| 5    | 325-17      | 2    | Screw-HH                 |
| 6    | 29-4820     | 2    | Roller                   |
| 7    | 3296-45     | 2    | Nut-Hex                  |
| 8    | 105-7469    | 2    | Latch ASM                |
| 8:1  | 256-252     | 2    | Bearing-Flange           |
| 8:2  | 302-5       | 1    | Fitting-Grease           |
| 9    | 1278        | 2    | Washer                   |
| 10   | 32120-93    | 4    | Ring-Retaining           |
| 11   | 322-6       | 6    | Screw-HH                 |
| 12   | 3296-47     | 6    | Nut-Lock, NI             |

| Ref. | Part Number | Qty. | Description          |
|------|-------------|------|----------------------|
| 13   | 106-4317    | 2    | Support-Spring       |
| 14   | 86-2560     | 2    | Spring-Comp          |
| 15   | 242-50      | 2    | Nut-Lug              |
| 16   | 86-2120     | 4    | Roller-Lock          |
| 17   | 86-2090     | 6    | Bushing              |
| 18   | 106-7171    | 4    | Pin Pivot ASM        |
| 19   | 104-8300    | 6    | Nut-HF, NI           |
| 20   | 302-11      | 4    | Fitting-Lube, 45 DEG |
| 21   | 112-9116    | 4    | Link ASM             |
| 21:1 | 105-7441    | 1    | Bearing-Spherical    |
| 21:2 | 110-6198    | 2    | Washer-Flat          |
| 21:3 | 105-7468    | 1    | Stud-Tapered         |
| 21:5 | 106-7248    | 2    | Bushing              |
| 21:6 | 110-6197    | 1    | Cap-Dust             |
| 21:7 | 32128-42    | 1    | Nut-HF               |
| 21:8 | 32151-34    | 1    | Ring-Retaining       |
| 22   | 322-10      | 2    | Screw-HH             |
| 23   | 9547        | 8    | Washer-Thrust        |
| 24   | 3256-27     | 4    | Washer-Flat          |



## Right Hand and Left Hand Deck Installation Assembly (continued)


| Ref. | Part Number | Qty. | Description     | Ref. | Part Number | Qty. | Description                        |
|------|-------------|------|-----------------|------|-------------|------|------------------------------------|
| 25   | 112-9119    | 4    | Nut-Lock, NI    | 40   | 302-39      | 4    | Fitting-Plug                       |
| 26   | 3230-2      | 4    | Bolt-CARR       | 41   | 302-52      | 4    | Fitting-Grease                     |
| 27   | 105-7482    | 2    | Pin-Latch       | 42   | 110-6196    | 4    | Washer-Foam                        |
| 28   | 53-6380     | 2    | Washer-Flat     | 43   | 112-9106-01 | 2    | Skid-Link (Left Front, Right Rear) |
| 29   | 323-4       | 4    | Screw-HH        | 44   | 112-9105-01 | 2    | Skid-Link (Right Front, Left Rear) |
| 30   | 325-8       | 2    | Screw-HH        | 45   | 110-3299    | 1    | LH Deck ASM                        |
| 31   | 3217-9      | 2    | Nut-HH          | 45:1 | 120-6604    | 1    | Decal-Danger                       |
| 32   | 32104-95    | 12   | Screw-HWH       | 45:2 | 100-6578    | 2    | Decal-Danger                       |
| 33   | 107-0170-03 | 2    | Strap-Wing      | 45:3 | 93-7818     | 1    | Decal-Torque, Blade Bolt           |
| 34   | 106-4334    | 2    | Shield-Flex     | 45:4 | 100-5622    | 1    | Decal-HOC                          |
| 35   | 107-0171-03 | 2    | Strap-Shield    | 45:5 | 32148-9     | 4    | Insert-Nut                         |
| 37   | 3290-379    | 4    | Tie-Cable       | 46   | 105-7437-01 | 1    | LH Skid ASM                        |
| 38   | 107-0182    | 1    | Guide-Hose, RH  |      |             |      |                                    |
| 39   | 92-7845     | 4    | Spacer-Hardened |      |             |      |                                    |



## Caster Wheel Assembly


| Ref. | Part Number | Qty. | Description           |
|------|-------------|------|-----------------------|
| 1    | 105-7414    | 2    | Center Castor Arm ASM |
| 1:1  | 69-6470     | 2    | Bushing-Castor        |
| 1:2  | 302-5       | 1    | Fitting-Grease        |
| 2    | 92-9727     | 4    | HOC Cap ASM           |
| 2:1  | 92-5581     | 1    | Ring-Retaining        |
| 2:2  | 92-5583     | 1    | Washer-Cap            |
| 2:3  | 92-9726     | 1    | Spring-Compression    |
| 2:4  | 92-8861     | 1    | Cap-HOC               |
| 3    | 69-1510     | 20   | Spacer                |
| 4    | 69-6860     | 8    | Washer-Thrust         |
| 5    | 105-7429    | 2    | Side Castor Arm ASM   |
| 5:1  | 69-6470     | 2    | Bushing-Castor        |
| 5:2  | 302-5       | 1    | Fitting-Grease        |
| 6    | 104-8301    | 24   | Nut-HF, NI            |
| 7    | 3256-24     | 18   | Washer-Flat           |
| 8    | 323-15      | 20   | Screw-HH              |
| 9    | 92-7750-01  | 4    | Fork-Castor           |
| 10   | 3296-53     | 6    | Nut-Lock, NI          |
| 11   | 327-24      | 6    | Screw-HH              |
| 12   | 93-9938     | 6    | Wheel ASM             |
| 12:1 | 93-9939     | 1    | Tire                  |

| Ref.  | Part Number | Qty. | Description           |
|-------|-------------|------|-----------------------|
| 12:2  | 68-8950     | 1    | Tube-Inner (W/Valve)  |
| 12:3  | 93-4241     | 1    | Spacer-Bearing, Inner |
| 12:4  | 120-3366    | 2    | Bearing               |
| 12:6  | 32128-16    | 4    | Nut-HHF               |
| 12:7  | 93-4242     | 1    | Plate                 |
| 12:8  | 93-4239     | 1    | Rim-Wheel, Half       |
| 12:9  | 93-5980     | 1    | Hub                   |
| 12:10 | 95-2741     | 1    | Rim-Wheel, Half       |
| 13    | 100-5569    | 4    | Pin-Clevis            |
| 14    | 3290-343    | 4    | Pin-Hair              |
| 15    | 3233-4      | 6    | Screw-CARR            |
| 16    | 105-7457-01 | 2    | Fork-Rear             |
| 17    | 104-7524    | 8    | Shim                  |
| 18    | 104-7529-01 | 2    | Bracket-Castor        |
| 19    | 3296-45     | 6    | Nut-Hex               |
| 20    | 100-5623    | 1    | Decal-HOC             |
| 20    | 104-3579    | 1    | Decal-HOC             |
| 21    | 106-2047    | 2    | Rod-Tension           |
| 22    | 3256-3      | 2    | Washer-Flat           |
| 23    | 107-0183    | 1    | Guide-Hose, LH        |




## Caster Wheel Assembly (continued)

| Ref. | Part Number | Qty. | Description |
|------|-------------|------|-------------|
| 24   | 3231-2      | 2    | Bolt-CARR   |
| 25   | 107-0229    | 2    | Tab-Guide   |



## Spindle and Blade Assembly


| Ref. | Part Number | Qty. | Description                 |
|------|-------------|------|-----------------------------|
| 1    | 119-4547    | 2    | Driving Spindle ASM         |
| 2    | 3256-24     | 12   | Washer-Flat                 |
| 3    | 323-6       | 12   | Screw-HH                    |
| 4    | 106-7166-03 | 7    | Blade-Combination (19 Inch) |
| 5    | 72-9361     | 7    | Cup-Scalp, Anti             |
| 6    | 92-5816     | 7    | Bolt-Blade                  |
| 7    | 119-5298    | 1    | Double-Driven Spindle ASM   |



## Driving Spindle Assembly No. 119-4547

| Ref.  | Part Number | Qty. | Description           |
|-------|-------------|------|-----------------------|
| 1     | 104-3554    | 1    | Shaft-Spindle         |
| 2     | 69-6950     | 1    | Spacer-Shaft, Spindle |
| 3     | 119-4546    | 1    | Spindle Housing ASM   |
| 3:1   | 104-3549    | 1    | Bearing Spacer Set    |
| 3:2   | 110-8297    | 1    | Bearing ASM           |
| 3:3   | 253-154     | 2    | Seal-Oil              |
| 3:4   | 302-60      | 1    | Fitting-Grease        |
| 3:5   |             | 1    | Spindle ASM ●         |
| 3:5:2 | 114-8195    | 4    | Bolt-Ribbed Neck      |
| 4     | 106-7159    | 1    | O-Ring                |
| 5     | 104-3545    | 1    | Pulley-Driving        |
| 6     | 104-8322    | 1    | Washer-Hardened       |
| 7     | 3296-60     | 1    | Nut-Lock, NI          |
| 8     | 104-3544    | 1    | Mount-Motor, Drive    |


● Not serviced separately



## Double Driven Spindle Assembly No. 119-5298

| Ref.  | Part Number | Qty. | Description           |
|-------|-------------|------|-----------------------|
| 1     | 3296-60     | 1    | Nut-Lock, NI          |
| 2     | 106-4269    | 1    | Pulley-Drive, Double  |
| 3     | 119-4546    | 1    | Spindle Housing ASM   |
| 3:1   | 104-3549    | 1    | Bearing Spacer Set    |
| 3:2   | 110-8297    | 1    | Bearing ASM           |
| 3:3   | 253-154     | 2    | Seal-Oil              |
| 3:4   | 302-60      | 1    | Fitting-Grease        |
| 3:5   |             | 1    | Spindle ASM ●         |
| 3:5:2 | 114-8195    | 4    | Bolt-Ribbed Neck      |
| 4     | 69-6950     | 1    | Spacer-Shaft, Spindle |
| 5     | 104-3554    | 1    | Shaft-Spindle         |
| 6     | 104-8322    | 1    | Washer-Hardened       |
| 7     | 106-7159    | 1    | O-Ring                |
| 8     | 106-4268    | 1    | Mount-Motor, Drive    |


● Not serviced separately



## Deck Cover Assembly


| Ref. | Part Number | Qty. | Description         |
|------|-------------|------|---------------------|
| 1    | 74-5950     | 18   | Latch-Swell         |
| 2    | 106-4256-03 | 2    | Cover-Outer, Wing   |
| 3    | 106-4258-03 | 1    | Cover-Inner, LH     |
| 4    | 106-4260    | 1    | Cover-Mount, LH     |
| 5    | 106-4252-03 | 2    | Cover-Outer, Center |
| 6    | 3234-1      | 17   | Screw-HHF           |
| 7    | 106-4255-03 | 2    | Cover-Inner, Center |
| 8    | 106-4253-03 | 1    | Cover-Rear, Center  |

| Ref. | Part Number | Qty. | Description         |
|------|-------------|------|---------------------|
| 9    | 106-4254    | 1    | Cover-Front, Center |
| 10   | 106-4259    | 1    | Cover-Mount, RH     |
| 11   | 106-4257-03 | 1    | Cover-Inner, RH     |
| 12   | 106-7173-01 | 1    | Shield-RH           |
| 13   | 32104-95    | 4    | Screw-HWH           |
| 14   | 106-7174-01 | 1    | Shield-LH           |
| 15   | 1-804254    | 18   | Nut-Lock, HH        |
| 18   | 107-3154    | 7    | Nut-Push            |



## Rear Discharge Baffle Assembly


| Ref. | Part Number | Qty. | Description           |
|------|-------------|------|-----------------------|
| 1    | 104-8300    | 24   | Nut-HF, NI            |
| 2    | 3230-22     | 23   | Screw-CARR            |
| 3    | 106-4308-01 | 1    | LH Out Chamber ASM    |
| 4    | 106-4304-01 | 1    | LH Inside Chamber ASM |
| 5    | 106-4291-01 | 1    | LH Center Chamber ASM |
| 6    | 106-4294-01 | 1    | Center Chamber ASM    |
| 7    | 106-4286-01 | 1    | RH Center Chamber ASM |
| 8    | 106-4298-01 | 1    | RH Inside Chamber ASM |
| 9    | 106-4301-01 | 1    | RH Out Chamber ASM    |
| 10   | 32121-24    | 2    | Pin-Spring            |
| 11   | 3230-18     | 5    | Screw-CARR            |
| 12   | 106-4340-01 | 2    | Latch-Wing            |
| 13   | 233-39      | 2    | Knob-Control          |
| 14   | 3296-25     | 2    | Nut-Lock, NI          |
| 15   | 3290-483    | 2    | Washer-Conical        |
| 16   | 3256-6      | 2    | Washer-Flat           |
| 17   | 3234-11     | 2    | Screw-HHF             |
| 18   | 325-8       | 2    | Screw-HH              |
| 19   | 3256-23     | 4    | Washer-Plain          |
| 20   | 3296-47     | 4    | Nut-Lock, NI          |



## Cylinder Block Assembly

| Ref. | Part Number | Qty. | Description        |
|------|-------------|------|--------------------|
| 1    | 125-7244    | 1    | Cylinder Block Asm |
| 4    | 125-6969    | 1    | Plug               |
| 5    | 125-6980    | 1    | Plug               |
| 6    | 125-6973    | 1    | Plug               |
| 7    | 125-6973    | 1    | Plug               |
| 8    | 125-7170    | 1    | Plug               |
| 9    | 125-7007    | 10   | Bolt               |
| 12   | 125-7108    | 1    | Bushing            |


| Ref. | Part Number | Qty. | Description         |
|------|-------------|------|---------------------|
| 13   | 125-7237    | 2    | Plug                |
| 14   | 125-7239    | 8    | Plug                |
| 24   | 125-7010    | 2    | Metal-Thrust        |
| 27   | 125-7006    | 18   | Bolt                |
| 28   | 125-7049    | 1    | Gasket-Head         |
| 29   | 125-6981    | 5    | Metal-Main          |
| 32   | 125-7009    | 5    | Metal-Main (0.25)   |
| 35   | 125-7011    | 1    | Metal-Thrust (0.25) |



## Gear Housing Assembly

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i> |
|-------------|--------------------|-------------|--------------------|
| 1           | 125-7247           | 1           | Case ASM           |
| 3           | 125-6944           | 1           | Seal-Oil           |
| 4           | 125-6936           | 1           | Flange             |
| 5           | 125-6919           | 3           | Stud               |
| 6           | 125-6972           | 1           | Cover-Filler       |
| 7           | 125-6977           | 1           | Cover              |
| 8           | 125-7107           | 2           | Pipe               |
| 9           | 125-6909           | 2           | O-Ring             |
| 10          | 125-6957           | 1           | O-Ring             |
| 11          | 125-7174           | 5           | Washer-Seal        |

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i> |
|-------------|--------------------|-------------|--------------------|
| 12          | 125-7197           | 1           | O-Ring             |
| 13          | 125-7214           | 3           | Bolt               |
| 14          | 125-7214           | 4           | Bolt               |
| 15          | 125-7216           | 1           | Bolt               |
| 16          | 125-7221           | 12          | Bolt               |
| 17          | 125-7224           | 3           | Bolt               |
| 18          | 125-7229           | 3           | Nut                |
| 19          | 125-6950           | 1           | Cover              |
| 20          | 125-7199           | 1           | O-Ring             |
| 21          | 125-7208           | 2           | Bolt               |




## Flywheel Housing and Oil Sump Assembly

| Ref. | Part Number | Qty. | Description  |
|------|-------------|------|--------------|
| 1    | 125-6995    | 2    | Pin          |
| 2    | 125-7100    | 1    | Housing      |
| 3    | 125-6910    | 1    | Cap          |
| 4    | 125-7226    | 6    | Bolt         |
| 5    | 125-7227    | 4    | Bolt         |
| 6    | 125-7241    | 1    | Oil Sump ASM |
| 7    | 125-6912    | 1    | Plug-Drain   |
| 9    | 125-7177    | 1    | Washer-Seal  |
| 10   | 125-7035    | 1    | Spacer       |


| Ref. | Part Number | Qty. | Description |
|------|-------------|------|-------------|
| 11   | 125-7214    | 4    | Bolt        |
| 12   | 125-7215    | 2    | Bolt        |
| 13   | 125-7219    | 20   | Bolt        |
| 14   | 125-7220    | 4    | Bolt        |
| 15   | 125-6995    | 2    | Pin         |
| 16   | 125-6996    | 1    | Case ASM    |
| 18   | 125-7106    | 1    | Seal-Oil    |
| 19   | 125-7045    | 6    | Bolt        |
| 20   | 125-7217    | 3    | Bolt        |

# Cylinder Head and Bonnet Assembly




## Cylinder Head and Bonnet Assembly (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>  | <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i> |
|-------------|--------------------|-------------|---------------------|-------------|--------------------|-------------|--------------------|
| 1           | 125-7055           | 1           | Shaft ASM           | 43          | 93-0418            | 4           | O-Ring             |
| 2           | 125-7056           | 1           | Shaft               | 44          | 125-7215           | 3           | Bolt               |
| 4           | 125-7057           | 2           | Support             | 45          | 125-7220           | 7           | Bolt               |
| 5           | 125-7058           | 3           | Support             | 46          | 125-6972           | 1           | Cover-Filler       |
| 6           | 125-7059           | 8           | Washer              | 47          | 125-7099           | 1           | Bonnet ASM         |
| 7           | 125-7061           | 4           | Arm-Rocker          | 48          | 125-7050           | 1           | Plate              |
| 8           | 125-7013           | 4           | Screw-Adjust, Valve | 49          | 125-6920           | 1           | Baffle             |
| 10          | 125-7014           | 4           | Nut                 | 50          | 125-7012           | 1           | Baffle             |
| 11          | 125-7062           | 4           | Arm-Rocker          | 51          | 125-7118           | 1           | Baffle-Breather    |
| 12          | 125-7013           | 4           | Screw-Adjust, Valve | 52          | 125-6959           | 1           | Diaphragm          |
| 14          | 125-7014           | 4           | Nut                 | 53          | 125-6960           | 1           | Plate              |
| 15          | 125-7593           | 1           | Retainer            | 54          | 125-6961           | 1           | Plate-Breather     |
| 16          | 125-7228           | 3           | Stud                | 55          | 125-6962           | 1           | Spring-Diaphragm   |
| 17          | 125-6963           | 8           | Seat-Bridge, Valve  | 57          | 125-7060           | 1           | Gasket             |
| 18          | 125-7089           | 1           | Cylinder Head ASM   | 58          | 125-6982           | 1           | Pipe               |
| 24          | 125-7196           | 4           | Plug                | 59          | 125-6994           | 1           | Spring             |
| 25          | 125-7240           | 2           | Plug                | 60          | 125-6913           | 1           | Plug               |
| 26          | 125-7051           | 8           | Valve               | 61          | 125-7186           | 4           | Screw              |
| 27          | 125-7052           | 8           | Valve               | 62          | 125-7186           | 6           | Screw              |
| 28          | 125-7053           | 16          | Spring              | 63          | 125-7186           | 1           | Screw              |
| 29          | 125-7054           | 16          | Retainer            | 64          | 125-6974           | 3           | Knob               |
| 30          | 125-6914           | 32          | Cotter              | 65          | 93-0418            | 3           | O-Ring             |
| 31          | 125-6915           | 8           | Seal-Stem, Valve    | 66          | 125-7197           | 1           | O-Ring             |
| 32          | 125-6916           | 8           | Seal-Stem, Valve    | 67          | 125-7086           | 1           | Joint              |
| 33          | 125-7104           | 8           | Bridge ASM          | 68          | 125-7087           | 1           | Hose ASM           |
| 35          | 125-7014           | 8           | Nut                 | 69          | 125-7088           | 1           | Hose               |
| 36          | 125-6965           | 8           | Adjuster            | 70          | 125-7040           | 2           | Clip-Hose          |
| 37          | 125-7063           | 8           | Guide               | 71          | 125-7090           | 1           | Hose               |
| 38          | 125-6921           | 4           | Protector           | 72          | 125-7190           | 2           | Clamp-Hose         |
| 39          | 125-6911           | 4           | Seat-Valve          | 73          | 125-7046           | 1           | Lifter             |
| 40          | 125-7064           | 4           | Retainer            | 74          | 125-7111           | 1           | Lifter             |
| 41          | 125-7119           | 4           | Bolt                | 75          | 125-7214           | 4           | Bolt               |
| 42          | 125-7184           | 2           | Pin-Spring          | 76          | 125-6917           | 16          | Guide              |




## Suction Manifold Assembly

| Ref. | Part Number | Qty. | Description     |
|------|-------------|------|-----------------|
| 1    | 125-7065    | 1    | Pipe            |
| 2    | 125-7066    | 1    | Gasket          |
| 3    | 125-7067    | 1    | Manifold-Intake |
| 4    | 125-7189    | 1    | Clamp-Hose      |
| 5    | 125-7190    | 1    | Clamp-Hose      |
| 6    | 125-7595    | 6    | Bolt            |
| 7    | 125-7223    | 1    | Bolt            |
| 8    | 125-7002    | 1    | Heater          |
| 9    | 125-7028    | 1    | Gasket          |
| 10   | 125-7217    | 4    | Bolt            |




## Exhaust Manifold and Silencer Assembly

| Ref. | Part Number | Qty. | Description      |
|------|-------------|------|------------------|
| 1    | 125-7093    | 1    | Manifold-Exhaust |
| 2    | 125-7096    | 1    | Gasket           |
| 3    | 125-6922    | 3    | Bolt             |
| 4    | 125-6923    | 1    | Bolt             |
| 5    | 125-6924    | 4    | Bolt             |
| 6    | 125-6906    | 4    | Stud             |
| 7    | 125-7094    | 1    | Silencer         |
| 8    | 125-7095    | 1    | Support-Silencer |
| 9    | 125-7071    | 1    | Gasket           |
| 10   | 125-7213    | 2    | Bolt             |
| 11   | 125-7595    | 2    | Bolt             |
| 12   | 125-7229    | 5    | Nut              |




## Camshaft and Driving Gear Assembly

| Ref. | Part Number | Qty. | Description  |
|------|-------------|------|--------------|
| 1    | 125-7016    | 8    | Tappet       |
| 2    | 125-7017    | 8    | Rod-Push     |
| 3    | 125-7068    | 1    | Camshaft ASM |
| 4    | 125-7008    | 1    | Metal-Thrust |
| 6    | 125-7015    | 1    | Gear         |
| 7    | 125-7185    | 1    | Key          |
| 8    | 125-7213    | 2    | Bolt         |
| 9    | 125-6938    | 1    | Shaft        |
| 10   | 125-6928    | 1    | Gear ASM     |
| 13   | 125-7218    | 3    | Bolt         |
| 14   | 125-7020    | 4    | Bolt         |
| 15   | 125-6929    | 1    | Gear         |
| 16   | 125-6927    | 1    | Bushing      |



## Turbine Assembly


| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i> |
|-------------|--------------------|-------------|--------------------|
| 1           | 125-7069           | 1           | Turbine            |
| 2           | 125-7070           | 1           | Gasket             |
| 3           | 125-7043           | 5           | Stud               |
| 4           | 125-7229           | 4           | Nut                |



## Crankshaft and Piston Assembly

| Ref. | Part Number | Qty. | Description    |
|------|-------------|------|----------------|
| 1    | 125-7091    | 1    | Crankshaft ASM |
| 2    | 125-6995    | 1    | Pin            |
| 4    | 125-6937    | 1    | Gear           |
| 5    | 125-7185    | 1    | Key            |
| 7    | 125-7182    | 1    | Pin-Spring     |
| 8    | 125-6925    | 1    | V-Pulley       |
| 9    | 125-7109    | 1    | Washer         |
| 10   | 125-6956    | 1    | Bolt           |
| 11   | 125-6951    | 6    | Bolt           |
| 12   | 125-7172    | 1    | Flywheel ASM   |
| 14   | 125-6943    | 1    | Gear           |


| Ref. | Part Number | Qty. | Description           |
|------|-------------|------|-----------------------|
| 15   | 125-7072    | 4    | Piston ASM            |
| 17   | 125-6983    | 4    | Piston Ring Set       |
| 21   | 125-7030    | 4    | Pin                   |
| 22   | 125-7180    | 8    | Ring                  |
| 23   | 125-7242    | 4    | Connecting Rod ASM    |
| 26   | 125-6955    | 8    | Bolt                  |
| 27   | 125-7018    | 4    | Pin-Crank             |
| 29   | 125-6997    | 4    | Pin-Piston            |
| 30   | 125-7019    | 4    | Pin-Crank (.25)       |
| 32   | 125-7073    | 4    | Piston ASM (0.25 Os)  |
| 34   | 125-6985    | 4    | Piston Ring Set (.25) |



## Lubrication and Oil System Assembly

| Ref. | Part Number | Qty. | Description     |
|------|-------------|------|-----------------|
| 1    | 125-7044    | 1    | Oil Pump ASM    |
| 14   | 125-7021    | 1    | Gasket          |
| 15   | 125-7232    | 4    | Bolt            |
| 16   | 125-6987    | 1    | Dipstick        |
| 17   | 125-6954    | 1    | Guide-Dipstick  |
| 18   | 125-7022    | 1    | Gasket          |
| 19   | 125-7023    | 1    | Pipe ASM        |
| 20   | 125-7217    | 2    | Bolt            |
| 21   | 125-7074    | 1    | Cooler ASM      |
| 22   | 125-7075    | 1    | O-Ring          |
| 23   | 125-7041    | 1    | Nut-Cooler, Oil |
| 24   | 125-6989    | 1    | Bracket ASM     |
| 25   | 125-6930    | 1    | Bracket         |
| 26   | 125-7042    | 1    | Stud            |


| Ref. | Part Number | Qty. | Description   |
|------|-------------|------|---------------|
| 27   | 125-7024    | 1    | Gasket        |
| 29   | 125-6990    | 1    | Joint         |
| 30   | 125-7078    | 1    | Pipe ASM      |
| 31   | 125-7162    | 1    | Clip          |
| 33   | 125-7191    | 1    | Clamp-Hose    |
| 34   | 125-7079    | 1    | Pipe ASM      |
| 35   | 125-7162    | 1    | Clip          |
| 37   | 125-6946    | 1    | Tube          |
| 38   | 125-7191    | 1    | Clamp-Hose    |
| 39   | 125-7001    | 1    | Elbow         |
| 40   | 125-7595    | 3    | Bolt          |
| 41   | 125-7171    | 1    | Plug-Drain    |
| 42   | 125-7025    | 1    | Filter-Engine |



## Lubrication Oil Line Assembly

| Ref. | Part Number | Qty. | Description      |
|------|-------------|------|------------------|
| 1    | 125-6918    | 1    | Switch-Oil       |
| 2    | 125-6975    | 1    | Bolt-Joint, Pipe |
| 3    | 125-6952    | 1    | Bolt-Joint, Pipe |
| 4    | 125-7076    | 1    | Pipe ASM         |
| 5    | 125-6931    | 1    | Retainer         |
| 6    | 125-6976    | 1    | Retainer         |
| 7    | 125-6988    | 1    | Joint Bolt ASM   |
| 8    | 125-7174    | 1    | Washer-Seal      |
| 9    | 125-7194    | 1    | Bolt-Joint       |
| 10   | 125-7174    | 1    | Washer-Seal      |
| 11   | 125-7175    | 2    | Washer-Seal      |
| 12   | 125-7193    | 2    | Gasket           |

| Ref. | Part Number | Qty. | Description     |
|------|-------------|------|-----------------|
| 13   | 125-7212    | 1    | Bolt            |
| 14   | 125-7231    | 1    | Nut             |
| 15   | 125-6971    | 1    | Elbow           |
| 16   | 125-7077    | 1    | Pipe            |
| 17   | 125-6958    | 1    | Hose            |
| 18   | 125-7188    | 2    | Clamp-Hose      |
| 19   | 125-7198    | 1    | O-Ring          |
| 20   | 125-7208    | 2    | Bolt            |
| 21   | 125-7105    | 4    | Check Valve ASM |
| 27   | 125-7098    | 4    | Nozzle          |
| 28   | 125-7182    | 4    | Pin-Spring      |




## Cooling Water System Assembly

| Ref. | Part Number | Qty. | Description |
|------|-------------|------|-------------|
| 1    | 125-7031    | 1    | CW Pump ASM |
| 3    | 125-6998    | 1    | Gasket      |
| 4    | 125-6999    | 1    | Plate       |
| 9    | 125-7123    | 3    | Plug        |
| 10   | 125-7195    | 1    | Plug        |
| 11   | 125-7196    | 1    | Plug        |
| 12   | 125-7234    | 3    | Screw       |
| 13   | 125-7047    | 1    | Gasket      |
| 14   | 125-6986    | 1    | Joint       |
| 15   | 125-7048    | 1    | O-Ring      |
| 16   | 125-6978    | 1    | Gasket      |
| 17   | 125-7192    | 1    | Gasket      |
| 18   | 125-7212    | 1    | Bolt        |
| 19   | 125-7214    | 3    | Bolt        |


| Ref. | Part Number | Qty. | Description           |
|------|-------------|------|-----------------------|
| 20   | 125-7219    | 1    | Bolt                  |
| 21   | 125-7222    | 3    | Bolt                  |
| 22   | 125-7039    | 1    | V-Pulley              |
| 24   | 125-7204    | 1    | V-Belt                |
| 25   | 125-7206    | 4    | Bolt                  |
| 26   | 125-7029    | 1    | Thermostat            |
| 27   | 125-7026    | 1    | Gasket                |
| 28   | 125-7034    | 1    | Cover                 |
| 29   | 125-7110    | 1    | Gasket                |
| 30   | 125-7594    | 2    | Bolt                  |
| 31   | 125-6953    | 1    | Plug                  |
| 32   | 125-7124    | 1    | Sensor-Thermostat, CW |
| 33   | 125-6979    | 1    | Gasket                |
| 34   | 125-7176    | 1    | Washer-Seal           |

# Fuel Injection Pump Assembly




## Fuel Injection Pump Assembly (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i> | <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i> |
|-------------|--------------------|-------------|--------------------|-------------|--------------------|-------------|--------------------|
| 1           | 125-7246           | 1           | Fie ASM            | 106         | 125-7176           | 1           | Washer-Seal        |
| 10          | 125-6991           | 1           | Cover              | 107         | 125-7591           | 1           | Washer-Seal        |
| 11          | 125-6992           | 2           | Bolt               | 108         | 125-7147           | 4           | Bolt               |
| 12          | 125-6932           | 1           | Key                | 111         | 125-7142           | 1           | O-Ring             |
| 15          | 125-7135           | 1           | Flange             | 112         | 125-7143           | 1           | O-Ring             |
| 39          | 125-7156           | 1           | Stopper            | 113         | 125-7176           | 2           | Washer-Seal        |
| 40          | 125-7154           | 1           | O-Ring             | 114         | 125-7179           | 1           | Washer-Spring      |
| 41          | 125-7154           | 1           | O-Ring             | 115         | 125-7181           | 2           | Pin-Parallel       |
| 42          | 125-7092           | 4           | Valve ASM          | 116         | 125-7183           | 2           | Pin-Spring         |
| 51          | 125-7155           | 4           | Spring             | 118         | 93-0400            | 1           | O-Ring             |
| 59          | 125-7157           | 1           | Plug               | 119         | 125-7201           | 1           | O-Ring             |
| 60          | 125-6933           | 1           | Plug               | 120         | 125-7202           | 1           | O-Ring             |
| 61          | 125-7136           | 4           | Gasket             | 121         | 125-7205           | 1           | Bolt               |
| 62          | 125-7136           | 1           | Gasket             | 123         | 125-7233           | 4           | Bolt               |
| 63          | 125-7151           | 1           | Plug               | 124         | 125-7236           | 1           | Nut                |
| 64          | 125-7137           | 1           | Lifter             | 127         | 125-7125           | 1           | Harness ASM        |
| 65          | 125-7102           | 1           | Timer Set          | 128         | 125-7126           | 1           | Harness            |
| 66          | 125-7103           | 1           | Timer ASM          | 129         | 125-7033           | 1           | Cap                |
| 69          | 125-7145           | 1           | O-Ring             | 130         | 125-7158           | 1           | Joint              |
| 70          | 125-6934           | 1           | Ring               | 131         | 125-7127           | 1           | Bracket            |
| 71          | 125-6935           | 1           | O-Ring             | 132         | 125-7139           | 1           | Joint              |
| 72          | 125-7202           | 1           | O-Ring             | 134         | 125-7141           | 1           | Feed Pump ASM      |
| 73          | 125-7203           | 1           | Ring-Back Up       | 135         | 125-7144           | 1           | O-Ring             |
| 74          | 125-7138           | 1           | Gasket             | 136         | 125-6945           | 1           | Joint              |
| 75          | 125-6940           | 1           | Spring             | 137         | 125-7176           | 1           | Washer-Seal        |
| 76          | 125-6941           | 1           | Cap                | 138         | 125-7178           | 1           | Washer-Spring      |
| 78          | 125-6942           | 1           | Solenoid Valve ASM | 139         | 125-7207           | 1           | Bolt               |
| 81          | 125-7146           | 1           | Gasket             | 140         | 125-7235           | 1           | Nut                |
| 101         | 125-7159           | 1           | Piston             | 141         | 125-7238           | 1           | Plug               |
| 102         | 125-7140           | 1           | Spring             | 143         | 125-7032           | 1           | Retainer           |
| 103         | 125-7160           | 1           | Plug               | 144         | 125-7214           | 4           | Bolt               |
| 105         | 125-7148           | 1           | Plug               |             |                    |             |                    |



## Governor Assembly


| Ref. | Part Number | Qty. | Description |
|------|-------------|------|-------------|
| 2    | 125-7148    | 1    | Plug        |
| 3    | 125-7149    | 1    | Gasket      |
| 20   | 125-6993    | 1    | Nut         |
| 23   | 125-7152    | 1    | Sensor      |
| 24   | 125-7150    | 1    | Gear        |
| 25   | 125-7176    | 1    | Washer-Seal |
| 26   | 125-7200    | 1    | O-Ring      |
| 27   | 125-7208    | 1    | Bolt        |
| 28   | 125-7209    | 10   | Bolt        |
| 29   | 125-7215    | 3    | Bolt        |



## Fuel Injection Valve Assembly

| Ref. | Part Number | Qty. | Description         |
|------|-------------|------|---------------------|
| 1    | 125-7245    | 4    | Injection Valve ASM |
| 2    | 125-7133    | 4    | Nozzle ASM          |
| 5    | 125-6901    | 4    | Nut                 |
| 6    | 125-7080    | 4    | Holder ASM          |
| 9    | 125-6902    | 4    | Spring              |
| 10   | 125-6903    | 4    | Seat-Spring         |
| 11   | 125-6904    | 4    | Plate               |
| 12   | 125-6905    | 8    | Pin                 |
| 13   | 125-6939    | 4    | Shim Set            |
| 40   | 125-6964    | 4    | Seal                |
| 41   | 125-6907    | 2    | Retainer            |
| 44   | 125-7027    | 2    | Bolt                |
| 45   | 125-7097    | 1    | Retainer            |
| 48   | 125-7027    | 2    | Bolt                |


| Ref. | Part Number | Qty. | Description             |
|------|-------------|------|-------------------------|
| 50   | 125-7082    | 1    | Injection Pipe ASM      |
| 51   | 125-7083    | 1    | Injection Pipe ASM      |
| 52   | 125-7084    | 1    | Injection Pipe ASM      |
| 53   | 125-7085    | 1    | Injection Pipe ASM      |
| 54   | 125-6948    | 1    | Pipe ASM                |
| 55   | 125-6949    | 1    | Pipe                    |
| 56   | 125-6970    | 2    | Clip                    |
| 57   | 125-6966    | 5    | Bolt-Joint, Pipe        |
| 58   | 125-7081    | 1    | Pipe ASM                |
| 59   | 125-6967    | 5    | Gasket                  |
| 60   | 125-6968    | 1    | Joint                   |
| 61   | 125-7174    | 1    | Washer-Seal             |
| 62   | 125-6900    | 1    | Label-Caution, Fuel Oil |



## Starting Motor Assembly


| Ref. | Part Number | Qty. | Description      |
|------|-------------|------|------------------|
| 1    | 125-7003    | 1    | Starter          |
| 2    | 125-7004    | 1    | Switch ASM       |
| 3    | 125-7112    | 1    | Armature ASM     |
| 4    | 125-7252    | 1    | Bearing-Ball     |
| 5    | 125-7249    | 1    | Bearing, Ball    |
| 6    | 125-7113    | 1    | Field Coil ASM   |
| 7    | 125-7114    | 2    | Brush            |
| 8    | 125-7163    | 4    | Screw            |
| 9    | 125-7115    | 1    | Cover            |
| 10   | 125-7116    | 1    | Brush Holder ASM |
| 11   | 125-7114    | 2    | Brush            |
| 12   | 125-7036    | 4    | Spring           |
| 13   | 125-7164    | 1    | Case-Gear        |
| 14   | 125-7005    | 1    | Housing          |

| Ref. | Part Number | Qty. | Description    |
|------|-------------|------|----------------|
| 15   | 125-7165    | 1    | Lever Set      |
| 18   | 125-7037    | 1    | Dust Cover ASM |
| 19   | 125-7117    | 2    | Bolt-Through   |
| 20   | 125-7166    | 1    | Pinion ASM     |
| 21   | 125-7250    | 1    | Clutch ASM     |
| 22   | 125-7251    | 1    | Bearing-Ball   |
| 23   | 125-7253    | 1    | Bearing-Ball   |
| 24   | 125-7167    | 1    | Shaft          |
| 25   | 125-7168    | 1    | Stopper Set    |
| 29   | 125-7210    | 2    | Bolt           |
| 30   | 125-7211    | 3    | Bolt           |
| 31   | 125-7169    | 1    | Cover          |
| 32   | 125-7225    | 2    | Bolt           |



## Generator Assembly

| Ref. | Part Number | Qty. | Description    |
|------|-------------|------|----------------|
| 1    | 125-7120    | 1    | Alternator-12V |
| 2    | 125-7121    | 1    | Bolt-Stopper   |
| 3    | 125-7122    | 1    | Piece-Distance |
| 4    | 125-7230    | 1    | Nut            |
| 5    | 125-6947    | 1    | Spacer         |
| 6    | 125-7101    | 1    | Adjuster-Belt  |
| 7    | 125-7134    | 1    | Bolt           |
| 8    | 125-7219    | 1    | Bolt           |
| 9    | 125-7173    | 2    | Relay          |
| 10   | 125-7131    | 3    | Washer         |
| 11   | 125-7132    | 2    | Relay          |



## Gasket Set

| Ref. | Part Number | Qty. | Description      |
|------|-------------|------|------------------|
| 1    | 125-7243    | 1    | Gasket Set       |
| 2    | 125-7049    | 1    | Gasket-Head      |
| 3    | 125-6909    | 2    | O-Ring           |
| 4    | 125-6957    | 1    | O-Ring           |
| 5    | 125-7197    | 2    | O-Ring           |
| 6    | 125-7199    | 1    | O-Ring           |
| 7    | 125-7177    | 1    | Washer-Seal      |
| 8    | 125-6915    | 8    | Seal-Stem, Valve |
| 9    | 125-6916    | 8    | Seal-Stem, Valve |
| 10   | 125-6921    | 4    | Protector        |
| 11   | 125-6911    | 4    | Seat-Valve       |
| 12   | 125-7060    | 1    | Gasket           |
| 13   | 93-0418     | 7    | O-Ring           |
| 14   | 125-7066    | 1    | Gasket           |
| 15   | 125-7028    | 1    | Gasket           |
| 16   | 125-7096    | 1    | Gasket           |
| 17   | 125-7070    | 1    | Gasket           |
| 18   | 125-7071    | 1    | Gasket           |

| Ref. | Part Number | Qty. | Description   |
|------|-------------|------|---------------|
| 19   | 125-7022    | 1    | Gasket        |
| 20   | 125-7024    | 1    | Gasket        |
| 21   | 125-7174    | 7    | Washer-Seal   |
| 22   | 125-7175    | 2    | Washer-Seal   |
| 23   | 125-7193    | 2    | Gasket        |
| 24   | 125-7198    | 1    | O-Ring        |
| 25   | 125-7047    | 1    | Gasket        |
| 26   | 125-7048    | 1    | O-Ring        |
| 27   | 125-6978    | 1    | Gasket        |
| 28   | 125-7192    | 1    | Gasket        |
| 29   | 125-7026    | 1    | Gasket        |
| 30   | 125-7110    | 1    | Gasket        |
| 31   | 125-6979    | 2    | Gasket        |
| 32   | 125-6967    | 5    | Gasket        |
| 33   | 125-7000    | 1    | Gasket        |
| 34   | 125-7021    | 1    | Gasket        |
| 35   | 125-7038    | 1    | Hone          |
| 36   | 125-7248    | 1    | Gasket-Liquid |

# Attachments and Accessories

## For 30602 Groundsmaster 4110 Rotary Mower

| Product Name                                              | Model/Part  |
|-----------------------------------------------------------|-------------|
| Bumper ASM .....                                          | 106-4278-03 |
| Blade-Combination (19in) .....                            | 106-7166-03 |
| Blade-Atomic (21.75in) .....                              | 107-0214-03 |
| Blade-Atomic (19in) .....                                 | 107-0215-03 |
| Premium All Season Hydraulic Fluid (55 Gallon Drum) ..... | 108-1177    |
| Premium All Season Hydraulic Fluid (5 Gallon Pail) .....  | 108-1178    |
| Atomic Blade Service Pack (7 Pack) .....                  | 108-1450    |
| Atomic Blade Service Pack .....                           | 108-1451    |
| Blade-Flat Sail (21.75in) .....                           | 110-6115-03 |
| Blade-Flat Sail (19in) .....                              | 110-6116-03 |
| Flat Blade Service Pack (7 Pack) .....                    | 110-6130    |
| Flat Blade Service Pack (19in) .....                      | 110-6140    |
| Work Light Kit .....                                      | 114-5610    |
| MVP Blade Kit .....                                       | 117-2722    |
| Vinyl Backrest Extension Kit .....                        | 119-7718    |
| Backrest Extension Kit .....                              | 119-7719    |
| Large Seat Cover .....                                    | 120-5179    |
| Premium Engine Oil 10w30 (55 Gal) .....                   | 121-6392    |
| Premium Engine Oil 10w30 (5 Gallon Pail) .....            | 121-6393    |
| Premium Engine Oil 15w40 (55 Gallon Drum) .....           | 121-6394    |
| Premium Engine Oil 15w40 (5 Gallon Pail) .....            | 121-6395    |
| MVP Blade Kit .....                                       | 130-2660    |
| MVP Filter Kit .....                                      | 30089       |
| Universal Sunshade .....                                  | 30349       |
| Flow Divider Kit .....                                    | 30407       |
| 400 Hour MVP Kit .....                                    | 30408       |
| North American Light Kit .....                            | 30414       |
| Leaf Mulcher Kit .....                                    | 30419       |
| Guardian Recycler Conversion Kit .....                    | 30420       |
| Leaf Mulcher Kit .....                                    | 30422       |
| Replacement Cutting Unit .....                            | 30451       |
| CE Kit .....                                              | 30453       |
| Right-Hand Replacement Mower .....                        | 30476       |
| Left-Hand Replacement Mower .....                         | 30477       |
| Front Deck .....                                          | 30479       |
| CE Light Kit .....                                        | 30660       |
| Beacon Kit .....                                          | 30661       |
| License Plate Kit .....                                   | 30664       |
| Slow-Moving Vehicle Sign Kit .....                        | 30665       |
| Blade (21.75in) .....                                     | 92-5608-03  |
| 8in Foam Filled Wheel ASM .....                           | 93-5974     |



**Count on it.**